

Allegro® User Guide: SKILL Reference

**Product Version 16.6
October 2012**

Document Last Updated on: October 22, 2013

© 1991–2012 Cadence Design Systems, Inc. All rights reserved.

Portions © Apache Software Foundation, Sun Microsystems, Free Software Foundation, Inc., Regents of the University of California, Massachusetts Institute of Technology, University of Florida . Used by permission. Printed in the United States of America.

Cadence Design Systems, Inc. (Cadence), 2655 Seely Ave., San Jose, CA 95134, USA.

Allegro Platform Products contain technology licensed from, and copyrighted by: Apache Software Foundation, 1901 Munsey Drive Forest Hill, MD 21050, USA © 2000-2005, Apache Software Foundation. Sun Microsystems, 4150 Network Circle, Santa Clara, CA 95054 USA © 1994-2007, Sun Microsystems, Inc. Free Software Foundation, 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA © 1989, 1991, Free Software Foundation, Inc. Regents of the University of California, Sun Microsystems, Inc., Scriptics Corporation, © 2001, Regents of the University of California. Daniel Stenberg, © 1996 - 2006, Daniel Stenberg. UMFPACK © 2005, Timothy A. Davis, University of Florida, (davis@cise.ulv.edu). Ken Martin, Will Schroeder, Bill Lorensen © 1993-2002, Ken Martin, Will Schroeder, Bill Lorensen. Massachusetts Institute of Technology, 77 Massachusetts Avenue, Cambridge, Massachusetts, USA © 2003, the Board of Trustees of Massachusetts Institute of Technology. All rights reserved.

Trademarks: Trademarks and service marks of Cadence Design Systems, Inc. contained in this document are attributed to Cadence with the appropriate symbol. For queries regarding Cadence's trademarks, contact the corporate legal department at the address shown above or call 800.862.4522.

Open SystemC, Open SystemC Initiative, OSCI, SystemC, and SystemC Initiative are trademarks or registered trademarks of Open SystemC Initiative, Inc. in the United States and other countries and are used with permission.

All other trademarks are the property of their respective holders.

Restricted Permission: This publication is protected by copyright law and international treaties and contains trade secrets and proprietary information owned by Cadence. Unauthorized reproduction or distribution of this publication, or any portion of it, may result in civil and criminal penalties. Except as specified in this permission statement, this publication may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without prior written permission from Cadence. Unless otherwise agreed to by Cadence in writing, this statement grants Cadence customers permission to print one (1) hard copy of this publication subject to the following conditions:

1. The publication may be used only in accordance with a written agreement between Cadence and its customer.
2. The publication may not be modified in any way.
3. Any authorized copy of the publication or portion thereof must include all original copyright, trademark, and other proprietary notices and this permission statement.
4. The information contained in this document cannot be used in the development of like products or software, whether for internal or external use, and shall not be used for the benefit of any other party, whether or not for consideration.

Disclaimer: Information in this publication is subject to change without notice and does not represent a commitment on the part of Cadence. Except as may be explicitly set forth in such agreement, Cadence does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Cadence does not warrant that use of such information will not infringe any third party rights, nor does Cadence assume any liability for damages or costs of any kind that may result from use of such information.

Restricted Rights: Use, duplication, or disclosure by the Government is subject to restrictions as set forth in FAR52.227-14 and DFAR252.227-7013 et seq. or its successor.

Contents

<u>Alphabetical List of Functions</u>	31
---	----

<u>Before You Start</u>	49
-------------------------------	----

<u>About This Manual</u>	49
--------------------------------	----

<u>Prerequisites</u>	50
----------------------------	----

<u>Command Syntax Conventions</u>	50
---	----

<u>Referencing Objects by Name</u>	51
--	----

<u>Finding Information in This Manual</u>	52
---	----

<u>Other Sources of Information</u>	58
---	----

1

<u>Introduction to Allegro PCB Editor SKILL Functions</u>	61
---	----

<u>Overview</u>	61
-----------------------	----

<u>AXL-SKILL in Allegro PCB Editor</u>	61
--	----

<u>AXL-SKILL Database</u>	64
---------------------------------	----

2

<u>The Allegro PCB Editor Database User Model</u>	75
---	----

<u>Overview</u>	75
-----------------------	----

<u>Description of Database Objects</u>	76
--	----

<u>Figure Database Types</u>	81
------------------------------------	----

<u>Logical Database Types</u>	97
-------------------------------------	----

<u>Property Dictionary Database Types</u>	105
---	-----

<u>Parameter Database Types</u>	107
---------------------------------------	-----

3

<u>Parameter Management Functions</u>	117
---	-----

<u>Overview</u>	117
-----------------------	-----

<u>axlcreate</u>	118
------------------------	-----

Allegro SKILL Reference

<u>axIDBGridGet</u>	121
<u>axIDBGridSet</u>	123
<u>axIDBTextBlockCreate</u>	125
<u>axIExportXmlIDBRecords</u>	126
<u>axImportXmlIDBRecords</u>	127
<u>axIPadSuppressGet</u>	129
<u>axIPadSuppressOkLayer</u>	131
<u>axIPadSuppressSet</u>	132
<u>axIGetParam</u>	135
<u>axISetParam</u>	138
<u>Color Access</u>	140
<u>axIColorDoc</u>	140
<u>axIColorGet</u>	142
<u>axIColorShadowGet</u>	144
<u>axIColorShadowSet</u>	146
<u>axIColorLoad</u>	148
<u>axIColorOnGet – Obsolete Command</u>	150
<u>axIColorOnSet – Obsolete Command</u>	151
<u>axIColorPriorityGet – Obsolete Command</u>	152
<u>axIColorPrioritySet – Obsolete Command</u>	153
<u>axIColorSave</u>	154
<u>axIColorSet</u>	155
<u>axCVFColorChooserDlg</u>	158
<u>axIClearObjectCustomColor</u>	159
<u>axICustomColorObject</u>	160
<u>axILayerPriorityClearAll</u>	162
<u>axILayerPriorityGet</u>	163
<u>axILayerPriorityRestoreAll</u>	165
<u>axILayerPrioritySaveAll</u>	166
<u>axILayerPrioritySet</u>	167
<u>axIlIsCustomColored</u>	169
<u>Database Layer Management</u>	170
<u>axIClasses</u>	170
<u>axIDBGetLayerType</u>	171
<u>axIGetXSection</u>	172
<u>axIlIsLayer</u>	174

<u>axlIsVisibleLayer</u>	175
<u>axlLayerCreateCrossSection</u>	176
<u>axlLayerCreateNonConductor</u>	178
<u>axlLayerGet</u>	179
<u>axlVisibleDesign</u>	180
<u>axlVisibleGet</u>	182
<u>axlVisibleLayer</u>	184
<u>axlVisibleSet</u>	185
<u>axlConductorBottomLayer</u>	186
<u>axlConductorTopLayer</u>	187
<u>axlDBCreateFilmRec</u>	188
<u>axlSetPlaneType</u>	191
<u>axlSubclasses</u>	192
<u>axlSubclassRoute</u>	194

4

<u>Selection and Find Functions</u>	197
<u>Overview</u>	197
<u>Select Set Highlighting</u>	198
<u>Select Modes</u>	198
<u>Finding Objects by Name</u>	198
<u>Point Selection</u>	199
<u>Area Selection</u>	199
<u>Miscellaneous Select Functions</u>	200
<u>axlSelect—The General Select Function</u>	200
<u>Select Set Management</u>	200
<u>Find Filter Control</u>	200
<u>Selection and Find Functions</u>	202
<u>axlSingleSelectPoint</u>	202
<u>axlAddSelectPoint</u>	204
<u>axlSubSelectPoint</u>	205
<u>axlSingleSelectBox</u>	207
<u>axlAddSelectBox</u>	209
<u>axlSubSelectBox</u>	210
<u>axlAddSelectAll</u>	211

Allegro SKILL Reference

<u>axlSubSelectAll</u>	212
<u>axlSingleSelectName</u>	214
<u>axlAddSelectName</u>	216
<u>axlSubSelectName</u>	218
<u>axlSingleSelectObject</u>	219
<u>axlAddSelectObject</u>	220
<u>axlSubSelectObject</u>	221
<u>axlSelect</u>	222
<u>axlGetSelSet</u>	224
<u>axlGetSelSetCount</u>	226
<u>axlClearSelSet</u>	227
<u>axlGetFindFilter</u>	228
<u>axlSetFindFilter</u>	229
<u>axlAutoOpenFindFilter</u>	240
<u>axlOpenFindFilter</u>	241
<u>axlCloseFindFilter</u>	242
<u>axlDBFindByName</u>	243
<u>axlFindFilterIsOpen</u>	244
<u>axlSelectByName</u>	245
<u>axlSelectByProperty</u>	250
<u>axlSnapToObject</u>	252
<u>axlLastPickIsSnapped</u>	254

5

<u>Interactive Edit Functions</u>	255
<u>Overview</u>	255
<u>AXL/SKILL Interactive Edit Functions</u>	256
<u>axlBondFingerDelete</u>	256
<u>axlBondWireDelete</u>	257
<u>axlChangeLine2Cline</u>	258
<u>axlChangeWidth</u>	259
<u>axlCopyObject</u>	261
<u>axlDBAltOrigin</u>	263
<u>axlDBChangeText</u>	265
<u>axlDeleteObject</u>	268

Allegro SKILL Reference

<u>axIDeleteTaper</u>	271
<u>axIDBDeleteProp</u>	272
<u>axIDBDeletePropAll</u>	275
<u>axIDBDeletePropDictEntry</u>	276
<u>axIDBOpenShape</u>	277
<u>axIGetLastEnterPoint</u>	279
<u>axILastPick</u>	280
<u>axIWindowBoxGet</u>	281
<u>axIWindowBoxSet</u>	282
<u>axIRemovePadstack</u>	283
<u>axIDeleteFillet</u>	284
<u>axIFillet</u>	285
<u>axIPurgePadstacks</u>	286
<u>axIShapeAutoVoid</u>	288
<u>axIShapeChangeDynamicType</u>	290
<u>axIShapeDeleteVoids</u>	292
<u>axIShapeDynamicUpdate</u>	294
<u>axIShapeRaisePriority</u>	295
<u>axIShapeMerge</u>	297
<u>axIShoveItems</u>	299
<u>axIShoveSetParams</u>	300
<u>axISmoothDesign</u>	303
<u>axISmoothItems</u>	304
<u>axISmoothSetParams</u>	305
<u>axISymbolAttach</u>	308
<u>axISymbolDetach</u>	310
<u>axIAddTaper</u>	312
<u>axITextOrientationCopy</u>	313
<u>axITransformObject</u>	314
<u>axIPadstackEdit</u>	318
 <u>6</u>	
<u>Database Read Functions</u>	325
<u>AXL-SKILL Database Read Functions</u>	325
<u>axIDBGetDesign</u>	326

Allegro SKILL Reference

<u>axIDBGetDrillPlating</u>	327
<u>axIIsDBIDType</u>	328
<u>axIDBGetAttachedText</u>	330
<u>axIDBGetPad</u>	332
<u>axIDBGetPropDictEntry</u>	334
<u>axIDBGetProperties</u>	336
<u>axIDBGetDesignUnits</u>	338
<u>axIDBRefreshId</u>	339
<u>axIDBGetLonelyBranches</u>	341
<u>axIDBGetConnect</u>	342
<u>axIDBIsFixed</u>	344
<u>axIDBIsPackagePin</u>	346
<u>axIGetInstanceDefinition</u>	347
<u>axIGetInstanceLocation</u>	348
<u>axIGetInstanceLogicMethod</u>	349
<u>axIGetInstanceNetExceptions</u>	350
<u>axIIsDummyNet</u>	351
<u>axIIsLayerNegative</u>	352
<u>axIIsPinUnused</u>	353
<u>axIIsitFill</u>	354
<u>axIOK2Void</u>	355
<u>axIDBDynamicShapes</u>	356
<u>axIDBGetShapes</u>	357
<u>axIDBTextBlockCompact</u>	358

7

<u>Allegro PCB Editor Interface Functions</u>	359
<u>Overview</u>	359
<u>AXL-SKILL Interface Function Examples</u>	359
<u>Allegro PCB Editor Interface Functions</u>	366
<u>axIClearDynamics</u>	366
<u>axIAddSimpleRbandDynamics</u>	367
<u>axIAddSimpleMoveDynamics</u>	370
<u>axIDesignFlip</u>	372
<u>axnEnterPoint</u>	373

Allegro SKILL Reference

<u>axlEnterString</u>	374
<u>axlEnterAngle</u>	375
<u>axlCancelEnterFun</u>	376
<u>axlFinishEnterFun</u>	377
<u>axlGetDynamicsSegs</u>	378
<u>axlGetLineLock</u>	379
<u>axlEnterBox</u>	381
<u>axlEnterPath</u>	383
<u>axlHighlightObject</u>	384
<u>axlDehighlightObject</u>	386
<u>axlMiniStatusLoad</u>	387
<u>axlDrawObject</u>	390
<u>axlDynamicsObject</u>	391
<u>axlEraseObject</u>	392
<u>axlControlRaise</u>	393
<u>axlEnterEvent</u>	394
<u>axlEventSetStartPopup</u>	398
<u>axlGetTrapBox</u>	400
<u>axlRatsnestBlank</u>	401
<u>axlRatsnestDisplay</u>	402
<u>axlSetDynamicsMirror</u>	403
<u>axlSetDynamicsRotation</u>	404
<u>axlShowObjectToFile</u>	405
<u>axlUICmdPopupSet</u>	406
<u>axlZoomToDbid</u>	407
<u>axlMakeDynamicsPath</u>	408

8

<u>Allegro PCB Editor Command Shell Functions</u>	411
<u>Overview</u>	411
<u>Command Shell Functions</u>	411
<u> axlGetAlias</u>	412
<u> axlGetFuncKey</u>	413
<u> axlGetVariable</u>	414
<u> axlGetVariableList</u>	416

Allegro SKILL Reference

<u>axlJournal</u>	418
<u>axlProtectAlias</u>	419
<u>axlIsProtectAlias</u>	420
<u>axlReadOnlyVariable</u>	421
<u>axlSetAlias</u>	423
<u>axlSetAlias</u>	425
<u>axlSetFuncKey</u>	427
<u>axlSetVariable</u>	429
<u>axlSetVariableFile</u>	431
<u>axlShell</u>	432
<u>axlShellPost</u>	433
<u>axlUnsetVariable</u>	435
<u>axlUnsetVariableFile</u>	436

9

<u>SiP/APD Commands</u>	437
<u>Overview</u>	437
<u>axlChangeLayer</u>	438
<u>axlCreateDeviceFileTemplate</u>	440
<u>axlCompAddPin</u>	441
<u>axlCompDeletePin</u>	444
<u>axlCompMovePin</u>	445
<u>axlDBIsBondingWireLayer</u>	447
<u>axlDBIsBondpad</u>	448
<u>axlDBIsBondwire</u>	449
<u>axlDBIsDiePad</u>	450
<u>axlDBIsPlatingbarPin</u>	451
<u>axlGetDieType</u>	452
<u>axlGetMetalUsageForLayer</u>	453
<u>axlGetWireProfileDefinition</u>	455
<u>axlAddAutoAssignNetAlgorithm</u>	456
<u>axlGetWireProfileDirection</u>	457
<u>axlGetAllVisibleProfiles</u>	458
<u>axlSetAllProfilesVisible</u>	459
<u>axlImportWireProfileDefinitions</u>	460

Allegro SKILL Reference

<u>axlSetDieStackData</u>	461
<u>axlDBIsDieStackLayer</u>	462
<u>axlGetDieData</u>	463
<u>axlGetDieStackData</u>	465
<u>axlGetDieStackMemberSet</u>	467
<u>axlGetDieStackNames</u>	469
<u>axlGetIposerData</u>	470
<u>axlGetSpacerData</u>	472
<u>axlGetWireProfileColor</u>	474
<u>axlGetWireProfileVisible</u>	475
<u>axlPackageDesignCheckAddCategory</u>	476
<u>axlPackageDesignCheckAddCheck</u>	477
<u>axlPackageDesignCheckDrcError</u>	479
<u>axlPackageDesignCheckLogError</u>	480
<u>axlSetDieData</u>	481
<u>axlSetDieType</u>	483
<u>axlSetIposerData</u>	484
<u>axlSetSpacerData</u>	485
<u>axlSetWireProfileColor</u>	486
<u>axlSetWireProfileVisible</u>	487

10

<u>User Interface Functions</u>	489
<u>Overview</u>	489
<u>Window Placement</u>	489
<u>Using Menu Files</u>	490
<u>Dynamically Loading Menus</u>	492
<u>Understanding the Menu File Format</u>	493
<u>AXL-SKILL User Interface Functions</u>	499
<u>axlCancelOff</u>	499
<u>axlCancelOn</u>	500
<u>axlCancelTest</u>	502
<u>axlCursorGet</u>	503
<u>axlCursorWarp</u>	504
<u>axlMeterCreate</u>	505

Allegro SKILL Reference

<u>axIMeterDestroy</u>	507
<u>axIMeterIsCancelled</u>	508
<u>axIMeterUpdate</u>	509
<u>axIUIMenuLoad</u>	510
<u>axIUIMenuDump</u>	511
<u>axIUIColorDialog</u>	512
<u>axIUIConfirm</u>	513
<u>axIUIConfirmEx</u>	514
<u>axIUIControl</u>	516
<u>axIUIMenuChange</u>	518
<u>axIUIMenuDebug</u>	520
<u>axIUIMenuDelete</u>	521
<u>axIUIMenuFind</u>	522
<u>axIUIMenuInsert</u>	525
<u>axIUIMenuRegister</u>	528
<u>axIUIPrompt</u>	530
<u>axIUIWCloseAll</u>	532
<u>axIUIWMove</u>	533
<u>axIUIWSize</u>	534
<u>axIIsViewFileType</u>	535
<u>axIUIViewFileCreate</u>	536
<u>axIUIViewFileReuse</u>	538
<u>axIUIYesNo</u>	540
<u>axIUIWExpose</u>	542
<u>axIUIWClose</u>	543
<u>axIUIWHelpRegister</u>	544
<u>axIUIWPrint</u>	546
<u>axIUIWRedraw</u>	547
<u>axIUIWBlock</u>	548
<u>axIUIEditFile</u>	549
<u>axIUIMultipleChoice</u>	551
<u>axIUIViewFileScrollTo</u>	552
<u>axIUIWBeep</u>	553
<u>axIUIWDisableQuit</u>	554
<u>axIUIWExposeByName</u>	555
<u>axIUIWPerm</u>	556

<u>axIUIWSetHelpTag</u>	558
<u>axIUIWSetParent</u>	559
<u>axIUIWShow</u>	560
<u>axIUIWTimerAdd</u>	561
<u>axIUIWTimerRemove</u>	563
<u>axIUIWUpdate</u>	564
<u>axIUIYesNoCancel</u>	565
<u>axUIDataBrowse</u>	566

11

<u>Form Interface Functions</u>	569
<u>Overview</u>	569
<u>Programming</u>	569
<u>Field / Control</u>	570
<u>Using Forms Specification Language</u>	579
<u>Moving and Sizing Form Controls During Form Resizing</u>	588
<u>Using Grids</u>	593
<u>AXL-SKILL Form Interface Functions</u>	610
<u>axIFormBNFDoc</u>	610
<u>axIFormCallback</u>	624
<u>axIFormCreate</u>	629
<u>axIFormClearMouseActive</u>	633
<u>axIFormClose</u>	634
<u>axIFormDisplay</u>	635
<u>axIFormBuildPopup</u>	636
<u>axIFormGetField</u>	640
<u>axIFormGridSelected</u>	642
<u>axIFormGridSelectedCnt</u>	643
<u>axIFormGridSetSelectRows</u>	644
<u>axIFormListDeleteAll</u>	646
<u>axIFormListSelect</u>	649
<u>axIFormSetEventAction</u>	650
<u>axIFormSetField</u>	652
<u>axIFormSetInfo</u>	655
<u>axIFormSetMouseActive</u>	656

Allegro SKILL Reference

<u>axlFormTest</u>	657
<u>axlFormRestoreField</u>	658
<u>axlFormTitle</u>	660
<u>axlIsFormType</u>	661
<u>axlFormSetFieldVisible</u>	662
<u>axlFormIsFieldVisible</u>	663
<u>Callback Procedure: formCallback</u>	664
<u>axlFormAutoResize</u>	669
<u>axlFormColorize</u>	670
<u>axlFormGetActiveField</u>	673
<u>axlFormGridBatch</u>	674
<u>axlFormGridCancelPopup</u>	675
<u>axlFormGridDeleteRows</u>	676
<u>axlFormGridEvents</u>	677
<u>axlFormGridGetCell</u>	680
<u>axlFormGridInsertCol</u>	682
<u>axlIsGridCellType</u>	686
<u>axlFormGridInsertRows</u>	687
<u>axlFormGridNewCell</u>	688
<u>axlFormGridReset</u>	689
<u>axlFormGridSetBatch</u>	690
<u>axlFormGridUpdate</u>	693
<u>axlFormInvalidateField</u>	694
<u>axlFormIsFieldEditable</u>	695
<u>axlFormListAddItem</u>	696
<u>axlFormListDeleteItem</u>	698
<u>axlFormListGetItem</u>	700
<u>axlFormListGetSelCount</u>	701
<u>axlFormListGetSelItems</u>	702
<u>axlFormListOptions</u>	703
<u>axlFormListSelAll</u>	705
<u>axlFormMsg</u>	706
<u>axlFormGetFieldType</u>	708
<u>axlFormDefaultButton</u>	709
<u>axlFormGridOptions</u>	711
<u>axlFormSetActiveField</u>	713

Allegro SKILL Reference

<u>axlFormSetDecimal</u>	714
<u>axlFormSetFieldEditable</u>	715
<u>axlFormSetFieldLimits</u>	716
<u>axlFormTreeViewAddItem</u>	717
<u>axlFormTreeViewChangeImages</u>	720
<u>axlFormTreeViewChangeLabel</u>	722
<u>axlFormTreeViewGetImages</u>	723
<u>axlFormTreeViewGetLabel</u>	724
<u>axlFormTreeViewGetParents</u>	725
<u>axlFormTreeViewGetSelectState</u>	726
<u>axlFormTreeViewLoadBitmaps</u>	727
<u>axlFormTreeViewSet</u>	729
<u>axlFormTreeViewSetSelectState</u>	732

12

Simple Graphics Drawing Functions

<u>Overview</u>	733
<u>Functions</u>	736
<u>axlGRPDrwBitmap</u>	736
<u>axlGRPDrwCircle</u>	737
<u>axlGRPDrwInit</u>	738
<u>axlGRPDrwLine</u>	739
<u>axlGRPDrwMapWindow</u>	740
<u>axlGRPDrwPoly</u>	741
<u>axlGRPDrwRectangle</u>	742
<u>axlGRPDrwText</u>	743
<u>axlGRPDrwUpdate</u>	744

13

Message Handler Functions

<u>Overview</u>	745
<u>Message Handler Functions</u>	748
<u>axIMsgPut</u>	748
<u>axIMsgContextPrint</u>	749
<u>axIMsgContextGetString</u>	750

<u>axIMsgContextGet</u>	751
<u>axIMsgContextTest</u>	752
<u>axIMsgContextInBuf</u>	753
<u>axIMsgContextRemove</u>	754
<u>axIMsgContextStart</u>	755
<u>axIMsgContextFinish</u>	756
<u>axIMsgContextClear</u>	757
<u>axIMsgCancelPrint</u>	758
<u>axIMsgCancelSeen</u>	759
<u>axIMsgClear</u>	760
<u>axIMsgSet</u>	761
<u>axIMsgTest</u>	762

14

<u>Design Control Functions</u>	763
<u>AXL-SKILL Design Control Functions</u>	763
<u>axICurrentDesign</u>	764
<u>axIDesignType</u>	765
<u>axICompileSymbol</u>	766
<u>axISetSymbolType</u>	767
<u>axIDBControl</u>	768
<u>axIDBGetExtents</u>	774
<u>axIDBIgnoreFixed</u>	775
<u>axIDBIsReadOnly</u>	777
<u>axIDBSectorSize - Obsolete</u>	778
<u>axIGetDrawingName</u>	779
<u>axILgnoreFixed</u>	780
<u>axILnTrigger</u>	781
<u>axILsSymbolEditor</u>	782
<u>axIKillDesign</u>	783
<u>axIOpenDesign</u>	784
<u>axIOpenDesignForBatch</u>	786
<u>axIRenameDesign</u>	787
<u>axISaveDesign</u>	788
<u>axISaveEnable</u>	790

Allegro SKILL Reference

<u>axIDBChangeDesignExtents</u>	791
<u>axIDBChangeDesignOrigin</u>	792
<u>axIDBChangeDesignUnits</u>	793
<u>axIDBCheck</u>	795
<u>axIDBCopyPadstack</u>	797
<u>axIDBDelLock</u>	799
<u>axIDBGetLock</u>	800
<u>axIDBMemoryReclaim</u>	801
<u>axIDBSetLock</u>	803
<u>axIDBTuneSectorSize</u>	805
<u>axITechnologyType</u>	806
<u>axITriggerClear</u>	807
<u>axITriggerPrint</u>	808
<u>axITriggerSet</u>	809
<u>axIGetActiveLayer</u>	814
<u>axIGetActiveTextBlock</u>	815
<u>axISetActiveLayer</u>	816
<u>axIWFMAnyExported</u>	817
<u>axIDBDisplayControl</u>	818

15

<u>Database Create Functions</u>	825
<u>Overview</u>	825
<u>Path Functions</u>	826
<u>axIPathStart</u>	828
<u>axIPathArcRadius</u>	830
<u>axIPathArcAngle</u>	830
<u>axIPathArcCenter</u>	830
<u>axIPathLine</u>	834
<u>axIPathGetWidth</u>	835
<u>axIPathSegGetWidth</u>	836
<u>axIPathGetPathSegs</u>	837
<u>axIPathGetLastPathSeg</u>	838
<u>axIPathSegGetEndPoint</u>	839
<u>axIPathSegGetArcCenter</u>	840

Allegro SKILL Reference

<u>axIPathSegGetArcClockwise</u>	841
<u>axIPathStartCircle</u>	842
<u>axIPathOffset</u>	843
<u>axIDB2Path</u>	844
<u>axIDBCreatePath</u>	845
<u>axIDBCreateLine</u>	848
<u>axIDBCreateCircle</u>	850
<u>Create Shape Interface</u>	851
<u>axIDBCreateOpenShape</u>	853
<u>axIDBCreateCloseShape</u>	857
<u>axIDBActiveShape</u>	858
<u>axIDBCreateVoidCircle</u>	859
<u>axIDBCreateVoid</u>	860
<u>axIDBCreateShape</u>	862
<u>axIDBCreateRectangle</u>	864
<u>Nonpath DBCreate Functions</u>	866
<u>axICreateBondFinger</u>	866
<u>axICreateBondWire</u>	868
<u>axIDBCreateExternalDRC</u>	870
<u>axIDBCreatePadStack</u>	874
<u>axIDBCreatePin</u>	879
<u>axIDBCreateSymbol</u>	882
<u>axIDBCreateSymbolSkeleton</u>	886
<u>axIDBCreateText</u>	890
<u>axIDBCreateVia</u>	893
<u>axIDBCreateSymbolAutosilk</u>	895
<u>axICreateWirebondGuide</u>	896
<u>Property Functions</u>	897
<u>axIDBCreatePropDictEntry</u>	897
<u>axDBAddProp</u>	901
<u>Load and Save Functions</u>	904
<u>axILoadPadstack</u>	904
<u>axILoadSymbol</u>	905
<u>axIPadstackToDisk</u>	907
<u>axIRefreshSymbol</u>	908

16

<u>Database Group Functions</u>	911
<u>Overview</u>	911
<u>axIDBAddGroupObjects</u>	912
<u>axIDBCreateGroup</u>	913
<u>axIDBDisbandGroup</u>	916
<u>axIDBGetGroupFromItem</u>	917
<u>axIDBGroupRename</u>	919
<u>axIDBRemoveGroupObjects</u>	920
<u>axINetClassAdd</u>	921
<u>axINetClassCreate</u>	923
<u>axINetClassDelete</u>	925
<u>axINetClassGet</u>	926
<u>axINetClassRemove</u>	928
<u>axIRegionAdd</u>	930
<u>axIRegionCreate</u>	932
<u>axIRegionDelete</u>	933
<u>axIRegionRemove</u>	934

17

<u>Database Attachment Functions</u>	937
<u>Overview</u>	937
<u>axICreateAttachment</u>	938
<u>axIDeleteAttachment</u>	941
<u>axIGetAllAttachmentNames</u>	942
<u>axIGetAttachment</u>	943
<u>axIIIsAttachment</u>	945
<u>axISetAttachment</u>	946

18

<u>Database Transaction Functions</u>	949
<u>Overview</u>	949
<u>axIDBCloak</u>	950
<u>axIDBTransactionCommit</u>	953

<u>axIDBTransactionMark</u>	954
<u>axIDBTransactionOops</u>	955
<u>axIDBTransactionRollback</u>	956
<u>axIDBTransactionStart</u>	957

19

<u>Constraint Management Functions</u>	959
<u>Overview</u>	959
<u>axICnsAddVia</u>	960
<u>axICnsAssignPurge</u>	961
<u>axICnsClassTableChange</u>	962
<u>axICnsClassTableCreate</u>	964
<u>axICnsClassTableDelete</u>	967
<u>axICnsClassTableFind</u>	968
<u>axICnsClassTableSeek</u>	970
<u>axICNSCreate</u>	972
<u>axICNSCsetLock</u>	974
<u>axICNSDelete</u>	976
<u>axICnsDeleteClassClassObjects</u>	977
<u>axICnsDeleteRegionClassClassObjects</u>	978
<u>axICnsDeleteRegionClassObjects</u>	979
<u>axICnsDeleteVia</u>	980
<u>axICNSDesignModeGet</u>	981
<u>axICNSDesignModeSet</u>	983
<u>axICNSDesignValueCheck</u>	986
<u>axICNSDesignValueGet</u>	987
<u>axICNSDesignValueSet</u>	989
<u>axICNSEcsetCreate</u>	991
<u>axICNSEcsetDelete</u>	993
<u>axICNSEcsetGet</u>	994
<u>axICNSEcsetModeGet</u>	995
<u>axICNSEcsetModeSet</u>	997
<u>axICNSEcsetValueCheck</u>	1000
<u>axICNSEcsetValueGet</u>	1001
<u>axICNSGetDefaultMinLineWidth</u>	1004

Allegro SKILL Reference

<u>axICNSGetPhysical</u>	1005
<u>axICNSGetPinDelayEnabled</u>	1008
<u>axICNSGetPinDelayPVF</u>	1009
<u>axICNSGetSameNet</u>	1010
<u>axICNSGetSameNetXtalkEnabled</u>	1012
<u>axICNSGetSpacing</u>	1013
<u>axICNSGetViaZEnabled</u>	1016
<u>axICNSGetViaZPVF</u>	1017
<u>axICNSPhysicalModeGet</u>	1018
<u>axICNSIsCsetLocked</u>	1020
<u>axICNSIsLockedDomain</u>	1021
<u>axICNSLockDomain</u>	1023
<u>axICNSPhysicalModeSet</u>	1024
<u>axICNSSameNetModeGet</u>	1026
<u>axICNSSameNetModeSet</u>	1028
<u>axICNSSetPhysical</u>	1030
<u>axICNSSetSpacing</u>	1033
<u>axICNSSetPinDelayEnabled</u>	1036
<u>axICNSSetPinDelayPVF</u>	1037
<u>axICNSSetSameNet</u>	1038
<u>axICNSSetSameNetXtalkEnabled</u>	1040
<u>axICNSSetViaZEnabled</u>	1041
<u>axICNSSetViaZPVF</u>	1042
<u>axICNSSpacingModeGet</u>	1043
<u>axICNSSpacingModeSet</u>	1045
<u>axICnsPurgeAll()</u>	1047
<u>axICnsPurgeCsets</u>	1048
<u>axICnsPurgeObjects</u>	1049
<u>axIViaZLength</u>	1050
<u>axINetEcsetValueGet</u>	1051
<u>axICNSEcsetValueSet</u>	1053
<u>axICnsGetViaList</u>	1055
<u>axIGetAllViaList</u>	1057
<u>axIDRCUpdate</u>	1058
<u>axIDRCWaive</u>	1059
<u>axIDRCGetCount</u>	1061

<u>axIDRCItem</u>	1062
<u>axIDRCWaiveGetCount</u>	1064
<u>axILayerSet</u>	1065
<u>axICnsList</u>	1066
<u>axICNSMapClear</u>	1068
<u>axICNSMapUpdate</u>	1069
<u>axICnsNetFlattened</u>	1071
 20	
<u>Command Control Functions</u>	1073
<u>Overview</u>	1073
<u>AXL-SKILL Command Control Functions</u>	1073
<u>axICmdRegister</u>	1074
<u>axICmdUnregister</u>	1077
<u>axIEndSkillMode</u>	1078
<u>axIFlushDisplay</u>	1079
<u>axIOKToProceed</u>	1081
<u>axISetLineLock</u>	1082
<u>axISetRotateIncrement</u>	1084
<u>axIUIGetUserData</u>	1085
<u>axIUIPopupDefine</u>	1086
<u>axIUIPopupSet</u>	1088
<u>axIBuildClassPopup</u>	1090
<u>axIBuildSubclassPopup</u>	1091
<u>axISubclassFormPopup</u>	1093
<u>axIVisibleUpdate</u>	1096
<u>axIWindowFit</u>	1098
 21	
<u>Polygon Operation Functions</u>	1099
<u>Overview</u>	1099
<u>About Polygon Operations</u>	1099
<u>AXL-SKILL Polygon Operation Attributes</u>	1102
<u>AXL-SKILL Polygon Operation Functions</u>	1104
<u>axIPolyFromDB</u>	1104

Allegro SKILL Reference

<u>axIPolyMemUse</u>	1108
<u>axIPolyOffset</u>	1110
<u>axIPolyOperation</u>	1112
<u>axIPolyExpand</u>	1114
<u>axIPolyType</u>	1120
<u>axIPolyFromHole</u>	1121
<u>axIPolyErrorGet</u>	1122
<u>Use Models</u>	1124

22

<u>Allegro PCB Editor File Access Functions</u>	1127
---	-------	------

<u>AXL-SKILL File Access Functions</u>	1127
<u>axIDMFileError</u>	1128
<u>axIDMFindFile</u>	1129
<u>axIDMGetFile</u>	1131
<u>axIDMOpenFile</u>	1133
<u>axIDMOpenLog</u>	1136
<u>axIDMClose</u>	1137
<u>axIDMBrowsePath</u>	1138
<u>axIDMDirectoryBrowse</u>	1139
<u>axIDMFileBrowse</u>	1140
<u>axIDMFileParts</u>	1142
<u>axIOSFileCopy</u>	1143
<u>axIOSFileMove</u>	1144
<u>axOSSlash</u>	1145
<u>axIRecursiveDelete</u>	1146
<u>axITempDirectory</u>	1148
<u>axITempFile</u>	1149
<u>axITempFileRemove</u>	1150

23

<u>Reports and Extract Functions</u>	1151
--------------------------------------	-------	------

<u>AXL-SKILL Data Extract Functions</u>	1151
<u>axIExtractToFile</u>	1151
<u>axIExtractMap</u>	1153

<u>axlReportList</u>	1155
<u>axlReportRegister</u>	1156
24	
<u>Utility Functions</u>	1159
<u>axlCheckString</u>	1160
<u>axlCmdList</u>	1162
<u>axlDebug</u>	1163
<u>axlDetailLoad</u>	1164
<u>axlDetailSave</u>	1166
<u>axlEmail</u>	1167
<u>axlHistory</u>	1169
<u>axlHttp</u>	1171
<u>axlIsDebugEnabled</u>	1173
<u>axlIsProductLineActive</u>	1174
<u>axlLicDefaultVersion</u>	1175
<u>axlLicFeatureExists</u>	1176
<u>axlLicIsProductEnabled</u>	1177
<u>axlLogHeader</u>	1178
<u>axlMKS2UU</u>	1179
<u>axlMKSAlias</u>	1181
<u>axlMKSCConvert</u>	1182
<u>axlMKSStr2UU</u>	1185
<u>axlMapClassName</u>	1186
<u>axlMemSize</u>	1188
<u>axlOSBackSlash</u>	1189
<u>axlOSControl</u>	1190
<u>axlPPrint</u>	1192
<u>axlPdfView</u>	1193
<u>axlPrintDbid</u>	1194
<u>axlRegexpls</u>	1196
<u>axlRunBatchDBProgram</u>	1197
<u>axlShowObject</u>	1202
<u>axlSleep</u>	1203
<u>axlSort</u>	1204

<u>axlStrcmpAlpNum</u>	1208
<u>axlStringCSVParse</u>	1209
<u>axlStringRemoveSpaces</u>	1211
<u>axlVersion</u>	1212
<u>axlVersionIdGet</u>	1216
<u>axlVersionIdPrint</u>	1217

25

<u>Math Utility Functions</u>	1219
<u>Overview</u>	1219
<u>axlDegToRad</u>	1219
<u>axlDistance</u>	1220
<u>axlGeo2Str</u>	1221
<u>axlGeoArcCenterAngle</u>	1223
<u>axlGeoArcCenterRadius</u>	1226
<u>axlGeoEqual</u>	1231
<u>axlGeoRotatePt</u>	1232
<u>axlGeoPointsEqual</u>	1233
<u>axllsBetween</u>	1234
<u>axllsPointInsideBox</u>	1235
<u>axllsPointOnLine</u>	1236
<u>axlLineSlope</u>	1237
<u>axlLineXLine</u>	1238
<u>axlMathConstants</u>	1239
<u>axlMidPointArc</u>	1240
<u>axlMidPointLine</u>	1241
<u>axlMPythag</u>	1242
<u>axlMUniVector</u>	1243
<u>axlMXYAdd</u>	1245
<u>axlMXYMult</u>	1246
<u>axlMXYSub</u>	1247
<u>axlRadToDeg</u>	1248
<u>axl ol ol2</u>	1249
<u>bBoxAdd</u>	1251

26

<u>Database Miscellaneous Functions</u>	1253
<u>Overview</u>	1253
<u>axlAirGap</u>	1254
<u>axlBackDrill</u>	1258
<u>axlDBGetLength</u>	1261
<u>axlDBGetManhattan</u>	1262
<u>axlDBGetSymbolBodyExtent</u>	1263
<u>axlDBPinPairLength</u>	1264
<u>axlDeleteByLayer</u>	1265
<u>axlExtentDB</u>	1267
<u>axlExtentLayout</u>	1268
<u>axlExtentSymbol</u>	1269
<u>axlFindPath</u>	1270
<u>axlGeoPointInShape</u>	1272
<u>axlGeoPointShapeInfo</u>	1273
<u>axlGetImpedance</u>	1274
<u>axlImpdedanceGetLayerBroadsideDPImp</u>	1275
<u>axlImpdedanceGetLayerBroadsideDPWidth</u>	1276
<u>axlImpdedanceGetLayerEdgeDPImp</u>	1277
<u>axlImpdedanceGetLayerEdgeDPSpacing</u>	1278
<u>axlImpdedanceGetLayerEdgeDPWidth</u>	1279
<u>axlImpedance2Width</u>	1280
<u>axlPadOnLayer</u>	1281
<u>axlPadstackSetType</u>	1283
<u>axlPinExport</u>	1285
<u>axlPinImport</u>	1286
<u>axlReratNet</u>	1288
<u>axlText2Lines</u>	1289
<u>axlUnfixAll</u>	1291
<u>axlWidth2Impedance</u>	1292
<u>axlIsHighlighted</u>	1293
<u>axlTestPoint</u>	1294
<u>axlChangeNet</u>	1297
<u>axlSegDelayAndZ0</u>	1299

<u>axISetDefaultDieInformation</u>	1300
27		
<u>Microsoft Excel Integration Functions</u>	1301
<u>axISpreadsheetClose</u>	1301
<u>axISpreadsheetDefineCell</u>	1302
<u>axISpreadsheetDoc</u>	1303
<u>axISpreadsheetGetCell</u>	1305
<u>axISpreadsheetGetRGBColorString</u>	1306
<u>axISpreadsheetGetRGBForNamedColor</u>	1307
<u>axISpreadsheetGetStyles</u>	1308
<u>axISpreadsheetGetWorksheets</u>	1309
<u>axISpreadsheetGetWorksheetSize</u>	1310
<u>axISpreadsheetInit</u>	1311
<u>axISpreadsheetRead</u>	1312
<u>axISpreadsheetReadDelimited</u>	1313
<u>axISpreadsheetSetCell</u>	1314
<u>axISpreadsheetSetCellProp</u>	1315
<u>axISpreadsheetSetColumnProp</u>	1316
<u>axISpreadsheetSetDocProp</u>	1317
<u>axISpreadsheetSetRowProp</u>	1318
<u>axISpreadsheetSetStyle</u>	1319
<u>axISpreadsheetSetStyleBorder</u>	1320
<u>axISpreadsheetSetStyleParent</u>	1321
<u>axISpreadsheetSetStyleProp</u>	1322
<u>axISpreadsheetSetWorksheet</u>	1323
<u>axISpreadsheetWrite</u>	1324
28		
<u>Plugin Functions</u>	1325
<u>Overview</u>	1325
<u>SKILL Programming</u>	1325
<u>DLL Programming</u>	1326
<u>Input/Output Data Primitives</u>	1327
<u>Programming Restrictions, Cautions and Hints</u>	1329

Allegro SKILL Reference

<u>Performance Considerations</u>	1330
<u>Cadence Customer Support</u>	1330
<u>Examples</u>	1330
<u>axIDllCall</u>	1331
<u>axIDllCallList</u>	1333
<u>axIDllClose</u>	1334
<u>axIDllDump</u>	1335
<u>axIDllOpen</u>	1336
<u>axIDllSym</u>	1338

29

<u>Skill Language Extensions</u>	1341
<u>axldo</u>	1341
<u>copyDeep</u>	1343
<u>isBoxp</u>	1344
<u>lastelem</u>	1345
<u>letStar</u>	1346
<u>listnindex</u>	1347
<u>movedown</u>	1348
<u>moveup</u>	1349
<u>parseFile</u>	1350
<u>parseQuotedString</u>	1352
<u>pprintIn</u>	1353
<u>propNames</u>	1354

30

<u>Logic Access Functions</u>	1355
<u>Overview</u>	1355
<u>axIDBAssignNet</u>	1356
<u>axIDBCreateConceptComponent</u>	1358
<u>axIDBCreateComponent</u>	1360
<u>axIDBCreateManyModuleInstances</u>	1362
<u>axIDBCreateModuleDef</u>	1364
<u>axIDBCreateModuleInstance</u>	1365
<u>axIDBCreateNet</u>	1367

Allegro SKILL Reference

<u>axIDBCreateSymDefSkeleton</u>	1368
<u>axIDBDummyNet</u>	1370
<u>axIDbidName</u>	1371
<u>axIDiffPair</u>	1372
<u>axIDiffPairAuto</u>	1374
<u>axIDiffPairDBID</u>	1376
<u>axIMatchGroupAdd</u>	1377
<u>axIMatchGroupCreate</u>	1379
<u>axIMatchGroupDelete</u>	1382
<u>axIMatchGroupProp</u>	1383
<u>axIMatchGroupRemove</u>	1385
<u>axINetSched</u>	1387
<u>axIPinPair</u>	1388
<u>axIPinPairSeek</u>	1392
<u>axIPinsOfNet</u>	1393
<u>axIRemoveNet</u>	1394
<u>axIRenameNet</u>	1395
<u>axIRenameRefdes</u>	1397
<u>axISchedule</u>	1399
<u>axIScheduleNet</u>	1401
<u>axIWriteDeviceFile</u>	1402
<u>axIWritePackageFile</u>	1404

A

<u>Building Contexts in Allegro</u>	1407
<u>Introduction</u>	1407
<u> Requirements</u>	1407
<u> Cautions</u>	1407
<u>Building Standard Contexts</u>	1408
<u>Building Autoload Contexts</u>	1409
<u>Files with This Package</u>	1410
<u> File B1</u>	1410
<u> File S1</u>	1411
<u> File A1</u>	1412
<u> File A2</u>	1415

Allegro SKILL Reference

Alphabetical List of Functions

<u>axl.ol.ol2</u>	1249
<u>axlAddAutoAssignNetAlgorithm</u>	456
<u>axlAddSelectAll</u>	211
<u>axlAddSelectBox</u>	209
<u>axlAddSelectName</u>	216
<u>axlAddSelectObject</u>	220
<u>axlAddSelectPoint</u>	204
<u>axlAddSimpleMoveDynamics</u>	370
<u>axlAddSimpleRbandDynamics</u>	367
<u>axlAddTaper</u>	312
<u>axlAirGap</u>	1254
<u>axlAutoOpenFindFilter</u>	240
<u>axlBackDrill</u>	1258
<u>axlBondFingerDelete</u>	256
<u>axlBondWireDelete</u>	257
<u>axlBuildClassPopup</u>	1090
<u>axlBuildSubclassPopup</u>	1091
<u>axlCancelEnterFun</u>	376
<u>axlCancelOff</u>	499
<u>axlCancelOn</u>	500
<u>axlCancelTest</u>	502
<u>axlChangeLayer</u>	438
<u>axlChangeLine2Cline</u>	258
<u>axlChangeNet</u>	1297
<u>axlChangeWidth</u>	259
<u>axlCheckString</u>	1160
<u>axlClasses</u>	170
<u>axlClearDynamics</u>	366
<u>axlClearObjectCustomColor</u>	159
<u>axlClearSelSet</u>	227
<u>axlCloseFindFilter</u>	242
<u>axlCmdList</u>	1162
<u>axlCmdRegister</u>	1074
<u>axlCmdUnregister</u>	1077
<u>axlCnsAddVia</u>	960
<u>axlCnsAssignPurge</u>	961
<u>axlCnsClassTableChange</u>	962
<u>axlCnsClassTableCreate</u>	964
<u>axlCnsClassTableDelete</u>	967

Allegro SKILL Reference

axICnsClassTableFind	968
axICnsClassTableSeek	970
axICNSCreate	972
axICNSCsetLock	974
axICNSDelete	976
axICnsDeleteClassClassObjects	977
axICnsDeleteRegionClassClassObjects	978
axICnsDeleteRegionClassObjects	979
axICnsDeleteVia	980
axICNSDesignModeGet	981
axICNSDesignModeSet	983
axICNSDesignValueCheck	986
axICNSDesignValueGet	987
axICNSDesignValueSet	989
axICNSEcsetCreate	991
axICNSEcsetDelete	993
axICNSEcsetGet	994
axICNSEcsetModeGet	995
axICNSEcsetModeSet	997
axICNSEcsetValueCheck	1000
axICNSEcsetValueGet	1001
axICNSEcsetValueSet	1053
axICNSGetDefaultMinLineWidth	1004
axICNSGetPhysical	1005
axICNSGetPinDelayEnabled	1008
axICNSGetPinDelayPVF	1009
axICNSGetSameNet	1010
axICNSGetSameNetXtalkEnabled	1012
axICNSGetSpacing	1013
axICnsGetViaList	1055
axICNSGetViaZEnabled	1016
axICNSGetViaZPVF	1017
axICNSIsCsetLocked	1020
axICNSIsLockedDomain	1021
axICnsList	1066
axICNSLockDomain	1023
axICNSMapClear	1068
axICNSMapUpdate	1069
axICnsNetFlattened	1071
axICNSPhysicalModeGet	1018
axICNSPhysicalModeSet	1024
axICnsPurgeAll()	1047
axICnsPurgeCsets	1048
axICnsPurgeObjects	1049

Allegro SKILL Reference

<u>axICNSSameNetModeGet</u>	1026
<u>axICNSSameNetModeSet</u>	1028
<u>axICNSSetPhysical</u>	1030
<u>axICNSSetPinDelayEnabled</u>	1036
<u>axICNSSetPinDelayPVF</u>	1037
<u>axICNSSetSameNet</u>	1038
<u>axICNSSetSameNetXtalkEnabled</u>	1040
<u>axICNSSetSpacing</u>	1033
<u>axICNSSetViaZEnabled</u>	1041
<u>axICNSSetViaZPVF</u>	1042
<u>axICNSSpacingModeGet</u>	1043
<u>axICNSSpacingModeSet</u>	1045
<u>axIColorDoc</u>	140
<u>axIColorGet</u>	142
<u>axIColorLoad</u>	148
<u>axIColorOnGet – Obsolete Command</u>	150
<u>axIColorOnSet – Obsolete Command</u>	151
<u>axIColorPriorityGet – Obsolete Command</u>	152
<u>axIColorPrioritySet – Obsolete Command</u>	153
<u>axIColorSave</u>	154
<u>axIColorSet</u>	155
<u>axIColorShadowGet</u>	144
<u>axIColorShadowSet</u>	146
<u>axICompAddPin</u>	441
<u>axICompDeletePin</u>	444
<u>axICompileSymbol</u>	766
<u>axICompMovePin</u>	445
<u>axIConductorBottomLayer</u>	186
<u>axIConductorTopLayer</u>	187
<u>axIControlRaise</u>	393
<u>axICopyObject</u>	261
<u>axIcreate</u>	118
<u>axICreateAttachment</u>	938
<u>axICreateBondFinger</u>	866
<u>axICreateBondWire</u>	868
<u>axICreateDeviceFileTemplate</u>	440
<u>axICreateWirebondGuide</u>	896
<u>axICurrentDesign</u>	764
<u>axICursorGet</u>	503
<u>axICursorWarp</u>	504
<u>axICustomColorObject</u>	160
<u>axICVFCColorChooserDlg</u>	158
<u>axIDB2Path</u>	844
<u>axIDBActiveShape</u>	858

Allegro SKILL Reference

<u>axIDBAddGroupObjects</u>	912
<u>axIDBAddProp</u>	901
<u>axIDBAltOrigin</u>	263
<u>axIDBAssignNet</u>	1356
<u>axIDBChangeDesignExtents</u>	791
<u>axIDBChangeDesignOrigin</u>	792
<u>axIDBChangeDesignUnits</u>	793
<u>axIDBChangeText</u>	265
<u>axIDBCheck</u>	795
<u>axIDBCloak</u>	950
<u>axIDBControl</u>	768
<u>axIDBCopyPadstack</u>	797
<u>axIDBCreateCircle</u>	850
<u>axIDBCreateCloseShape</u>	857
<u>axIDBCreateComponent</u>	1360
<u>axIDBCreateConceptComponent</u>	1358
<u>axIDBCreateExternalDRC</u>	870
<u>axIDBCreateFilmRec</u>	188
<u>axIDBCreateGroup</u>	913
<u>axIDBCreateLine</u>	848
<u>axIDBCreateManyModuleInstances</u>	1362
<u>axIDBCreateModuleDef</u>	1364
<u>axIDBCreateModuleInstance</u>	1365
<u>axIDBCreateNet</u>	1367
<u>axIDBCreateOpenShape</u>	853
<u>axIDBCreatePadStack</u>	874
<u>axIDBCreatePath</u>	845
<u>axIDBCreatePin</u>	879
<u>axIDBCreatePropDictEntry</u>	897
<u>axIDBCreateRectangle</u>	864
<u>axIDBCreateShape</u>	862
<u>axIDBCreateSymbol</u>	882
<u>axIDBCreateSymbolAutosilk</u>	895
<u>axIDBCreateSymbolSkeleton</u>	886
<u>axIDBCreateSymDefSkeleton</u>	1368
<u>axIDBCreateText</u>	890
<u>axIDBCreateVia</u>	893
<u>axIDBCreateVoid</u>	860
<u>axIDBCreateVoidCircle</u>	859
<u>axIDBDeleteProp</u>	272
<u>axIDBDeletePropAll</u>	275
<u>axIDBDeletePropDictEntry</u>	276
<u>axIDBDelLock</u>	799
<u>axIDBDisbandGroup</u>	916

Allegro SKILL Reference

<u>axIDBDisplayControl</u>	818
<u>axIDBDummyNet</u>	1370
<u>axIDBDynamicShapes</u>	356
<u>axIDBFindByName</u>	243
<u>axIDBGetAttachedText</u>	330
<u>axIDBGetConnect</u>	342
<u>axIDBGetDesign</u>	326
<u>axIDBGetDesignUnits</u>	338
<u>axIDBGetDrillPlating</u>	327
<u>axIDBGetExtents</u>	774
<u>axIDBGetGroupFromItem</u>	917
<u>axIDBGetLayerType</u>	171
<u>axIDBGetLength</u>	1261
<u>axIDBGetLock</u>	800
<u>axIDBGetLonelyBranches</u>	341
<u>axIDBGetManhattan</u>	1262
<u>axIDBGetPad</u>	332
<u>axIDBGetPropDictEntry</u>	334
<u>axIDBGetProperties</u>	336
<u>axIDBGetShapes</u>	357
<u>axIDBGetSymbolBodyExtent</u>	1263
<u>axIDBGridGet</u>	121
<u>axIDBGridSet</u>	123
<u>axIDBGroupRename</u>	919
<u>axIDbidName</u>	1371
<u>axIDBIgnoreFixed</u>	775
<u>axIDBIsBondingWireLayer</u>	447
<u>axIDBIsBondpad</u>	448
<u>axIDBIsBondwire</u>	449
<u>axIDBIsDiePad</u>	450
<u>axIDBIsDieStackLayer</u>	462
<u>axIDBIsFixed</u>	344
<u>axIDBIsPackagePin</u>	346
<u>axIDBIsPlatingbarPin</u>	451
<u>axIDBIsReadOnly</u>	777
<u>axIDBMemoryReclaim</u>	801
<u>axIDBOpenShape</u>	277
<u>axIDBPinPairLength</u>	1264
<u>axIDBRefreshId</u>	339
<u>axIDBRemoveGroupObjects</u>	920
<u>axIDBSectorSize - Obsolete</u>	778
<u>axIDBSetLock</u>	803
<u>axIDBTextBlockCompact</u>	358
<u>axIDBTextBlockCreate</u>	125

Allegro SKILL Reference

<u>axIDBTransactionCommit</u>	953
<u>axIDBTransactionMark</u>	954
<u>axIDBTransactionOops</u>	955
<u>axIDBTransactionRollback</u>	956
<u>axIDBTransactionStart</u>	957
<u>axIDBTuneSectorSize</u>	805
<u>axIDebug</u>	1163
<u>axIDegToRad</u>	1219
<u>axIDehighlightObject</u>	386
<u>axIDeleteAttachment</u>	941
<u>axIDeleteByLayer</u>	1265
<u>axIDeleteFillet</u>	284
<u>axIDeleteObject</u>	268
<u>axIDeleteTaper</u>	271
<u>axIDesignFlip</u>	372
<u>axIDesignType</u>	765
<u>axIDetailLoad</u>	1164
<u>axIDetailSave</u>	1166
<u>axIDiffPair</u>	1372
<u>axIDiffPairAuto</u>	1374
<u>axIDiffPairDBID</u>	1376
<u>axIDistance</u>	1220
<u>axIDllCall</u>	1331
<u>axIDllCallList</u>	1333
<u>axIDllClose</u>	1334
<u>axIDllDump</u>	1335
<u>axIDllOpen</u>	1336
<u>axIDllSym</u>	1338
<u>axIDMBrowsePath</u>	1138
<u>axIDMClose</u>	1137
<u>axIDMDirectoryBrowse</u>	1139
<u>axIDMFileBrowse</u>	1140
<u>axIDMFileError</u>	1128
<u>axIDMFileParts</u>	1142
<u>axIDMFindFile</u>	1129
<u>axIDMGetFile</u>	1131
<u>axIDMOpenFile</u>	1133
<u>axIDMOpenLog</u>	1136
<u>axldo</u>	1341
<u>axIDrawObject</u>	390
<u>axIDRCGetCount</u>	1061
<u>axIDRCItem</u>	1062
<u>axIDRCUpdate</u>	1058
<u>axIDRCWaive</u>	1059

Allegro SKILL Reference

<u>axIDRCWaiveGetCount</u>	1064
<u>axIDynamicsObject</u>	391
<u>axlEmail</u>	1167
<u>axlEndSkillMode</u>	1078
<u>axlEnterAngle</u>	375
<u>axlEnterBox</u>	381
<u>axlEnterEvent</u>	394
<u>axlEnterPath</u>	383
<u>axlEnterPoint</u>	373
<u>axlEnterString</u>	374
<u>axlEraseObject</u>	392
<u>axlEventSetStartPopup</u>	398
<u>axlExportXmlIDBRecords</u>	126
<u>axlExtentDB</u>	1267
<u>axlExtentLayout</u>	1268
<u>axlExtentSymbol</u>	1269
<u>axlExtractMap</u>	1153
<u>axlExtractToFile</u>	1151
<u>axlFillet</u>	285
<u>axlFindFilterIsOpen</u>	244
<u>axlFindPath</u>	1270
<u>axlFinishEnterFun</u>	377
<u>axlFlushDisplay</u>	1079
<u>axlFormAutoResize</u>	669
<u>axlFormBNFDoc</u>	610
<u>axlFormBuildPopup</u>	636
<u>axlFormCallback</u>	624
<u>axlFormClearMouseActive</u>	633
<u>axlFormClose</u>	634
<u>axlFormColorize</u>	670
<u>axlFormCreate</u>	629
<u>axlFormDefaultButton</u>	709
<u>axlFormDisplay</u>	635
<u>axlFormGetActiveField</u>	673
<u>axlFormGetField</u>	640
<u>axlFormGetFieldType</u>	708
<u>axlFormGridBatch</u>	674
<u>axlFormGridCancelPopup</u>	675
<u>axlFormGridDeleteRows</u>	676
<u>axlFormGridEvents</u>	677
<u>axlFormGridGetCell</u>	680
<u>axlFormGridInsertCol</u>	682
<u>axlFormGridInsertRows</u>	687
<u>axlFormGridNewCell</u>	688

Allegro SKILL Reference

<u>axlFormGridOptions</u>	711
<u>axlFormGridReset</u>	689
<u>axlFormGridSelected</u>	642
<u>axlFormGridSelectedCnt</u>	643
<u>axlFormGridSetBatch</u>	690
<u>axlFormGridSetSelectRows</u>	644
<u>axlFormGridUpdate</u>	693
<u>axlFormInvalidateField</u>	694
<u>axlFormIsFieldEditable</u>	695
<u>axlFormIsFieldVisible</u>	663
<u>axlFormListAddItem</u>	696
<u>axlFormListDeleteAll</u>	646
<u>axlFormListDeleteItem</u>	698
<u>axlFormListGetItem</u>	700
<u>axlFormListGetSelCount</u>	701
<u>axlFormListGetSelItems</u>	702
<u>axlFormListOptions</u>	703
<u>axlFormListSelAll</u>	705
<u>axlFormListSelect</u>	649
<u>axlFormMsg</u>	706
<u>axlFormRestoreField</u>	658
<u>axlFormSetActiveField</u>	713
<u>axlFormSetDecimal</u>	714
<u>axlFormSetEventAction</u>	650
<u>axlFormSetField</u>	652
<u>axlFormSetFieldEditable</u>	715
<u>axlFormSetFieldLimits</u>	716
<u>axlFormSetFieldVisible</u>	662
<u>axlFormSetInfo</u>	655
<u>axlFormSetMouseActive</u>	656
<u>axlFormTest</u>	657
<u>axlFormTitle</u>	660
<u>axlFormTreeViewAddItem</u>	717
<u>axlFormTreeViewChangeImages</u>	720
<u>axlFormTreeViewChangeLabel</u>	722
<u>axlFormTreeViewGetImages</u>	723
<u>axlFormTreeViewGetLabel</u>	724
<u>axlFormTreeViewGetParents</u>	725
<u>axlFormTreeViewGetSelectState</u>	726
<u>axlFormTreeViewLoadBitmaps</u>	727
<u>axlFormTreeViewSet</u>	729
<u>axlFormTreeViewSetSelectState</u>	732
<u>axlGeo2Str</u>	1221
<u>axlGeoArcCenterAngle</u>	1223

Allegro SKILL Reference

axIGeoArcCenterRadius	1226
axIGeoEqual	1231
axIGeoPointInShape	1272
axIGeoPointsEqual	1233
axIGeoPointShapeInfo	1273
axIGeoRotatePt	1232
axIGetActiveLayer	814
axIGetActiveTextBlock	815
axIGetAlias	412
axIGetAllAttachmentNames	942
axIGetAllViaList	1057
axIGetAllVisibleProfiles	458
axIGetAttachment	943
axIGetDieData	463
axIGetDieStackData	465
axIGetDieStackMemberSet	467
axIGetDieStackNames	469
axIGetDieType	452
axIGetDrawingName	779
axIGetDynamicsSegs	378
axIGetFindFilter	228
axIGetFuncKey	413
axIGetImpedance	1274
axIGetPoserData	470
axIGetLastEnterPoint	279
axIGetLineLock	379
axIGetMetalUsageForLayer	453
axIGetModuleInstanceDefinition	347
axIGetModuleInstanceLocation	348
axIGetModuleInstanceLogicMethod	349
axIGetModuleInstanceNetExceptions	350
axIGetParam	135
axIGetSelSet	224
axIGetSelSetCount	226
axIGetSpacerData	472
axIGetTrapBox	400
axIGetVariable	414
axIGetVariableList	416
axIGetWireProfileColor	474
axIGetWireProfileDefinition	455
axIGetWireProfileDirection	457
axIGetWireProfileVisible	475
axIGetXSection	172
axIGRPDrwBitmap	736

Allegro SKILL Reference

<u>axIGRPDrwCircle</u>	737
<u>axIGRPDrwInit</u>	738
<u>axIGRPDrwLine</u>	739
<u>axIGRPDrwMapWindow</u>	740
<u>axIGRPDrwPoly</u>	741
<u>axIGRPDrwRectangle</u>	742
<u>axIGRPDrwText</u>	743
<u>axIGRPDrwUpdate</u>	744
<u>axHighlightObject</u>	384
<u>axHistory</u>	1169
<u>axHttp</u>	1171
<u>axIgnoreFixed</u>	780
<u>axImpdedanceGetLayerBroadsideDPImp</u>	1275
<u>axImpdedanceGetLayerBroadsideDPWidth</u>	1276
<u>axImpdedanceGetLayerEdgeDPImp</u>	1277
<u>axImpdedanceGetLayerEdgeDPSpacing</u>	1278
<u>axImpdedanceGetLayerEdgeDPWidth</u>	1279
<u>axImpedance2Width</u>	1280
<u>axImportWireProfileDefinitions</u>	460
<u>axImportXmlDBRecords</u>	127
<u>axInTrigger</u>	781
<u>axIsAttachment</u>	945
<u>axIsBetween</u>	1234
<u>axIsCustomColored</u>	169
<u>axIsDBIDType</u>	328
<u>axIsDebug</u>	1173
<u>axIsDummyNet</u>	351
<u>axIsFormType</u>	661
<u>axIsGridCellType</u>	686
<u>axIsHighlighted</u>	1293
<u>axIsInFill</u>	354
<u>axIsLayer</u>	174
<u>axIsLayerNegative</u>	352
<u>axIsPinUnused</u>	353
<u>axIsPointInsideBox</u>	1235
<u>axIsPointOnLine</u>	1236
<u>axIsPolyType</u>	1120
<u>axIsProductLineActive</u>	1174
<u>axIsProtectAlias</u>	420
<u>axIsSymbolEditor</u>	782
<u>axIsViewFileType</u>	535
<u>axIsVisibleLayer</u>	175
<u>axJournal</u>	418
<u>axKillDesign</u>	783

Allegro SKILL Reference

<u>axILastPick</u>	280
<u>axILastPickIsSnapped</u>	254
<u>axILayerCreateCrossSection</u>	176
<u>axILayerCreateNonConductor</u>	178
<u>axILayerGet</u>	179
<u>axILayerPriorityClearAll</u>	162
<u>axILayerPriorityGet</u>	163
<u>axILayerPriorityRestoreAll</u>	165
<u>axILayerPrioritySaveAll</u>	166
<u>axILayerPrioritySet</u>	167
<u>axILayerSet</u>	1065
<u>axILicDefaultVersion</u>	1175
<u>axILicFeatureExists</u>	1176
<u>axILicIsProductEnabled</u>	1177
<u>axILineSlope</u>	1237
<u>axILineXLine</u>	1238
<u>axILoadPadstack</u>	904
<u>axILoadSymbol</u>	905
<u>axILogHeader</u>	1178
<u>axIMakeDynamicsPath</u>	408
<u>axIMapClassName</u>	1186
<u>axIMatchGroupAdd</u>	1377
<u>axIMatchGroupCreate</u>	1379
<u>axIMatchGroupDelete</u>	1382
<u>axIMatchGroupProp</u>	1383
<u>axIMatchGroupRemove</u>	1385
<u>axIMathConstants</u>	1239
<u>axIMemSize</u>	1188
<u>axIMeterCreate</u>	505
<u>axIMeterDestroy</u>	507
<u>axIMeterIsCancelled</u>	508
<u>axIMeterUpdate</u>	509
<u>axIMidPointArc</u>	1240
<u>axIMidPointLine</u>	1241
<u>axIMiniStatusLoad</u>	387
<u>axIMKS2UU</u>	1179
<u>axIMKSAlias</u>	1181
<u>axIMKSCConvert</u>	1182
<u>axIMKSStr2UU</u>	1185
<u>axIMPythag</u>	1242
<u>axIMsgCancelPrint</u>	758
<u>axIMsgCancelSeen</u>	759
<u>axIMsgClear</u>	760
<u>axIMsgContextClear</u>	757

Allegro SKILL Reference

<u>axIMsgContextFinish</u>	756
<u>axIMsgContextGet</u>	751
<u>axIMsgContextGetString</u>	750
<u>axIMsgContextInBuf</u>	753
<u>axIMsgContextPrint</u>	749
<u>axIMsgContextRemove</u>	754
<u>axIMsgContextStart</u>	755
<u>axIMsgContextTest</u>	752
<u>axIMsgPut</u>	748
<u>axIMsgSet</u>	761
<u>axIMsgTest</u>	762
<u>axIMUniVector</u>	1243
<u>axIMXYAdd</u>	1245
<u>axIMXYSMult</u>	1246
<u>axIMXYSub</u>	1247
<u>axINetClassAdd</u>	921
<u>axINetClassCreate</u>	923
<u>axINetClassDelete</u>	925
<u>axINetClassGet</u>	926
<u>axINetClassRemove</u>	928
<u>axINetEcsetValueGet</u>	1051
<u>axINetSched</u>	1387
<u>axIOK2Void</u>	355
<u>axIOKToProceed</u>	1081
<u>axOpenDesign</u>	784
<u>axOpenDesignForBatch</u>	786
<u>axOpenFindFilter</u>	241
<u>axOSBackSlash</u>	1189
<u>axOSControl</u>	1190
<u>axOSFileCopy</u>	1143
<u>axOSFileMove</u>	1144
<u>axOSSlash</u>	1145
<u>axPackageDesignCheckAddCategory</u>	476
<u>axPackageDesignCheckAddCheck</u>	477
<u>axPackageDesignCheckDrcError</u>	479
<u>axPackageDesignCheckLogError</u>	480
<u>axPadOnLayer</u>	1281
<u>axPadstackEdit</u>	318
<u>axPadstackSetType</u>	1283
<u>axPadstackToDisk</u>	907
<u>axPadSuppressGet</u>	129
<u>axPadSuppressOkLayer</u>	131
<u>axPadSuppressSet</u>	132
<u>axPathArcAngle</u>	830

Allegro SKILL Reference

<u>axlPathArcCenter</u>	830
<u>axlPathArcRadius</u>	830
<u>axlPathGetLastPathSeg</u>	838
<u>axlPathGetPathSegs</u>	837
<u>axlPathGetWidth</u>	835
<u>axlPathLine</u>	834
<u>axlPathOffset</u>	843
<u>axlPathSegGetArcCenter</u>	840
<u>axlPathSegGetArcClockwise</u>	841
<u>axlPathSegGetEndPoint</u>	839
<u>axlPathSegGetWidth</u>	836
<u>axlPathStart</u>	828
<u>axlPathStartCircle</u>	842
<u>axlPdfView</u>	1193
<u>axlPinExport</u>	1285
<u>axlPinImport</u>	1286
<u>axlPinPair</u>	1388
<u>axlPinPairSeek</u>	1392
<u>axlPinsOfNet</u>	1393
<u>axlPolyErrorGet</u>	1122
<u>axlPolyExpand</u>	1114
<u>axlPolyFromDB</u>	1104
<u>axlPolyFromHole</u>	1121
<u>axlPolyMemUse</u>	1108
<u>axlPolyOffset</u>	1110
<u>axlPolyOperation</u>	1112
<u>axlPPrint</u>	1192
<u>axlPrintDbid</u>	1194
<u>axlProtectAlias</u>	419
<u>axlPurgePadstacks</u>	286
<u>axlRadToDeg</u>	1248
<u>axlRatsnestBlank</u>	401
<u>axlRatsnestDisplay</u>	402
<u>axlReadOnlyVariable</u>	421
<u>axlRecursiveDelete</u>	1146
<u>axlRefreshSymbol</u>	908
<u>axlRegexpls</u>	1196
<u>axlRegionAdd</u>	930
<u>axlRegionCreate</u>	932
<u>axlRegionDelete</u>	933
<u>axlRegionRemove</u>	934
<u>axlRemoveNet</u>	1394
<u>axlRenameDesign</u>	787
<u>axlRenameNet</u>	1395

Allegro SKILL Reference

<u>axIRenameRefdes</u>	1397
<u>axIRemovePadstack</u>	283
<u>axIReportList</u>	1155
<u>axIReportRegister</u>	1156
<u>axIReratNet</u>	1288
<u>axIRunBatchDBProgram</u>	1197
<u>axISaveDesign</u>	788
<u>axISaveEnable</u>	790
<u>axISchedule</u>	1399
<u>axIScheduleNet</u>	1401
<u>axISegDelayAndZ0</u>	1299
<u>axISelect</u>	222
<u>axISelectByName</u>	245
<u>axISelectByProperty</u>	250
<u>axISetActiveLayer</u>	816
<u>axISetAlias</u>	423
<u>axISetAlias</u>	425
<u>axISetAllProfilesVisible</u>	459
<u>axISetAttachment</u>	946
<u>axISetDefaultDieInformation</u>	1300
<u>axISetDieData</u>	481
<u>axISetDieStackData</u>	461
<u>axISetDieType</u>	483
<u>axISetDynamicsMirror</u>	403
<u>axISetDynamicsRotation</u>	404
<u>axISetFindFilter</u>	229
<u>axISetFuncKey</u>	427
<u>axISetIposerData</u>	484
<u>axISetLineLock</u>	1082
<u>axISetParam</u>	138
<u>axISetPlaneType</u>	191
<u>axISetRotateIncrement</u>	1084
<u>axISetSpacerData</u>	485
<u>axISetSymbolType</u>	767
<u>axISetVariable</u>	429
<u>axISetVariableFile</u>	431
<u>axISetWireProfileColor</u>	486
<u>axISetWireProfileVisible</u>	487
<u>axIShapeAutoVoid</u>	288
<u>axIShapeChangeDynamicType</u>	290
<u>axIShapeDeleteVoids</u>	292
<u>axIShapeDynamicUpdate</u>	294
<u>axIShapeMerge</u>	297
<u>axIShapeRaisePriority</u>	295

Allegro SKILL Reference

<u>axIShell</u>	432
<u>axIShellPost</u>	433
<u>axIShoeItems</u>	299
<u>axIShoeSetParams</u>	300
<u>axIShowObject</u>	1202
<u>axIShowObjectToFile</u>	405
<u>axISingleSelectBox</u>	207
<u>axISingleSelectName</u>	214
<u>axISingleSelectObject</u>	219
<u>axISingleSelectPoint</u>	202
<u>axISleep</u>	1203
<u>axISmoothDesign</u>	303
<u>axISmoothItems</u>	304
<u>axISmoothSetParams</u>	305
<u>axISnapToObject</u>	252
<u>axISort</u>	1204
<u>axISpreadsheetClose</u>	1301
<u>axISpreadsheetDefineCell</u>	1302
<u>axISpreadsheetDoc</u>	1303
<u>axISpreadsheetGetCell</u>	1305
<u>axISpreadsheetGetRGBColorString</u>	1306
<u>axISpreadsheetGetRGBForNamedColor</u>	1307
<u>axISpreadsheetGetStyles</u>	1308
<u>axISpreadsheetGetWorksheets</u>	1309
<u>axISpreadsheetGetWorksheetSize</u>	1310
<u>axISpreadsheetInit</u>	1311
<u>axISpreadsheetRead</u>	1312
<u>axISpreadsheetReadDelimited</u>	1313
<u>axISpreadsheetSetCell</u>	1314
<u>axISpreadsheetSetCellProp</u>	1315
<u>axISpreadsheetSetColumnProp</u>	1316
<u>axISpreadsheetSetDocProp</u>	1317
<u>axISpreadsheetSetRowProp</u>	1318
<u>axISpreadsheetSetStyle</u>	1319
<u>axISpreadsheetSetStyleBorder</u>	1320
<u>axISpreadsheetSetStyleParent</u>	1321
<u>axISpreadsheetSetStyleProp</u>	1322
<u>axISpreadsheetSetWorksheet</u>	1323
<u>axISpreadsheetWrite</u>	1324
<u>axIStrcmpAlpNum</u>	1208
<u>axIStringCSVParse</u>	1209
<u>axIStringRemoveSpaces</u>	1211
<u>axISubclasses</u>	192
<u>axISubclassFormPopup</u>	1093

Allegro SKILL Reference

<u>axISubclassRoute</u>	194
<u>axISubSelectAll</u>	212
<u>axISubSelectBox</u>	210
<u>axISubSelectName</u>	218
<u>axISubSelectObject</u>	221
<u>axISubSelectPoint</u>	205
<u>axISymbolAttach</u>	308
<u>axISymbolDetach</u>	310
<u>axITechnologyType</u>	806
<u>axITempDirectory</u>	1148
<u>axITempFile</u>	1149
<u>axITempFileRemove</u>	1150
<u>axITestPoint</u>	1294
<u>axIText2Lines</u>	1289
<u>axITextOrientationCopy</u>	313
<u>axITransformObject</u>	314
<u>axITriggerClear</u>	807
<u>axITriggerPrint</u>	808
<u>axITriggerSet</u>	809
<u>axUICmdPopupSet</u>	406
<u>axUIColorDialog</u>	512
<u>axUIConfirm</u>	513
<u>axUIConfirmEx</u>	514
<u>axUIControl</u>	516
<u>axUIDataBrowse</u>	566
<u>axUIEditFile</u>	549
<u>axUIGetUserData</u>	1085
<u>axUIMenuChange</u>	518
<u>axUIMenuDebug</u>	520
<u>axUIMenuDelete</u>	521
<u>axUIMenuDump</u>	511
<u>axUIMenuFind</u>	522
<u>axUIMenuInsert</u>	525
<u>axUIMenuLoad</u>	510
<u>axUIMenuRegister</u>	528
<u>axUIMultipleChoice</u>	551
<u>axUIPopupDefine</u>	1086
<u>axUIPopupSet</u>	1088
<u>axUIPrompt</u>	530
<u>axUIViewFileCreate</u>	536
<u>axUIViewFileReuse</u>	538
<u>axUIViewFileScrollTo</u>	552
<u>axUIWBeep</u>	553
<u>axUIWBlock</u>	548

Allegro SKILL Reference

<u>axlUIWClose</u>	543
<u>axlUIWCloseAll</u>	532
<u>axlUIWDisableQuit</u>	554
<u>axlUIWExpose</u>	542
<u>axlUIWExposeByName</u>	555
<u>axlUIWHelpRegister</u>	544
<u>axlUIWMove</u>	533
<u>axlUIWPerm</u>	556
<u>axlUIWPrint</u>	546
<u>axlUIWRedraw</u>	547
<u>axlUIWSetHelpTag</u>	558
<u>axlUIWSetParent</u>	559
<u>axlUIWShow</u>	560
<u>axlUIWSize</u>	534
<u>axlUIWTimerAdd</u>	561
<u>axlUIWTimerRemove</u>	563
<u>axlUIWUpdate</u>	564
<u>axlUIYesNo</u>	540
<u>axlUIYesNoCancel</u>	565
<u>axlUnfixAll</u>	1291
<u>axlUnsetVariable</u>	435
<u>axlUnsetVariableFile</u>	436
<u>axlVersion</u>	1212
<u>axlVersionIdGet</u>	1216
<u>axlVersionIdPrint</u>	1217
<u>axlViaZLength</u>	1050
<u>axlVisibleDesign</u>	180
<u>axlVisibleGet</u>	182
<u>axlVisibleLayer</u>	184
<u>axlVisibleSet</u>	185
<u>axlVisibleUpdate</u>	1096
<u>axlWFManyExported</u>	817
<u>axlWidth2Impedance</u>	1292
<u>axlWindowBoxGet</u>	281
<u>axlWindowBoxSet</u>	282
<u>axlWindowFit</u>	1098
<u>axlWriteDeviceFile</u>	1402
<u>axlWritePackageFile</u>	1404
<u>axlZoomToDbid</u>	407
<u>bBoxAdd</u>	1251
<u>Cadence Customer Support</u>	1330
<u>Callback Procedure: formCallback</u>	664
<u>Cautions</u>	1407
<u>copyDeep</u>	1343

Allegro SKILL Reference

<u>DLL Programming</u>	1326
<u>Examples</u>	1330
<u>Field / Control</u>	570
<u>File A1</u>	1412
<u>File A2</u>	1415
<u>File B1</u>	1410
<u>File S1</u>	1411
<u>Input/Output Data Primitives</u>	1327
<u>isBoxp</u>	1344
<u>lastelem</u>	1345
<u>letStar</u>	1346
<u>listnindex</u>	1347
<u>movedown</u>	1348
<u>moveup</u>	1349
<u>parseFile</u>	1350
<u>parseQuotedString</u>	1352
<u>Performance Considerations</u>	1330
<u>pprintln</u>	1353
<u>Programming Restrictions, Cautions and Hints</u>	1329
<u>Programming</u>	569
<u>propNames</u>	1354
<u>Requirements</u>	1407
<u>SKILL Programming</u>	1325

Before You Start

About This Manual

This manual is for designers and engineers who use the Allegro PCB Editor SKILL functions to customize existing Allegro PCB Editor interactive commands or create new ones. It describes the AXL (Allegro eXtension Language) user model, how to start AXL, and how to use each AXL function.

This manual assumes that you are familiar with the development and design of printed circuit boards (PCBs). It also assumes you are familiar with Allegro PCB Editor for the physical design of PCBs and analysis of reliability, testability, and manufacturability.

If you are reading this manual for a general understanding of AXL capabilities, but do not actually intend to program in AXL, read [Chapter 1, “Introduction to Allegro PCB Editor SKILL Functions.”](#)

You should also be familiar with the Cadence SKILL language. The following manuals describe SKILL:

- *SKILL Language User Guide*
- *SKILL Language Reference*
- *Cadence SKILL Functions Quick Reference*

Prerequisites

Before you begin using Allegro PCB Editor to design boards, you should be familiar with the Allegro PCB Editor environment.

The *Allegro PCB Editor User Guide: Getting Started with Physical Design* explains how to:

- Start Allegro PCB Editor
- Navigate in the Allegro PCB Editor software
- Get help on a command
- Use the mouse, menus and forms
- Start a design session

Command Syntax Conventions

AXL-SKILL descriptions adhere to the conventions described in the *SKILL Language Basics*. In addition, this manual uses the conventions described below.

<i>italics</i>	Data type name.
<i>nil</i>	Standard SKILL for empty list; as a return value, may indicate failure.
<i>t</i>	Standard SKILL for “true;” return value for success.
<i>[name]</i>	Optional argument “name.”
<i><name></i>	Argument of type “name” required.
<i>dbid</i>	Instance of an Allegro PCB Editor database object (means “database id”)
<i>figure</i>	Geometric Allegro PCB Editor database object—for example, line, shape, or symbol are all Allegro PCB Editor figures. This is not to be confused with the Allegro PCB Editor’s database object “figure”, a special graphic denoting DRC markers and drill holes. To ensure clear distinction in this manual, “Allegro PCB Editor figure” denotes this special object.

Allegro SKILL Reference

Before You Start

<i>l_bBox</i>	A list of the coordinates of a bounding box. Coordinate pairs are lower left and upper right. For example,
	(list(100:100 200:200))
<i>t_layer</i>	A pair of names separated by a slash “/” denoting the name of an Allegro PCB Editor class-subclass. For example, “PACKAGE GEOMETRY/SILKSCREEN_TOP”
<i>lo_dbid</i>	Function that takes or returns a dbid or list of dbids.
<i>o_dbid</i>	Function that takes or returns a single dbid.

Referencing Objects by Name

When programming AXL, you can select or refer to a named object by using the unique name of that object. The table shows Allegro PCB Editor object types and their associated names:

Table P-1 Allegro PCB Editor Object Types and Names

Allegro PCB Editor Object Type	Name
NET	netname
COMPONENT	refdes
SYMBOL	refdes or symbol pin: <refdes>.<pin number>
FUNCTION	function designator
DEVTYPE	device type
SYMTYPE	symbol type, for example, “DIP 14”
PROPERTY	property name, for example, “MAX_OVERSHOOT”

You can select objects using the `axlName` functions in [Chapter 4, “Selection and Find Functions”](#).

Finding Information in This Manual

The following table summarizes the topics described in this manual.

For Information About . . .	Read . . .
AXL operation and the relation between Allegro PCB Editor database and AXL functions:	<u>Chapter 1. “Introduction to Allegro PCB Editor SKILL Functions”</u>
<ul style="list-style-type: none">■ AXL functions■ AXL initialization, environment■ Starting and stopping AXL■ Debugging AXL programs■ <i>dbids</i> and object persistence■ Selecting Allegro PCB Editor database objects■ AXL–SKILL database object types	
The structure of Allegro PCB Editor AXL database objects, and how they are related to each other. Lists attributes of each object type.	<u>Chapter 2. “The Allegro PCB Editor Database User Model”</u>
<ul style="list-style-type: none">■ Database rules■ Attribute types■ Figure (geometric) database types■ Logical database types■ Property database types■ Full attribute listing for all Allegro PCB Editor database objects	

Allegro SKILL Reference

Before You Start

For Information About . . .	Read . . .
Path structures and AXL functions that add path objects and other figure objects to the Allegro PCB Editor database.	<u>Chapter 15, “Database Create Functions”</u>
<ul style="list-style-type: none">■ Path create functions■ Create shape and rectangle functions■ Create functions for line, pin, symbol, text, and via	
Read/Write access to Allegro PCB Editor database parameter objects.	<u>Chapter 3, “Parameter Management Functions”</u>
The select set and AXL functions for managing the select set and selecting single and multiple database objects.	<u>Chapter 4, “Selection and Find Functions”</u>
<ul style="list-style-type: none">■ Point selection■ Box selection■ Selection by name and object <i>dbid</i>■ Find filter management■ Selection set management	
AXL functions that operate on database objects in the same way as interactive Allegro PCB Editor commands, including functions to:	<u>Chapter 5, “Interactive Edit Functions”</u>
<ul style="list-style-type: none">■ Delete objects■ Show objects	
Reading database objects:	<u>Chapter 6, “Database Read Functions”</u>
<ul style="list-style-type: none">■ Opening an Allegro PCB Editor design■ Accessing standalone branch figures, properties, pads, and text	

Allegro SKILL Reference

Before You Start

For Information About . . .	Read . . .
AXL functions for	<u>Chapter 7, “Allegro PCB Editor Interface Functions”</u>
■ Highlighting and displaying database objects	
■ Loading the cursor buffer and dynamic rubberband displays for interactive commands	
■ Accepting single and multiple user coordinate picks	
■ Callback functions for completing and cancelling commands	
AXL functions for	<u>Chapter 8, “Allegro PCB Editor Command Shell Functions”</u>
■ Setting Allegro PCB Editor shell variables	
■ Sending a command string to the Allegro PCB Editor shell.	
AXL functions for	<u>Chapter 10, “User Interface Functions”</u>
■ Prompting and getting confirmation from the user, displaying text files	
■ Displaying and printing ASCII files	
AXL forms and functions for	<u>Chapter 11, “Form Interface Functions”</u>
■ Creating forms, including the various types of form fields	
■ Setting up callbacks for response to input to individual fields	
AXL functions related to Simple Graphics Drawing	<u>Chapter 12, “Simple Graphics Drawing Functions”</u>
Writing AXL functions for	<u>Chapter 13, “Message Handler Functions”</u>
■ Setting up for user messages	
■ Displaying messages to users	

Allegro SKILL Reference

Before You Start

For Information About . . .	Read . . .
AXL functions for	<u>Chapter 14, “Design Control Functions”</u>

- Opening a design
- Compiling, running edit check, and saving the current (symbol) design
- Getting the type of the active design
- Setting the Allegro PCB Editor symbol type
- Getting or setting the value for a specified database control, sector, and obstacle
- Changing the extents, origin, units and accuracy of the design
- Setting, deleting, and getting information about locks on the database
- Setting, clearing, and printing information about triggers, which register interest in events that occur in Allegro PCB Editor
- Getting the active class and subclass, active text block, type of design technology in use, and the full path of the drawing
- Saving the design
- Saving a board padstack out to a library
- Creating a new padstack by copying from an existing padstack
- Running dbdoctor on the current database

Allegro SKILL Reference

Before You Start

For Information About . . .	Read . . .
AXL functions for	<u>Chapter 16, “Database Group Functions”</u>
<ul style="list-style-type: none">■ Creating and removing database groups.■ Adding and removing database objects from database groups.	
AXL functions for	<u>Chapter 17, “Database Attachment Functions”</u>
<ul style="list-style-type: none">■ Creating, changing, and deleting database attachments■ Checking whether an object is a database attachment■ Getting the ids of all database attachments■ Getting a database attachment	
AXL functions for	<u>Chapter 18, “Database Transaction Functions”</u>
<ul style="list-style-type: none">■ Improving the performance and program memory use while updating many etch or package symbols in batch mode■ Marking the start of a database transaction and returning the mark to the calling function■ Writing a mark in the database to allow future rollback or commitment■ Committing and undoing a database transaction	

Allegro SKILL Reference

Before You Start

For Information About . . .	Read . . .
AXL functions for	
<ul style="list-style-type: none">■ Getting and setting current DRC modes and values for design constraints and ECset members■ Creating, deleting, and getting the dbid of an ECset■ Checking the syntax of a given value against the allowed syntax for a given constraint■ Batching and tuning DRC updates from constraint changes made using axlCNS<xxx> functions	<u>Chapter 19, “Constraint Management Functions”</u>
AXL functions for	<u>Chapter 20, “Command Control Functions”</u>
<ul style="list-style-type: none">■ Registering and unregistering SKILL commands with the command interpreter■ Getting and setting the controls for line lock, active layer■ Defining popups■ Getting user data	
Polygon operation functions, attributes, and use models.	<u>Chapter 21, “Polygon Operation Functions”</u>
Getting Allegro PCB Editor file names, and opening and closing files	<u>Chapter 22, “Allegro PCB Editor File Access Functions”</u>
AXL functions for	<u>Chapter 23, “AXL-SKILL Data Extract Functions”</u>
<ul style="list-style-type: none">■ SKILL access to the extract command■ Selecting sets of database objects as members of a view and applying an AXL function to each	

Allegro SKILL Reference

Before You Start

For Information About . . .	Read . . .
AXL functions for	Chapter 24, “Utility Functions”
■ Calculating an arc center given various data	
■ Converting quantities to various units	
Using math utility functions.	Chapter 25, “Math Utility Functions”
Odds and ends.	Chapter 26, “Database Miscellaneous Functions”
Using logic access functions.	Chapter 30, “Logic Access Functions”

Other Sources of Information

For more information about Allegro PCB Editor and other related products, consult the sources listed below.

Product Installation

The *Cadence Installation Guide* tells you how to install Cadence products.

Related Manuals

The following manuals comprise the Allegro PCB Editor documentation set for your workbench of PCB design tools:

For Information About...	Read...
The Allegro PCB Editor user interface. An overview of the design process using Allegro PCB Editor, starting and exiting, controlling the graphic display, graphic and text elements, design information, and system information.	<i>Allegro PCB Editor User Guide: Getting Started with Physical Design</i>
Building and managing libraries, including defining padstacks, custom pads, packages, electrical attributes, and formats.	<i>Allegro PCB Editor User Guide: Defining and Developing Libraries</i>

Allegro SKILL Reference

Before You Start

For Information About...

Read...

Loading logical design data and converting third-party mechanical data, including loading data from Concept™, netlists, and board mechanical data.

[Allegro PCB Editor User Guide: Transferring Logic Design Data](#)

Setting up the design and specifying design rules and controls, including instructions for specifying properties and constraints.

[Allegro PCB Editor User Guide: Preparing the Layout](#)

Placing components using Allegro PCB Editor, including automatic and interactive placement.

[Allegro PCB Editor User Guide: Placing the Elements](#)

Routing using Allegro PCB Editor, including interactive and automatic routing.

[Allegro PCB Editor User Guide: Routing the Design](#)

Design output, including renaming reference designators, creating drill and silkscreen data, and generating penplots.

[Allegro PCB Editor User Guide: Preparing Manufacturing Data](#)

Optional Allegro PCB Editor interfaces, including Cadnetix-E, CBDS, Racal Visula, IGES, Greenfield, Computervision CADDs, SDRC I-DEAS, AutoCAD DXF, PTC, CATIA, IPC-D_350C, GDSII, Fluke Defect Analyzer, and HP3070 Tester.

[Converting Third Party Designs and Mechanical Data](#)

Allegro PCB Editor commands, listed alphabetically.

[Allegro PCB and Package Physical Layout Command Reference](#)

Allegro PCB Editor properties, extracts (examples), and reports.

[Allegro PCB Editor User Guide: Design Rules, Extract Data Dictionary, and Viewing Reports On Screen in HTML Format](#)

A comprehensive glossary for the Allegro PCB Editor user guides and reference manuals.

[Allegro PCB Editor User Guide Glossary](#)

Allegro SKILL Reference

Before You Start

Customer Support

Cadence offers many customer education services. Ask your sales representative for more information.

Customer support is available for customers who have a maintenance agreement with Cadence. Contact Cadence Customer Support at <http://sourcelink.cadence.com>

SourceLink

You can also find technical information, including SKILL documentation and shareware code, online through SourceLink at:

<http://sourcelink.cadence.com>

SourceLink provides the latest in quarterly software rollups (QSRs), case and product change release (PCR) information, technical documentation, solutions, software updates and more.

Allegro PCB Editor Users Mailing List Subscription

You can use electronic mail (email) to subscribe to the Allegro PCB Editor users mailing list. You will receive periodic newsletters containing up-to-date information on the Allegro PCB Editor product family.

To subscribe to the Allegro PCB Editor mailing list

- Send an email message to *majordomo@cadence.com*, and include the phrase "subscribe allegro_users" in the body of the message.
You will receive an acceptance notification.

AXL-SKILL Example Files

You can find AXL-SKILL example files in this location:

`%cds_inst_dir%/share/pcb/examples/skill`

User Discussion Forums

You can find discussion groups for users of Cadence products at:

<http://www.cadenceusers.org>

Introduction to Allegro PCB Editor SKILL Functions

Overview

This chapter is a brief overview of the following:

- Allegro PCB Editor AXL-SKILL
- AXL-SKILL functions
- How to initialize and run AXL-SKILL
- The AXL Allegro PCB Editor database

Later chapters describe in detail the AXL database objects and all AXL-SKILL functions.

AXL-SKILL in Allegro PCB Editor


AXL-SKILL is a language processor contained in Allegro PCB Editor, as shown in the following figure.

AXL-SKILL contains and is an extension of the core Cadence SKILL language. You use AXL-SKILL functions to access the Allegro PCB Editor database and its display and user interfaces. Once you have accessed the Allegro PCB Editor database, you can process the

Allegro SKILL Reference

Introduction to Allegro PCB Editor SKILL Functions

data using the core SKILL functions. The *SKILL Language Functions Reference* describes core SKILL and its available functions.



You access AXL-SKILL by entering the command `skill` on the Allegro PCB Editor command line.

AXL-SKILL initializes automatically when you start Allegro PCB Editor. As Allegro PCB Editor starts, it reads the Allegro PCB Editor `env` file, then the AXL `ilinit` file (as described below) then any script you may have specified with the `-s` option in the UNIX command starting Allegro PCB Editor.

Allegro PCB Editor looks for the `ilinit` file in the following way:

- For the locations specified below, Allegro PCB Editor reads one of the following files:

`<program_name>.ilinit`

`allegro.ilinit`

From the locations:

`<cdsroot>/share pcb/etc/skill`

`<cdssite>/pcb/skill`

Allegro SKILL Reference

Introduction to Allegro PCB Editor SKILL Functions

Note: <cdssite> defaults to <cdsroot>/share/local/pcb/skill, otherwise you can set the CDS_SITE variable to point to another location, the directory where your program started:

```
$HOME/pcbenv
```

If you have multiple *ilinit* files in the locations listed above, *each* of the *ilinit* files will be read. If you wish only the *first* found *ilinit* file to be read (the methodology employed in pre-14.2 releases), set the environment variable *skill_old_ilinit*.

Note: You cannot insert SKILL commands in the *env* file.

Running AXL-SKILL from the Command Line

You run AXL-SKILL by typing *skill* on the Allegro PCB Editor command line. The AXL-SKILL interpreter appears with the *skill>* prompt in place of the Allegro PCB Editor command line.

You can also run AXL-SKILL functions from the Allegro PCB Editor command line with the following syntax:

```
skill (<function> <arguments>)
```

Type *exit* to close the AXL-SKILL interpreter and return to the Allegro PCB Editor command line.

Running AXL-SKILL in Batch Mode

You can run AXL-SKILL in batch mode using an X terminal window without displaying Allegro PCB Editor, by typing the following command:

```
.allegro -nographic
```

If your system is not running the X window system, verify that it has its DISPLAY environment variable set to a system running an X-server.

Note: The *-nographic* switch is valid for all Allegro PCB Editor graphic executables, such as *allegro_layout*, *allegro_engineer*, *allegro_prep*, *allegro_interactive*, and *allegro_layout*.

You can also program the Allegro PCB Editor and AXL-SKILL startup and command entry in a shell script, allowing full batch capability.

Debugging AXL-SKILL Programs

If you have a SKILL ACCESS development license, you can debug AXL-SKILL programs in Allegro PCB Editor using the same tools offered by other Cadence SKILL programs. See *SKILL Language Functions Reference* for a description of those tools, which are primarily available on Unix.

AXL-SKILL Grammar

AXL-SKILL functions follow SKILL grammar rules. In addition, the following characteristics apply to most AXL-SKILL functions:

- All Allegro PCB Editor AXL function names begin with `axl`.
- AXL functions are classified into families that typically have similar calling sequences and share a common part of their names, for example the `axlDBCreate` family, with members such as `axlDBCreateShape` and `axlDBCreateSymbol`.

SKILL Development Window

You can get a larger SKILL-only window by setting the Allegro PCB Editor environment variable, `TELSKILL`.

Note: All Allegro PCB Editor console output is directed to the SKILL window when the `TELSKILL` variable is set.

AXL-SKILL Database

Allegro PCB Editor stores design data as various types of objects in a proprietary database format. These object types can create a complete representation of an electronic layout. You can create, operate on, and extract information from this database using AXL-SKILL programs.

The AXL-SKILL database stores both physical and logical information about your design. Physical information is objects such as geometrical shapes (connecting etch, for example). Logical information is objects such as nets and logical components.

Object dbids (database identifiers)

Every Allegro PCB Editor database object has a unique *dbid* (database identifier) associated with it. When you call a function to operate on a database object, you identify the object to the function by giving the object's *dbid* as an argument.

Only AXL routines can create *dbids*. You cannot alter *dbids* directly, except for parameter record ids.

Out of Scope dbids

When a dbid is separated from its object, the dbid is considered out-of-scope. A dbid can become separated from its object for any of the following reasons:

- You delete an object.
- You add a connect line that touches an existing connect line. This causes the existing line to break in to two objects, each with a separate dbid, so the original dbid of the line no longer denotes the same object.
- You return to Allegro PCB Editor from AXL.
- You run an Allegro PCB Editor command while in SKILL, using the AXL shell function. To minimize out-of-scope issues with AXL shell, isolate AXL shell functions and if necessary refresh dbids after AXL shell calls with the function `axlDBRefreshID`.
- You open a new layout.

Out of scope *dbids* have no attributes, so they have no object type. If you try to evaluate a *dbid* that is out of scope, SKILL displays the message:

`dbid: removed`

Using an out of scope *dbid* in a function causes unexpected results.

Object Types

Each Allegro PCB Editor object has an associated *type* and a set of *attributes* that describe the object. For example, all `symbol` objects are of type `symbol`. All `symbols` have the `isMirrored` attribute, among others, and this attribute has the value `t` if the symbol is mirrored or `nil` if it is not. You can use an AXL-SKILL function with "`->`" (the access operator) to access any object attribute. If the attribute does not exist for that object the function returns `nil`.

You use the SKILL special attributes `?` (question mark) and `??` to see all attributes and all attribute/value pairs of an object. See [Chapter 2, “The Allegro PCB Editor Database User Model.”](#) for more information about object types.

Object Classes

An *object class* is a data-type abstraction used to group related object types. When a number of distinct object types share enough attributes, you can discuss them as a single class. The start of each section describing a class of object types lists all attributes common to that class.

The different types and classes of objects form a class hierarchy. At the top of the hierarchy is a class containing all types. At the bottom of the hierarchy, each leaf (terminal node) represents an object type that you can create, delete, and save on disk. Each intermediate node in the hierarchy has attributes that are common to all of its children. AXL-SKILL figures, for example, have common attributes of `layer` and `bBox` (bounding box). These higher level classes do not exist as objects.

Select Sets and Find Functions

AXL-SKILL edit functions obtain the identities of the objects on which they operate from a list of `dbids` called the *select set*. You accumulate `dbids` in the select set by selecting one or several objects using AXL select functions. You then apply edit functions to the objects by passing the select set as an argument to the functions.

AXL-SKILL has functions to do the following:

- Set the Find Filter to control the types of objects selected and select options
- Select objects at a single point, over an area, or by name
- Select parts of objects (for example, pins, which are parts of symbols)
- Add or remove objects from the select set (the set of selected objects)
- Get `dbids` and return the count of `dbids` in the select set
- Add `dbids` to and remove them from the select set before using it.

See [Chapter 4, “Selection and Find Functions.”](#) for information about select set functions.

Note: Allegro PCB Editor highlights selected objects whenever it refreshes the display.

Design Files

Design files are containers for Allegro PCB Editor database objects. AXL-SKILL has two major design file types:

Layout	Contains printed circuit or MCM layout data.
--------	--

Allegro SKILL Reference

Introduction to Allegro PCB Editor SKILL Functions

Symbol	Contains the definition drawing of a symbol. The compiled output of a symbol file can be added to layouts. Symbol files can define any of package, mechanical, format, and shape symbols.
--------	---

Logical Objects

Logical objects are the objects in the netlist that Allegro PCB Editor loads from a schematic or third-party netlist file:

Component	Contains the electrical functions, such as nand gates, and pins that define the electrical behavior of an object. A component's reference designator is its name.
Net	Is the set of all the etch objects—ppins, etch paths, shapes, and vias—associated with a particular signal name. Every net has a name which is its signal name. A net contains one or more branches. Each branch is a list of the etch objects that are physically connected among themselves. A branch can include ppins, etch paths, shapes, and vias. The number of branches in a net varies as Allegro PCB Editor connects or disconnects parts of the net. A completely connected net consists of one and only one branch.

Layer Attributes

Each Allegro PCB Editor figure exists on a class/subclass in the database. For example, a c-line might be on class ETCH, subclass TOP. AXL-SKILL represents this class/subclass combination with a layer attribute. Each AXL-SKILL layer is in one-to-one correspondence with an Allegro PCB Editor class/subclass combination. A later section describes this structure in detail.

Allegro PCB Editor Properties

Although they are a class of Allegro PCB Editor objects, you do not create or access Allegro PCB Editor properties directly. Rather, you use AXL-SKILL commands to attach, delete, and read the values of properties on Allegro PCB Editor database objects. You can also use AXL-SKILL commands to read, create and delete definitions of your own properties.

Property Definitions

AXL-SKILL stores each property definition for an object indirectly associated with that object. You can access any property definition on an object to find its value and you can create new, user-defined properties using AXL-SKILL functions.

You can use an AXL-SKILL function to attach a property to an object if the object accepts that property type. The property must be defined in the property dictionary of that database. A property definition is an object that contains the property name, value type, and a list specifying to what object types it can be attached.

Figures

The following AXL-SKILL figures are Allegro PCB Editor geometry types.

Arc	Is a figure that is either an arc or a circle. You can specify arcs to AXL-SKILL with start and end points, and either radius or center point. (Allegro PCB Editor figure: <code>arc</code> <code>segment</code>).
Branch	Is a collection of etch figures that make up one physically connected part of a net. Nets are made up of branches, and branches are made up of pins, vias, tees and etch figures, as described later in this chapter.
DRC	Is a design rule violation marker with one or more object identities and a violation type and location.
Line	An object defined by the coordinates of its center line and a width (Allegro PCB Editor figure: <code>line</code> <code>segment</code>).
Path	Is a sequence of end-to-end lines and arcs on the same layer. Each segment can have a different width (Allegro PCB Editor figures: <code>lines</code> and <code>clines</code>).
PPin	Is a physical instance of a pin with associated padstack.
Polygon	Is an unfilled, closed path (Allegro PCB Editor figure: <code>unfilled shape</code>).
Shape	Is a filled shape. It can optionally contain voids.

Allegro SKILL Reference

Introduction to Allegro PCB Editor SKILL Functions

Pad	Is a geometric shape (circle, oblong, rectangle) defining the shape of one type of pad on one layer. Pads are always owned by padstacks.
Symbol	Is a collection of geometries and text with a type name, location, rotation and mirroring.
Tee	Is the single point where the endpoints of three or more etch paths connect.
Text	Is a string of characters with associated size, mirror, rotation, and location.
Via	Is a connecting drill path between layers with associated padstack.

The following types are not figures but contain geometry that defines figure instances:

Padstack	(Pin/Via Definition) Contains the definition data for all ppins or vias of a named type.
Symdef	Contains the definition data for all symbols of a named type.

Accessing Allegro PCB Editor Colors with AXL-SKILL

You can access predefined colors and Allegro PCB Editor database colors using AXL-SKILL. Only graphics editors support access to Allegro PCB Editor database colors.

Forms

You set and access pre-defined colors by their symbols. The pre-defined colors include the following:

- ‘black’
- ‘white’
- ‘red’
- ‘green’
- ‘yellow’
- ‘blue’

- ‘button

Button means grey, the color of buttons in the application.

Note: You can use only pre-defined colors in Allegro PCB Editor forms.

Design Object

Graphics editors support access to the colors used for Allegro PCB Editor layers. These are represented by integers.

AXL API calls, including `axlLayerGet` (“class/subclass”) or its primitive form `axlGetParm(paramLayerGroup:<class>/paramLayer:<subclass>)`, return the current color setting of a layer via the color attribute call, as shown.

```
p = axlLayerGet("etch/top")
p->color->2
```

These color settings range between 1 and 24 with 0 reserved for the background color.

Form based interfaces supporting color include the following:

- `axlFormDoc`
- `axlFormColorize`
- `axlFormGridDoc`
- `axlGRPDoc`

Notes:

- AXL does not allow you to change the red/green/blue (RGB) of Allegro PCB Editor database colors.
- Pre-defined colors are restricted to minimize problems with 8 bit color graphics on UNIX.

Database Objects

A design is made of various database objects that you can combine to make other database objects. This section describes the relationships among database objects.

Parts of a Design

A design can include any of the following database objects:

- Property Dictionary

Allegro SKILL Reference

Introduction to Allegro PCB Editor SKILL Functions

- Lines
- Text
- Polygons
- Shapes
- Property Definitions
- DRCs
- Vias that are Padstack object types
- Symbols that are Symdef object types
- Components
- Nets

Parts of a Symbol

Symbols that are Symdef objects types can include any of the following database objects:

- PPins that are Padstack object types
- Vias that are Padstack object types
- Lines
- Arcs
- Text
- Polygons
- Shapes

Parts of a Branch

Branches can include any of the following database objects:

- Tees
- Vias that are Padstack object types
- PPins that are Padstack object types
- Paths
- Shapes

Parts of a Path

A path can include any of the following database objects:

- Lines
- Arcs

Parts of a Symdef

A symdef can include any of the following database objects:

- PPins that are Padstack object types
- Vias that are Padstack object types
- Lines
- Arcs
- Text
- Polygons
- Shapes

Types of Parameters

Allegro PCB Editor parameters store feature or board level options to the Allegro PCB Editor database. You can modify parameters using a SKILL program. The parameter types include the following:

- Design
- Display
- Layer Group
- Textblock Group

Table 1-1 Other Database Object Relationships

Object Name	Object Parts
Property Dictionary	Property Entries
Net	Branches
Padstack	Pads

Allegro SKILL Reference

Introduction to Allegro PCB Editor SKILL Functions

Table 1-1 Other Database Object Relationships

Object Name	Object Parts
Polygon	Paths
Shape	Paths
Void	Polygons
Polygon	Paths
PPin	Pin Number Text
Layer Group	Layers
Textblock Group	Textblocks

Allegro SKILL Reference
Introduction to Allegro PCB Editor SKILL Functions

The Allegro PCB Editor Database User Model

Overview

This chapter describes each AXL database object type, listing each type's attributes and relationships to other object types.

Object Types

- Figure objects
 - Arcs ([Table 2-3 on page 82](#))
 - Branches ([Table 2-4 on page 82](#))
 - Design Files ([Table 2-5 on page 83](#))
 - DRCs ([Table 2-6 on page 84](#))
 - Lines ([Table 2-9 on page 85](#))
 - Paths ([Table 2-12 on page 89](#))
 - Polygons ([Table 2-14 on page 91](#))
 - Pins ([Table 2-13 on page 89](#))
 - Shapes ([Table 2-16 on page 92](#))
 - Symbols ([Table 2-17 on page 94](#))
 - Tees ([Table 2-19 on page 95](#))
 - Vias ([Table 2-21 on page 96](#))
 - Pads ([Table 2-10 on page 86](#))
 - Padstacks ([Table 2-11 on page 86](#))

- Symdefs ([Table 2-18 on page 94](#))
- Logical objects
 - Components ([Table 2-24 on page 97](#))
 - Functions ([Table 2-26 on page 98](#))
 - Function Pins ([Table 2-27 on page 99](#))
 - Nets ([Table 2-29 on page 100](#))
- Property dictionary objects ([Table 2-38 on page 107](#))
- Parameter objects
 - Design ([Table 2-41 on page 109](#))
 - Display ([Table 2-42 on page 110](#))
 - Layer Group ([Table 2-44 on page 112](#))
 - Layer ([Table 2-45 on page 113](#))
 - Textblock Group ([Table 2-46 on page 114](#))
 - Textblock ([Table 2-47 on page 114](#))

Description of Database Objects

Although a database object type can have dozens of attributes, you need only learn the semantics of a few attributes to get useful information from the Allegro PCB Editor database. Requesting an attribute not applicable to an object, or a property not existing on the object, causes the access function to return `nil`.

AXL Database Rules

The Allegro PCB Editor database interacts with AXL functions as specified in the following rules. Changes to the Allegro PCB Editor database made using AXL functions can affect both the database references (*dbids*) and the attributes of the Allegro PCB Editor database objects that the AXL program has already accessed.

- Invoking the `axlShell` function or editing a new Allegro PCB Editor database invalidates all *dbids*.

Accessing the object's attributes with an out-of-scope *dbid* yields unreliable values. The `axlDBRefreshId` function returns `nil` for any out-of-scope *dbid*.

- An AXL function that modifies one attribute of an object may cause a related attribute of that object to become out-of-date.

A parent's attribute may become out-of-date when you modify one of its children's attributes. For example, changing path width might affect the bounding box attribute of both a child and its parent.

- Operations you perform on an object affect the attributes of other objects if they refer to the changed object either directly or indirectly.

An example of direct reference is deleting a segment from a path. An example of indirect reference is changing the width of a single segment in a path. These can cause `isSameWidth` to be incorrect.

- Accessing an out-of-date `dbid` does not cause the AXL program to crash or corrupt the Allegro PCB Editor database.

- The AXL function, `axlDBRefreshId`, updates an object.

AXL does not update objects asynchronously.

- Allegro PCB Editor maintains properties across operations for all objects that support properties.

- DRC objects are volatile.

By changing Allegro PCB Editor database objects, you can create or destroy DRCs.

You cannot *directly* change a DRC object.

The following Allegro PCB Editor rule for treating non-etch figures applies only to paths or path segments:

- Path `dbids` on non-etch layers are more stable than those on etch layers.

Deleting a segment from a path breaks the segment into two paths with separate `dbids`. Non-etch paths never merge, even if they touch.

The Allegro PCB Editor database treats etch figures differently from non-etch figures. The following are the etch figure rules. [Figure 2-1](#) on page 78 shows the connectivity model used by Allegro PCB Editor.

- Path, line and arc `dbids` are volatile on etch layers.

Allegro PCB Editor merges and breaks these objects to maintain connectivity.

- Deleting a segment from a path so it detaches from a pin, via, tee, or shape causes the etch to be classed as *floating*.

Allegro SKILL Reference


The Allegro PCB Editor Database User Model

That means the etch is not a member of any net. A floating etch has a `nil` netname.

- Tees and branches are volatile.

Changes in paths or path segments can cause tees to disappear or branches to combine or break into multiple branches.

Figure 2-1 Allegro PCB Editor Connectivity Model



Tee	Connection of three or more paths, added and removed as needed
Via	Can be deleted by ripup or glossing operations
Path	The net attribute on paths, vias and tees changes due to connectivity to pins and shapes.
Line/Arc	Paths, lines and arcs can be broken, merged, or can change parent with the modification (add, delete or modify) of any etch object.

* The “net” attribute is an empty string “” for all figures that are on a dummy net.

Data Types

AXL database objects can have the following data types:

Type	Meaning
bbox	Boundary box (list of two points, lower left and upper right of a rectangular area that encloses the object)
integer	Signed integer number
float	Floating-point number
string	A string. For attributes with a list of possible string values, the attribute description lists the allowed values.
t/nil	Either true (<code>t</code>) or false (<code>nil</code>)
dbid	Allegro PCB Editor object identifier
l_dbid	List of <i>dbids</i>
point	A point—a list of two floats denoting a coordinate pair
l_propid	A list of properties accessed by <code>axlDbGetProperties</code>
l_fill	<code>t = solid; nil = polygon; r_fill = crosshatch type</code>

Generic Allegro PCB Editor Object Attributes

The following attributes are generic to all Allegro PCB Editor database objects. All Allegro PCB Editor database objects have at least these attributes.

Table 2-1 Generic Object Attributes

Attribute Name	Type	Description
objType	string	Name of the object type
prop	propid	Attached properties
parentGroups	l_dbid	List of groups to which the object belongs
readOnly	t/nil	t = cannot modify object with AXL function

propid refers to properties attached to the object. When a *dbid* is returned to an AXL program, the properties attached to that object are not immediately returned. You access the property value by referencing the property name via the prop attribute. The `axlDBGetProperties` function returns the property names/value pairs as an “assoc” list to allow easier processing by applications.

Figure Database Types

Figures, in Allegro PCB Editor, also share a common set of attributes. However, “figure” is not actually an attribute of any object. [Table 2-2](#) on page 81 lists the common figure attributes. In Allegro PCB Editor, figures are sometimes called geometries.

Among other attributes, figures have a bounding box called *bBox*. *bBox* is an orthogonal rectangle that defines the geometrical extents of the figure.

Table 2-2 Common Figure Attributes

Attribute Name	Type	Description
bBox	bbox	Figure's bounding box
branch	dbid	For etch, the figure's branch parent
layer	t_layer	Layer of figure, nil if object is multi-layer
parent	dbid	Nonconnective owner
net	dbid	Net object if figure is associated with a net

Note: The “*net*” attribute is an empty string “ ” for all figures that are on a dummy net.

Attributes for Each Figure Type

The following tables list the attributes specific to each Allegro PCB Editor object type. The Common Figure attributes (see [Table 2-2](#) on page 81) and the Generic Allegro PCB Editor Object attributes (see [Table 2-1](#) on page 80) also apply to these figure types.

The tables are in alphabetical order by figure type name. The attributes in each table are in alphabetical order by attribute name.

Table 2-3 Arc Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
isCircle	t/nil	t = circle; nil = unclosed arc
isClockwise	t/nil	t = clockwise; nil = counterclockwise
isEtch	t/nil	t = a CLINE; nil = a LINE
objType	string	Type of object, in this case "arc".
parent	dbid	Path, polygon or shape
radius	float	Radius
startEnd	l_point	Start and end points of arc
width	float	Width of arc
font	int/nil	Line font, etch always has nil while 0 indicates a solid font.
xy	point	Location of arc center

Table 2-4 Branch Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
children	l_dbid	List of <i>dbids</i> of the objects that make up branch: paths, tees, vias, pins and shapes
objType	string	Type of object, in this case "branch"
parent	dbid	Always nil

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-5 Design Attributes Represents the design root, axIDBGetDesign()

Attribute Name	Type	Description
Also includes generic object and figure attributes		
bus	l_dbid	List of busses
compdefs	l_dbid	List of component definitions
components	l_dbid	List of components
diffpair	l_dbid	List of differential pairs
drcs	l_dbid	List of DRCs
drcState	symbol	State of DRC t = up to date nil = out-of-date batch = batch out-of-date
ecsets	l_dbid	List of Electrical Csets
groups	l_dbid	List of groups
matchgroup	l_dbid	List of match groups in the design
module	l_dbid	List of module instances in the design
nets	l_dbid/nil	List of nets
netclass	l_dbid	List of netclass constraints group
netgroup	l_dbid	List of netgroups in the design
objType	string	Type of object, in this case "design"
region	l_dbid	List of regions
padstacks	l_dbid	List of padstacks
pins	l_dbid	If a .dra, list of pins, else nil
symbols	l_dbid	List of symbol instances
symdefs	l_dbid	List of symbol defs
waived	l_dbid	List of waived DRCs
xnet	l_dbid	List of Xnets (no nets with VOLTAGE property)

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-6 DRC Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
actual	string	Actual value (user units)
expected	string	Expected value (user units)
fixed	t/nil	t = Allegro PCB Editor generated DRC nil = user defined DRC
name	string	Name of constraint that was violated
objType	string	Type of object, in this case "drc"
parent	dbid	Design <i>dbid</i>
source	string	DRC source (property or constraint set name)
type	string	Domain of DRC, values can be: <ul style="list-style-type: none"> ■ "NET SPACING CONSTRAINTS" ■ "PHYSICAL CONSTRAINTS" ■ "DESIGN" ■ "NET ELECTRICAL CONSTRAINTS" ■ "SAME NET CONSTRAINTS" ■ "EXTERNAL REFERENCE"
Weird names are due to evolution of Allegro		
violations	l_dbid	List of figures causing error (2 max)
waived	t/nil	t = waived drc nil = regular
xy	point	Location of DRC marker

Table 2-7 Group Attributes

Attribute Name	Type	Description
Also includes generic object attributes		

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-7 Group Attributes

Attribute Name	Type	Description
groupMembers	l_dbid	List of members of the group
name	string	Name of the group
objType	string	Type of object, in this case "group"
type	string	Predefined group type.
		Note: This cannot be defined in SKILL. User defined groups are considered "GENERIC."

Table 2-8 Module Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
bBox	bBox	Bounding box of all physical members of group
groupMembers	l_dbid	List of members of the module
name	string	Name of the module
objType	string	Type of object, in this case "group"
type	string	"MODULE"

Table 2-9 Line Attributes

Attribute Name	Type	Description
Also includes generic and figure object attributes		
isEtch	t/nil	t = a CLINE; nil = a LINE
lineType	s_type	a symbol: horizontal, vertical, odd
objType	string	Type of object, in this case "line"
parent	dbid	Path, polygon, or shape
startEnd	l_point	Start and end points
thermal	t/nil	Cline is a thermal relief.
width	float	Width of line

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-9 Line Attributes, *continued*

Attribute Name	Type	Description
font	int/nil	Line font, etch always has <code>nil</code> , while 0 indicates a solid font.

Table 2-10 Pad Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
bBox	bBox	Bounding box. Coordinates are always relative.
figure	lr_path	List of <i>r_paths</i> defining pad's boundary <i>lr_path</i> always contains at most one <i>r_path</i> <code>nil</code> denotes a null pad
figureName	string	Name of pad figure is one of the following: CIRCLE, SQUARE, OBLONG, RECTANGLE, SHAPE or <code>nil</code> (if drill only)
flash	string	If of type FLASH, name of flash symbol otherwise an empty string "" (Obsolete; use name attribute)
layer	string	Pad layer
name	string	If type is a SHAPE or FLASH, name of symbol.
objType	string	Type of object, in this case "pad"
offset	l_point	Offset of pad (relative to pin/via origin)
parent	dbid	Padstack <i>dbid</i>
readOnly	t	Cannot be modified.
type	string	Pad type is one of: REGULAR, ANTI, or THERMAL

Table 2-11 Padstack (PPin/Via Definition) Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-11 Padstack (PPin/Via Definition) Attributes, *continued*

Attribute Name	Type	Description
definition	o_dbid	(see isPadRef) Points to padstack definition if this is padReference otherwise nil
drillChar	string	drill characters (max 3)
drillDiameter	float	Drill hole diameter
drillSizeWidth	float	width of slot, diameter if hole and extents of multidrill
drillSizeHeight	float	height of slot, diameter if hole and extents of multidrill
drillOffset	point	offset of drill hole
drillFigureName	string	type of drill symbol (circle, square, and so on.)
drillFigureWidth	float	Width of drill symbol (for slots same as drillSizeWidth)
drillFigureHeight	float	Height of drill symbol (for slots same as drillSizeHeight)
drillNonStandard	string	Type of drill (nil is standard) <i>(not supported by slots)</i>
holeTolerance	l_float	A list of two numbers reporting the + and - drill hole tolerance.
multiDrillData	l_values	If not multidrill then nil otherwise list of: (rows columns clearanceX clearanceY staggered) Both clearances are in dbreps and staggered is t/nil
holeType	string	Type of hole (circle_drill, oval_slot, etc.)
keepout	t/nil	Padstack built to accommodate anti-pads as Route keepouts for mechanical pins. This padstack can also be used for logical connections but this option is ignored.

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-11 Padstack (PPin/Via Definition) Attributes, *continued*

Attribute Name	Type	Description
isPadRef	t/nil	<code>t</code> = padstack is a padstack reference. This means that the actual padstack is a template and the start and end layers of the padstack are dynamically mapped, depending upon its use with a pin or a via.
isThrough	t/nil	<code>t</code> = through padstack
name	string	Padstack name
objType	string	Type of object, in this case "padstack"
pads	ll_dbid	List of pads
parent	dbid	Design
padSuppression	t/nil	Does padstack have Pad Suppression enabled. This is for the legacy artwork based pad suppression. The dynamic pad suppression ignores this option.
plating	string	One of "Plated", "Non-Plated", "Plating-Optional"
prop	nil	Always <code>nil</code> , padstacks do not support properties
startEnd	lt_layer	Start and end layer of padstack
type	string	Type of padstack; valid values are: <ul style="list-style-type: none"> ■ through ■ smd ■ bbvia ■ uvia
uvia	t/nil	A sub-type of bbvias, to differentiate in constraint system.

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-12 Path Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
branch	dbid/nil	Branch owner
hasArcs	t/nil	t = path has one or more arcs
isSameWidth	t/nil	t = all segments in path have same width
isEtch	t/nil	t = a CLINE; nil = a LINE
nSegs	integer	Number of segments in path
objType	string	Type of object, in this case "path"
parent	dbid	Branch, symbol, shape or nil
segments	_dbid	List of arc and line figures in this path
symbolEtch	dbid	Symbol owner if etch.
startEnd	t_layer	If bond-wire start and end layers; nil if not bondwire.

Table 2-13 Pin Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
branch	dbid/nil	Branch owner
component	dbid/nil	Component owner of pin nil if unassigned symbol pin
definition	dbid/nil	Padstack definition nil if unplaced component pin
fixedByTestPoint	t/nil	OBSOLETE - kept for backwards compatibility. Use axlDBIsFixed(<dbid>) or axlDBControl(?testPointFixed) instead.
functionPins	_dbid/nil	List of function pins nil if unassigned symbol pin

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-13 Pin Attributes, *continued*

Attribute Name	Type	Description
isExploded	t/nil	t = pin is instance edited
isMech	t/nil	t = pin is mechanical
isMirrored	t/nil	t = pin is mirrored
isThrough	t/nil	t = pin is a throughhole
mirrorType	string	Type of mirror.
name	string	Padstack name of this pin nil if unplaced component pin
number	string	Pin number
objType	string	Type of object, in this case "pin"
pads	l_dbid	Unordered list of pads. ¹ To access a particular pad, use ax1DBGetPad.
parent	dbid	dbid of symbol owning this pin ² nil if pin is standalone (as it is in a symbol drawing)
relRotation	float	Pin rotation (relative to symbol)
relxy	point	Location (relative to symbol)
rotation	float	Pin rotation (absolute)
startEnd	lt_layer	Range of layers spanned by pin ²
testPoint	t_layer/nil	t_layer, denotes layer of testpoint nil = pin is not a testpoint
use	string	Pin use as shown by show element
xy	point	Location of pin in absolute coordinates

1. May be nil if component is unplaced.

2. Will say etch/(unknown) if unplaced component.

Note: Ppins straddle the line between physical and logical elements. They have attributes that are conditional on their owners. If the padstack definition is nil, then the pin is purely logical. If the component attribute is nil, then the pin is purely physical. If both are non-nil, then the pin is fully instantiated.

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-14 Polygon Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
area	float	Area of the polygon in drawing units.
bBox	bBox	Bounding box.
holes	list	List of <i>o_polygons</i> .
isHole	t/nil	t = polygon is a hole
isRect	t/nil	t = polygon is a rectangle
nSegs	integer	Number of segments in polygon
objType	string	Type of object, in this case "polygon"
parent	dbid	Symbol, shape (for voids), or nil
segments	l_dbid	Path describing boundary of shape. Boundary consists of line and arc segments.
symbolEtch	dbid	Symbol owner if etch
vertices	list	Outer boundary available as a list containing a point, which is the vertex of a polygon, and a floating point number, which is the radius of the edge from the previous to the present vertex.

Table 2-15 Rat_T Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
name	string	Name of T to T-<n>
net	dbid	Net of Rat-T
objType	string	Type of object, in this case "rat_t"
parent	dbid	Net
xy	point	Location of T

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-16 Shape Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
bBox	bBox	Bounding box
cavity	t/nil	If a boundary shape is for cavity generation (embedded design). Cavity shapes are generated automatically based on the rki.
branch	dbid/nil	Branch owner
children	l_dbid	Used when a Boundary Shape points to a list of dynamic shapes
connect	l_dbid/nil	List of connected figures
fill	g_fill/t/nil	Fill pattern (see ax1DBCreateOpenShape on page 853). t = filled; nil = unfilled
		Each ax1FillType has spacing width, origin, and angle.
fillet	t/nil	shape is a fillet (teardrop)
fillOOD	t/nil	Dynamic fill is out of date. t = shape needs fill updating (Only dynamic shapes can be t) nil = shape does not refill
holes	list	List of o_polygons
isHole	t/nil	t = polygon is a hole nil = polygon is not a hole
isRect	t/nil	t = shape is a rectangle
nSegs	integer	Number of segments in polygon
objType	string	Type of object, in this case "shape"
parent	dbid	Branch (if etch shape), Symbol, shape (for voids) nil = no parent

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-16 Shape Attributes, *continued*

Attribute Name	Type	Description
priority	integer/nil	If shape is a dynamic shape boundary this is an integer voiding priority. For all other shapes this is nil. The priority is relative to other dynamic shapes on the same layer. If two dynamic shapes are coincident, the shape with the higher priority wins in voiding. This number is re-calculated as needed, so use only for comparison purposes.
region	l_dbid/nil	Region owner if a region shape.
segments	l_dbid	Path boundary of shape
shapeAuto	l_dbid/nil	If dynamic shape list of generated shapes on the matching auto-gen ETCH or CAVITY layer
shapeBoundary	dbid/nil	If this shape is generated from a dynamic shape, this points to that shape. Boundary shapes may either be used for ETCH or CAVITY (see state of cavity attribute)
shapelsBoundary	t/nil	This shape is a dynamic shape, for example, on BOUNDARY class.
taper	t/nil	shape is used for tapering
dynamicGroup	t/nil	If this a dynamic shape (BOUNDARY class) return its dynamic group object. This is where voiding instance overrides are stored.
symbolEtch	dbid	Symbol owner, if etch
vertices	list	outer boundary available as a list containing a point (vertex of a polygon) and a floating point number (radius of the edge from the previous to the present vertex).
voids	l_dbid	List of polygon boundaries defining voids in this shape

Note: You cannot manipulate (move, add property, delete and more) auto-generated shapes (shapeBoundary != nil). You should modify the dynamic shape (shapeBoundary). You can use ax1SetFindFilter to set the find filter to auto-select the boundary shape when the user selects one of the auto-generated children.

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-17 Symbol Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
children	l_dbid/nil	List of figures other than pins making up symbol
component	dbid	Component owner of symbol
definition	dbid	Symbol definition
isMirrored	t/nil	t = symbol is mirrored
mirrorType	string	Type of mirror.
name	string	Symbol name
objType	string	Type of object, in this case "symbol"
parent	dbid	Design (no other parent possible for symbols)
pins	l_dbid/nil	List of pins
refdes	string/nil	Reference designator
rotation	float	Symbol rotation
type	string	Symbol type is one of: PACKAGE, MECHANICAL, FORMAT, SHAPE or DRAFTING
xy	point	Symbol location
embedded	t/nil	symbol placed on embedded layer
embeddedLayer	string	layer of placed symbol or nil if external
embeddedMethod	string	method (CHIP_UP or CHIP_DOWN)
embeddedAttach	string	attachment method (DIRECT_ATTACH or INDIRECT_ATTACH)

Table 2-18 Symdef (Symbol Definition) Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
children	l_dbid/nil	List of figures other than pins making up shape
instances	l_dbid	Symbol instances

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-18 Symdef (Symbol Definition) Attributes, *continued*

Attribute Name	Type	Description
name	string	Name of symbol definition
objType	string	Type of object, in this case "symdef"
parent	dbid	Design
pins	l_dbid/nil	List of pins
type	string	Symbol type is one of the following: PACKAGE, MECHANICAL, FORMAT, or SHAPE

Table 2-19 Tee Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
branch	dbid	Branch owner
objType	string	Type of object, in this case "tee"
parent	dbid	Branch
readOnly	t	User cannot directly modify
xy	point	Location

Table 2-20 Text Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
isMirrored	t/nil	t = text mirrored
justify	string	"left", "right" or "center"
mirrorType	string	Type of mirror.
objType	string	Type of object, in this case "text"
parent	dbid	Symbol or nil
rotation	float	Rotation angle
text	string	The text itself

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-20 Text Attributes, *continued*

Attribute Name	Type	Description
textBlock	string	Text block type
xy	point	Location of text origin

Table 2-21 Via Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
branch	dbid/nil	Branch owner
definition	dbid	Padstack definition
isMirrored	t/nil	t = via mirrored
isThrough	t/nil	t = through via
mirrorType	string	Type of mirror.
name	string	Padstack name
objType	string	Type of object, in this case "via"
pads	l_dbid	Unordered list of pads. To access a specific pad, use ax1DBGetPad.
parent	dbid	Symdef or nil
rotation	float	Via rotation
startEnd	l_t_layer	Start and end layer of via
testPoint	t_layer/nil	Via test point state is one of: ETCH/TOP or ETCH/BOTTOM
xy	point	Location of via

Logical Database Types

Allegro PCB Editor logical database objects have these generic attributes (see [Description of Database Objects](#) on page 76): objType, prop, and readOnly. Logical database objects do not have other attributes in common. The tables below list the attributes for each Allegro PCB Editor logical type.

Table 2-22 Bus Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	l_dbid	List of xnets of the bus
name	string	Name of the bus
objType	string	“group”
type	string	“BUS”
lock	t/nil	Is locked for editing (vector buses)

Table 2-23 Compdef Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
class	string	Component classification
components	l_dbid	List of component instances of this definition.
deviceType	string	Device type of the component
functions	l_dbid	List of functions.
objType	string	Type of object, in this case "compdef"
pins	l_dbid	List of pins comprising the component.

Table 2-24 Component Attributes

Attribute Name	Type	Description
Also includes generic object attributes		

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-24 Component Attributes, *continued*

Attribute Name	Type	Description
class	string	Component classification
compdef	dbid	dbid of component definition (COMPDEF)
deviceType	string	Device type of component (see COMPDEF)
functions	l_dbid	List of functions
name	string	Reference designator
objType	string	Type of object, in this case "component"
package	string	Package name
pins	l_dbid	List of pins comprising component
symbol	dbid/nil	dbid of the placed symbol of this component, nil if unplaced

Table 2-25 Diffpair Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	l_dbid	List of xnets of the differential pair
name	string	Name of the differential pair
objType	string	"group"
type	string	"DIFFPAIR"
userDefined	t/nil	If you create t, can be modified. Nil indicates creation by SigNoise models and cannot be changed.

Table 2-26 Function Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
name	string	Function designator

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-26 Function Attributes, *continued*

Attribute Name	Type	Description
objType	string	Type of object, in this case "function"
parent	dbid	<i>dbid</i> of component owning this function
pins	l_dbid	List of function pins composing function
slot	string	Slot name
type	string	Function type

Table 2-27 Function Pin Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
name	string	Function pin name
objType	string	Type of object, in this case "functionPin"
parent	dbid	<i>dbid</i> of function owning this pin
pin	dbid	Pin owner of function pin
swap code	integer	Swap code of function pin
use	string	Pin usage description, one of UNSPECIFIED, POWER, GROUND, NC, LOADIN, LOADOUT, BI, TRU, OCA, OCL

Table 2-28 MATCH_GROUP Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	l_dbid	List of xnets, nets and pinpairs making up this group.
name	string	Name of the match group.
objType	string	"group"
pinpair	l_dbid	List of pinpairs associated with xnet

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-28 MATCH_GROUP Attributes

Attribute Name	Type	Description
type	string	"MATCH_GROUP"

Note: For more information, see [axlMatchGroupCreate](#).

Table 2-29 Net Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
branches	l_dbid	List of branches
name	string	Net name
bus	dbid	Bus dbid if part of a bus
nBranches	integer	Number of branches (when exactly one, net is fully connected)
Note: Island shapes causes the count to be not one, even if all pins are connected.		
objType	string	Type of object, in this case "net"
pinpair	l_dbid	List of pinpairs associated with net (1)
Note: If a net is a member of an xnet, all pinpairs appear on the xnet.		
ratsnest	l_dbid	List of ratsnest for net.
ratsnest On	t/nil	State of ratsnest display for the net.
ratT	l_dbid	List of rat_T's. If none exist, this is NULL.
rpd	l_rpd	List of lists for each member net of a match group (<code>mg_dbid</code> , <code>t_relatePropDelay</code>).
For more information, see axlMatchGroupCreate		
isBundled	t/nil	t = net contains at least one bundled ratsnest.
scheduleLocked	t/nil	t = net schedule cannot be changed
unconnected	integer	Number of remaining connections. This does not include connections to unplaced symbols.

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-29 Net Attributes, *continued*

Attribute Name	Type	Description
unplaced	integer	Number of unplaced pins.

Note:

- 1) If net is a member of an xnet then all pinpairs will appear on the xnet.
- 2) For more information on the rpd attribute see axlMatchGroupCreate

Table 2-30 NETCLASS Attributes: NetClass objects for constraint grouping

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	l_dbid	List of nets, xnets, buses or differential pairs.
name	string	Name of the net class
objType	string	"group"
type	string	"NETCLASS"
electrical	t/nil	If part of the electrical and same net domain
physical	t/nil	If part of the physical and same net domain
spacing	t/nil	If part of the spacing and same net domain

Note:

- a. A NetClass can be a member of one or more domains but its name must be unique across all domains.
- b. Constraint overrides can be added to netclass via properties.

Table 2-31 REGION Attribute: Region objects for constraint grouping

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	l_dbid	List of constraint area shapes.

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-31 REGION Attribute: Region objects for constraint grouping

Attribute Name	Type	Description
name	string	Name of the region
objType	string	"group"
type	string	"REGION"

Table 2-32 CLASS Table Attribute

Attribute Name	Type	Description
name	string	Name of ecset
netclass1	dbid	net class entry
netclass2	dbid	second net class entry (may be nil)
region	dbid	region class for table entry (may be nil)
physical	dbid	physical cset associated with entry or nil
spacing	string	spacing cset associated with entry or nil
sameNet	string	sameNet cset associated with entry or nil
assembly	string	physical assembly cset associated with entry (SIP/APD only)
objType	string	"classTable"
readOnly	t/nil	Cannot be modified
prop	I_dbid	List of properties on table entry. Typically where constraint overrides on entry exist. Also duplicates the cset names.

Note: These are the class-class, class-class-region and class-region constraint table entries.
See `axlCnsClassTableCreate`.

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-33 Pinpair Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
ecsetDerived	t/nil	If t, pinpair was created from an ECset. Nil indicates pinpair created due to net override property.
groupMembers	l_dbid	List of two pins making up pinpair.
name	string	Name of the pinpair (<refdes>. <pin#>: <refdes>. <pin#>)
objType	string	"group"
parent	l_dbid	Net or xnet owning the pinpair.
parentGroups	l_dbid	Lists match groups that have this pinpair. May also list other parent groups.
rpd	l_rpd	For each match group that has this pinpair as a member, will list as a list of lists. (mg_dbid t_relatePropDelay)
type	string	"PIN_PAIR"

Note: For nets that are part of an xnet, the pinpair always has the xnet as the pinpair owner. For more information on the rpd attribute, see [axlMatchGroupCreate](#).

Table 2-34 NET_GROUP Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	l_dbid	members of the group (net_groups, nets, xnets, diffpairs, buses)
name	string	Name of group
objType	string	"group"
type	string	"NET_GROUP"
isInterfaceTop	t/nil	If t, group is the top of a definition-driven interface instance.

Allegro SKILL Reference

The Allegro PCB Editor Database User Model

Note: Use `ax1DBCreateGroup` family of commands to add, delete and modify these groups.

Table 2-35 PORT_GROUP Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	<code>l_dbid</code>	members of the group (port_groups, pins, function pins)
name	string	Name of group
objType	string	"group"
type	string	"PORT_GROUP"
isInterfaceTop	<code>t/nil</code>	If <code>t</code> , group is the top of a definition-driven interface instance.

Note: PORT_GROUPS are groupings of Allegro pin objects.

Table 2-36 RATSNEST Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
bus	<code>t/nil</code>	Currently being shown with bus routes option
objType	string	Type of object, in this case "ratsnest"
pinsConnected	<code>t/nil</code>	Ratsnest not displayed (both pins on same branch)
pins	<code>l_dbid</code>	The two pins (or ratTs) that the rats connect
pwrAndGnd	<code>t/nil</code>	Net is power and ground scheduled
ratnest	<code>t/nil</code>	Two dbids of the next ratsnest for dbid's of the pins attribute.
ratsPlaced	<code>t/nil</code>	User defined rats only, one or more pins unplaced
userDefined	<code>t/nil</code>	Ratsnest is user defined

Table 2-37 XNET Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
bus	dbid	Bus dbid if part of a bus.
diffpair	dbid	differential pair dbid if part of a differential pair.
groupMembers	l_dbid	List of nets of the xnet.
name	string	Name of the xnet.
objType	string	“group”
pinpair	l_dbid	List of pinpairs associated with xnet.
rpd	l_rpd	For each match group that has this xnet as a member, lists as a list of lists (<code>mg_dbid t_relatePropDelay</code>).
type	string	“XNET”.

Note:

- 1) This attribute can only be defined indirectly from the SigNoise model assignment.
- 2) For more information on rpd, see `axlMatchGroupCreate`.

Property Dictionary Database Types

The following section contains tables listing the attributes of Allegro PCB Editor property dictionary objects. You must enter a dictionary object with a particular name in the property dictionary before you attach properties by that name to Allegro PCB Editor objects.

Object Types Allowing Attachment of Properties

You can attach properties to the database object types listed here. Each property type has a list of the objects types to which it can be attached. Attempting to attach a non-qualified property to an object returns `nil`.

NETS	COMPONENTS	FUNCTIONS	PINS
VIAS	SHAPES	SYMBOLS	CLINES
LINES	DRCS	FIGURES	DESIGNS
COMPDEFS	PINDEFS	FUNCDEFS	

Allowed Property Data Types

An Allegro PCB Editor property value can be one of the data types listed. The right column shows the checks you can optionally apply to user input for that data type. Pre-defined properties have pre-defined range checks. You define your own range checks for user-defined properties.

Note: The right column includes default units for that property data type, however, you can set the units of these standard data types in the `<tools>/text/units.dat` file.

Data Type	Data Check Available (default units)
STRING	N/A
INTEGER	range and units
REAL	range and units
DESIGN_UNITS	range (units of current design)
BOOLEAN	N/A
ALTITUDE	range (meters)
CAPACITANCE	range (pF)
DISTANCE	range (cm)
ELEC_CONDUCTIVITY	range (mho/cm)
LAYER_THICKNESS	range (mil)
IMPEDANCE	range (ohm)
INDUCTANCE	range (nH)
PROP_DELAY	range (nS)
RESISTANCE	range (ohm)
TEMPERATURE	range (degC)
THERM_CONDUCTANCE	range (w/cm-degC)
THERM_CONDUCTIVITY	range (w/cm-degC)
VOLTAGE	range (mV)
VELOCITY	range (m/sec)

Table 2-38 Property Dictionary Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
dataType	string	Data type for property value (see Allowed Property Data Types on page 106)
name	string	Name of property
objType	string	Type of object, in this case “propDict”
range	If_range	Optional limits for value
units	string	Optional value units
useCount	integer	Number of objects using property
write	t/nil	t = writable or user defined nil = read-only or Allegro PCB Editor pre-defined

Parameter Database Types

The following Allegro PCB Editor parameter types, which are critical to the function of interactive commands, are modeled:

- drawing
- layer
- text block
- display

Only drawing parameters support attached properties.

You can access and change parameters with `axlParamGetByName` and `axlSetParam`, respectively. See [Chapter 3, “Parameter Management Functions”](#) for functions that provide easier access to layers and other parameter objects.

Allegro SKILL Reference

The Allegro PCB Editor Database User Model

Unlike other Allegro PCB Editor objects these attributes contain a column, `Set?`, that shows whether you can modify this field via the `axlSetParam` function.

Table 2-39 Artwork Parameter Attributes

Attribute Name	Type	Description
Includes no generic object attributes		
groupMembers	l_string	List of film names
nChildren	number	Number of films
objType	string	Type of object, in this case "artwork"

Table 2-40 Artwork Film Parameter Attributes

Attribute Name	Type	Description
Includes no generic object attributes		
drawMissingPadApertures	t/nil	Specifies the apertures you can use to draw (fillin) the shape of any pad for which there is no matching pad aperture in <code>art_aper.txt</code> . Not selecting this option means that you cannot draw such pads.
fullContact	t/nil	Applies to negative film. When t, a pin or via that is connected to a shape uses no flash, causing a solid mass of copper to cover the pad. When you do not select this field, a pin or via connected to a shape uses a thermal-relief flash.
groupMembers	l_string	List of layers comprising film
mirrored	t/nil	Specifies whether to mirror the photoplot output.
name	string	Name of film
negative	t/nil	Is film positive (nil) or negative (t)
objType	string	Type of object, in this case "artwork"
offset	point	Specifies the x and y offset to add to each photoplot coordinate. If you enter positive x and y offsets, all photoplotted lines shift in the positive direction on the film.

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-40 Artwork Film Parameter Attributes, *continued*

Attribute Name	Type	Description
rotation	integer	Rotation of the plotted film image. Choices are: 0, 90, 180, and 270 degrees.
shapeBoundingBox	float	Applies to negative film. Adds another outline around the design outline, extending the shape boundary of the filled area. This new artwork outline extends, by default, 100 mils in all directions beyond the design outline.
suppressShapeFill	t/nil	Area outside the shapes is not filled on a negative film. You must replace the filled areas with separation lines before running artwork.
suppressUnconnectPads	t/nil	Specifies that the pads of pins and vias with no connection to a connect line in a gerber data file are not plotted. This option applies only to internal layers and to pins whose padstack flags the pads as optional. Selecting this button also suppresses donut antipads in raster based negative artwork.
undefineLineWidth	float	Determines the width of any line that is 0.
useApertureRotation	t/nil	Specifies whether or not to use the aperture rotation raster. Artwork uses gerber behavior to determine which type of pad to flash.
vectorBasedPad	string	Extracts information about vector based pad behavior from the artwork control dialog box.

Table 2-41 Design Parameter Attributes

Attribute Name	Set?	Type	Description
Includes generic object attributes			
accuracy	no	integer	Number of decimal places of accuracy
bBox	no	bbox	The design's bounding box
height	no	float	Height in user units
objType	no	string	Type of object, in this case "paramDesign"

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-41 Design Parameter Attributes, *continued*

Attribute Name	Set?	Type	Description
units	no	string	Type of user units (mils, inch, micron, millimeter and centimeter)
width	no	float	Width in user units
xy	no	point	Lower left corner of design

Notes:

- To avoid harmful side effects, such as rounding errors, do not toggle between English and metric.
- Changes to accuracy are very time consuming since all objects in the design must be changed.

Setting drawing accuracy to a value greater than Allegro PCB Editor supports is an error. Typical range is 0 to 4.

- Change units and accuracy at the same time to avoid loss of accuracy.
- The size (width and height) may not be decreased where it will leave some objects outside of the drawing extents.

Table 2-42 Display Parameter Attributes

Attribute Name	Set?	Type	Description
Includes no generic object attributes			
activeLayer	yes	string	Active layer name
altLayer	yes	string	Alternative layer name which must be of group "etch"
objType	no	string	Type of object, in this case "paramDisplay"

Table 2-43 ECset Parameter Attributes

Attribute Name	Set?	Type	Description
Includes generic object attributes			

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-43 ECset Parameter Attributes

Attribute Name	Set?	Type	Description
locked	t/nil		Cset locked from UI based editing
members	l_dbid		List of electrical constraints in set
name	string		Name of ECset
objType	string		Type of object, in this case "ecset"
prop	l_dbid		List of user defined properties on ECset
readOnly	t/nil		Cannot be modified, always t
topology	t/nil		This is derived from a topology file, and may contain constraints that have restrictions on how they can be modified.
prop	l_dbid		List of user-defined properties on an ECset.

Figure 2-2 Allegro PCB Editor Class/Subclass to AXL Layer Model




Table 2-44 Layer Group Parameter Attributes (Allegro Classes)

Attribute Name	Set?	Type	Description
Includes no generic object attributes			
color	yes	integer	Layer color index; -1 if all child layers are not the same color
groupMember	no	l_string	List of subclasses belonging to this class
isEtch	no	t/nil	Is an etch layer
name		string	Name of this class
nChildren	no	integer	Number of subclasses in class
objType	no	string	Type of object, in this case "paramLayerGroup"
pattern	yes	integer	Pattern for layer; -1 if all child layers not the same pattern (see Layer Parameter Attributes (Allegro Subclasses) table on page 113)
visible	yes	t/nil	All subclasses of this class are visible

Table 2-45 Layer Parameter Attributes (Allegro Subclasses)

Attribute Name	Set?	Type	Description
Includes no generic object attributes			
color	yes	integer	Subclass color number
drcPhotoType	no	l_string	"Positive" or "negative" (applies only to etch)
isEtch	no	t/nil	Is an etch layer
material	NO	string	Layer material (etch only)
name	no	string	Name of this subclass
number	no	integer	Layer number, while this is reported for both etch and non-etch layers it is only meaningful for etch layers where it shows the stackup order.
nextLayer	no	string	Name of next layer in stackup (etch only)
objType	no	string	Type of object, in this case "paramLayer"
parentname	no	string	Name of owning class
pattern	yes	integer	Pattern of layer where 0 is default solid pattern. For maximum patterns see axlColorGet('pattern') . Pattern style for each pattern number can be found in the color192 dialog.
thickness	no	string	Layer thickness (etch only)
type	no	string	"Positive" or Negative (etch only)
userDefined	No	t/nil	Is layer user defined. User defined layers can have been added by the user. Note for etch layers all are user defined but you typically cannot delete or rename the TOP or BOTTOM.
visible	yes	t/nil	All subclasses of this class are visible

Note: The Allegro PCB Editor class/subclass system is modeled in AXL as layers. The previous drawing figure shows how AXL layers are mapped to Allegro PCB Editor class/subclasses. The define etch form in Allegro PCB Editor does not match this model. AXL does not support access to the dielectric pseudo-layers nor does it support analysis layer attributes

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

such as material and thickness. To access these records, use Allegro PCB Editor's technology file feature.

Table 2-46 Textblock Group Parameter Attributes

Attribute Name	Set?	Type	Description
Includes no generic object attributes			
groupMembers	no	l_string	Names of members in this group
nChildren	no	integer	Number of children
objType	no	string	Type of object, in this case "paramTextGroup"

Table 2-47 Textblock Parameter Attributes

Attribute Name	Set?	Type	Description
Includes no generic object attributes			
charSpace	no	float	Spacing between characters
height	no	float	Height of character
lineSpace	no	float	Spacing between lines
name	no	string	Name of block (currently 1 through 16)
objType	no	string	Type of object, in this case "paramTextBlock"
photoWidth	no	float	Width of character for photoplotting
width	no	float	Width of character

Table 2-48 Testprep Parameter Attributes

Attribute Name	Set?	Type	Description
Includes no generic object attributes			
allowUnderComp	yes	t/nil	Allows test pads under components.
autoInsert	yes	t/nil	Allows automatic generation of test points as needed.

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-48 Testprep Parameter Attributes, continued

Attribute Name	Set?	Type	Description
bareBoard	yes	t/nil	If nil, you can only test component pins on non-component design side. If t, then you can check pins on either side of the design, as long as padstack is defined on that side.
directTest	yes	t/nil	Allows pins to be selected as test point.
executelnc	yes	t/nil	If t, returns in incremental mode where you can analyze only nets without test points. If nil, removes all test points at beginning of run.
layer	yes	symbol	Layer for test: top, bottom or either.
maxTestDisplacement	yes	float	Maximum distance from pin or via where you can place the test point.
minPadSize	yes	float	Minimum padstack size. Works with replaceVias to upscale padstacks.
minTestDisplacement	yes	float	Minimum distance from pin or via where you can place a test point. A value of 0 indicates DRC distance you should use.
minTestSpacing	yes	float	Minimum spacing between test points.
objectType	no	string	Type of object, in this case "testprep"
pinType	yes	symbol	Type of pin selectable for testing: input, output, pin, via, or point.
replaceVias	yes	t/nil	If t, replaces vias that are too small with a larger via.
testGridX	yes	float	Testprep grid.
testGridY	yes	float	Testprep grid.
testMethod	yes	symbol	Method used for test: single, node, or flood.
testPad	yes	nil/string	Padstack that you use for test pads on the probe side of the design. Must meet criteria specified in the <i>testPadType</i> attribute. If relative name is given, uses database then PSMPATH to find pad.

Allegro SKILL Reference
The Allegro PCB Editor Database User Model

Table 2-48 Testprep Parameter Attributes, continued

Attribute Name	Set?	Type	Description
testPadDB	no	dbid	<i>dbid</i> of the testPad
testPadType	yes	symbol	Type of padstacks for probes: <code>smd</code> , <code>through</code> , or <code>either</code> .
testVia	yes	nil/string	Padstack that you use for testpads on the probe side of the design. Must be through hole. If relative name is given, uses database then <code>PSMPATH</code> to find pad.
testViaDB	no	dbid	<i>dbid</i> of testVia.
unusedPins	yes	t/nil	Allows test points on pins, not on a net.
			The following are Text Controls
alpha	yes	t/nil	If <code>t</code> , use Alphabetic extension, <code>nil</code> use numeric extension.
displayText	yes	t/nil	Displays text for each test point.
textOffsetX	yes	float	X offset of text from pad center.
textOffsetY	yes	float	Y offset of text from pad center.
textRotation	yes	integer	Rotation of text labels: values are 0, 90, 180, or 270 degrees. Other values are moduled and truncated.

Note: Specifying `testVia` or `testPad` loads them into the current database if they are not already loaded. Changing to another padstack does not delete the old padstack from the database.

Example

```
p = axlGetParam("testprep")
p->displayText = t
p->testMethod = 'flood
axlSetParam(p)
```

Turns on text display and sets test method to flood.

Parameter Management Functions

Overview

This chapter describes the AXL-SKILL functions that retrieve and set Allegro database parameters. You can access certain Allegro parameters using these functions. Additional functions are built on top of `axlGetParam`/`axlSetParam` to make programming easier.

See [Chapter 1, “Introduction to Allegro PCB Editor SKILL Functions.”](#) for a description of available parameter attributes.

The use model follows:

- Get the parameter using `axlGetParam`.
- Modify the values using `axlSetParam`.
- Update the parameter using `axlSetParam`.

AXL-SKILL restricts you from creating new parameters or subclasses.

axlcreate

```
axlcreate (
    t_filmname
    (n_rotate_code
    n_x_offset
    n_y_offset
    n_undef_line_width
    n_shape_bound
    n_plot_mode
    n_mirrored
    n_full_contact
    n_supp_unconnect
    n_draw_pad
    n_aper_rot
    n_fill_out_shapes
    n_vector_based
    n_draw_holes)
    (lt_layers))
->name/nil
```

Description

This command creates a new film record or updates an existing record in active Allegro board. This function is most commonly called through the artwork control form's film record load option.

t_filename = film record name

l_params is a list consisting of 13 parameters that correspond to the "Film Options" fields in the film control form (see below for a description of the fields).

lt_layers is the list of layers, each layer is a string of the form

`('ETCH/TOP" "VIA/TOP" ...)`



Caution

The filmname is limited by the database. Entering a name longer than the design allows will return a nil. See the artwork parameter dialog for the current name limit.

All units based parameters, such as, x offset, and width, must be specified in database units NOT design units. Database units are always integers and can be converted from designs units using the following formula.

db_units = design_units * design_accuracy ** 10

For example, if the design has 2 units of accuracy and you want to a width of 12.34, you would specify 1234, as (1234=12.34*10**2) **or**
(1234=12.34*100)

Arguments

<i>t_filmname</i>	the name of the film record to be created
<i>l_params</i>	list of parameters for the film They are: <ul style="list-style-type: none">■ rotate_code – 0, 2, 4, or 6, corresponding to 0, 90, 180, 270 degree rotation■ x_offset – film record block origin x offset■ y_offset – film record block origin y offset■ undef_line_width – film record undefined line width■ shape_bound – shape bounding box size■ plot_mode – film record plot mode.The two valid values are 0 = NEGATIVE, and 1 = POSITIVE.■ mirrored – flag denoting mirroring■ supp_unconnect – indicator to not flash unconnected pads■ draw_pad – indicator to draw pads■ aper_rot – boolean indicator for aperture rotation■ fill_out_shapes – boolean indicator to not suppress shape fill. This is the opposite of the <i>suppress shape fill</i> switch in the film control form. For example, if <i>suppress shape fill</i> is selected, <i>fill_out_shapes</i> should be 0. This is named this way because it how it is represented within the Allegro database. This should be set to 1 for 274X, Barcode and MDA since it is ignored by these formats in Allegro but certain 3rd party applications may work differently.■ vector_based – boolean indicator for vector-based pad behavior.■ draw_holes – boolean indicator for draw holes in pads.

Allegro SKILL Reference

Parameter Management Functions

l_t_layers list of layers to include in the film

Value Returned

The name of the film record created, or `nil` if command fails.

Example

Film control form's film record "save" option is called. This creates a `.txt` file containing the following:

```
axlcreate( "TRACE_2" '(0 0 0 0 0 1 0 0 0 0 0 1 1 0) '("ETCH/TRACE_2" "PIN/TRACE_2"  
"VIA CLASS/TRACE_2" ))
```

axIDBGridGet

```
axlDBGridGet( nil)  
=> lt_grids  
  
axlDBGridGet( t_gridName)  
=> og_grid
```

Description

This command returns current grid values. Function has two modes:

- if gridname is nil returns list of names
 - If given a grid name return its grid characteristics (see below)

Note: Reserved grid name is "non-etch" otherwise grid names follow Allegro ETCH subclass names.

Use `ax1DBDisplayControl` to control grid color and visibility.

Grids have the following attributes:

Name	Type	Description
objType	string	Name of the object - grids
readOnly	nil	can modify object
name	string	Name of grid
xOrigin	dbrep	X origin of grid
yOrigin	dbrep	Y origin of grid
xMajor	dbrep	Major X spacing of grid (read-only)
yMajor	dbrep	Major Y spacing of grid (read-only)
xGrids	l_dbrep	Spacings X of grid (always a list of dbreps)
yGrids	l_dbrep	Spacings Y of grid (always a list of dbreps)

Arguments

t_gridName name of grid or *nil* to get all grid names

Value Returned

- `lt_grids` – list of grids
- `og_grid` – disembodied property list containing grid settings

See Also

[axlDBGridSet](#)

Example

Run the following code to get all grids and print them.

```
grids = axlDBGridGet(nil)

foreach(g grids
    grd = axlDBGridGet(g)
    printf("GRID name=%s  values=%L\n", grd->name, grd))
```

axIDBGridSet

```
ax1DBGridSet(og_grid)==>t/nil
```

Description

This command modifies the grid settings in the design.

In addition to the grid names (see `axlDBGGridGet`), two symbolic grid names are available:

- 'all – sets all grid values
 - 'etch – sets all ETCH grid values

As a convenience when setting a single the xGrids or yGrids attribute, you can use a float.

Both xMajor and yMajor values are automatically determined by the sum of the spacings in xGrids and yGrids respectively.

Notes:

- ❑ Non etch grids may not have multiple spacings. We only use the first grid seen.
 - ❑ Setting grids is not undo-able (this may change in the future).
 - ❑ Etch grids names are the same as ETCH layer names. This may change in the future.
 - ❑ Origin values must be within drawing extents or 0.
 - ❑ If Grid dialog is open it will not be updated when you change the grid settings using this API command.

Arguments

og_grid a grid disembodied property list from [axIDBGridGet](#)

Value Returned

`t` if the command is successful and the grid is changed, `nil` in case of failure.

See Also

[axlDBGridGet](#), [axlDBDisplayControl](#)

Examples

1. Modify TOP grid settings

```
grid = axlDBGridGet("TOP")
grid = axlDBG
```

2. Modify all grids (note allow xGrids and yGrids to NOT be list)

```
grid = axlDBGridGet("TOP")
grid->name = 'all
grid->xGrids = 5.0
grid->yGrids = 5.0
axlDBGridSet(grid)
```

3. Modify all etch grids

```
grid = axlDBGridGet("TOP")
grid->name = 'etch
grid->xGrids = '(5.0 7.0)
grid->yGrids = '(5.0 6.0)
axlDBGridSet(grid)
```

axlDBTextBlockCreate

```
axlDBTextBlockCreate(  
    x_blockTemplate  
    ?width f_width  
    ?height f_height  
    ?lineSpace f_lineSpace  
    ?charSpace f_charSpace  
    ?photoWidth f_photoWidth  
) => x_textBlock/nil
```

Description

Creates a new text block from the template block number provided. By providing optional text block characteristics, you can get available text blocks by:

```
lst = axlGetParam("paramTextBlock")
```

Arguments

x_blockTemplate

f_XXX values

Value Returned

- *x_textBlock* – new text block
- *nil* – Returned if the command fails. Typically, this happens when you have exhausted the number block Allegro provides, or one of the parameters is not of the correct data type.

See Also

[axlGetParam](#), [axlSetParam](#), [axlDBTextBlockCompact](#)

Examples

Create a new text block based upon text block 1 but change width and height

```
blockNum = axlDBTextBlockCreate(1 ?width 15.0 ?height 16.0)
```

axlExportXmlDBRecords

```
axlExportXmlDBRecords(  
    t_fileName  
    lt_parmGroups/nil  
) -> t/nil  
  
axlExportXmlDBRecords(  
    nil  
) -> lt_parmGroups
```

Description

This exports an Allegro Parameter file from the current design. It offers the same capability as (*File – Import – Parameter*). Side effect is creation of a `param_write.log` file.

Arguments

<code>t_fileName</code>	Name of parameter file. Default extension is <code>.prm</code> and if not given a path component will locate the file via <code>PARAMPATH</code> . If filename is <code>nil</code> report back as a list the supported parameter groups.
<code>lt_parmGroups</code>	List of parameter groups to export or <code>nil</code> to export all.

Value Returned

`t` if command is successfully executed, `nil` in case of an error

See Also

[axlImportXmlDBRecords](#)

Examples

1. In an existing dump, save all its settings and load into a new design

```
axlExportXmlDBRecords("myparam" nil)  
axlOpenDesign(?design "newDesign")  
axlImportXmlDBRecords("myparam")
```

2. Dump current parameter groups

```
axlExportXmlDBRecords(nil)
```

axlImportXmlDBRecords

```
axlImportXmlDBRecords(  
    t_fileName  
) -> t/nil
```

Description

This command imports an Allegro Parameter file into the current design. It offers the same capability as (*File – Import – Parameter*). A side effect is creation of `param_read.log` file.



Caution

For new releases, the `prm` files may require updating to support new parameter records or additions to current records.



Tip

You can create your own custom parameter files and load them with this interface. While the export interface typically groups several Allegro parameters together, you can custom craft a `prm` file with a single parameter record or just a single parameter from one record (see example below). The only `prm` file requirements are:

- `prm` file xml header
- parameter header and trailer
- revision number per parameter (currently these are all 1)

Arguments

`t_fileName` Name of parameter file. Default extension is `.prm`. If filename is not provided component will located the file via `PARAMPATH`.

Value Returned

`t` if success, `nil` an error

See Also

[axlExportXmlDBRecords](#)

Examples

See [axlExportXmlIDBRecords](#)

Example of a parameter file with setting just the dynamic shape min area to 75.0:

```
<?xml version="1.0" encoding="UTF-8" standalone="no" ?>

<CadenceAllegroParameter xmlns="">
  <dynfill_parm_type>
    <rev>1</rev>
    <min_area>75.0 MIL</min_area>
  </dynfill_parm_type>
</CadenceAllegroParameter>
```

axIPadSuppressGet

```
axIPadSuppressGet(  
    nil  
)  
==> ll_LayerPadSuppress  
  
axIDBGridGet(  
    t_layer/x_layerNumber  
)  
==> l_LayerPadSuppress
```

Description

Returns pad suppress layer characteristic for a layer or design. Pad suppression is not available in symbol editor.

Name dielectric layers will appear in the list unlike the pad suppress dialog.

Arguments

<i>nil</i>	Return all layers
<i>t_layer</i>	Get suppress characteristics of named layer
<i>x_layerNumber</i>	Layer number (1st layer is 0)

Value Returned

- *ll_LayerPadSuppress* - list of *l_LayerPadSuppress* for all etch layers. Layers are ordered from top to bottom.
- *l_LayerPadSuppress* - suppress characteristics of named layer. The symbols pin and via are optional and if present indicate pin and/or vias will be suppressed on that layer.

(<*t_layer*> [<*s_pin*>] [<*s_via*>])

See Also

[axIPadSuppressSet](#), [axIPadSuppressOkLayer](#), [axIDBControl](#), [axISubclassRoute](#), [axIPadOnLayer](#)

Example

- Get and print suppress state of all layers

```
suppress = axlPadSuppressGet(nil)

foreach(item suppress
    printf("Layer=%s  what= %L\n", car(item) cdr(item)))
```

- Get settings for layer "GND"

```
suppress = axlPadSuppressGet("GND")
```

- Get settings for layer 1

```
suppress = axlPadSuppressGet(1)
```

axlPadSuppressOkLayer

```
axlPadSuppressOkLayer(  
    t_layer/x_layerNumber  
)  
==> t/nil
```

Description

Indicates if layer can be set for pad suppression. Only internal conductor and shape layers that are not set for negative artwork, support pad suppression.

Argument

t_layer name of layer (e.g. "TOP")

x_layerNumber layer number (starts at 0);

Value Returned

t if layer can allows pad suppress; *nil* otherwise

See Also

[axlPadSuppressGet](#)

Examples

The following are the same in the PCB tool but may not be in APD or SiP Layout:

```
axlPadSuppressOkLayer ("TOP")  
axlPadSuppressOkLayer (0)
```

axlPadSuppressSet

```
axlPadSuppressSet(  
    g_mode  
    ll_LayerPadSuppress/'all/'none/nil  
)  
==> t/nil  
  
axlPadSuppressSet(  
    g_mode  
    t_layer/x_layerNumber  
    ls_options  
)  
==> t/nil
```

Description

This modifies the pad suppression settings in the design. Allows control of both dynamic suppression setting (g_mode) and the individual layer options (subsequent arguments).

Notes:

- ❑ If passing a list of suppression layers then any errors in the list are ignored.
- ❑ Will mark dynamic shapes and DRC out of date.
- ❑ If enabling dynamic mode and no suppression layers are enabled the dynamic mode will be left disabled.
- ❑ Unlike the dynamic it will not automatically enable the display of padless holes.



Pad suppression dialog should not be open when using this API.

Argument

g_mode

The possible values are:

- nil - maintain current pad suppression mode
- 'on - turn pad suppression on
- 'off - turn pad suppression off

In the first format, second argument can have one of the following values.

Allegro SKILL Reference

Parameter Management Functions

'all	Enable suppress on all supported layers
'none	Clear suppression on all supported layers
nil	leave suppression layers allow (typically used to toggle global mode)

ll_LayerPadSuppress List of layers using same form as [axIPadSuppressGet](#).

Alternatively, use the second format to set suppression on single layers.

t_layer Layer name

or

x_layerNumber Layer number when first layer is 0

ls_options May be nil or a list of 'via and/or 'pin

Value Returned

τ if success, nil a failure

See Also

[axIDBGridGet](#), [axIDRCUpdate](#), [axIDBDynamicShapes](#)

Examples

- Enable dynamic suppression setting

```
axIPadSuppressSet('on nil')
```

- Enable all layers and dynamic mode

```
axIPadSuppressSet('on 'all')
```

- Delete suppression layer settings and turn off dynamic mode

```
axIPadSuppressSet('off 'none')
```

- Turn on via suppression on layer GND

```
axIPadSuppressSet(nil "GND" '(via))
```

- Turn on via & pin suppression on layer GND

```
axIPadSuppressSet(nil "GND" '(via pin))
```

Allegro SKILL Reference

Parameter Management Functions

- Turn off suppression on a layer GND

```
axlPadSuppressSet(nil "GND" nil)
```

- Turn on suppression for GND and VCC layers

```
axlPadSuppressSet(nil '(("GND" via pin) ("VCC" via pin)))
```

axlGetParam

```
axlGetParam (
  t_parm_name
)
⇒ fio_paramDbid/nil
```

Description

Gets the parameter *dbid* for a named object. Supported parameter names are shown below. For descriptions of attributes of a parameter, see are [Chapter 2, “The Allegro PCB Editor Database User Model.”](#)

Arguments

t_parm_name Name of the parameter to seek. The legal naming conventions follow:

```
paramTextBlock:<#> where # is 1-16 (Example: paramTextBlock:1)
paramDesign
paramDisplay
paramLayerGroup:<name> where name is legal Allegro class name
paramLayerGroup:<name>/paramLayer:<name>
artworkList of film names
artwork:<filmNameA film given by filmName
testprepSee axlParamTestPrepDoc
```

Value Returned

o_paramDbid *dbid* for the requested parameter.

nil Parameter requested not found.

Example

1) Get etch layer (to find all members of the etch class).

```
Skill> etch_parm = axlGetParam("paramLayerGroup:ETCH")
param:123456
```

Allegro SKILL Reference

Parameter Management Functions

```
Skill> etch_parm->??  
(objType "paramLayerGroup" name "ETCH" visible  
-1 nChildren 4 groupMembers  
("TOP" "GND" "VCC" "BOTTOM")  
color -1  
)
```

```
Skill> etch_parm->color  
-1
```

```
Skill> etch_parm->groupMembers  
("TOP" "GND" "VCC" "BOTTOM")
```

2) Access artwork records:

A) Get list of all possible records.

```
Skill> p = axlGetParam("artwork")  
Skill> p->??  
(objType "artwork" nChildren 4 groupMembers  
("TOP" "GND" "VCC" "BOTTOM")
```

B) Get information on film record "VCC".

```
r = axlGetParam("artwork:VCC")  
Skill> r->??  
(objType "artwork" groupMembers  
("ETCH/VCC" "PIN/VCC" "VIA CLASS/VCC") vectorBasedPad  
t suppressShapeFill t useApertureRotation nil  
drawMissingPadApertures nil suppressUnconnectPads t fullContact  
nil mirrored nil shapeBoundingBox 100.0  
offset (0.0 0.0) rotation 0 undefineLineWidth  
0.0 negative t name "VCC"  
)
```

C) Delete a TOP parameter record.

Allegro SKILL Reference

Parameter Management Functions

```
axlDeleteObject("artwork:TOP")
```

3) Design (paramDesign) modification.

```
axlDBChangeDesignOrigin: change design origin
```

```
axlDBChangeDesignExtents: change extents
```

```
axlDBChangeDesignUnits: change units and/or accuracy
```

See Also

[Description of Database Objects on page 76.](#)

axlSetParam

```
axlSetParam (
  od_paramDbid
)
⇒ rd_paramDbid/nil
```

Description

This allows applications to modify certain aspects of Allegro parameters. After a parameter has been retrieved, attributes of it can be changed locally. Those changes can then be put back into the database using `axlSetParam`.

Arguments

`od_paramDbid` Parameter id returned from [axlGetParam](#). Modify the parameters to be changed then call `axlSetParam` function to update the database.

Value Returned

`rd_paramDbid` Returns the input parameter id if successful

`nil` Database was not modified.

Example

1. Change visibility (note it is easier to use [axlVisibleSet](#) to do this)

```
(setq etch_top (axlGetParam "paramLayerGroup:ETCH/paramLayer:TOP"))
=>param:123456
; is layer visible ?
etch->visible
t
; blank it
etch_top->visible = nil
t
(axlSetParam etch_top)
=>param:123456
; layer is now invisible
```

Allegro SKILL Reference

Parameter Management Functions

```
etch_top->visible  
nil
```

2. Change accuracy

```
p = axlGetParam("paramDesign")  
p->accuracy = 3  
axlSetParam(p)
```

Color Access

axlColorDoc

axlColorDoc

Description

Allegro supports two color access methods: pre-defined colors and Allegro database colors. Not all Allegro based programs support access to Allegro database colors. (This is only supported by the graphics editors.)

Pre-defined colors are set and accessed by their symbols:

- 'black
- 'white
- 'red
- 'green
- 'yellow
- 'blue
- 'multivalue - use `dfor` fields where value not the same
- 'button - current color of button faces (grey)

In addition, graphics editors support access to the colors used for Allegro layers. These are integer numbers.

AXL API calls such as `axlLayerGet("class/subclass")` or its primitive form

`axlGetParm("paramLayerGroup:<class>/paramLayer:<subclass>")`

return the current color setting of a layer via the color attribute call.

Example:

```
p = axlLayerGet("etch/top")
p->color      -> 2
```

These colors currently range between 1 and 24 with 0 reserved for the background color.

Allegro SKILL Reference

Parameter Management Functions

Interfaces supporting setting color are mostly form based. For there interfaces see:

- axlFormDoc
- axlFormColorize
- axlFormGridDoc
- axlGRPDoc

Notes

No AXL method is currently supported to allow you to change the red/green/blue (RGB) of Allegro database colors

We restrict the pre-defined colors to those defined to minimize use of colors to minimize problems with 8 bit color graphics on UNIX. When 24 (or higher) color cards become standard on UNIX, this will be relaxed.

Arguments

none

Value Returned

none

axlColorGet

```
axlColorGet(  
    x_number/'background  
) -> lx_rgb-nil  
  
axlColorGet(  
    'count)  
-> x_count  
  
axlColorGet(  
    'all)  
-> llx_rgb  
  
axlColorGet(  
    'pattern  
) -> x_count
```

Description

Get color palette. Supports the following modes:

- If passed, an index less the color count returns a list containing the red, green, blue palette values for that color index. These are integer values between 0 (no color and 255 (maximum color). For example, a value of 255 255 255 is white. Or if passed, '*background* returns the palette for the background.
- If given '*count* returns the current size of the database palette (currently always 24).
- If passed '*all* returns a list of list (red, green, blue) for all entire database palette EXCEPT the background.
- Returns number of patterns supported (includes default solid).

The color index is the number assigned to each layer in Allegro PCB Editor. (see axlVisibleGet).

Arguments

<i>x_number</i>	Color number.
' <i>background</i>	Get background color.
' <i>count</i>	Query current database color palette size.
' <i>all</i>	Get entire database color palette (except background).

Value Returned

<i>x_count</i>	Size of database palette.
<i>nil</i>	Error.
<i>lx_rgb</i>	A palette.
<i>lx_rgb</i>	The entire database palette.

See Also

[axlColorSet](#), [axlVisibleGet](#)

Examples

Get red/green/blue of color 2:

```
clr = axlColorGet(2)
```

Get background color:

```
bground = axlColorGet(`background)
```

Get number of colors:

```
cnt = axlColorGet(`count)
```

Get all red/green/blue color settings except background:

```
all = axlColorGet(`all)
```

Get number of display patterns supported

```
cnt = axlColorGet(`pattern)
```

axIColorShadowGet

```
axIColorShadowGet(  
    g_option  
) -> t/nil/x_percent
```

Description

Provides the options of shadow mode.

Arguments

g_option

'mode	Shadow mode status (<i>t</i> is on, <i>nil</i> is off).
'activeLayer	Active layer dimming enabled (<i>t</i>). This is called "Dim active layer in Options panel.
'highlight	This is called "Dim color assignments" in the Options panel
'percent	Current brightness percentage (0 to 100).
'custom	Custom colors, these are not shadowed.

Value Returned

t/nil Shadow or active layer mode on or off.

x_percent Brightness percentage.

See Also

[axIColorSet](#), [axIColorShadowSet](#)

Examples

Is shadow mode on:

```
axIColorShadowGet('mode)
```

Is shadow mode percent:

Allegro SKILL Reference

Parameter Management Functions

```
axlColorShadowGet('percent')
```

axlColorShadowSet

```
axlColorShadowSet(  
    g_mode  
    t/nil  
) -> t/nil  
  
axlColorShadowSet(  
    'percent  
    x_percentage  
) -> t/nil
```

Description

Sets the shadow mode options. These are equivalent to the color commands in the shadow mode box under the Display group.

The Mode Options are:

- The mode option is either `t` or `nil` to turn shadow mode on or off.
- The activeLayer option is either `t` or `nil` to automatically dim the active layer. This is called "Dim active layer in Options panel."
- The highlight can be `t` or `nil` to dim highlighted objects. This is called *Dim color assignments* in the Options panel.
- The percent option sets the dimness (0) to brightness (100) percentage.

Note: On graphics or display combinations, shadow values of less than 40 percent disappear into the background. For example, you have what appears to be black on black.

After you finish all the color changes, call `axlVisibleUpdate` to update the display.

This interface is disabled if you set the `display_noshadow` environment variable.

Arguments

`g_mode`

The possible values are:

- `'mode` – Enable or disable shadow mode.
- `'highlighted` – Enable or disable shadow mode for highlighted objects.
- `'activeLayer` – Enable or disable active layer dimming.
- `'percent` – Set shadow mode percentage (0 to 100)

Value Returned

t	If successful.
nil	An argument error.

See Also

[axlColorSet](#), [axlColorShadowSet](#), [axlVisibleUpdate](#)

Examples

Is shadow mode on:

```
axlColorShadowSet('mode t')
```

Is shadow mode percent:

```
axlColorShadowSet('percent 20')
```

axlColorLoad

```
axlColorLoad(  
    t_file/nil  
) -> t/nil
```

Description

Loads an Allegro PCB Editor color file (default .col file). Master color file is located at <cdsroot>/share pcb/text/lallegro.col.

File format is:

```
# Comment if in first column.  
#N Next line with a number is number of colors (currently only 24 is supported).  
This should appear first in the file.  
Number format  
#Number  
24  
#B - next line with a number is background color. This should appear after color  
number. Format of color line must be:  
(name is currently ignored):  
0 <red> <green> <blue> [<name>]  
EXAMPLE of background format setting it to black  
#Background Color  
0      0      0      0  
#I - next set of lines sets the colors. These should always appear last in the file.  
We will read until the first color number that exceeds the color number (currently  
hardcoded as 24) or the end of file is reached. The order the colors appear in the  
file determines the initial color [priority (highest (first) to lowest (last))].  
Format is:  
<color number> <pen number> <red> <green> <blue> [<name>]  
EXAMPLE:  
1      1      255      255      255      White  
2      2      14       210      255      LtBlue  
<color number>: entry in color table. This is the color number referenced by the  
allegro subclass (axlLayerGet)  
<pen number>: Used by Allegro plot (UNIX) to control what pen to use during  
plotting. Not applicable on Windows.  
<red> intensity of red to blend into color 0 to 255  
<green> intensity of green to blend into color 0 to 255  
<blue> intensity of blue to blend into color 0 to 255  
<name> (optional) name of color, currently not used by Allegro but sigxp takes  
advantage of the name to auto-assign colors.
```

Allegro SKILL Reference

Parameter Management Functions

Call `axlVisibleUpdate` to update the display after you finish manipulating the colors.

In Allegro PCB Editor, you need the color file to start a new design. Opening existing databases uses the color table stored in that database. A new database created, when Allegro PCB Editor is already running, copies the color table from the previous database.

Arguments

<code>s_file</code>	Color file name to load.
<code>nil</code>	Uses <code>lallegro.col</code> . If no directory path, Allegro PCB Editor uses the <code>LOCALPATH</code> environment variable to find the file.

Value Returned

<code>t</code>	If loaded file.
<code>nil</code>	File not found or error in loading file.

Example

Load user-defined default color. Overriding and setting current board values:

```
axlColorLoad(nil)  
axlVisibleUpdate(t)
```

See Also

[axlColorSave](#), [axlColorSet](#).

axlColorOnGet – Obsolete Command

```
axlColorOnGet(  
    g_item  
) -> t
```

Description

This function is obsolete. Due to change in display model, switching off colors is no longer supported.

Arguments

Ignored

Value Returned

always *t*

axlColorOnSet – Obsolete Command

```
axlcolorOnSet(  
    g_item  
    g_state  
) -> t
```

Description

This is an obsolete command. Due to changes in the viewing model, now you cannot turn off a color in Allegro PCB Editor.

Arguments

Items are ignored.

Value Returned

t	Success always.
---	-----------------

axlColorPriorityGet – Obsolete Command

```
axlColorPriorityGet(  
    g_item  
    [g_item2]  
) -> nil
```

Description

Due to the changes in color model of Allegro PCB Editor, this command is now obsolete. Instead of this command, use [axlLayerPriorityGet](#).

Arguments

Items are ignored.

Value Returned

nil

See Also

[axlColorSet](#)

axlColorPrioritySet – Obsolete Command

```
axlColorPrioritySet(  
    g_item  
    [g_item2]  
) -> t
```

Description

Due to the changes in color model of Allegro PCB Editor, this command is now obsolete. Instead of this command, use [axlLayerPrioritySet](#).

Arguments

Items are ignored.

Value Returned

t

See Also

[axlColorSet](#)

axlColorSave

```
axlColorSave(  
    t_file/nil  
) -> t/nil
```

Description

Saves current design colors to specified file.

Argument

t_file File name. If nil; saves to <HOME>/pcbenv/lallegro.col.
 If no extension, uses .col extension.

Value Returned

t Successful.

nil Failed to save.

EXAMPLES

Save current design color settings:

```
axlColorSave( "mycolor" )
```

See Also

[axlColorSave](#),[axlColorSet](#)

axlColorSet

```
axlColorSet(  
    x_number / 'background  
    l_rgb  
) -> t/nil  
  
axlColorSet(  
    'all  
    ll_rgb  
) ->t/nil
```

Description

Sets red, green, blue palette for a color number or background.

Modes supported:

- Color number (*x_number*) and red/green/blue list. *x_number* must be between one and axlColorGet ('count), or 'background sets red/green/blue as the background color.
- 'all takes a list of red/green/blue values and sets colors starting at one to the end of the list. Intended to use with axlColorGet ('all) to save or restore color values.

Red/green/blue colors are values between 0 (least intensity) to 255 (maximum intensity).

After color changes are made, call axlVisibleUpdate to update the display.

Color model:

A color (or colorNumber) in Allegro PCB Editor has the following attributes:

- A palette of red, green and blue values between 0 and 255. 0 adds none of the primary color to the mixture while 255 adds the maximum. For example, 0, 0, 0 is black and 255, 255, 255 is white. The color mixture is controlled using the palette section of the color command.
- Each color number can be assigned to a layer. Multiple layers will have the same color number, because there are more layers than colors.
- Allegro PCB Editor supports setting a background palette value. Grids, ratsnest, temporary highlight can have a color number assigned via axlDBControl.

Color services:

axlColorSet	This routine.
-------------	---------------

Allegro SKILL Reference

Parameter Management Functions

axlColorGet	Get red, green, or blue of one or more color numbers.
axlColorShadowGet	Shadow mode options.
axlColorShadowSet	Set shadow mode options.
axlLayerPrioritySet	set a layer to a display priority
axlLayerPriorityGet	get a layer's current priority
axlLayerPriorityClearAll	clear all layer priorities (restore to default)
axlLayerPrioritySaveAll	save existing priority table
axlLayerPriorityRestoreAll	restore saved priority table
axlColorSave	Save color values to file.
axlColorLoad	Load color values from file.
axlUIColorDialog	Standard color chooser dialog box.
axlDBControl	Miscellaneous color number assignments (for example, highlight).
axlLayerGet	Get layer (class/subclass) attributes (control color) number and visibility for individual layers.
axlLayerSet	Set color number or visibility for a layer.
axlVisibleLayer	Set visibility of layer.
axlIsVisibleLayer	Provides the layer visibility.
axlVisibleGet	Get visibility set for design.
axlVisibleSet	Set visibility set for design.
axlVisibleDesign	Global design visibility control.
axlVisibleUpdate	Update windows with color changes.

Allegro SKILL Reference

Parameter Management Functions

Arguments

<i>x_number</i>	Color index.
'background	Set background color.
'all	Set colors based upon a list starting at color number one.
<i>l_rgb</i>	Red/green/blue lists; three integers.
<i>ll_rgb</i>	Lists of red/green/blue values.

Value Returned

<i>t</i>	Successful.
nil	An error; wrong arguments: color number is less than one or greater than maximum.

EXAMPLES

Set color number three same as color two:

```
clr = axlColorGet(2)
axlColorSet(3 clr)
axlVisibleUpdate(nil)
```

Set first three colors:

```
axlColorSet('all '((10 10 10) (40 40 40) (100 100 100)))
```

axlCVFColorChooserDlg

```
axlCVFColorChooserDlg(  
    [x_color_index]  
    [g_show_hilite]  
    [x_hilite_flag]  
    [x_bitmap_index]  
)  
==> t/nil
```

Description

Displays color palette modal dialog. Color wells reflect current design colors.

Arguments

<i>x_color_index</i>	Color index to initialize palette dialog. Values 0 to 191.
<i>g_show_hilite</i>	Specifies whether or not the highlight check box is to be displayed. If the value is set to: <ul style="list-style-type: none">■ <i>t</i> – displays the highlight check box.■ <i>nil/default</i> – highlight check box is not displayed.
<i>x_hilite_flag</i>	Highlight state to initialize highlight check box (if displayed). Pass 1 or 0.
<i>x_bitmap_index</i>	Bitmap index to initialize palette dialog. Values 0 to 15.

Value Returned

<i>list</i>	containing one or two int values for user color palette selection and highlight check box selection. if <i>g_show_hilite</i> is not <i>nil</i> , <i>list</i> contains the two values, or else <i>list</i> contains color index only.
<i>nil</i>	if user cancels the form or error occurred.

axlClearObjectCustomColor

```
axlClearObjectCustomColor(  
    [lo_dbid]  
)  
==> t/nil
```

Description

Clear custom color of dbids

Arguments

lo_dbid: List of dbids to clear custom color.

Value Returned

t/nil: Returns *t* if at least one object custom color was cleared.

Returns *nil* otherwise.

Examples

See *axlCustomColorObject* for examples

See Also

[axlCustomColorObject](#)

axlCustomColorObject

```
axlCustomColorObject(  
    [lo_dbid]  
    [g_custom_color]  
)  
==> t/nil
```

Description

Custom color the provided dbid or list of dbids. Objects supported are nets, symbol instances, pins, and external DRCs.

Arguments

<i>od_dbid</i>	list of DBIDS or one DBID
<i>g_custom_color</i>	Color index to be used to set custom color. If the value is <i>nil</i> , perm highlight will be used.

Value Returned

<i>t</i>	Something was custom colored.
<i>nil</i>	No valid dbids.

See Also

[axlClearObjectCustomColor](#), [axlDBControl](#), [axlIsCustomColored](#)

Example

The example covered in this section uses `axlCustomColorObject` and `axlClearObjectCustomColor` functions to respectively, set and clear custom color of database elements during interactive commands.

The following example does the following:

- Defines the function `highlight` Loop.
- Loops on the function `axlSelect` gathering user selections to set/clear custom color.

Allegro SKILL Reference

Parameter Management Functions

- Custom colors objects using color 4.
- Waits then clears custom color.

The command can be stopped at any time by selecting Cancel or Done from the pop-up menu.

```
(defun customColorLoop ()  
    axlSetFindFilter( ?enabled '("noall" "alltypes" "nameform")  
    ?onButtons "alltypes")  
    while( axlSelect()  
        axlCustomColorObject( axlGetSelSet() 4)  
        checkColor = axlIsCustomColored( car(axlGetSelSet()) )  
        axlSleep(1)  
        axlClearObjectCustomColor( axlGetSelSet())  
    )  
)
```

axILayerPriorityClearAll

```
axILayerPriorityClearAll(  
    ) -> t/nil
```

Description

Clears all layer priority information in Allegro database. Use [axILayerPrioritySet](#) for usage.

Arguments

None

Value Returned

t : success

See Also

[axILayerPrioritySaveAll](#), [axILayerPriorityRestoreAll](#)

axILayerPriorityGet

get layer's priority

```
axlLayerPriorityGet(  
    t_layer  
) -> x priority/t mapClass/nil
```

Description

Obtains layer priority, where 0 is normal (not set). Priority can range from 1 (highest) to 255 (lowest).

Depending on the argument value, the function operates in two modes:

- if t_layer is layer name (class / subclass), returns priority of that layer as an integer
 - if t_layer is class name then returns the mapped layer

Note: Mapped layer groupings may change from release to release (e.g. future releases may choose to break up some class groupings).

Argument

t_layer layer name (<class>/<subclass>) or class name (<class>)

Value Returned

- `x_priority` - priority of layer (0 layer draws at normal priority)
 - `t_mapClass` - class name used as lead group for provided class
 - `nil` - error in layer name

See Also

axILayerPrioritySet

Examples

- ### ■ Get and fetch priority

```
axlLayerPrioritySet("BOARD GEOMETRY/OUTLINE" 1)  
prior = axlLayerPriorityGet("BOARD GEOMETRY/OUTLINE")
```

Allegro SKILL Reference

Parameter Management Functions

- Get group class mapping of class Ref Des

```
axlLayerPrioritySet("REF DES") -> "COMPONENT VALUE"
```

axILayerPriorityRestoreAll

```
axILayerPriorityRestoreAll(  
    ) -> t/nil
```

Description

Restores previously saved layer priority information. This function only works if a call to [axILayerPrioritySaveAll](#) has been done already.

Arguments

None

Value Returned

t : success

nil : nothing to restore.

See Also

[axILayerPrioritySaveAll](#), [axILayerPriorityClearAll](#)

axlLayerPrioritySaveAll

```
axlLayerPrioritySaveAll(  
    ) -> t/nil
```

Description

Saves all layer priority information to be restored later. Until a [axlLayerPriorityRestoreAll](#) is called, any subsequent calls to this function are no-op.

Arguments

None

Value Returned

t : success

nil : this function has been called already but
axlLayerPriorityRestoreAll has not been called yet.

See Also

[axlLayerPriorityClearAll](#), [axlLayerPriorityRestoreAll](#)

axlLayerPrioritySet

```
axlLayerPrioritySet(  
    t_layer  
    x_priority  
) -> t/nil
```

Description

This changes the drawing priority of given layer. Priority is from 1 (highest) to 255 (lowest). Layers without priority in standard drawing order below all priority layers. The active layer is always drawn first.

Only one layer may be at a priority level, thus adding a new layer at a priority replaces the existing layer at that priority. For example, executing following line of code results in just the ASSEMBLY_TOP being drawn at priority 1 and OUTLINE returning to normal drawing order.

```
axlLayerPrioritySet( "BOARD GEOMETRY/OUTLINE" 1)  
axlLayerPrioritySet( "PACKAGE GEOMETRY/ASSEMBLY_TOP" 1)
```

From priority level 1 each level must be set for lower priority levels to be enabled. For example, if you set a layer to priority level 2 but leave level 1 empty then level 2 is disabled until level 1 is assigned.

Classes may be grouped together in a class group with one class being the lead of that group. For example, all etch layers (ETCH, PIN, etc.) are mapped together into the stack-up group with class ETCH the lead. You can set the priority using class names but you cannot prioritize the different stack-up layers individually. This interface automatically maps a class name to its class group (see [axlLayerPriorityGet](#) to determine groupings).

You should do a [axlVisibleUpdate](#) after changing layer priority to have the display updated.

Note: Priority value of 0 means remove layer priority of the layer.

Arguments

<i>x_layer</i>	layer name (i.e. "ETCH/TOP")
<i>x_priority</i>	priority value in the range of 1-255 and 0 means remove.

Value Returned

<i>t</i>	success
----------	---------

nil error in one of the arguments

Examples

Set priority for class BOARD GEOMETRY and subclass OUTLINE:

```
axlLayerPrioritySet("BOARD GEOMETRY/OUTLINE" 1)
```

To temporarily force a set of layers to display on top, you should take the following steps:

- ❑ save existing layer table,
- ❑ clear existing layer priorities
- ❑ set your layer priorities
- ❑ draw objects
- ❑ restore old layer priority:

```
axlLayerPrioritySaveAll()  
axlLayerPriorityClearAll()  
axlLayerPrioritySet() -- multiple times if needed  
axlLayerPriorityRestoreAll()
```

See Also

[axlLayerPriorityClearAll](#), [axlLayerPrioritySaveAll](#), [axlLayerPriorityRestoreAll](#),
[axlLayerPriorityGet](#), [axlMapClassName](#), [axlVisibleUpdate](#)

axlIsCustomColored

```
axlIsCustomColored (
  o_dbid
)
==> x_customColor/nil
```

Description

If object has custom color, will return the object custom color, otherwise nil.

Arguments

o_dbid An dbid for which custom color information is desired.

Value Returned

x_customColor custom color or nil if object has no custom color or object does not support custom color.

See Also

[axlCustomColorObject](#)

Database Layer Management

These functions allow easier access to layer attributes.

axlClasses

```
axlClasses(  
    ) -> lt_classes
```

Description

Return list of classes. This is actually just:

```
axlGetParam("paramLayerGroup")->groupMembers
```

Arguments

Nothing

Value Returned

list of class strings

See Also

[axlSubclasses](#), [axlGetParam](#), [axlMapClassName](#)

Examples

```
axlClasses()
```

axlDBGetLayerType

```
axlDBGetLayerType  
  t_layerName  
)  
=> t_layertype/nil
```

Description

Retrieves the cross-section type of a given layer. This may be (Layer Type in define xsection form): CONDUCTOR, CROSSOVER, DIELECTRIC, PLANE, BONDING WIRE, MICROWIRE, MULTIWIRE, OPTICAL WAVE GUIDE, or THERMAL GLUE COATING.

Arguments

t_layername Layername is <*class*>/<*subclass*>.

Value Returned

t_layertype Layer type string.

nil Layer is invalid.

Example

```
axlDBGetLayerType("ETCH/TOP") => "BONDING_WIRE"
```

axlGetXSection

```
axlGetXSection(  
)  
==> l_layers/nil
```

Description

Returns a list of all layers in the cross section found in the current drawing.

Notes

Both *t_SignalDieConstant* and *t_SignalLossTangent* are the values for dielectric material between traces on signal layers. Beginning with 15.0, a property stores the *dieConst/LossTan* for dielectric material on signal layers.

The dielectric material properties from the dielectric layer above (toward the closest surface) is used as the dielectric material between signal traces unless the design property SQ_STRIPLINE_DIELECTRIC is set. Then this defines the material, dielectric constant, and loss tangent to be used for non-plane, non-surface conductor layers. Surface layers always look to the outside for their dielectric.

If the property is missing, invalid, or the material in the property is set to _LS_AUTOMATIC_, then the *t_SignalDieConstant* and *t_SignalLossTangent* values are set to match those of the adjacent dielectric (looking toward the closest surface).



New releases may add to the list of data returned for each layer. These items will be added at the end of the list. Added items:

16.01 - g_freqDepFileName

Values Returned

An ordered skill list of layers in the board's cross section. A list of the following format defines each layer:

```
(t_name t_type t_material t_thickness t_thermalCond t_elecCond  
t_dielectricConst y_artworkNeg y_shield t_lossTangent  
t_usage t_SignalDieConstant t_SignalLossTangent g_freqDepFileName)
```

where:

Allegro SKILL Reference

Parameter Management Functions

<i>t_name</i>	Layer name.
<i>t_type</i>	Layer type.
<i>t_material</i>	Layer material.
<i>t_thickness</i>	Layer thickness.
<i>t_thermalCond</i>	Layer thermal conductivity.
<i>t_elecCond</i>	Layer electrical conductivity.
<i>t_dielectricConst</i>	Layer dielectric constant.
<i>y_artworkNeg</i>	Indicates whether the artwork for the layer is negative.
<i>y_shield</i>	Indicates whether the layer is a shield layer.
<i>t_lossTangent</i>	Layer loss tangent (valid for dielectrics only).
<i>t_usage</i>	Layer usage (that is, IC RDL or DRIVER layers)
<i>t_SignalDieConstant</i>	Dielectric between traces on interior signal layers (or <i>nil</i>).
<i>t_SignalLossTangent</i>	Dielectric between traces on interior signal layers (or <i>nil</i>).
<i>g_freqDepFileName</i>	Defines the name of the frequency-dependent data file for the file; <i>nil</i> if no file name is defined for this layer.
<i>t_etchFactor</i>	Defines the etch factor for this layer which is in degrees.

Note: The *t_SignalDieConstant* and *t_SignalLossTangent* are *nil* on PLANE and dielectric layers. If an error occurs, returns *nil*.

axlIsLayer

```
axlIsLayer(  
    t_layer  
)  
⇒ t/nil
```

Description

Determines if the *t_layer* exists. *t_layer* is a fully qualified layer name.

Arguments

<i>t_layer</i>	Name of layer in format “<class>/<subclass>.”
----------------	---

Value Returned

t	Layer exists.
---	---------------

nil	Layer does not exist.
-----	-----------------------

axlIsVisibleLayer

```
axlIsVisibleLayer(  
    t_layer  
)  
⇒ t/nil
```

Description

Returns the visibility (t/nil) of a fully qualified layer.

Arguments

t_layer Name of layer in format "<class>/<subclass>".

Value Returned

t Layer is visible.

nil Layer is invisible or not present.

Example

```
axlIsVisibleLayer("pin/top") ⇒ t
```

axILayerCreateCrossSection

```
axILayerCreateCrossSection (
    t_Prev_layerName
    t_layerType
    t_materialType
    [t_subclassName]
    [t_planeType]
)
⇒ t/nil
```

Description

Adds a new cross-section layer to the design.

If *t_subclassName* is *nil* then an unnamed dielectric layer is created. It is suggested that you create unnamed dielectric layers if they are only required for signal analysis and board thickness calculations since using a name will create ETCH layer in the design.

Arguments

<i>t_Prev_layerName</i>	Name of the layer above which the new layer is to be added
<i>t_layerType</i>	Type of layer to be added, such as Conductor or Surface.
<i>t_materialType</i>	Material of the layer.
<i>t_subclassName</i>	Optional parameter. Name of the new layer.
<i>t_planeType</i>	Optional parameter. Type of plane, either Positive or Negative. The default is Positive.

Value Returned

<i>t</i>	Layer is created or already exists.
<i>nil</i>	Layer does not exist and could not be created.

See Also

[axILayerCreateNonConductor](#), [axILayerGet](#)

Example

```
axlLayerCreateCrossSection("Bottom""Conductor"  
    "Copper" "New_Layer" "Positive");
```

Creates a conductor layer with these characteristics:

- Located above a layer subclass called Bottom
- Has copper layer material
- Has a subclass name New_Layer
- Positive plane

axlLayerCreateNonConductor

```
axlLayerCreateNonConductor(  
    t_layerName  
)  
⇒ t/nil
```

Description

Creates a new subclass for non-etch subclasses. AXL-SKILL restricts you from creating etch subclasses.

Arguments

t_layerName *<class>/<subclass>*

Value Returned

t New subclass is created or, subclass already exists.

nil New subclass is not created.

Example

```
axlLayerCreateNonConductor("BOARD GEOMETRY/MYSUBCLASS")
```

Creates a new subclass named MYSUBCLASS.


axlLayerGet

```
axlLayerGet(  
    t_layer  
)  
⇒ o_dbid/nil
```

Description

Gets the layer parameter given the shortcut notation of <class>/<subclass>. This is an ease of use function that does:

```
axlGetParam("paramLayerGroup:<class>/paramLayer:<subclass>")
```



Tip

You can use the groupMembers attribute of result —

result=axlGetParam("paramLayerGroup:<class>") — to iterate over all subclass of a class.

Arguments

t_layer Name of layer in format "<class>/<subclass>".

Value Returned

o_dbid Layer parameter *dbid*.

nil Layer is not present.

See Also

[axlGetParam](#)

Example

Changes color of top etch layer.

```
q = axlLayerGet( "ETCH/TOP" )  
q->color = 7  
axlLayerSet(q)  
axlVisibleUpdate(t)
```

axlVisibleDesign

```
axlVisibleDesign(  
    g_makeVis  
)  
⇒ t/nil
```

Description

Makes entire design visible or invisible. This command does not visually change the display, since it can also be used in conjunction with the `axlSelect` command family to provide additional filtering of the database objects. If you wish to visually update the display, call `axlUIWUpdate(nil)` after changing the visibility.

Note: This routine along with `axlVisibleGet` and `axlVisibleSet` allows you to temporarily change the visibility of the design to provide additional filtering capability when finding objects via the selection set. The programming model is:

```
saveVis = axlVisibleGet()  
axlVisibleDesign(nil)  
; set desired layers visible via one or more calls to  
axlVisibleLayer(...)  
; set find filter for objects to find  
axlSetFindFilter(...)  
; find objects by using one of the Select APIs .. example  
axlAddSelectAll()  
objs = axlGetSelSet()  
  
; restore visibility  
axlVisibleSet(saveVis)  
; note no need to make a call to axlVisibleUpdate because  
; the visisbility changes are a wash
```

Arguments

g_makeVis Either `t` or `nil`.

`t` = make entire design visible

`nil` = make entire design invisible

Value Returned

t Design made visible or invisible as specified.

nil Should never be seen.

See Also

[axlVisibleUpdate](#) and [axlIsVisibleLayer](#)

Note: This command does not visually change the display. To visually update the display, call `axlUIWUpdate (nil)` after changing the visibility.

axlVisibleGet

```
axlVisibleGet(  
)  
⇒ l_visList/nil
```

Description

Returns the visibility of the entire design - which layers are visible/invisible.

Arguments

None.

Value Returned

l_visList List of lists. The format is for each class:

```
(nil class <t_className> visible t/nil/-1  
subclassinfo <l_subclass>)  
....)  
l_subclass format:  
((<t_subclass> t/nil) ....)  
where t/nil/-1  
t - visible  
nil - invisible  
-1 - class has both visible and invisible components.
```

Note: Any change in the structure of *l_vislist* affects `axlVisibleSet`, this function's complementary function.

Example

```
visList = axlVisibleGet()  
(  
(nil class "BOARD GEOMETRY" visible nil subclassinfo nil)  
(nil class "COMPONENT VALUE" visible nil subclassinfo nil)  
(nil class "DEVICE TYPE" visible nil subclassinfo nil)  
(nil class "DRAWING FORMAT" visible nil subclassinfo nil)  
(nil class "DRC ERROR CLASS" visible t subclassinfo nil)  
(nil class "ETCH" visible -1  
subclassinfo  
(("TOP" t)  
("TRACE_2" nil)  
("TRACE_3" nil))
```

Allegro SKILL Reference

Parameter Management Functions

```
("BOTTOM" t)
))
(nil class "MANUFACTURING" visible nil subclassinfo nil)
(nil class "ANALYSIS" visible nil subclassinfo nil)
(nil class "PACKAGE GEOMETRY" visible nil subclassinfo nil)
(nil class "PACKAGE KEEPIN" visible t subclassinfo nil)
(nil class "PACKAGE KEEPOUT" visible nil subclassinfo nil)
(nil class "PIN" visible t subclassinfo nil)
(nil class "REF DES" visible nil subclassinfo nil)
(nil class "ROUTE KEEPIN" visible t subclassinfo nil)
(nil class "ROUTE KEEPOUT" visible nil subclassinfo nil)
(nil class "TOLERANCE" visible nil subclassinfo nil)
(nil class "USER PART NUMBER" visible nil subclassinfo nil)
(nil class "VIA CLASS" visible nil subclassinfo nil)
(nil class "VIA KEEPOUT" visible nil subclassinfo nil)
)
```

Returns the visibility of the entire design.

axlVisibleLayer

```
axlVisibleLayer(  
    t_layer  
    g_makeVis  
)  
⇒ t/nil
```

Description

Sets a given layer to visible or invisible. If given only a class name, sets the entire layer to visible or invisible. If you want to update the display, call `axlVisibleUpdate` when finished with your layer visibility updates.

Arguments

<i>t_layer</i>	Name of the layer. Either a fully qualified layer name in the format <code><class>/<subclass></code> or a class name in the format <code><class></code> .
<i>g_makeVis</i>	Either <code>t</code> or <code>nil</code> . <code>t</code> = make visible <code>nil</code> = make invisible.

Value Returned

<code>t</code>	Layer set to visible or invisible as specified.
<code>nil</code>	Layer does not exist.

See Also

[axlVisibleUpdate](#)

Note: This command does not visually change the display. To visually update the display, call `axlUIWUpdate (nil)` after changing the visibility.

axlVisibleSet

```
axlVisibleSet(  
    l_visList  
)  
⇒ t/nil
```

Description

Sets the visibility of the entire design.

Arguments

l_visList List with visibility attributes.

Value Returned

t Set the visibility of the design as specified.

nil Incorrect format for *l_visList*.

See Also

[axlVisibleUpdate](#) and [axlVisibleLayer](#)

Note: This command does not visually change the display. To visually update the display, call `axlUIWUpdate (nil)` after changing the visibility.

axlConductorBottomLayer

```
axlConductorBottomLayer(  
)  
⇒ t_name
```

Description

Returns the name of the bottom conductor layer.

Arguments

none

Value Returned

<i>t_name</i>	Name of the bottom conductor layer.
---------------	-------------------------------------

Example

```
axlConductorBottomLayer()  
⇒ "BOTTOM"
```

axlConductorTopLayer

```
axlConductorTopLayer()  
⇒ t_name
```

Description

Returns the name of the top conductor layer.

Arguments

none

Value Returned

t_name	Name of the top conductor layer.
--------	----------------------------------

Example

```
axlConductorTopLayer()  
⇒ "TOP"
```

axlDBCreateFilmRec

```
axlDBCreateFilmRec(  
    t_filmname  
    n_rotate_code  
    n_x_offset  
    n_y_offset  
    n_undef_line_width  
    n_shape_bound  
    n_plot_mode  
    n_mirrored  
    n_full_contact  
    n_supp_unconnect  
    n_draw_pad  
    n_aper_rot  
    n_fill_out_shapes  
    n_vector_based  
)  
⇒ t_name/nil
```

Description

Creates a film record with parameters and visible layers specified.

[Example 1](#) on page 190 shows a common use of this function through the film control form's film record *load* option, which calls axlfcreate using the following form:

```
(axlfcreate t_name l_params l_vis)
```

The axlfcreate call includes these arguments and passes all parameters needed as arguments to axlDBCreateFilmRec:

<i>t_name</i>	Name of the record to be created, of the form "NAME"
<i>l_params</i>	List consisting of 13 numbers, of the form '(0 0 0 ...), which correspond to the <i>Film Options</i> fields in the film control form.
<i>l_vis</i>	The list of visible layers, each layer enclosed in quotes, space delimited, of the form '("ETCH/TOP" "VIA/TOP" ...)

axlfcreate first makes the specified layers visible, then calls axlDBCreateFilmRec, providing the filmname and the 13 numbers it was passed as *l_params*.

Allegro SKILL Reference

Parameter Management Functions

Arguments

<i>t_filmname</i>	The name of the film record to create.
<i>n_rotate_code</i>	0, 2, 4, or 6, corresponding to 0, 90, 180, or 270 degree rotation.
<i>n_x_offset</i>	Film record block origin x offset.
<i>n_y_offset</i>	Film record block origin y offset.
<i>n undef_line_width</i>	Film record undefined line width.
<i>n_shape_bound</i>	Shape bounding box size.
<i>n_plot_mode</i>	Film record plot mode -- 0 = NEGATIVE, 1 = POSITIVE.
<i>n_mirrored</i>	Flag denoting mirroring.
<i>n_supp_unconnect</i>	Indicator to not flash unconnected pads
<i>n_draw_pad</i>	Indicator to draw pads.
<i>n_aper_rot</i>	Boolean indicator for aperture rotation.
<i>n_fill_out_shapes</i>	Boolean indicator to fill outside shapes. This is the opposite of the “suppress shape fill” switch in the film control form, for example, if suppress shape fill is selected, <i>fill_out_shapes</i> should be 0. This is named this way because <i>art_film_block_type</i> structures have <i>fill_out_shapes</i> fields instead of <i>suppress_shape_fill</i> fields.
<i>n_vector_based</i>	Boolean indicator for vector-based pad behavior.

Value Returned

<i>t_name</i>	Name of the film record created.
<i>nil</i>	Failure to create the film record.

Allegro SKILL Reference

Parameter Management Functions

Example 1

```
(axlfcreate "TRACE_2" '(0 0 0 0 0 1 0 0 0 0 0 0 1) '("ETCH/TRACE_2" "PIN/TRACE_2"  
"VIA CLASS/TRACE_2" ))
```

- Called through film control form

Call the film control form's film record *save* option, which creates a .txt file.

axlfcreate changes layer visibility and calls axlDBCreateFilmRecord as shown:

```
(axlDBCreateFilmRecord "TRACE_2" 0 0 0 0 0 1 0 0 0 0 0 0 1)
```

Select the */load* option, which evaluates the contents of the file, calling axlfcreate.

Example 2

```
(axlDBCreateFilmRecord "TOP" 0 0 0 0 0 0 0 0 0 0 0 0 0)
```

Creates a film record TOP with current visible layers and fields initialized to 0/false/default:

axlSetPlaneType

```
axlSetPlaneType(  
    t_subclassName  
    t_planeType  
)  
⇒ t/nil
```

Description

This changes the photoplot type of a conductor or plane type layer between positive or negative artwork. Changing a layer already containing data will require re-voiding existing shapes and updating DRC.

Arguments

<i>t_subclassName</i>	Subclass name whose plane type is to be changed.
<i>t_planeType</i>	Plane type (“Positive”, “Negative”)

Value Returned

t	Plane type changed.
nil	Plane type is not changed.

See Also

[axlGetParam](#), [axlSetParam](#)

axlSubclasses

```
axlSubclasses (
    t_class
    ?field s_name
    ?value g_value
) -> lt_subclasses
```

Description

Lists subclasses that make up a class. This function is supported in both, APD and Allegro name space. The field and value options provide additional filtering based upon the characteristics of the layer.

The information about the attributes and values permitted on a layer, can be obtained using the following function.

```
axlLayerGet ("MANUFACTURING/PROBE_TOP") ->??
```

You should map the class name via axlMapClassName if you are writing code for both PCB and APD/SIP as certain class names are different in these products.

The base call is actually just:

```
axlGetParam ("paramLayerGroup:ETCH") ->groupMembers
```

Arguments

<i>t_class</i>	Class name.
<i>field</i>	Optional field for filtering. If value option is not present filters on basis of a non-nil value.
<i>value</i>	Optional value of field to use for filtering. Requires field option to be passed.

Values Returned

<i>lt_subclasses</i>	A list of subclass strings.
----------------------	-----------------------------

See Also

[axlSubclassRoute](#), [axlGetParam](#), [axlMapClassName](#), [axlClasses](#)

Example

- get all subclasses on class

```
axlSubclasses( axlMapClassName ("MANUFACTURING") )
```

- get user defined subclasses

```
axlSubclasses ("MANUFACTURING" ?field 'userDefined)
```

- all allegro defined

```
axlSubclasses ("MANUFACTURING" ?field 'userDefined ?value nil)
```

axlSubclassRoute

```
axlSubclassRoute(  
    ?field s_name  
    ?value g_value  
) -> lt_subclasses
```

Description

Lists subclasses that make up class ETCH.

If no arguments are passed to the function, it returns a list of subclasses in the ETCH class, or CONDUCTOR class, in case of non-PCB product.

The field and value options provide additional filtering based upon the characteristics of the layer. For information on layer parameters, see the section Layer Parameter Attributes (Allegro Subclasses).

The information about the attributes and values permitted on a layer can be obtained using the following command.

```
axlLayerGet( "ETCH/TOP" ) ->??
```

The base call is actually just:

```
axlGetParam("paramLayerGroup:ETCH") ->groupMembers
```

Arguments

field Optional field for filtering. Uses the value specified by the **value** argument to filter subclasses.

value Optional value of field to use for filtering. Requires **field** option to be passed.

Values Returned

List of subclass as strings.

See Also

[axlSubclasses](#), [axlGetParam](#)

Example

- all etch subclasses

```
axlSubclassRoute() -> ("TOP" "GND" "VCC" "BOTTOM")
```

- all subclasses that are of type etch

```
axlSubclassRoute(?field 'isEtch)
```

- all subclasses that are not etch (e.g dielectric)

```
axlSubclassRoute(?field 'isEtch ?value nil)
```

- all subclasses with material FR-4

```
axlSubclassRoute(?field 'material ?value "FR-4")
```

Allegro SKILL Reference
Parameter Management Functions

Selection and Find Functions

Overview

AXL edit functions such as move or delete operate on database object *dbids* contained in the *select set*. The select set is a list of one or more object *dbids* you have previously selected. You add *dbids* to the select set with the axlSelect functions described in this chapter. You use the select set as an argument in any edit function calls. This differs from interactive Allegro PCB Editor edit commands, where you first start a command, then select the objects to be edited. One advantage of a select set is that selected object *dbids* stay in the select set from function to function until you explicitly change it. You can perform multiple edits on the same set of objects without reselecting. Remember, however, that edit functions might cause *dbids* to go out of scope. This chapter also describes functions for managing the select set and controlling the selection filter.

AXL supports one active select set. The contents of the select set becomes invalid when you exit Allegro PCB Editor.

The interactive select functions find objects only on visible layers.

You can do the following with the selection functions:

- Set the Find Filter to control the types of objects selected
- Select objects at a single point, over an area, or by name
- Select parts of objects, such as individual pins of a package symbol
- Add or remove *dbids* from the select set

A select set can contain *dbids* of parts of a figure without containing the figure itself. For example, you can select one or more pins of a symbol or individual segments of a path figure. See [Chapter 2, “The Allegro PCB Editor Database User Model.”](#) for a list of Allegro PCB Editor figure types.

You can add figure *dbids* to the select set interactively with a mouse click on the figure (point selection) or by drawing a box that includes the figure (box selection). The **Find Filter**

controls filtering for specific object types. This chapter describes AXL–SKILL functions to set the filter for any object type.

All coordinates are in user units unless otherwise noted.

Select Set Highlighting

Objects in the select set are displayed as highlighted when control passes from SKILL to you for interactive input (for selection) or when SKILL returns control to the Allegro PCB Editor shell. You can select and modify objects using AXL–SKILL functions. To keep these objects from displaying as highlighted, remove them from the select set before returning SKILL control to you for interactive input or to the Allegro PCB Editor shell.

Select Modes

AXL provides two select modes:

single	Selects one or a group of objects that match the selection criteria. When you select an object in this mode, AXL deselects any objects previously in the select set.
cumulated	Adds to or subtracts from the select set one or a group of objects that match the selection criteria. Add cumulated mode never adds an object already in the set, so you do not have duplicate entries if you mistakenly select the same object twice. Subsequent selects of the same object are ignored.

Finding Objects by Name

The `axlSingleSelectName`, `axlAddSelectName`, and `axlSubSelectName` functions find objects by using their names. You can search for the following Allegro PCB Editor object types by name:

NET	List of net names for net selection.
COMPONENT	List of reference designators for component instance selection.
SYMBOL	List of reference designators for symbol instance selection.
FUNCTION	List of function designators for function instance selection.

Allegro SKILL Reference

Selection and Find Functions

DEVTYPE	List of device type for component or symbol instance selection. **
SYMTYPE	List of symbol types for symbol instance selection.
REFDES"	List of reference designators for component or symbol instance selection. **
DEVSYM	List of device type for symbol instance selection.
GROUP	List of group names for group or group member selection.
PROPERTY	List of property names or property value) lists for selection of database object that have the property/value. If no value is provided, the value will be ignored for the database property comparison. The find filter enabled and onButtons control the type of elements that will be selection.

** For DEVTYPE and REFDES, a component instance is selected if COMPONENTS are in the find filter ?enabled list. Otherwise, if SYMBOLS are enabled, a symbol instance is selected.

See the descriptions of the `SelectName` functions for how to set up the arguments.

Point Selection

These functions select objects at a single geometric point. They prompt you for the point if that argument is missing from the function call.

```
axlSingleSelectPoint  
axlAddSelectPoint  
axlSubSelectPoint
```

Area Selection

These functions select objects over an area. They prompt you for the area (*Bbox*) if that argument is missing from the function call.

```
axlSingleSelectBox  
axlAddSelectBox
```

`axlSubSelectBox`

Miscellaneous Select Functions

These functions select by other means as shown in each function description later in this chapter:

`axlAddSelectAll`
`axlSubSelectAll`
`axlSingleSelectName`
`axlAddSelectName`
`axlSubSelectName`
`axlSingleSelectObject`
`axlAddSelectObject`
`axlSubSelectObject`

axlSelect—The General Select Function

One function, `axlSelect`, combines the capabilities of the `axlAddSelect` functions. Use `axlSelect` as you write interactive commands to give the user the same select capabilities available in Allegro PCB Editor commands *move* or *delete*.

Select Set Management

These functions manage the select set:

`axlGetSelSet`
`axlGetSelSetCount`
`axlClearSelSet`

Find Filter Control

These functions control the selection filter:

- `axlGetFindFilter`
- `axlSetFindFilter`

Find Filter Options

You can restrict selection in a given window to a subset of all possible figure types by using the **Find Filter** or the `FindFilter` functions described in this chapter. `FindFilter` functions also control whether the **Find Filter** is immediately visible to you.

The permissible keywords for the *lt_options* list are shown. These keywords are a subset of the Allegro PCB Editor Find Filter. You can prefix any of these keywords with NO to reverse the effect. See the description of [axlSetFindFilter](#) on page 229 for details on how to use these keywords:

<i>Global</i>	ALL, ALLTYPES, EQUIVLOGIC
<i>Figures</i>	PINS, VIAS, CLINES, CLINESEGS, LINES, LINESEGS, DRCS, TEXT, SHAPES (includes rectangles), SHAPESEGS, VOIDS, VOIDSEGS, TEXT.
	Note: The <code>xxxSEG</code> keywords also select arc and circle segments
<i>Logic</i>	COMPONENTS, SYMBOLS, NETS

Except for EQUIVLOGIC, the *Find Filter* functions take the keywords in the order found. For example, the list (ALL NOPIN) results in all objects except pins being selectable.

EQUIVLOGIC is a global find state. It instructs *find* to select the physically equivalent parts, as specified in the filter of the found logic object. For example, if the user picks any physical part of a net, the selection returns any physical parts of the (logical) net selected by the *find filter*. Both the logical and the physical objects must be enabled. For example, to select all pins of a net, both NETS and PINS must be enabled and set with ?onButton.

Selection and Find Functions

This section lists selection and find functions.

axlSingleSelectPoint

```
axlSingleSelectPoint(  
    [l_point]  
)  
⇒ t/nil
```

Description

Clears the select set, finds a figure at *l_point* according to the Find Filter, and puts the selected figure *dbid* in the select set. If *l_point* is nil, the function requests a single pick from the user.

axlSingleSelectPoint selects a *single* object and adds it to the select set, unless EQUIVLOGIC is on. In that case, it may select multiple objects, for example, if it finds a qualified figure (such as a pin, connect line, or via) that is part of a net.

axlSingleSelectPoint adds all the qualified figures that belong to the net to the select set. (See the [Find Filter Options](#) on page 201.)

This finds objects within the current trapsize (*axlGetTrapBox*), which varies based upon the zoom factor.

Arguments

l_point Point in database coordinates at which to look for figures.

Value Returned

t One or more *dbids* put in the select set.

nil No *dbids* put in the select set.

Example


```
axlSetFindFilter(?enabled "pins" ?onButtons "pins")
    axlSingleSelectPoint( 6325:3575 )
    axlDBAddProp(axlGetSelSet() list( "MYPROP" 23.5 ))
    =>t
```

Adds a previously defined user property **MYPROP** to a pin at X6325 Y3575.

To check

1. From Allegro PCB Editor, choose *Display – Element*.
2. Select the pin to display its properties.

The **Show Element** window displays **MYPROP** with value **23.500000 level**



axlAddSelectPoint

```
axlAddSelectPoint(  
    [l_point]  
)  
⇒ t/nil
```

Description

Finds a figure at *l_point* according to the Find Filter and adds its *dbid* to the select set in cumulated mode. If *l_point* is *nil*, requests a single pick from the user.

Selects a *single* object and adds it to the select set, unless `EQUIVLOGIC` is on. In that case, selects multiple objects, for example, if it finds a qualified figure (such as a pin, connect line, or via) that is part of a net. Adds all the qualified figures that belong to the net to the select set. (See the [Find Filter Options](#) on page 201.)

This finds objects within the current trapsize (`axlGetTrapBox`), which varies based upon the zoom factor.

Arguments

l_point Point in the layout at which to find figures.

Value Returned

t One or more *dbids* put in the select set.

nil No *dbids* put in the select set.

Example

See [axlSingleSelectPoint](#) on page 202 for an example. `axlSingleSelectPoint` has the same behavior except that it selects only one object.

axISubSelectPoint

```
ax1SubSelectPoint(  
    [l_point]  
)  
⇒ t/nil
```

Description

Finds a figure at *l_point* according to the Find Filter and deletes its *dbid* from the select set in cumulated mode. That is, it deletes that *dbid* while leaving any others currently in the select set. If *l_point* is nil, requests a single pick from the user.

Removes a *single* object from the select set, unless EQUIVLOGIC is on. In that case, finds multiple objects, for example, if it finds a qualified figure (such as a pin, connect line, or via) that is part of a net. Deletes all the qualified figures that belong to the net from the select set. (See the [Find Filter Options](#) on page 201.)

This finds objects within the current trapsize (`axlGetTrapBox`), which varies based upon the zoom factor.

Arguments

l_point Point in the layout at which to find figures to deselect.

Value Returned

t One or more *dbids* removed from the select set

nil No *dbids* removed from the select set.

Example

```
axlSetFindFilter(?enabled "pins" ?onButtons "pins")
axlSingleSelectBox( list(6200:3700 6500:3300))
axlSubSelectPoint( 6325:3575 )
axlDBAddProp(axlGetSelSet() list("MYPROP" 23.5))
⇒t
```

Adds a previously defined user property, `MYPROP`

1. Selects four pins in a box in order.

Allegro SKILL Reference


Selection and Find Functions

2. Before adding the property, subtracts the pin at 6325 : 3575 from the list, then adds as shown.

To check

1. Select *Edit – Properties*.
2. Select a window around all four pins.
3. Select *MYPROP* from the Available Properties list in the **Edit Property** window.

The command displays the pins that have properties in the **Show Properties** window. Only the three pins not subtracted from the select set have the property, *MYPROP*.



axlSingleSelectBox

```
axlSingleSelectBox(  
    [l_bBox]  
)  
⇒ t/nil
```

Description

Clears the select set, finds all figures inside the rectangle *l_bBox* according to the Find Filter, and adds the selected figure *dbids* in single mode to the select set.

Arguments

<i>l_bBox</i>	List containing one or two coordinates defining the bounding box to be used to select the figures. If <i>l_bBox</i> is <i>nil</i> , requests two picks from the user. If <i>l_bBox</i> has only one point, asks for a second point from the user.
---------------	---

Value Returned

<i>t</i>	One or more objects added to the select set.
----------	--

<i>nil</i>	No objects added to the select set.
------------	-------------------------------------

Example

```
axlSetFindFilter(?enabled "pins" ?onButtons "pins")  
axlSingleSelectBox( list(6200:3700 6500:3300))  
axlDBAddProp(axlGetSelSet() list( "MYPROP" 23.5))  
⇒ t
```

Adds a previously defined user property **MYPROP** to four pins by selecting a box around them with corners (6200:3700 6500:3300).


To check

1. Select *Edit – Properties*.
2. Select the four pins.
3. Select **MYPROP** from the Available Properties list in the **Edit Property** window.

Allegro SKILL Reference

Selection and Find Functions

The command displays the four pins in the **Show Properties** window as having **MYPROP** with value *23.500000 level*



axlAddSelectBox

```
axlAddSelectBox(  
    [1_bBox]  
)  
⇒ t/nil
```

Description

Finds one or more figures inside the rectangle *1_bBox* according to the current Find Filter, and adds the selected figure *dbids* in cumulated mode for the select set.

Arguments

<i>1_bBox</i>	List containing one or two coordinates defining the bounding box to be used to the select figures. If <i>1_bBox</i> is <i>nil</i> , requests two picks from the user. If <i>1_bBox</i> has only one point, asks for a second point from the user.
---------------	---

Value Returned

<i>t</i>	One or more objects added to the select set.
----------	--

<i>nil</i>	No objects added to the select set.
------------	-------------------------------------

Example

See the example for [axlSingleSelectBox](#) on page 207. That function behaves exactly as `axlAddSelectBox`, except that `axlSingleSelectBox` does not clear the select set.

axlSubSelectBox

```
axlSubSelectBox(  
    [1_bBox]  
)  
⇒ t/nil
```

Description

Finds one or more figures inside the rectangle *1_bBox* according to the Find Filter, and deletes their *dbids* from the select set in *cumulated* mode. Deletes those *dbids* while leaving any others currently in the select set.

Arguments

<i>1_bBox</i>	List containing one or two coordinates defining the bounding box to be used to the select figures. If <i>1_bBox</i> is <i>nil</i> , requests two picks from the user. If <i>1_bBox</i> has only one point, asks for a second point from the user.
---------------	---

Value Returned

t	One or more objects deleted from select set.
---	--

nil	No objects deleted from select set.
-----	-------------------------------------

Example

See [axlSubSelectPoint](#) on page 205 for an example of subtracting from the select set, and [axlAddSelectPoint](#) on page 204 for an example of using a box for selection.

axlAddSelectAll

```
axlAddSelectAll()  
⇒ t/nil
```

Description

Finds all the figures in the database that pass the current Find Filter and adds their *dbids* to the select set.

Arguments

None.

Value Returned

t	One or more object <i>dbids</i> added to the select set.
nil	No object <i>dbids</i> added to the select set.

Example

```
axlSetFindFilter(?enabled list( "noall" "vias")  
    ?onButtons list( "noall" "vias"))  
axlAddSelectAll()  
axlDeleteObject(axlGetSelSet())  
⇒ t
```

Selects all vias in a layout and deletes them.

axlSubSelectAll

```
axlSubSelectAll()  
⇒ t/nil
```

Description

Finds all figures in the database that pass the current Find Filter and deletes their *dbids* from the select set. Use `axlSubSelectAll` to subtract all of a given type of figure from a larger set of selected objects.

Note: Use `axlClearSelSet` to deselect all figures in the current select set, regardless of the current Find Filter.

Arguments

None.

Value Returned

t	One or more <i>dbids</i> deleted from select set.
---	---

nil	No <i>dbids</i> deleted from select set.
-----	--

Note: Dependent on find filter ?enabled settings.

Example 1

The following example selects the nets GND and VCC by their names.

```
axlClearSelSet()  
axlSetFindFilter(?enabled  
    list( "noall" "equivlogic" "nets" "clines" "vias")  
    ?onButtons list( "all"))  
axlSingleSelectName( "NET" list( "GND" "VCC"))  
    ==> (dbid:234436 dbid:98723)  
axlSingleSelectName("PROPERTY" list( list("BUS_NAME" "MEM") "FIXED"  
)⇒ t
```

Interactively selects all connect lines (clines) and vias on a net, subtracts the via *dbids* from the select set, and deletes the remaining *dbids* in the select set.

The prompt *Enter selection point*, is displayed. Only the connect lines on the net you select are deleted—not the vias of the net.

Example 2

The following example selects a set of nets--one set by the property name ELECTRICAL_CONSTRAINT_SET with value DEFAULT, and another set that has the name ROUTE_PRIORITY.

```
axlClearSelSet()
axlSetFindFilter( ?enabled list( "noall" "nets")
                  ?onButtons list( "all"))
axlSingleSelectName("PROPERTY"
                    list( list( "ELECTRICAL_CONSTRAINT_SET" "DEFAULT"
                               "ROUTE_PRIORITY"))
                    ==> (dbid:234436 dbid:98723 dbid:234437 dbid:98727
                          dbid:234438 dbid:98725 dbid:234439 dbid:98726)
```

axlSingleSelectName

```
axlSingleSelectName (
  t_nameType
  l_names
  [g_wildcard]
)
⇒ t/nil
```

Description

Finds figures by their names. Clears the current contents of the select set and adds named figure *dbids* to the select set in single mode using the arguments as described below. The function selects any figures completely, regardless of the selection mode. If the function selects a figure already partially selected, the figure becomes fully selected.

Note: The *on* buttons are used for selecting *Properties* by name only. Both `axlSubSelectName` and `axlAddSelectName` always operate in wildcard mode. Both take the optional wildcard argument but ignore it. In the future, if passed `nil`, they may obey the argument.

Arguments

t_nameType Indicates the type of name string being provided. Also implies the type of object to be selected. (see [Finding Objects by Name](#) on page 198).

l_names One of three possibilities (See examples):

- Name
- List of names
- List of name/value pairs

g_wildcard A *t* means that * or ? performs regular expression matching. Default is `nil` where * and ? are treated as normal characters.

Value Returned

t One or more objects added to the select set.

nil No objects added to the select set.

Allegro SKILL Reference

Selection and Find Functions

Example 1

```
axlClearSelSet()
axlSetFindFilter(
    ?enabled list( "noall" "nets")
    ?onButtons list( "all"))
axlSingleSelectName ("NET" (list ("GND" "VCC"))
⇒ (dbid:234436 dbid:98723)
    axlSingleSelectName ("PROPERTY" (list (list "BUS_NAME" "MEM") "FIXED"))
```

Selects the nets GND and VCC by their names.

Example 2

```
axlClearSelSet()
axlSetFindFilter(
    ?enabled list( "noall" "nets")
    ?onButtons list( "all"))
axlSingleSelectName ("PROPERTY"
    list(
        list( "ELECTRICAL_CONSTRAINT_SET" "ECL_DEFAULT"
            "ROUTE_PRIORITY"))
⇒ (dbid:234436 dbid:98723 dbid:234437 dbid:98727
    dbid:234438 dbid:98725 dbid:234439 dbid:98726)
```

Selects a set of nets—one set by the property name ELECTRICAL_CONSTRAINT_SET with value ECL_DEFAULT, and another set that has the name ROUTE_PRIORITY.

axlAddSelectName

```
axlAddSelectName (
  t_nameType
  l_names
)
⇒ t/nil
```

Description

Adds the named figure *dbids* to the select set in cumulated mode according to the arguments described below. Adds the found figures to the select set if not already there. Selects figures completely regardless of the selection mode. If the function selects a figure already partially selected, the figure becomes fully selected.

Arguments

<i>t_nameType</i>	String denoting the name type to be selected (see Finding Objects by Name on page 198). Also implies the type of object to be selected.
<i>l_names</i>	One of three possibilities (See examples): A name A list of names A list of name/value pairs

Value Returned

t One or more objects added to the select set.

nil No objects added to the select set.

The *on* buttons matter for select Properties by name, but don't for other name types. Both `axlSubSelectName` and `axlAddSelectName` always operate in wildcard mode. Both take the optional wildcard argument, but ignore it. In the future, if passed `nil` they may obey the argument.

Example

See examples for [axlSingleSelectName](#) on page 214. The only difference is that `axlSingleSelectName` clears the select set, while `axlAddSelectName` adds the

Allegro SKILL Reference

Selection and Find Functions

selected *dbids* into the select set without removing any already in it. The arguments for `axlAddSelectName` are the same as for `axlSingleSelectName`.

axlSubSelectName

```
axlSubSelectName (
  t_nameType
  l_names
)
⇒ t/nil
```

Description

Removes *dbids* of the named figure from the select set using the arguments described. Removes figures completely regardless of the selection mode. If the function finds a figure already partially selected, it removes all of its *dbids* from the select set.

Arguments

<i>t_nameType</i>	String denoting name type to be selected (see Finding Objects by Name on page 198). Also implies the type of object to be selected.
<i>l_names</i>	One of three possibilities (See examples): -Name -List of names -List of name/value pairs

Value Returned

<i>t</i>	One or more objects deleted from select set.
<i>nil</i>	No objects deleted from select set.

Note: The *on* buttons matter for select Properties by name, but don't for other name types. Both `axlSubSelectName` and `axlAddSelectName` always operate in wildcard mode. Both take the optional wildcard argument, but ignore it. In the future, if passed `nil`, they may obey the argument.

Example

See examples for [axlSingleSelectName](#) on page 214. The only difference is that `axlSingleSelectName` clears the select set and then puts the *dbids* it finds into the select set, while `axlSubSelectName` removes the *dbids* of the elements it selects from the select set. The arguments are the same as `axlSingleSelectName`.

axlSingleSelectObject

```
axlSingleSelectObject(  
    lo_dbid  
)  
⇒ t/nil
```

Description

Clears contents of the select set and adds the *dbids* in *lo_dbid* to the select set in single mode. *lo_dbid* is either a single *dbid* or a list of *dbids*. Selects figures completely regardless of the selection mode. If the *dbid* of any part of a figure is in *lo_dbid*, the function adds the entire figure.

Arguments

lo_dbid *dbid*, or list of *dbids* to be added to the select set.

Value Returned

t One or more objects added to the select set.

nil No objects added to the select set.

Example

```
axlClearSelSet()  
axlSetFindFilter(  
    ?enabled list( "all" "equivlogic")  
    ?onButtons list( "all"))  
mysym = axlDBCreateSymbol(  
    list( "dip14" "package"), 5600:4600)  
axlSingleSelectObject(car(mysym))  
⇒ t
```

Creates a symbol and add its *dbid* to the select set.

axlAddSelectObject

```
axlAddSelectObject(  
    lo_dbid  
)  
⇒ t/nil
```

Description

Adds the *dbids* in *lo_dbid* to the select set in cumulated mode, that is, without removing already selected objects. *lo_dbid* is either a single *dbid* or a list of *dbids*. Adds *dbids* in the select set only if they are not already there. Selects figures completely regardless of the selection mode. If the *dbid* of any part of a figure is in *lo_dbid*, adds the entire figure.

Arguments

lo_dbid *dbid*, or list of *dbids* to be added to the select set.

Value Returned

t One or more objects added to the select set.

nil No objects added to the select set.

Example

```
axlSetFindFilter(  
    ?enabled list( "all")  
    ?onButtons list( "all"))  
mysym = axlDBCreateSymbol(  
    list("dip14" "package") 2600:2600 ) axlAddSelectObject(car(mysym))  
⇒ t
```

Creates a symbol instance and adds its *dbid* to the select set.

axlSubSelectObject

```
axlSubSelectObject(  
    lo_dbid  
)  
⇒ t/nil
```

Description

Removes the *dbids* in *lo_dbid* from the select set in cumulated mode. *lo_dbid* is either a single *dbid* or a list of *dbids*. Removes figures completely regardless of the selection mode.

Arguments

lo_dbid *dbid*, or list of *dbids* to be removed from select set.

Value Returned

t One or more objects deleted from select set.

nil No objects deleted from select set.

Example

```
axlClearSelSet()  
axlSetFindFilter(?enabled list("noall" "vias")  
    ?onButtons list( "vias"))  
myvia = axlDBCreateVia( "pad1", 3025:3450)  
axlAddSelectBox( list( 3000:3100 3200:3600))  
axlSubSelectObject( car( myvia))  
⇒ t
```

Creates a via, then selects all the vias in a surrounding region for deletion, but saves the one just created by subtracting its *dbid* from the selection set.

The resulting select set contains the *dbids* of all vias in the box except *myvia*, the one just created.

axlSelect

```
axlSelect(  
    ?firstEventCallbacks_callback  
    ?groupMode/nil  
    ?promptt_prompt  
)  
⇒ t/nil
```

Description

General tool for AXL programs to solicit interactive object selections from the user. axlSelect automatically sets up the pop-up to provide any of the possible Allegro PCB Editor selection methods:

- Single point select
- Window select
- Group select

You can set up the pop-up to display other options such as *Done* and *Cancel*, but the function also displays the find options. See the example.

Before axlSelect returns, it puts in the select set a list of the *dbids* of the objects the user selected.

Use axlSelect when you create interactive commands that allow the user to select objects in the same way as existing Allegro PCB Editor interactive commands such as *move* or *delete*. axlSelect allows the user to select objects using the standard methods of mouse pick, window, and group. It returns when the user has selected one or more objects or picks *Done* or *Cancel*, depending on the pop-up selections you set up. The default mode for axlSelect is selecting a single object by point—equivalent to axlSingleSelectPoint.

axlSelect removes any previously selected *dbids* in the selection set when the user first selects one or more objects.

You must set up the find filter to meet your requirements before calling axlSelect.

Arguments

<i>firstEventCallback</i>	Procedure to be called once the first user event occurs. The callback takes no arguments.
---------------------------	---

Allegro SKILL Reference

Selection and Find Functions

<i>groupMode</i>	Default is for <code>axlSelect</code> to return when the user makes a selection. If <code>groupMode</code> is ' <code>t</code> ', <code>axlSelect</code> won't return until you do an <code>axlCancelEnterFun</code> or <code>axlFinishEnterFun</code> . You perform all of your activity in popup callbacks instead of when <code>axlSelect</code> returns. In <code>groupMode</code> , <code>axlSelect</code> does not clear existing selections. To clear existing selections after the first event, clear them in your <code>firstEventCallback</code> .
<i>prompt</i>	Prompt to the user. The default prompt is: "Enter selection point"

Value Returned

<code>t</code>	One or more object <code>dbids</code> put into the select set during the call. The select set is a list of the <code>dbids</code> of the objects the user selected.
<code>nil</code>	No object <code>dbids</code> put into the select set.

Example

```
(defun showElement ()
  mypopup = axlUIPopupDefine( nil
    (list (list "Done" 'axlFinishEnterFun)
          (list "Cancel" 'axlCancelEnterFun)))
  axlUIPopupSet( mypopup)
  axlSetFindFilter( ?enabled list( "NOALL" "ALLTYPES" "NAMEFORM")
    ?onButtons "ALLTYPES")
  while( axlSelect()
    axlShowObject( axlGetSelSet())))
```

Function loops, performing the `Show Element` command on each object selected by the user.

Although you explicitly set *Done* and *Cancel* for this command, AXL also adds *Group*, *Window Select*, and *FindFilter* to the pop-up.

Done
Cancel
Group
Window Select
Find Filter

axlGetSelSet

```
axlGetSelSet()  
⇒ lo_dbid/nil
```

Description

Gets the list of object *dbids* in the select set.

Arguments

None.

Value Returned

<i>lo_dbid</i>	List of figure <i>dbids</i> .
<i>nil</i>	Select set is empty.

Example


```
axlClearSelSet()  
axlSetFindFilter(?enabled list("noall" "vias")  
    ?onButtons list("vias"))  
axlAddSelectBox(list(3000:3100 3200:3600))  
axlShowObject(axlGetSelSet())  
⇒ t
```

Selects all vias in a box area and shows the contents of the select set.

Allegro SKILL Reference

Selection and Find Functions

The **Show Element** window is displayed, with the via selected.



axlGetSelSetCount

```
axlGetSelSetCount()  
⇒ x_selCount
```

Description

Returns the number of figure *dbids* in the select set.

Arguments

None.

Value Returned

x_selCount	Number of objects selected. Returns 0 if nothing is selected.
------------	---

Example

```
axlClearSelSet()  
axlSetFindFilter(?enabled list("noall"))  
axlSetFindFilter(?enabled list("pins")  
    ?onButtons list("pins"))  
axlAddSelectBox()  
axlGetSelSetCount()  
⇒ 14
```

Sets the Find Filter to find pins, selects a box around a 14 pin dip and prints the number of *dbids* in the select set. It is 14, as expected.

axlClearSelSet

```
axlClearSelSet()  
⇒ t/nil
```

Description

Removes all *dbids* from select set.

Arguments

None.

Value Returned

t	One or more <i>dbids</i> removed in order to empty the select set.
nil	Select set already empty.

Example

```
axlClearSelSet()  
axlSetFindFilter(?enabled list("noall"))  
axlSetFindFilter(?enabled list("pins"))  
    ?onButtons list("pins"))  
axlAddSelectBox()  
axlGetSelSetCount()  
⇒ 14
```

Ensures the select set does not have any leftover *dbids* in it, as in the example for axlGetSelSetCount.

axlGetFindFilter

```
axlGetFindFilter(  
    [onEnabledF]  
)  
⇒ lt_filters/nil
```

Description

Returns the current Find Filter settings as a list of keyword strings. The return find filters settings (onButton or enabled) is controlled by the boolean *onEnabledF*

Arguments

onEnabledF If *onEnabledF* is t, returns the enabled list.
 If *onEnabledF* is nil, returns the *onButton* list.
 Default is nil.

Value Returned

lt_filters List of element types in the Find Filter
OR
list of current onButton settings.

nil If list would be empty.

Example

```
axlSetFindFilter ?enabled (list "vias" "pins" "nets" "clinesegs" "nameform")  
?onButtons (list "vias" "pins" "clinesegs"))  
ret =axlGetFindFilter()
```

Returns the following:

```
("NAMEFORM" "NETS" "CLINESEGS" "VIAS" "PINS"  
<plus default items that may change from release to release> )
```

```
ret = axlGetFindFilter(t)
```

Returns:

```
("CLINESEGS" "VIAS" "PINS")
```

axlSetFindFilter

```
axlSetFindFilter(  
    ?enabledlt_enabled  
    ?onButtonslt_filterOn  
)  
t/nil
```

Description

Sets up both the object types to be displayed in the Find Filter, and which types among those are set to *on* in the **Find Filter**.

The first argument, *lt_enabled*, is a list of the object types to be displayed in the Find Filter and of the select options described. The second argument, *lt_onButtons*, lists the object types whose buttons are to be *on* (and therefore selectable) when the filter displays. The table lists the keywords that can be included in the enabled and *onButtons* lists for setting up the Find Filter. The diagrams show the keywords and the buttons they cause `axlSetFindFilter` to display.

Each change is additive and processed in the order that they appear in the list. For example, you type the following to enable all object types except for pins.

```
' ("ALLTYPES" "NOPINS")
```

Each of the following keywords may be preceded with a "NO" to disable the particular option or object type. For example, "NOPINS". The initial default is "NOALL".

axlSetFindFilter Keywords

Keyword	Description
"PINS"	Enable pins
"VIAS"	Enable vias
"CLINES"	Enable clines
"CLINESEGS"	Enable cline (arc or line) segs
"LINES"	Enable lines
"LINESEGS"	Enable line (arc or line) segs
"DRCS"	Enable drc errors
"TEXT"	Enable text
"SHAPES"	Enable shapes, rects and frects

Allegro SKILL Reference

Selection and Find Functions

axlSetFindFilter Keywords, *continued*

Keyword	Description
"SHAPESEGS"	Enable shape segments
"BOUNDARY_SHAPES"	Enable promotion to boundary shape if auto-shape is selected (see dynamic shape discussion)
"VOIDS"	Enable shape voids
"VOIDSEGS"	Enable shape void segments
"SYMBOLS"	Enable symbol instances
"FIGURES"	Enable figures
"COMPONENTS"	Enable component instances
"FUNCTIONS"	Enable function instances
"NETS"	Enable nets
"AUTOFORM"	Option - OBSOLETE
"EQUIVLOGIC"	Option - For logic object types (nets and components), causes the physical equivalent to be selected. Physical objects must be enabled in both " <i>enabled</i> " and " <i>onButton</i> " lists.
"INVISIBLE"	Option - Allows selection of objects that are not visible due to color <i>class</i> / <i>subclass</i> form setting.
"NAMEFORM"	Option - Enables the <i>Find by Name/property</i> fields in the Find Filter form.
"ALLTYPES"	Enables all object types ("PINS" . . . "NETS").
"ALL"	Enables all object types and options.
"DYNTHEMALS"	Enable selection of thermal reliefs generated by dynamic shapes. Only applicable to ?enabled. By default, you should not select these if you plan on modifying the objects since the dynamic shape will just re-generate them. You should only access them for read-only purposes.

Allegro SKILL Reference

Selection and Find Functions

ax1SetFindFilter Keywords, *continued*

Keyword	Description																			
"GROUPS"	"GROUPS" and "GROUPMEMBERS" operate together to produce four possible selection states:																			
	<table border="1" data-bbox="533 606 1153 753"> <thead> <tr> <th data-bbox="538 614 791 635" rowspan="2">Keyword</th><th colspan="4" data-bbox="791 614 1147 616">States</th></tr> <tr> <th data-bbox="830 614 850 635">1</th><th data-bbox="889 614 907 635">2</th><th data-bbox="946 614 966 635">3</th><th data-bbox="1005 614 1024 635">4</th></tr> </thead> <tbody> <tr> <td data-bbox="538 663 791 684">GROUPS</td><td data-bbox="830 663 850 684">OFF</td><td data-bbox="889 663 907 684">ON</td><td data-bbox="946 663 966 684">OFF</td><td data-bbox="1005 663 1024 684">ON</td></tr> <tr> <td data-bbox="538 711 791 732">GROUPMEMBERS</td><td data-bbox="830 711 850 732">OFF</td><td data-bbox="889 711 907 732">OFF</td><td data-bbox="946 711 966 732">ON</td><td data-bbox="1005 711 1024 732">ON</td></tr> </tbody> </table>	Keyword	States				1	2	3	4	GROUPS	OFF	ON	OFF	ON	GROUPMEMBERS	OFF	OFF	ON	ON
Keyword	States																			
	1	2	3	4																
GROUPS	OFF	ON	OFF	ON																
GROUPMEMBERS	OFF	OFF	ON	ON																
	<ul style="list-style-type: none"> ■ State 1: Legacy. This supports code that predates the group implementation. This is the same as State 3. ■ State 2: Group only. By only setting the group bitfield, any selected group is returned to the application as a group. ■ State 3: Members only. By only setting the group_members bitfield, group members are returned to the application when a group is selected. ■ State 4: Hierarchical. By setting both the group and group_members bitfields, a group is returned for any hierarchical group that is selected (such as a Module instance), and group members are returned for all other selected group types. 																			
"AUTOFORM"	OBSOLETE																			
"EQUIVLOGIC"	Option - For logic object types (nets and components), causes the physical equivalent to be selected. Physical objects must be enabled in both "enabled" and "onButton" lists.																			
"INVISIBLE"	Option - Allows selection of objects that are not visible due to color class/subclass form setting.																			
"NAMEFORM"	Option - enables the find by name/property fields in the find filter form.																			

ax1SetFindFilter Keywords, continued

Keyword	Description
"DYNTHEMALS"	<p>Option - Enable selection of thermal reliefs generated by dynamic shapes. Only applicable to ?enabled. By default, you should not select these if you plan on modifying the objects since the dynamic shape will just re-generate them. You should only access them from read-only purposes.</p> <p>If in the partition editor or the design has partitions active then this option is used to selections of read-only objects.</p> <p>This option should also be used to select shape base fillets. The system will not allow shape based fillets to be modified if the dynamic fillet option is enabled.</p>
"BONDSMART"	<p>Option - Application has been updated to differentiate bond wires and/or fingers (APD/SIP).</p> <p>For more information, see Bond Objects.</p>
"ALLTYPES"	Enable all object types ("PINS" ... "NETS").
"ALL"	Enable all object types and options.

`ax1SetFindFilter` processes the keywords in each argument list in order and only makes the changes occurring in the list. Changes are incremental for each call to the function. To remove a selection, attach the string "NO" to the front of the keyword. For example, the list ("ALLTYPES" "NOPINS") enables all object types except pins. The initial default setting of the Find Filter is "NOALL", or, nothing enabled. Use "NOALL", as shown, to clear the Find Filter before enabling particular types.

Dynamic Shapes

When writing an application and it needs to handle shapes, you need to decide how you want to handle dynamic shapes. If your SKILL program does not access shapes, read no further.

A shape on `ETCH` may be either static or dynamic. A static shape is similar to what existed in Allegro PCB Editor prior to PSD15.0. You add a shape to an etch layer and manually void objects that impact the shape. A dynamic shape is placed on the `BOUNDARY CLASS` and generates zero or more shapes on the `ETCH` layer based upon voiding.

If you want to modify a dynamic shape, then you should set `BOUNDARY_SHAPES`. This allows the user to select the generated shape, but selection will return its dynamic shape (e.g. a

Allegro SKILL Reference

Selection and Find Functions


move shape). If you want to access information on the shape, then do not set the BOUNDARY_SHAPES option (e.g. *show element*).

Note: If you pass "ALL" or "ALLTYPES" to *setOptions*, then BOUNDARY_SHAPES will be enabled and user's selecting a ETCH layer generated shape will result in the selection returning its dynamic shape on the "BOUNDARY CLASS". If you wish to select the generated shape, but want to use the *all* option, then use the following:

```
"(ALLTYPES" "NOBOUNDARY_SHAPES")
```

You need only pass BOUNDARY_SHAPES to the enabled list. It will be ignored if passed to the onButtons list.

Figure 4-1 Find Filter and Related Keywords




The differences in effects of different combinations of keywords can be subtle. [Figure 4-2](#) on page 234 shows the relationship between the keywords.

Allegro SKILL Reference

Selection and Find Functions

Figure 4-2 Relationship Among axlSetFindFilter Keywords (See examples also)



Bond Objects

Bond objects (bond wires and fingers) are enabled only in SIP/APD. These options are ignored in the PCB products.

In SIP/APD, to maintain backward compatibility, an application is not considered to be "bond smart". This means if the Skill application enables VIAs then FINGERS are enabled and if CLINES is enabled, the BOND WIRES are automatically enabled.

Allegro SKILL Reference

Selection and Find Functions

To make an application BOND SMART, you either set the BONDSMART option or use the BONDWIRES, NOBONDWIRES, FINGERS or NOFINGERS options. An application that is bond smart can separately control the selection of bond objects (fingers or bond wires) from their base objects (vias or clines).

Note: You only need to make your Skill application bond smart if you wish to differentiate the disabling of one of these objects. By default, users in SIP/APD will be able to independently select:

- VIAS or FINGERS if the Skill application enables VIAS
- CLINES and WIRES if CLINES are enabled.

Ideally most applications will not need to be updated to be bond smart.

Arguments

`lt_enabled` List of keyword strings that describe object types that are to be selectable. Enabled object types will appear in the **Find Filter** form. Object types need the `onButton` set as well to fully enable selection. List may also include selection options.

Also supports a single keyword string instead of a list of strings.

`lt_onButtons` List of keyword strings that describe object types that are to be enabled for selection. Enabled types will appear with the `onButton` depressed in the Find Filter form. `onButton` settings provide the default for controls which can be modified by the user when the Find Filter form is opened. An object type must be *on* in both the enabled and the `onButton` lists to be fully enabled for selection. Options are ignored when provided in the `onButton` list.

Also supports a single keyword string instead of a list of strings.

Note: `axlSetFindFilter` does not display or select any types that are not enabled. That means that `?onButtons` keywords only effect enabled types. For example, to have all enabled buttons be *on*, use `?onButtons list("alltypes")`. In general, you need only set specific buttons *on* if you want those on and others off.

Value Returned

`t` One or more Find Filter changes were made.

Allegro SKILL Reference

Selection and Find Functions

nil

No valid keywords were provided.

Application Programming Note

When you use `axlSetFindFilter` to implement an interactive command, make your AXL-SKILL program restore the user's FindFilter settings from the previous time he or she used the same command. Find Filter settings are incremental. Clear any previous settings as you start, then set the ones you want. Call `axlSetFindFilter` with "noall" as the first member of the list for both the `?enabled` and `?onButtons` arguments the first time you call it.

To maintain the user's Find Filter settings between invocations of your command

1. The first time the user invokes your program (when it loads), preset global variables to the list of `?enabled` and `?onButtons` settings you want as the initial default, as follows:

```
myglobal_enabled = list("noall" "xxx" "yyy" ... "zzz")
myglobal_onButtons = list("xxx" ... "zzz")
```

2. Each time the user invokes your command, call `axlSetFindFilter` with the current global values of `?enabled` and `?onButtons`.

```
axlGetFindfilter( ?enabled myglobal_enabled
                  ?onButtons myglobal_onButtons)
```

Since users can set or clear any of the buttons on the Find Filter, you need to save the button settings as you exit the command.

3. As you end the command, save the user's Find Filter `onButton` settings as shown:

```
myglobal_onButtons = cons( "noall" axlGetFindFilter(t))
```

Note: The `cons` - "noall" ensures that when you call `axlSetFindFilter` again you clear any settings left over from any previous command, and set only the buttons set at the time you call `axlGetFindFilter`.


Allegro SKILL Reference

Selection and Find Functions

Example 1

```
(axlSetFindFilter ?enabled (list "vias" "pins" "nets")
?onButtons (list "vias" "pins"))
```

Displays the Find Filter with a list of Nets, Pins, and Vias. The Pins and Vias boxes are turned on as shown:




Allegro SKILL Reference

Selection and Find Functions

Example 2

```
(axlSetFindFilter ?enabled (list "noall" "vias" "pins"  
"nets" "clinesegs" "nameform")  
?onButtons (list "vias" "pins" "clinesegs"))
```

Displays the Find Filter with Pins, Vias, and Clinesegs turned on.



Example 3

```
axlSetFindFilter(  
?enabled list("noall" "equivlogic" "nets" "pins" "vias")  
?onButtons list("all"))
```

Sets to find all the pins and vias on a net when the user selects any part of the net.

axlAutoOpenFindFilter

axlAutoOpenFindFilter()
⇒ t

Description

This function is no longer required, but is kept for backward compatibility.

Arguments

None.

Value Returned

t Returns t always.

axlOpenFindFilter

```
axlOpenFindFilter()  
    => t
```

Description

This function is no longer required, but is kept for backward compatibility.

Arguments

None.

Value Returned

t	Returns t always.
---	-------------------

axlCloseFindFilter

axlCloseFindFilter()
⇒ t

Description

This function is no longer required, but is kept for backward compatibility.

Arguments

None.

Value Returned

t Returns t always.

axlDBFindByName

```
axlDBFindByName (
  s_type
  t_name
) => o_dbid/nil
```

Description

Finds *dbid* of an object by name without involving the selection set. This means you can run this command any time without affecting what exists in the selection set. The following object lookup types are supported:

type	t_name	return type
'net	net name	<i>dbid</i> of a net
'refdes	refdes	<i>dbid</i> of a component instance
'padstack	padstack name	<i>dbid</i> of a padstack

This is restricted to a single object. To find objects using wildcards, use `axlSelectByName`.

Arguments

<i>s_type</i>	Type symbol; see above.
<i>t_name</i>	Object's name (this is case insensitive).

Value Returned

o_dbid *dbid* of object or nil.

See Also

[axlSelectByName](#)

Examples

```
db = axlDBFindByName('net "GND")
db = axlDBFindByName('padstack "VIA")
db = axlDBFindByName('refdes "U1")
```

axlFindFilterIsOpen

```
axlFindFilterIsOpen()  
    => t
```

Description

This function is no longer required, but is kept for backward compatibility.

Arguments

None.

Value Returned

t	Returns t always.
---	-------------------

axlSelectByName

```
axlSelectByName (
    t_objectType
    t_name /!t_name
    [g_wildcard]
)
⇒ lo_dbid/nil
```

Description

Selects database objects by name.

Interface allows more than one name to be passed, but only one object type per call. For certain object types, a single name may return multiple objects. The supported object types and related items follow:

Object Type	Item the function finds
"NET"	net name
"COMPONENT"	component name
"FUNCTION"	function name
"DEVTYPE"	device type name
"SYMTYPE"	symbol type name
"PIN"	refdes.pinname
"REFDES"	find symbol by refdes name
"COMPREFDES"	find component by refdes name
"GROUP"	find group by name
"BUS"	find bus by name
"DIFF_PAIR"	find differential pair by name
"NETCLASS"	find netclass by name
"NET_GROUP"	find a net group by name
"REGION"	find region by name
"XNET"	find xnet by name; Will return a Net if xnet is a single net xnet. See <cdsroot>/share/pcb/examples/skill/select/ ashfindxnet.il

Allegro SKILL Reference

Selection and Find Functions

Object Type	Item the function finds
"MATCH_GROUP"	find matchgroup by name
"MODULE"	find module by name

You can use wildcards with this function:

- “*” matches any sequence of zero or more characters.
- “?” matches any single character.
- “\” is used to send a special character, for example, \x.

Provided third argument [*g_wildcard*] is set to TRUE.

Note: This saves and restores the current find filter settings, but resets the selection set.

Allegro SKILL Reference

Selection and Find Functions

Arguments

<i>t_objectType</i>	Type of database name.
<i>t_name</i>	Object to find.
<i>l t_name</i>	List of names to find.
<i>[g_wildcard]</i>	If * or ? appear in name, use regular expression matching

Value Returned

<i>t</i>	List of objects found.
<i>nil</i>	No matching name or illegal <i>objectType</i> name.

Example 1

```
Skill > p = axlSelectByName ("NET" ' ("GND" "NET1"))
(dbid:28622576 dbid:28639844)
```

Finds two nets.

Example 2

```
Skill > p = axlSelectByName ("NET" ' ("GND" "FOO"))
(dbid:28622576)
```

Finds two nets, but board only has GND.

Example 3

```
Skill > p = axlSelectByName ("COMPONENT" "C1")
(dbid:28590388)
Skill > car(p)->objType
"component"
```

Finds Component C1.

Example 4

```
Skill > p = axlSelectByName ("FUNCTION" "TF-326")
(dbid:28661572)
```

Allegro SKILL Reference

Selection and Find Functions

```
Skill > car(p)->objType  
"function"
```

Finds function TF-326.

Example 5

```
Skill > p = axlSelectByName ("DEVTYPE" "CAP1")  
(dbid:28591032 dbid:28590700 dbid:28590388)  
Skill > car(p)->objType  
"component"
```

Finds devices of type CAP1.

Example 6

```
Skill > p = axlSelectByName ("SYMTYPE" "dip14_3")  
(dbid:28688416 dbid:28686192)  
Skill > car(p)->objType  
"symbol"
```

Finds symbols of type DIP14_3.

Example 7

```
Skill > p = axlSelectByName ("PIN" "U1.1")  
(dbid:28630692)  
Skill > car(p)->objType  
"pin"
```

Finds pin U2.1.

Example 8

```
Skill > p = axlSelectByName ("REFDES" "U3")  
(dbid:28688416)  
Skill > car(p)->objType  
"symbol"
```

Finds symbol by refdes U3.

Example 9

```
Skill > p = axlSelectByName ("COMPREFDES" "U3")
```

Allegro SKILL Reference

Selection and Find Functions

```
(dbid:28621208)
Skill > car(p)->objType
"component"
```

Finds component by refdes U3.

Example 10

```
Skill > p = axlSelectByName ("GROUP" "BAR")
(dbid:28593776)
Skill > car(p)->objType
```

Finds a group BAR by name.

Example 11

```
Skill > p = axlSelectByName ("PIN" "U1.*" t)
(dbid:28630856 dbid:28630784 dbid:28630692 dbid:28630572 dbid:28630400
dbid:28630228 dbid:28630076 dbid:28630004 dbid:28629912 dbid:28629800
dbid:28629728 dbid:28629656 dbid:28629484 dbid:28629372 dbid:28629280
dbid:28629208
)
```

Finds all pins on refdes U1.

Example 12

```
Skill > p = axlSelectByName ("PIN" "U1.?" t)
(dbid:28630856 dbid:28630692 dbid:28630572 dbid:28630400 dbid:28630228
dbid:28630076 dbid:28630004 dbid:28629912 dbid:28629800
)
```

Finds pins with single digit number on U1.

Example 13

```
Skill > p = axlSelectByName ("NET" "N*" t)
(dbid:28630044 dbid:28634000 dbid:28638750)
```

Finds nets starting with N.

axlSelectByProperty

```
axlSelectByProperty(  
    t_objectType  
    t_property  
    [t_value]  
    [g_regularExpression]  
)  
⇒ lo_dbid/nil
```

Description

Selects the *dbid* set of a particular Allegro PCB Editor database object with the indicated property.

Property can be a name or a name/value pair. Value may contain a regular expression (* or ?), since certain select by name functions support wildcards. You can test for the presence of wildcards before you call this function.

Regular expressions used by Allegro PCB Editor differ from the Skill regular expressions. Allegro PCB Editor handles regular expressions such that they are more compatible with the character set allowed in Allegro PCB Editor object names. Do not use this function to test patterns sent to the Skill `regexp` family of functions.

For value, match the database formats into the value string to contain the units preference if applicable for the property. If the data type of the attribute is BOOLEAN, and if it exists on the element, the string is empty. If the data type is INTEGER or REAL, the user units string, if any, is appended to the value. If the data type is one of the "units category" types, for example, ALTITUDE, PROP_DELAY, the MKS package converts the value.

All names are case insensitive.

Note: Property names may change from release to release, or may be rendered obsolete. Skill programs using property names may require modifications in future releases.

Arguments

<i>t_objectType</i>	String for Allegro PCB Editor database object type. Must be: compdef, component, drc, net, symdef, symbol, or group.
<i>t_property</i>	String name of property.
<i>t_value</i>	Option property value.

Allegro SKILL Reference

Selection and Find Functions

gRegularExpression t if property value is to be treated as a regular expression,
 or nil, which is the default, to treat property value as a
 simple match.

Value Returned

t One or more *dbids* added to the select set.

nil No *dbids* added to the select set.

Example 1

```
p = axlSelectByProperty("net" "ELECTRICAL_CONSTRAINT_SET")
axlAddSelectObject(p)
```

Selects all nets with an ECset property, then adds them to the current select set.

Example 2

```
p = axlSelectByProperty("net" "ELECTRICAL_CONSTRAINT_SET", "SPITFIRE_ADDRESS")
```

Selects all nets with ECset property of value SPITFIRE_ADDRESS.

Example 3

```
p = axlSelectByProperty("net" "ELECTRICAL_CONSTRAINT_SET", "SPITFIRE*" t)
```

Selects all nets with ECset property with any value matching spitfire.

axlSnapToObject

```
axlSnapToObject(  
    g_mode  
    xy  
)  
⇒ xy/nil
```

Description

Supports snapping to a logic object's connect point. A logic object is a:

- Cline
- Clines segments (lines or arcs)
- Via
- Pin

For cline objects, the two end points are considered the connect points. For pad objects, the connect point is defined in the padstack. Snapping is based upon the trap size, which varies based upon the zoom factor (see `axlGetTrapBox`). The smaller the trap size, the higher the zoom. If no object is found within the original `xy` location is returned.

Note: Avoid using the grid snapping option with `axlEnterPoint` as it might move the user pick outside the trap size.

Arguments

`g_mode` `nil`: Use active sel set to determine snapping.

`t`: Snap based upon the visible layers in the database.

`xy` Location in design units to snap (list of design units x:y).

Value Returned

`xy` Object snapped point (list of design units x:y).

`nil` If not object exists for snapping returns nil.

Also nil if arguments are incorrect

See Also

[axlGetSelSet](#), [axlGetTrapBox](#), [axlGetLastEnterPoint](#)

Examples

Pseudo code to move objects.

```
; select object(s); do not do a axlClearSelSet
    _clpSelect
        ; first snap to an object that is the selection list
        gridSnap = axlEnterPoint(?prompts list("Pick origin point")
                                ? gridSnap t)
; for better results use the unsnapped pick
    origin = axlSnapToObject(nil axlLastPick(nil))
    ; if no object found fallback to the grid snapped pick
    unless( origin origin = gridSnap)
; ok to do clear now
    axlClearSelSet()
; now ask user for a destination
    gridSnap = axlEnterPoint(?prompts list("Pick origin point")
                            ? gridSnap t)
; Now snap the destination point based upon what can be found at that
    ; location
    ; for better results use the unsnapped pick
    dest = axlSnapToObject(nil axlLastPick(nil))
    ; fallback to grid snapped location if nothing found
    unless( origin dest = gridSnap)
; modify coordinates with dest location
    axlTransformObject(....)
```

axlLastPickIsSnapped

```
axlLastPickIsSnapped()  
-> t/nil
```

Description

Normally called after an `axlEnter` call to determine if the pick was snapped or unsnapped.

Arguments

none

Value Returned

`t` if last picked was snapped, `nil` if unsnapped

Examples

```
snappedPoint = axlEnterPoint(?prompts list("Pick origin point")  
    ?gridSnap t)  
state = axlLastPickIsSnapped()
```

Interactive Edit Functions

Overview

This chapter describes the basic database edit functions `axlDeleteObject` and `axlDBDeleteProp`. It also describes `axlShowObject`, which you can use to display the data about an object.

`axlDeleteObject` does not allow you to delete Allegro PCB Editor logical or parameter objects. Also, certain figure or property objects may be marked `readOnly`. `axlDeleteObject` ignores objects with that property. DRC markers created by Allegro PCB Editor are an example of `readOnly` Allegro PCB Editor figure objects. An AXL program cannot modify DRC objects directly.

AXL/SKILL Interactive Edit Functions

This section lists interactive edit functions.

axlBondFingerDelete

```
axlBondFingerDelete (
    bondFingers
    deleteWires
)
==> t/nil
```

Description

Deletes the (list of) bond fingers passed in. Optionally, it will delete the connect bond wire elements as well.

Arguments

bondFingers	either a dbid or a list of dbids representing the bond fingers to be deleted.
deleteWires	t/nil to tell the system whether it should remove any bond wires connected to the fingers.

Value Returned

Value is `t` returned, if one or more objects are deleted; otherwise the return value is `nil`.

axlBondWireDelete

```
axlBondWireDelete(  
    bondWires  
    deleteFingers  
)  
==> t/nil
```

Description

Deletes the (list of) bond wires passed in. Optionally, it will delete the connect bond finger elements as well.

Arguments

Argument...	Value...
bondWires	dbid or list of dbid, representing the bond wires to be deleted.
deleteFingers	<ul style="list-style-type: none">■ t: Bond fingers connected to the wires are removed■ nil: Connect bond fingers are not deleted

Value Returned

Value is t returned, if one or more objects are deleted; otherwise the return value is nil.

axlChangeLine2Cline

```
axlChangeLine2Cline(  
    lo_dbid/o_dbid  
)  
==> x_cnt/nil
```

Description

Changes provided lines to clines. Lines not on an etch layer are ignored. If a line is converted to a cline then it may be assigned to a net, otherwise it will be left on a the standalone branch.

Arguments

lo_dbid/o_dbid A single dbid or list of line dbids

Value Returned

t if succeeded, *nil* if failure

FAILURES: (for debug purposes set axlDebug(*t*) to see additional messages)

- dbid is not a line or a line on ETCH class
- line is LOCKED or FIXED

Examples

■ Convert a line

```
res = axlDBCreateLine(' (0:0 100:100) 5 "ETCH/TOP")  
res = car(res)  
cnt = axlChangeLine2Cline(res)
```

See Also

[axlTransformObject](#)

axlChangeWidth

```
axlChangeWidth(  
    lo_dbid/o_dbid  
    f_newWidth  
    [g_invisible]  
)  
==> lo_dbid/nil
```

Description

Changes width of lines, clines and segments (arc and line).

By default, only visible lines are changed. This allows layer filtering by temporary changing the visible layers (see example in [axlVisibleUpdate](#)). If you wish to override this behavior then set the value of the optional variable *g_invisible* to t.

Note: If you need to change the width of multiple lines, it is more efficient to pass them as a list of *dbids* than to call this function for each *dbid*. This function does not support change in the width of shape borders.

Arguments

<i>lo_dbid/o_dbid</i>	Single dbid or list of dbids.
<i>f_newWidth</i>	New width of line.
<i>g_invisible</i>	If t objects do not need to be visible on the display to have their width changed.

Value Returned

List of width objects or nil if failed.

Failures:

- *dbid* is not a cline, line or line/arc segment of a line/cline.
- Illegal option types.
- Transformed object is outside of database extents.

Example

Changes the width of a cline to 20 in current database use units

```
; ashOne is a selection utility found at
;   <cdsroot>/pcb/examples/skill/ash-fxf/ashone.il
dbid = ashOne()
; pick a line, cline or segment (set find filter)
updatedDbid = axlChangeWidth(dbid, 20.0)
```

See Also

[axlTransformObject](#), [axlChangeLayer](#)

axlCopyObject

```
axlCopyObject(
    lo_dbid/o_dbid
    ?move          l_deltaPoint
    ?mirror        t/nil
    ?angle         f_angle
    ?origin        l_rotatePoint
    ?allOrNone     t/nil
    ?retainNet     t/nil
)
==> t/nil
```

Description

Use this function to copy the database object(s). This supports the same functionality as [axlTransformObject](#) except it copies and transforms one or more objects.

One additional option supported is retainNet. This only applies to vias. If the value of this option is set to `t`, the net of the via is retained on copy, `nil` allows the via to connect to whatever it touches at the new location. In the board, pins are not supported.



Caution


Properties and text attached to the database object are also copied. Also see [axlTransformObject](#) **cautions**.

Arguments

lo_dbid/o_dbid	a single dbid or list of dbids
l_deltaPoint	optional move distance
mirror	optional mirror object (see above table)
f_angle	optional rotation angle
l_rotatePoint	optional rotation point
allOrNone	if <code>t</code> and a group of objects, transform must succeed on all objects or fail
retainNet	<code>t/nil</code> (applies to vias only)

Value Returned

list of transformed objects or `nil` if failed.



If you need to copy a group of objects the performance is much better if you call this function with the object group instead of passing each dbid individually.

Examples

`lDbid` = list of database objects

`dbid` = one database object

Case 1: Copy a set of objects 1000 database units vertically

```
r = axlCopyObject(lDbid, ?move '1000.0:0.0)
```

Case 2: Copy and rotate an object about its origin 45 degrees

```
r = axlCopyObject(dbid, ?angle 45)
```

Case 3: Copy and rotate an object about a rotate point

```
r = axlCopyObject(dbid, ?angle 45 ?origin 100:100)
```

See Also

[axlTransformObject](#), [axlDBCloak](#)

axlDBAltOrigin

```
axlDBAltOrigin(  
    g_mode  
    o_dbid  
)=>xy-nil
```

Description

Returns alternative center for a *dbid*. This provides Skill access to the `move` command's origin point option in the Options tab.

It is intended for symbols instances (it will convert a component instance to its symbol). Body origin rules for symbols, origin is the first rule that is met:

1. the origin of text on the PACKAGE_GEOMETRY/BODY_CENTER layer
2. the center of an extent box created by the union of all shapes on layers
PACKAGE_GEOMETRY (PLACE_BOUND_TOP, PLACE_BOUND_BOTTOM,
DFA_BOUND_TOP, DFA_BOUND_BOTTOM) and EMBEDDED_GEOMETRY
(PLACE_BOUND and DFA_BOUND)
3. center of the symbol bbox

Other Allegro figure *dbids* can be supplied, but all options may not be supported. For example, a CLINE supports the center option, but not '*origin*' or '*pin1*'.

Arguments

g_mode The '*center*' option returns the body center of an object.

The '*origin*' option returns the origin of an object (normally if *dbid* has an *xy* attribute, this is the same coordinate).

For Symbols, the board origin can be set by the origin of text on the PACKAGE_GEOMETRY/BODY_CENTER layer.

The '*pin1*' option returns pin1 as center.

o_dbid A figure (geometric object) *dbid*.

Value Returned

xy	Location requested.
nil	Not a <i>dbid</i> , <i>dbid</i> is not a figure dbid, or mode is not supported for that object.

See Also

[axlDBGetSymbolBodyExtent](#)

Example

The ;ashOne utility is supplied in the examples Skill code.

```
sym = ashOne()  
;  
; select symbol in Find filter and select a symbol  
sym->xy  
;  
; prints (3503.0 1058.0)  
axlDBAltOrigin('origin sym)  
;  
; prints (3503.0 1058.0) -- origin of symbol is same as xy  
axlDBAltOrigin('center sym)  
;  
; prints (3250.0 1737.0)  
axlDBAltOrigin('pin1 sym)  
;  
; prints (3503.0 1058.0) -- pin1 of symbol is same as its x
```

axlDBChangeText

```
axlDBChangeText(  
    o_dbid  
    t_text  
    [r_textOrientation/x_textBlock]  
    ?layer t_layer  
)  
==> l_result/nil
```

Description

Modifies the characteristics of a text string in the layout. To keep current settings on the text, set the arguments, `t_text` and `r_textOrientation` to `nil`. To move text use the [axlTransformObject](#) object.

Note: For renaming refdes this works the same as edit text in that it checks for the `HARD_LOCATION` property and will not rename refdes if this property is present. If you want to ignore this property, use [axlRenameRefdes](#).

Arguments

<code>o_dbid</code>	Database ID of text
<code>t_text</code>	Text string. If the value of this argument is set to <code>nil</code> , current settings are retained on the text
<code>r_textOrientation</code>	Orientation of text The <code>nil</code> value indicates that current settings are to be retained on the text. See <u>Structure</u> .
<code>x_textBlock</code>	To be specified if only the text block is to be changed

Structure

The axlTextOrientation structure is as follows.

```
defstruct axlTextOrientation  
  r_textOrientation ; orientation of text  
    textBlock;      A string specifying the text block name  
    rotation;       A floatnum variable specifying rotation in degrees  
    mirrored;       Possible values are:  
      ○ t: mirrored  
      ○ nil: not mirrored  
      ○ GEOMETRY: only geometry is mirrored.  
  justify;        Supported values:  
    ○ left  
    ○ center  
    ○ right
```

If any of these arguments is modified, then you need to provide values for all arguments. Arguments for which the values are not changed, copy the values from the existing text dbid.

Note: As with all SKILL defstructs, use constructor function, make_axlTextOrientation to create instances of axlTextOrientation. To copy instances of axlTextOrientation, use the copy function, copy_axlTextOrientation.

Value Returned

nil	defstruct not created
I_result	List containing: <ul style="list-style-type: none">■ (car) list of DBID of the text■ (cadr) t if DRCs created or nil.



Do not pass text string with newlines as an argument.

See Also

[axlTransformObject](#), [axlChangeLayer](#), [axlRenameRefdes](#), [axlTextOrientationCopy](#)

Example

Example is text added in axlDBCreateText

```
text = car(ret)
```

- Change text

```
cret = axlDBChangeText(text "Chamfer neither sides")
```

- Change text block

```
cret = axlDBChangeText(text nil 4)
```

- Change rotation and text

```
axlTextOrientationCopy(text myorient)  
myorient->rotation = 0.0  
cret = axlDBChangeText(text "New text" myorient)
```

axlDeleteObject

```
axlDeleteObject(  
    o_dbid/lo_dbid  
    [g_mode]  
)  
⇒ t/nil
```

Description

Deletes single or list of database objects from database.
Deletion of components deletes the symbol owner as well.
Deletion of nets is LOGIC only, and leaves the physical objects.

Command allows for rip-up of associated etch via the ripup option.

```
axlDeleteObject(lo_dbid 'ripup)
```

Except for Nets, objects will be erased before they are deleted. Only the Net's Ratsnests is erased. Other parts of a Net will not be erased because there is no ripup. If a Net is in a highlighted state, it will be dehighlighted.

Also allows deletion of the following parameter records:

- artwork (films)

Both individual films can be deleted and all films. If all films are deleted then next time the artwork dialog is opened then it will be auto-populated with the default films.

- subclasses

subclasses must be empty and legal for deletion (cannot delete PIN subclasses).

In the case of deleting parameter records, the current restriction is to only pass that single object. Do not try to pass multiple parameter objects or to mix them with non-parameter objects.

Arguments

o_dbid/lo_dbid *dbid*, or list of *dbids* to delete from layout.

g_mode optional delete options.

'ripup - enable etch ripup option (same as Allegro delete ripup command ripup option)

Value Returned

t Deleted one or more objects from the layout.

nil Deleted no objects from the layout.



If passed component or net dbid will delete the logic. This is different from the Allegro delete command which will delete the physical objects associated with the logic (clines/vias for nets and symbols for components). To emulate the Allegro delete command behavior, select and then set objects selection using axlSetFindFilter with the equivlogic parameter passed to the ?enabled option (See example below).

Example

The following example loops on axlSelect and axlDeleteObject, deleting objects interactively selected by user. This could be dangerous because object is deleted without allowing *oops* (left as an exercise to the reader -- required use of axlDBStartTransaction and popup enhancement).

```
(defun DelElement ()  
    let ((mypopup)  
        "Delete selected Objects"  
        mypopup = axlUIPopupDefine(nil  
            '("Done" axlFinishEnterFun)  
            ("Cancel" axlCancelEnterFun)))  
        axlUIPopupSet(mypopup)  
        axlSetFindFilter(?enabled '("ALL" "EQUIVLOGIC") ?onButtons '("ALL"))  
        while( axlSelect() axlDeleteObject(axlGetSelSet()))  
        axlUIPopupSet( axlUIPopupDefine(nil nil))  
) )
```

The following deletes the TOP artwork film record

```
p = axlGetParam("artwork:TOP")  
axlDeleteObject(p)
```

Allegro SKILL Reference

Interactive Edit Functions

The following deletes all films

```
axlDeleteObject(axlGetParam) ("artwork"))
```

axlDeleteTaper

```
axlDeleteTaper(  
    o_dbid  
)  
==> t/nil
```

Description

Deletes tapers

Arguments

o_dbid dbid of Shape or PATH.

Value Returned

- *t* – indicates success
- *nil* – command failed

axlDBDeleteProp

```
axlDBDeleteProp(  
    lo_attach  
    lt_name  
)  
⇒ l_result/nil
```

Description

Deletes the properties listed by name, in *lt_name*, from the objects whose *dbids* are in *lo_attach*.

Arguments

<i>lo_attach</i>	List of <i>dbids</i> of objects from which properties are to be deleted. <i>lo_attach</i> may be a single <i>dbid</i> . If <i>lo_attach</i> is <i>nil</i> , then the property is to be deleted from the design itself.
<i>lt_name</i>	List of names of the properties to be deleted. <i>lt_name</i> may be a list of strings for several properties, or a single string, if only one property is to be deleted.

Value Returned

<i>l_result</i>	List. (car) list of <i>dbids</i> of members of <i>lo_attach</i> that successfully had at least one property deleted. (cadr) always <i>nil</i> .
<i>nil</i>	No properties deleted.

See Also


[axlDBAddProp](#), [axlDBDeletePropAll](#)

Example

```
axlDBCreatePropDictEntry(  
    "myprop", "real", list( "pins" "nets" "symbols"),  
    list( -50. 100), "level")  
axlClearSelSet()  
axlSetFindFilter(  
    ?enabled '("NOALL" "ALLTYPES" "NAMEFORM")  
    ?onButtons "ALLTYPES")  
axlSingleSelectName( "NET" "ENA2")  
axlDBAddProp(axlGetSelSet(), list("MYPROP" 23.5))  
axlShowObject(axlGetSelSet())
```

First defines the string-valued property "myprop", then adds it to the net "ena2", then deletes the property from the net.

The following **Show Element** form shows the net with "MYPROP" attached.




Allegro SKILL Reference

Interactive Edit Functions

```
axlDBDeleteProp(axlGetSelSet() list("myprop"))
axlShowObject(axlGetSelSet())
```

Using `axlDBDeleteProp`, deletes the attached property.

The following Show Element form shows the net with *MYPROP* deleted.



axIDBDeletePropAll

```
ax1DBDeletePropAll( t_name ) ==> x_count/nil
```

Description

Deletes all instances of the property `t_name` in the database. This includes properties that exist on the `symDef` and `compDef` that cannot be accessed via the property edit command. If you delete a property that effects the DRC system, you may wish to wrap this call with a `axIDBCloak` for better performance.

Arguments

t_name Name of property to have all its instances deleted.

Value Returned

x_count Returns number of properties deleted

nil Error, property definition doesn't exist

See Also

[axIDBAddProp](#), [axIDBDeleteProp](#), and [axIDBCloak](#)

EXAMPLE

Delete all fixed properties in database

```
axlDBDeletePropAll( "FIXED" )
```

ax1DBDeletePropDictEntry

```
ax1DBDeletePropDictEntry(  
    t_name  
)  
==> t/nil
```

Description

Deletes an unused user property definition. Property entry must be unused. The property definition must be a user property and its useCount (ax1DBGetPropDictEntry) must be zero for you to delete it. Use ax1DBDeletePropAll if property is in use.

Arguments

t_name String specifying the name of the user property dictionary entry to be deleted.

Value Returned

t : Deleted the property definition.

nil Property is in use, is an Allegro property, property does not exist, or name is not legal.

See Also

[ax1DBAddProp](#), [ax1DBDeleteProp](#), and [ax1DBCreatePropDictEntry](#)

EXAMPLE

take property, myprop, created ax1DBCreatePropDictEntry

```
    ax1DBDeletePropDictEntry("myprop")
```

axIDBOpenShape

```
axIDBOpenShape(  
    o_shapeDbid/nil  
    [o_polygon/r_path/nil]  
    [g_close]  
)  
==> o_dbid/nil
```

Description

Opens an existing shape to replace its boundary or to modify its voids.

Shape can be left open so you can update the voids within the shape. If only the outline needs to be replaced, you can close the shape as part of this call. The new outline cannot overlap existing voids or allow existing voids to exist outside the outline.

Note: A side-effect of opening an existing shape is the shape will be displayed as unfilled until it is closed.

Arguments

o_shapeDbid	dbid of shape to be modified. If dbid is nil then use the existing open shape
o_polygon	new shape outline in polygon format
r_path	new shape outline in r_path format
g_close	optional option to close the shape (t) boundary modification

Value Returned

o_dbid	dbid of provided shape or nil if an error
--------	---

See Also

[axIDBCreateCloseShape](#), [axIDBCreateOpenShape](#), [axIDBCreateVoid](#),
[axIShapeDeleteVoids](#), [axIShapeAutoVoid](#)

Examples

ashOne is a shareware utility that allows user to select an object (see *<CDSROOT>/share/pcb/examples/skill/ash-fxf/ashone.il*)

1. Select a shape and expand it by 100

```
shp = ashOne("shapes")
edge = car( axlPolyFromDB(shp) )
newedge = car( axlPolyExpand(edge 100.0 'NONE) )
newshp = axlDBOpenShape(shp newedge t)
```

2. Select a void delete it

```
shp = ashOne("voids")
edge = axlPolyFromDB(shp)
newedge = car( axlPolyExpand(edge 100.0 'NONE) )
newshp = axlDBOpenShape(shp newedge)
q = axlDBCreateCloseShape(newshp)
```

3. Select a shape, delete all voids and contract boundary by 100

```
shp = ashOne("shapes")
edge = car( axlPolyFromDB(shp) )
newedge = car( axlPolyExpand(edge -100.0 'NONE) )
newshp = axlDBOpenShape(shp nil)
axlShapeDeleteVoids(shp)
q = axlDBCreateCloseShape(newshp)
```

axlGetLastEnterPoint

```
axlGetLastEnterPoint ()  
⇒ l_point/nil
```

Description

Gets the last pick location from `axlEnterPoint`.

Arguments

None.

Value Returned

`axlGetLastEnterPoint` User pick from last call to `axlEnterPoint()`.

Example

Returned list for a pick: (1000.000 2000.000).

axILastPick

```
ax1LastPick( l_mode ) ⇒ xy
```

Description

This returns the last processed cursor pick. You can snap to current grid (`l_mode`) → t) or leave it unsnapped. Position is returned in design units. The grid used depends on the active layer. A pick event causes the last pick. In Skill, a call to `axlEnterPoint`, `axlEnterEvent`, etc. may generate this. It allows switching from a snapped to an unsnapped event. If a user has made no pick since launching Allegro PCB Editor, then it returns (0 0).

Arguments

l_mode t for snapped and nil for unsnapped.

Value Returned

Last pick as an xy list.

Examples

```
snappedPoint = axlEnterPoint(?prompts list("Pick origin point") ?gridSnap t)  
unsnapped = axlLastPick(nil)
```

axlWindowBoxGet

```
axlWindowBoxGet(  
)  
⇒ l_bBox
```

Description

Returns the bounding box of the Allegro PCB Editor window currently visible to the user, in design units.

Arguments

None.

Value Returned

<i>l_bBox</i>	bBox of the current Allegro PCB Editor window.
---------------	--

axlWindowBoxSet

```
axlWindowBoxSet(  
    l_bBox  
)  
⇒ l_bBox/nil
```

Description

Sets Allegro PCB Editor display to given bBox. Adjusts it according to the aspect ratio and returns the adjusted bBox.

Arguments

<i>l_bBox</i>	bBox for display change.
---------------	--------------------------

Value Returned

<i>l_bBox</i>	Adjusted bBox.
---------------	----------------

<i>nil</i>	Invalid argument.
------------	-------------------

axlReplacePadstack

```
axlReplacePadstack (
    o_dbid/lo_dbid
    o_padstackdbid/t_padname
)
⇒ lo_dbid
```

Description

Replaces the padstack on a pin or via (or a list of them). Will not print any error messages unless you have argument errors.

The pin/via can be a list or a single *dbid*. Ignores items in the list that are not pins or vias.

The padstack can be referenced by name or a *dbid* and must be present in the Allegro PCB Editor database. Use `axlDBCreatePadStack` to obtain a *dbid*.

Returns a list of pins/vias that have had their padstacks changed. This may not be the same as your initial list as the software removes *dbids* that are not pins or vias and those items where changing the padstack would create a database error.

Note: This function will not change symbol definition pins.



Caution

Changing the padstack on a pin in the drawing editor results in an exploded pin which increases your database size and impacts refresh_symbol.

Using this function can result in disconnects and new DRC violations.

Performance Hints

To change all instances of a particular padstack, it is faster to change the padstack itself.

If you are changing many pins and vias to the same padstack, you can save time by calling this function with a list of pins/vias instead of calling it for each pin or via.

axlDeleteFillet

```
axlDeleteFillet(  
    o_dbid  
)  
⇒ t/nil
```

Description

Deletes fillet associated with a PIN, VIA, T, or CLINE. The command also deletes a single fillet if *o_dbid* is a fillet shape.

When deleting via a cline, Allegro PCB Editor searches for the via/pin connections and deletes the fillets from that pin or via. It only deletes FILLETS on the layer of the CLINE. If deleting FILLETS from a PIN or VIA, it deletes FILLETS on all layers.

Arguments

o_dbid *dbid of a PIN, VIA, PATH, or T.*

Value Returned

t Fillet deleted.

nil No fillet deleted.

axlFillet

```
axlFillet (
    o_dbid
)
⇒ t/nil
```

Description

Adds fillet between cline and pin/via, and at T. Removes and re-generates existing fillets. Fillet parameters are controlled from the Glossing **Pad and T Parameter** form.

Arguments

o_dbid *dbid* can either be a NET or CLINE.

Value Returned

t Fillet added.

nil No fillet added.

Notes

Pins, vias and Ts are not supported; use axlDBGetConnect on these objects to get a list of clines that connect.

For best performance, especially if fillets impact dynamic shapes, make a single call with the list of objects to be filleted.

Examples

```
fillet new MEMDATA8

axlFillet(car(axlSelectByName( "NET"  "MEM_DATA8" )) )
```


axlPurgePadstacks

```
axlPurgePadstack (
  S_mode
  t/nil
)
⇒ x-cnt
```

Description

Purges unused padstacks from the database in the area controlled by *S_mode* symbol.

S_mode symbol	2nd arg = t	2nd arg = nil
'padstacks	Only purges unused derived padstacks.	Purges all unused padstacks.
'via	Purges vias not found from all via list constraints under the physical rule set and purges vias not loaded in the database, but found by looking on the disk via the PSMPATH environment variable.	Purges vias not found from all the via list constraints under the physical rule set. The nil option is NOT available from the Allegro PCB Editor user interface.



Tip
For best results, first delete the unused padstacks from the database, then purge the via lists.

Arguments

<i>S_mode</i>	'padstacks or 'via.
<i>option</i>	t- purge unused derived padstacks or nil - purge all

Value Returned

x_cnt Number of padstacks eliminated.

Examples

```
axlPurgePadstacks('padstacks nil)  
axlPurgePadstacks('via t)
```

Emulates the default Allegro PCB Editor user interface behavior.

axlShapeAutoVoid

```
axlShapeAutoVoid(  
    o_shapeId  
    [s_options/ls_options]  
)  
==> lo_shapeIds/nil
```


Description

Autovoids a static shape using current static shape parameters to control voiding except where options provide an override. Voiding dynamic shapes or dynamically-generated shapes is not supported.

This function produces a file, `shape.log`, as a side effect of the autovoid.

Options:

- '*noRipThermals*' - by default autovoid rips up all existing thermal ties in the shape and creates a new set, maintaining existing thermals.
- '*fragment*' - by default, if shape fragments into multiple shapes, prompts you before proceeding. If you proceed, Allegro PCB Editor allows a silent fragment. Overrides setting in static shape parameter record.
- '*noFragment*' - opposite of fragment. API fails if shape needs to be fragmented.



Do not use this function to void shapes on negative planes. Artwork does not represent inside voiding.

Arguments

<i>o_shapeId</i>	Voidable shape.
<i>s_options</i>	Single option symbol (see above).
<i>ls_options</i>	List of options (see above).

Value Returned

<i>lo_shapeId</i>	List of voided shape. Normally this is one shape unless shape is broken into multiple pieces.
nil	Failed to void or illegal arguments.

See Also

[axlShapeDeleteVoids](#)

Examples

See <cdsroot>/share pcb/examples/skill/ash/ashshape.il

```
axlShapeAutoVoid(shapeDbid '(noRipThermals fragment))
```

axlShapeChangeDynamicType


```
axlShapeChangeDynamicType (
    o_shapeId
    g_dynamic
    g_msgs
) -> o_dynShapeId/l_staticShapeId/nil
```

Description

Swaps a connectivity shape from static to dynamic or the reverse. This offers the same functionality as the Allegro PCB Editor command `shape change type`.

Notes:

- Voids in static are deleted when shape is converted to dynamic.
- Converting a dynamic shape to static can result in the loss of the original boundary since Allegro PCB Editor converts the generated shapes (on ETCH) to static shapes not boundary shapes.
- Shapes converted to static maintain voids.



Tip

If changing the type of multiple shapes or doing multiple operations on a single shape (for example, convert then raise priority) consider wrapping the code in `axlDBCloak` to batch updates.

Arguments

<code>o_shapeId</code>	Dynamic shape id or static id.
<code>g_dynamic</code>	<code>t</code> makes the shape dynamic, <code>nil</code> makes the shape static.
<code>g_msgs</code>	<code>t</code> issue error messages if failed to convert; <code>else</code> be silent

Value Returned

<code>nil</code>	Failure.
<code>o_dynShapeId</code>	<code>dbid</code> of the dynamic shape converted from static.

l_staticShapeId List of static shapes converted from dynamic shapes.

See Also

[axlShapeChangeDynamicType](#)

Examples

See <cdsroot>/share pcb/examples/skill/axlcore/ashshape.il

Change to dynamic shape with messages:

```
ret = axlShapeChangeDynamicType(shape t t)
```

Change to static shape; no messages

```
ret = axlShapeChangeDynamicType(shape nil nil)
```

axIShapeDeleteVoids

```
axIShapeAutoVoid(  
    o_shapeId/o_voidId/lo_voidid  
) -> t/nil
```

Description

Lets you delete voids in a shape. Supports the following forms of arguments:

- Shape that deletes all voids in that shape
- Delete single void
- Delete list of voids

Non-voids in list of voids options are silently ignored. You cannot delete the voids that are a part of auto-generated shapes.

If you are making a series of modifications to a shape, such as, deleting and adding voids or changing the shape boundary, then for best performance, it is recommended that you wrap your calls in [axIDBOpenShape](#) and [axIDBCreateCloseShape](#).

Arguments

o_shapeId Given a shape; deletes all voids associated with that shape.

o_voidId Deletes the given void.

lo_voidid Deletes the list of voids.

Value Returned

t Deletes voids.

nil Error.

See Also

[axIShapeAutoVoid](#), [axIDBOpenShape](#), [axIDBCreateCloseShape](#)

Examples

See <cdsroot>/share pcb/examples/skill/axlcore/ashshape.il

Assuming you have `shape dbid (shapeId)`:

- Delete a single void

```
axlShapeDeleteVoids(car(p->voids))
```

- Delete all voids in shape except first:

```
axlShapeDeleteVoids(cdr(p->voids))
```

- Delete all voids in the shape:

```
axlShapeDeleteVoids(p)
```

axlShapeDynamicUpdate

```
axlShapeDynamicUpdate(  
    o_shapeDbid/nil  
    g_force  
) -> x_ood/nil
```

Description

Updates a dynamic shape, or if `nil`, all dynamic shapes are updated. This ignores the current dynamic shape mode setting of the design.

By default, only updates the shape if it is out of date unless `g_force` is `t`. In this case, it updates the shape. If `g_force` is `nil` the shape is only updated if `dbid->fillOOD` is `t`. This function supports shapes whose `dbid->shapeIsBoundary` is `t`. Updating a dynamic shape includes voiding, artwork smoothing, and thermal relief generation.

Arguments

`o_shapeDbid` `dbid` a dynamic shape.

`g_force` Force shape to update even if it is up to date.

Value Returned

`x_ood` If updating all returns count of all shapes that failed in updating.
If single shape returns 0; update successful, 1 otherwise.

`nil` Return if there is an error; `dbid` is not a dynamic shape.

Examples

Force update of one dynamic shape:

```
axlShapeDynamicUpdate(shapeId, t) -> 0
```

Update all shapes `ood`:

```
axlShapeDynamicUpdate(nil nil) -> 0
```

axlShapeRaisePriority


```
axlShapeRaisePriority(  
    o_shapeId  
) -> x_priority/nil
```

Description

Raises the voiding priority of a dynamic shape (*o_shapeId*) to the highest on the chosen layer. If this shape overlaps other dynamic shapes on the layer, the other shapes void away from this shape.

The priority number is relative. Allegro PCB Editor adjusts the numbers, as necessary. You should only use the priority number for comparison with other dynamic shape priority numbers.

For a dynamic shape (those on CLASS=BOUNDARY) the attribute priority reflects the current priority (for example, `dbid->priority`).



If raising priority on multiple shapes or doing multiple operations on a single shape (for example, convert; then raise priority) consider wrapping the code in `axlDBCloak` to batch updates.

Arguments

o_shapeId Dynamic shape id.

Value Returned

x_priority > 0 New priority of shape.

-1 Already at highest priority.

nil Not a dynamic shape.

See Also

[axlShapeChangeDynamicType](#)

Example

See <cdsroot>/share pcb/examples/skill/axlcore/ashshape.il

```
axlShapeRaisePriority(shape)
```

axIShapeMerge


```
axIShapeMerge(  
    o_shapeId  
    lo_shapes  
    g_options/lg_options  
) -> o_dynShapeId/l_staticShapeId/nil
```

Description

This merges shapes. Shapes must be overlapped without the fixed property to merge. All merging shapes (`lo_shapes`) must overlap the primary shape (`o_shapeId`).

Supports merging db types; shapes, rectangle and filled rectangles.

The resulting shape will take on the characteristics of the first shape. This includes shape type and properties. Any properties on the secondary shapes are lost.



Tip

If changing type of multiple shapes or doing multiple operations on a single shape (e.g. convert then raise priority) consider wrapping the code in `axIDBCloak` to batch updates.

Arguments

<code>o_shapeId</code>	dynamic shape id or static id.
<code>g_dynamic</code>	<code>t</code> make shape dynamic, <code>nil</code> make static
<code>g_options</code>	Available options are: 'check' - do not merge only perform checks for merging 'quiet' - do not output any messages

Value Returned

- `nil`: indicates failure
- `o_dynShapeId`: the dbid of the dynamic shape that was converted from static
- `l_staticShapeId`: list of static shapes that was converted from a dynamic shape.

See Also

[axlShapeChangeDynamicType](#)

Example

See *<cdsroot>/share pcb/examples/skill/ash/ashshape.il*

- Change to dynamic with messages

```
ret = axlShapeChangeDynamicType(shape t t)
```

- Change to static no messages

```
ret = axlShapeChangeDynamicType(shape nil nil)
```

axlShovelItems

```
list  
axlShovelItems(  
    l_itemList  
)  
⇒ t/nil
```

Description

Takes a list of *dbids* and shoves them according to the parameters set using axlShoveSetParams.

Arguments

l_itemList List of *dbids* (clines, pins, or vias) to be shoved.

Value Returned

t One or more items shoved.

nil No items shoved.

Note: Pins and vias are not shoved, but the clines around them are shoved in an attempt to eliminate any DRCs between the pin/via and the cline.

The list of *dbids* passed in does not reflect the results of the shove, as the original item may be deleted and/or replaced.

Example

```
(defun ShoveElement ()  
    axlSetFindFilter (?enabled '("CLINES" "VIAS")  
                      ?onButtons '("CLINES" "VIAS"))  
  
    axlSelect()  
    axlShovelItems (axlGetSelSet())  
)
```

Shoves an item (or items) interactively selected by the user.

axlShoveSetParams

```
axlShoveSetParams(  
    l_params  
)  
⇒ t/nil
```

Description

Sets the parameters used for shoving by the `axlShoveItems`. If you do not provide all values, the indicated default is used.

Arguments

l_params List of parameters of the form:

(shoveMode cornerType gridded smooth oop samenet)

ShoveMode is an integer as shown:

shoveMode	Description
0	hug preferred - Items passed in try to mold around items they are in violation with (default)
1	shove preferred - Items passed in try to shove items they are in violation with.

CornerType is an integer as shown:

cornerType	Description
90	90 degree corners.
45	45 degree corners.
0	Any angle corners.

Gridded is an integer as shown:

gridded	Description
0	Ignore grids (default)
1	Perform shoves on grid.

Smooth allows smoothing of shoved traces and is an integer as shown:

smooth	Description
0	No smoothing (default)
1	Minimal smoothing.
2	More smoothing.
3	Still more smoothing.
4	Full smoothing.

Oops allows aborting the shove of DRCs result and is an integer as shown:

oops	Description
0	<i>Oops</i> off (default)
1	<i>Oops</i> if drcs are left over.

Samenet tests for samenet violations.

Note: This results in a post-shove check for drcs that is meaningful only if you also set *oops* to the "oops if drcs" value.

samenet	Description
0	No <i>samenet</i> tests (default).
1	Enable <i>samenet</i> DRC checking.

Value Returned

t Shove parameters set.

nil No shove parameters set.

Example

```
(defun SetParams ()  
  (let (params (shoveMode 1) (cornerType 45) (gridded 1))  
    params = list(shoveMode cornerType gridded)  
    axlShoveSetParams (params)  
  ))
```

Sets shove parameters to shove preferred, 45 degree mode, and snap to grid.

axlSmoothDesign

```
axlSmoothDesign(  
    lx_numPasses  
) -> x_change
```

Description

Smooths the entire design. For good results on complicated designs, multiple passes are necessary. Since changes in one pass may open space that can be used in the next pass. Suggest 3 is a typical number although very complex designs can benefit from a higher number of passes. But the more passes the longer it will take.

Arguments

lx_numPasses list of number of passes to perform

Value Returned

x_change, number of items changed

Example

Smooth design using 3 passes

```
axlSmoothSetParams(list("45" -1.0 "0" 10.0 0))  
res = axlSmoothDesign(list(3))
```

See Also

[axlSmoothSetParams](#)

axlSmoothItems

```
axlSmoothItems (
    lo_clineList
) ==> (x_list
```

Description

Takes a list of dbids representing clines and/or cline segments and smooths them according to the parameters set using the [axlSmoothSetParams\(\)](#) function.

Arguments

lo_clineList List of dbids representing clines and/or cline segments to be smoothed.

Value Returned

This function returns a list containing the number of clines that were changed by the smoothing process and the list of changed items. The format is as follows:

```
(x_change (o_dbid1 o_dbid2 o_dbid3))
```

Where `x_change` indicates the number of items changed, or `-1` if a user interrupt occurred.

If an error occurs, the function will return `nil`.

Example

■ Smooth a set of clines

```
clines = <list of ...>
axlSmoothSetParams(list("45" -1.0 "0" 10.0 0))
res = axlSmoothItems(clines)
```

See Also

[axlSmoothSetParams](#)

axlSmoothSetParams


```
axlSmoothSetParams(  
    l_params  
) ==> t/nil
```

Description

Sets the parameters used for smoothing the routes. All parameters must be supplied but a nil as a parameter option will leave the existing setting.

The smooth functionality is provided on an "as-is" basis. It works well on many designs but has the following restrictions:

- not differential pair aware.
- may have issues with electrically constrained nets



Tip
See [axlDBIgnoreFixed](#) if you want to temporary disable FIXED testing.

Arguments

l_params List containing the parameters, the list is of the following format.

```
(cornerType maxCornerLength padEntryRestriction minPadEntryLength  
sortDirection)
```

cornerType	Can be one of the following string values: 90 for 90 degree corners 45 for 45 degree corners 0 for any angle corners 1 for arc corners
maxCornerLength	This is an integer value indicating the maximum length of a bubble or jog in dbunits. A negative value indicates UNLIMITED.
padEntryRestriction	Can be one of the following string values:

Allegro SKILL Reference

Interactive Edit Functions

	2	Indicates that there are no restrictions
	1	Indicates that all pad entry segments be fixed
	0	Indicates that the entry segments for all rectangular pads be fixed
minPadEntryLength		This is an double value indicating the minimum length of fixed pad entry segments in user units. If a pad entry segment is longer than this length, it will be broken at or near that point so that smoothing can occur on that segment. A negative value indicates UNLIMITED. This value is not applicable if padEntryRestriction is "2".
sortDirection		This indicates how the clines are to be sorted before smoothing begins. This can be one of the following integer values:
	0	No sorting.
	1	Sort from the North.
	2	Sort from the NorthEast.
	3	Sort from the East.
	4	Sort from the SouthEast.
	5	Sort from the South
	6	Sort from the SouthWest
	7	Sort from the SouthWest
	8	Sort from the NorthWest

Value Returned

t if successful, nil if not.

Example

■ set params

```
axlSmoothSetParams(list("45" -1.0 "0" 10.0 0))
```

- Update cornertype to 90

```
axlSmoothSetParams(list("90" nil nil nil nil))
```

See Also

[axlSmoothItems](#), [axlSmoothDesign](#), [axlDBIgnoreFixed](#)

axlSymbolAttach

```
axlSymbolAttach(  
    o_symInstDbid  
    o_dbid/lo_dbid  
)  
==> t/nil
```

Description

Attaches an object or list of objects to symbol instance. For etch objects, provides the ability to associate pin escapes with a symbol.

Attach/detach rules:

- For detaching, object must be linked to the symbol instance provided. For attaching, the object can not be linked to any other symbol.
- If text appears of a REFDES class, it can't be linked or unlinked
- Linking or unlinking non-etch objects cause them to be deleted or duplicated if refresh symbol is run. Etch objects is more fully supported by refresh symbol.
- CLINES, LINES, SHAPES, RECTS, FRECTS and TEXT are supported with the layer limits noted below:
 - Items on BOUNDARY class items are NOT supported.
 - Shapes cannot be dynamic or generated from a dynamic shape.
 - Objects cannot be on the DRC class.



Running refresh_symbol may result in deletion of design level attachments.

Arguments

o_symInstDbid symbol instance

o_dbid dbid to assign to symbol

lo_dbid list of dbid to assign to symbol

Value Returned

t was able to change object

nil otherwise

See Also

[axlSymbolDetach](#)

Example

Examples use ashOne which is a shareware utility that allows user to select an object (see <cdsroot>/share pcb/examples/skill/ash-fxf/ashone.il)

■ Attach an object to a symbol:

```
symdbid = ashOne("SYMBOLS")
dbid = ashOne("NOALL")
ret = axlSymbolAttach(symdbid dbid)
```

axlSymbolDetach

```
axlSymbolDetach(  
    o_symInstDbid  
    o_dbid/lo_dbid/g_mode  
)  
==> t/nil
```

Description

Remove an object from a symbol instance. This function unlinks objects from the given symbol instance.

For pin escapes, two special modes are provided to detach all or most symbol etch from a given symbol instance.

It only unlinks an object from a symbol if it matches the provided symbol instance.

See [axlSymbolAttach](#) for the rules.



Running refresh_symbol result results in duplicate objects as the detached objects are loaded again.

Arguments

<i>o_symInstDbid</i>	symbol instance to modify.
<i>o_dbid</i>	dbid to unlink from symbol
<i>lo_dbid</i>	list of dbids to unlink from symbol
<i>g_mode</i>	special modes for unlinking all "etch" from symbol
	<ul style="list-style-type: none">○ 'allEtch – deassign all etch from symbol○ 'allClineVia – design all etch except for shapes from symbol

Value Returned

<i>t</i>	was able to change symbol
----------	---------------------------

nil Otherwise

See Also

[axlSymbolAttach](#)

Example

Examples use ashOne which is a shareware utility that allows user to select an object (see <cdsroot>/share pcb/examples/skill/ash-fxf/ashone.ill)

- Typical method: To get the symdbid from the object:

- if etch

```
symdbid = dbid->symbolEtch
```

- if nonetch

```
symdbid = dbid->parent
symdbid = ashOne("SYMBOLS")
dbid = ashOne("NOALL")
ret = axlSymbolDetach(symdbid, dbid)
```

- Deassign all etch from symbol except shapes

```
symdbid = ashOne("SYMBOLS")
ret = axlSymbolDetach(symdbid, 'allClineVia)
```

axlAddTaper

```
axlAddTaper(  
    o_dbid/lo_dbid  
)  
==> t/nil
```

Description

Adds tapered trace. Tapered trace parameters are controlled from the Glossing "Pad and T" Parameter form.

Arguments

o_dbid dbid can either be a Path (CLINE) or line (segment).

Value Returned

- *t*, returned when the function call is successful
- *nil*, indicates failure

axlTextOrientationCopy

```
axlTextOrientationCopy(  
    o_textDbid  
    [orient]  
) -> orient/nil
```

Description

This is a convenience function that updates a TextOrientation defstruct based upon a text dbid. This is typically used with [axlDBCreateText](#) or [axlDBChangeText](#).

Arguments

o_textDbid	text dbid
orient	optional existing defstruct, if nil will create a new defstruct

Value Returned

- orient, update TextOrientation defstruct
- nil, if there are error in the arguments

See Also

[axlDBChangeText](#)

axlTransformObject

```
axlTransformObject(  
    lo_dbid/o_dbid  
    ?move l_deltaPoint  
    ?mirror t/nil/'GEOMETRY  
    ?angle f_angle  
    ?origin l_rotatePoint  
    ?allOrNone t/nil)  
)  
⇒ lo_dbid/nil
```

Description

Moves, rotates, and/or spins one object or a list of objects. Each Allegro PCB Editor database object has a legal set of transforms (see [Table 5-1 on page 314](#)). If the object does not accept a transform, then that transform is silently ignored.

If multiple transformations are applied, the order used is:

1. move
2. mirror
3. rotate

If `allOrNone` flag is set, then the entire transformation fails when one object's transformation fails. By default, one object's failure does not stop the transformation on the other objects. A failure is a database failure. For example, a move that puts an object outside of the database extents is a database failure. Attempting an illegal transform is NOT a failure. If one or more objects are not transformed, there is no failure.

Table 5-1 Supported Transforms

OBJECT	MOVE	MIRROR	GEOMETRY	ROTATE	SPIN	ORIGIN (5)	NOTES
segments	X	X	X	X		box	
cline	X	X	X	X		box	
line	X	X	X	X		box	
symbol	X	X		X		xy	
shape	X	X	X	X		box	
text	X	X	X	X		xy	

Allegro SKILL Reference

Interactive Edit Functions

Table 5-1 Supported Transforms, *continued*

OBJECT	MOVE	MIRROR	GEOMETRY	ROTATE	SPIN	ORIGIN (5)	NOTES
pin	X			X		xy	3, 4
via	X	X	X	X		xy	
rat_t	X			X		xy	
group	X	X	X	X		xy	7

Notes

1. If object is not listed, then it is not supported.
2. If object has attached text, it also has the transformation applied.
3. Mirror occurs within the same class. See mirror rules.
4. Symbol is exploded and `refresh_symbol` does not maintain transformation.
5. For Pins on a board to be transformed, the `UNFIXED_PINS` either must be present on the drawing or on the symbol owning the pin.
6. `ORIGIN` column shows what rotate/mirror uses when operating on a single object without the origin option. For box, the `dbid` does not have an origin and it uses the center of its bounding box (`dbid->bBox`). For an `xy` object that has an origin (`dbid->xy`), it rotates about the origin. For further discussion, see the note 9 on angles.
7. This API rejects objects whose owner is a symbol definition
8. The only groups that support a transform are user and module group types.
9. If mirror is `t` then we mirror in x-direction AND across subclasses. For example, if object is on ETCH/TOP it will be mirrored both in x and to layer ETCH/BOTTOM. If mirror is ``GEOMETRY` only a x-direction is done and the object remains on its layer.
10. Rotation (angle option) works as follows:
 - ❑ Positive angle results in a counter-clockwise rotation.
 - ❑ If just angle is provided, then the object is rotated about its origin point. If the `dbid` has no origin, then the center of its bounding box is used. If a list of `dbids` is provided, then the rotation always occurs about the center of the object set.
 - ❑ You can provide a rotation origin.
`(?origin 1_rotatePoint)`.

This point is then used as the rotation point.

Cautions


- More objects may be added in the future. For example, voids.
- The return list may be changed to show the actual set of objects that were transformed.
- Spin (rotate a list of objects about each of their centers) is not supported. Use `axlTransformObject` for each object in the list.
- If you pass a list containing a symbol and pins of the symbol, you get unexpected results.
- If transforming multiple objects, enclose this operation in an `axIDBCloak` call.
- If transforming a segment, it will have a new owning path `dbid`.

Arguments

<code>1o_dbid/o_dbid</code>	Single <code>dbid</code> or a list of <code>dbids</code> .
<code>1_deltaPoint</code>	Move distance.
<code>mirror</code>	Mirror object (see table)
<code>f_angle</code>	Rotation angle.
<code>1_rotatePoint</code>	Rotation point.
<code>allOrNone</code>	If <code>t</code> and a group of objects, transform must succeed on all objects, or fail.

Value Returned

<code>1o_dbid</code>	List of transformed objects.
<code>nil</code>	Failure due to one of the following: <ul style="list-style-type: none">○ An object can't be transformed (for example, a net)○ An object is fixed or a pin does not have an <code>UNFIX_PINS</code> property.○ Illegal option types used.○ Transformed object is outside of the database extents.



Tip

For better performance when transforming a group of objects, call this function with the object group instead of passing each *dbid* individually.

See Also

[axlDBCloak](#), [axlCopyObject](#)

Examples

dbid represents one database objects.

l₁dbid represents a list of database objects.

Example 1

```
axlTransformObject(l1dbid, ?move '(100.0 0.0))
```

Moves a set of objects 100 database units vertically.

Example 2

```
axlTransformObject(dbid ?angle 45)
```

Rotates an object about its origin 45 degrees.

Example 3

```
axlTransformObject(dbid ?angle 45 ?origin 100:100)
```

Rotates an object about a rotation point.

axlPadstackEdit

```
axlPadstackEdit(  
    nil  
    nil  
)  
==> l_attributes  
  
axlPadstackEdit(  
    o_dbidPadstack/t_Padstack  
    s_name  
    g_value  
)  
==> t/nil  
  
axlPadstackEdit(  
    o_dbidPadstack/t_Padstack  
    [[s_name g_value] .... ]  
)  
==> t/nil
```


Description

Edits global settings of an existing padstack.

This edits the padstack definition, this means that any changes made applies to all instances of the padstacks (pins and vias) in the design.

Supports the following modes:

- If first two arguments are `nil`, command returns a list of all editable attributes.
- If padstack, attribute, and new value are provided, changes one attribute of padstack.
- If padstack, and a list of attributes with new values are provided change all the items specified in the padstack. This is the most efficient method for changing multiple items on a single padstack.



Tip
Order is important, so if you are changing a CIRCULAR drill to a slot then you must provide the `holeType`, then `drillSizeWidth` then `drillSizeHeight`.

For best performance if changing multiple items in a single padstack use the list mode to change all items in one call.

Currently only global padstack settings are supported. Editing pad layer characteristics is not allowed.

Allegro SKILL Reference

Interactive Edit Functions

Certain changes will set DRC out of date and dynamic shapes out of date.

Attributes currently supported (all Equivalent items are field names in pad_designer):

Table 5-2 Supported Controls

Name	Value	Description	Equivalent	Side Effects
drillDiameter	dbrep	Changes the drill diameter. Value must be a positive number and holeType must not be a slot. For multi-drill applies to all drills.	Drill diameter field	DRC is out of date and dynamic shapes are disabled
drillSizeWidth	dbrep	Changes the slot size width (x direction). Value must be a positive number and holeType must be a slot type. Usually done in association with drillSizeHeight.	Slot size X	DRC is out of date and dynamic shapes are disabled.
drillSizeHeight	dbrep	Changes the slot size width (y direction). Value must be a positive number and holeType must be a slot type. Usually done in association with drillSizeWidth.	Slot size Y	DRC is out of date and dynamic shapes are disabled.

Allegro SKILL Reference

Interactive Edit Functions

Table 5-2 Supported Controls, *continued*

Name	Value	Description	Equivalent	Side Effects
holeType	string	<p>One of "CIRCLE_DRILL", "OVAL_SLOT" or "RECTANGLE_SLOT". Changes hole type of padstack. If changing fundamental types:</p> <ul style="list-style-type: none"> ■ slot to drill; drillDiameter inherits drillSizeWidth. ■ drill to slot; both drillSizeWidth and drillSizeHeight inherit drillDiameter <p>For slots drillFigureName takes on figure for slot type selected and its width and height are the same as the slot width and height.</p>	Hole type	DRC is out of date and dynamic shapes are disabled.
drillNonStandard	string	<p>Changes type of type of non-standard drill. Hole type must be a circular drill. Types are "LASER_DRILL", "PLASMA_DRILL", "PUNCH_DRILL", "PHOTO_DRILL", "COND_INK_DRILL", "WET-DRY_DRILL", and "OTHER_DRILL". Use nil if you want to unset this field.</p>	Non-standard drill	None
drillOffset	point / dbrep	<p>Changes the drill offset. Must be a xy point or a single dbrep which applies to both x and y.</p>	Offset X and Y	DRC is out of date and dynamic shapes are disabled.

Allegro SKILL Reference

Interactive Edit Functions

Table 5-2 Supported Controls, *continued*

Name	Value	Description	Equivalent	Side Effects
holeTolerance	point/ dbrep	Changes the hole tolerance. Point values are taken to be a list of (+tolerance -tolerance) or a single dbrep which applies to both + and -. Both must be a positive number.	Tolerance + and -	None
plating	string	Sets the plating type, must be one of "NON_PLATED", "OPTIONAL", or "PLATED".	Plating	None
drillChar	string	Sets the drill characters. A maximum string of 3 is supported. Longer strings are truncated. Use a nil to remove the string.	Characters	None
drillFigureName	string	Sets the drill figure type. Not supported for slots. Value must be a string that matches one of the drop-down items in the pad_designer "Figure" field.	Figure	None
drillFigureHeight	dbrep	Changes the figure height, value must be a positive number. Option not available for slots. Used in conjunction with drillFigureWidth.	Height (under Drill/ Slot symbol)	None
drillFigureWidth	dbrep	Changes the figure width, value must be a positive number. Option not available for slots. Used in conjunction with drillFigureHeight.	Width (under Drill/Slot symbol)	None
uvia	t/nil	Sets the type of via to bbvia (nil) or micro via (t). Padstack must not be a through or smd padstack	Microvia check box under Usage options	DRC is out of date and dynamic shapes are disabled.

Allegro SKILL Reference

Interactive Edit Functions

Table 5-2 Supported Controls, *continued*

Name	Value	Description	Equivalent	Side Effects
keepout	t/nil	Allows the system to use Antipads of the padstack for voiding and DRC for mechanical pins using this padstack.	Enable Antipads as Route Keepouts (ARK) check box under Usage options	DRC is out of date and dynamic shapes are disabled.

Arguments

`o_dbidPadstack` dbid of a padstack (note VIA and PIN dbids are not supported)
`t_Padstack` Name of padstack
`s_name` Symbol name of attribute to change
`g_value` New value
`[[s_name g_value] ...]` list of name/value pairs

Value Returned

- `ls_names` - If name is nil then returns a list of all controls.
- `t/nil` - if t successful in updating padstack, nil an error

See Also

[axIDBCreatePadStack](#), [axILoadPadstack](#), [axIDBCopyPadstack](#), [axIReplacePadstack](#)

Examples

Finds a padstack using the ashOne share ware skill

```
p = ashOne()
def = p->definiton
```

Allegro SKILL Reference

Interactive Edit Functions

■ Set drill characters

```
ret = axlPadstackEdit(def 'drillChar "abc")
```

or its equivalent

```
ret = axlPadstackEdit(def '((drillChar "abc")))
```

■ Set tolerance

```
ret = axlPadstackEdit(def 'holeTolerance '(1.2 1.3))
```

■ Set tolerance same for + and -

```
ret = axlPadstackEdit(def 'holeTolerance 1.5)
```

■ Set drill symbol data

```
data = '((drillFigureName "RECTANGLE") (drillFigureHeight 20)  
        (drillFigureWidth 10) (drillChar A))
```

```
ret = axlPadstackEdit(def data)
```

■ Get list of all editable padstack parameters

```
lst = axlPadstackEdit(nil nil)
```

Allegro SKILL Reference

Interactive Edit Functions

Database Read Functions

AXL-SKILL Database Read Functions

The chapter describes the AXL-SKILL functions that read the Allegro PCB Editor database.

ax1DBGetDesign

```
ax1DBGetDesign()  
  ⇒ o_design/nil
```

Description

Returns the root design *dbid*. Use this *dbid* to get the design properties and to add properties to the design.

Note: You cannot edit the root design object. AXL-SKILL edit commands ignore this *dbid*.

Arguments

None.

Value Returned

o_design Root design *dbid*.

nil Error occurred.

Example

```
mydesign = ax1DBGetDesign()  
ax1DBAddProp( mydesign, list("board_thickness", 0.350))
```

Gets the root design and sets the *BOARD_THICKNESS* property to 0.350 inches.

To verify the property has the value specified:

1. From the Allegro PCB Editor menu, select *Display – Element*.
2. From the Find Filter, select *Drawing Select*.

The **Show** window appears, listing the current properties attached to the design.

axlDBGetDrillPlating

```
axlDBGetDrillPlating  
  t_padstackname  
)  
⇒ "PLATED"/"NON PLATED"/"OPTIONAL"/nil
```

Description

Retrieves the plating type of the padstack passed as an argument to this function.

Arguments

t_padstackname Name of padstack.

Value Returned

Plated/Nonplated/Optional Drillplating name.

nil Incorrect padstack name, or other error occurred.

axlIsDBIDType

```
axlIsDBIDType(  
    g_dbid  
)  
⇒ t/nil
```

Description

Determines if *g_dbid* is an Allegro PCB Editor database *dbid*. Returns *t* if so and *nil* otherwise.

Arguments

g_dbid Variable to be checked whether a *dbid* or not.

Value Returned

t *g_dbid* is a true Allegro PCB Editor *dbid*.

nil *g_dbid* is not a true Allegro PCB Editor *dbid*.

Example

Defines a function based on `axlIsDBIDType` to tell whether a symbol is an Allegro PCB Editor *dbid* or not. Then creates an *r_path* (which is not an Allegro PCB Editor *dbid*, because *paths* are only temporary building structures) and uses the *r_path* to create an Allegro PCB Editor line (which is an Allegro PCB Editor *dbid*). Shows whether each is a true *dbid*.

```
defun( isItDBID (testDBID)  
    "Print whether testDBID is a true Allegro dbid"  
    if( axlIsDBIDType( testDBID)  
        then  
            println( "This is an Allegro DBID.")  
        else  
            println( "This is NOT an Allegro DBID." ) )  
  
mypath = axlPathStart( list(100:500))  
axlPathLine( mypath, 0.0, 200:250)  
myline = axlDBCreatePath( mypath, "etch/top" nil)  
isItDBID(mypath)  
isItDBID(caar(myline))
```

The function prints the following:

Allegro SKILL Reference

Database Read Functions

"This is NOT an Allegro DBID."
"This is an Allegro DBID."

axlDBGetAttachedText

```
axlDBGetAttachedText (
  o_dbid
)
⇒ l_dbid/nil
```

Description

Returns the list of *dbids* of text objects attached to the object whose *dbid* is *o_dbid*. If [axlDBGetDesign](#) is used to retrieve the dbid, the function returns all text attached to root design.

Arguments

o_dbid *dbid* of object from which attached text *dbids* are retrieved.

Value Returned

l_dbid List of the text objects attached to *o_dbid*.

nil No attached text objects.

Example

```
(defun showText ()
  "Print text of selected objects"
  mypopup = axlUIPopupDefine( nil
    (list (list "Done" 'axlFinishEnterFun)
          (list "Cancel" 'axlCancelEnterFun)))
  axlUIPopupSet( mypopup)
  axlSetFindFilter( ?enabled list("noall")
    ?onButtons "noall")
  axlSetFindFilter( ?enabled list("symbols")
    ?onButtons "symbols")
  axlOpenFindFilter()
  (while (axlSelect)
    progn(
      alltext =
        axlDBGetAttachedText(car(axlGetSelSet())))
      foreach(thistext alltext
        printf( "Text on this symbol is : '%s'\n",
              thistext->text))))
  axlCloseFindFilter())
```

Lets the user pick a symbol, then prints the text attributes of each text object attached to that symbol.

Allegro SKILL Reference

Database Read Functions

Run `showText()` and pick a symbol of device type "74F74" , assigned as `refdes` "T23" .
The function prints the following:

```
Text on this symbol is : 'T23'  
Text on this symbol is : '74F74'
```

axlDBGetPad

```
axlDBGetPad(  
    o_dbid  
    t_layer  
    t_type  
)  
⇒ o_pad/nil
```

Description

For the pin or via specified by *o_dbid*, gets the pad of type *t_type* associated with layer *t_layer*.

Note: smd pads will not have a default internal layer.

Arguments

<i>o_dbid</i>	<i>dbid</i> of the pin, via, or a padstack definition.
<i>t_layer</i>	String representation of a layer of pad to retrieve, for example, "ETCH/TOP". Special layers: <ul style="list-style-type: none">■ 'internal - default internal layer (not present on SMD padstacks)■ 'composite - sum of all the layers (worse case) this option ignores the <i>t_type</i> argument
<i>t_type</i>	Type of pad to retrieve: "REGULAR", "ANTI", or "THERMAL".

Value Returned

<i>o_pad</i>	<i>dbid</i> of the pad of the type associated with <i>o_dbid</i> on the layer specified.
nil	Cannot get the pad <i>dbid</i> .

Example

```
(defun showPad ()  
  mypopup = axlUIPopupDefine( nil  
    (list (list "Done" 'axlFinishEnterFun)  
      (list "Cancel" 'axlCancelEnterFun)))
```

Allegro SKILL Reference

Database Read Functions

```
axlUIPopupSet( mypopup)
axlSetFindFilter( ?enabled list("noall")
    ?onButtons "noall")
axlSetFindFilter( ?enabled list("pins" "vias")
    ?onButtons list("pins" "vias"))
(while axlSelect()
  progn(
    mypad = axlDBGetPad(car(axlGetSelSet()))
    "etch/top" "regular")
  printf( "Pad figure type : %s\n",
    mypad->figureName) )))
```

Lets the user pick any pin or via and shows the *figureName* attribute of the selected pad.

Run `showPad()` and pick a pin with a square pad on "etch/top", then a circular pad. The function prints the following:

```
Pad figure type : SQUARE
Pad figure type : CIRCLE
```

axIDBGetPropDictEntry

```
axIDBGetPropDictEntry(  
    t_name  
)  
⇒ o_propDictEntry/nil  
  
axIDBGetPropDictEntry(  
    nil  
)  
==> lt_validObjects
```

Description

Gets the property dictionary entry for the property name given by the string *t_name*. Use [axIDBGetPropDictEntry](#) to get the information about a property dictionary entry. If name is nil, the command returns a list of legal objects that can be used to create property dictionary entries. This is the *objects* attribute of the *o_propDictEntry* data type. You cannot create a property with the same name as an existing Allegro property.

Arguments

<i>t_name</i>	String specifying the name of the property whose dictionary entry is to be retrieved.
---------------	---

Value Returned

<i>o_propDictEntry</i>	<i>dbid</i> of the property dictionary entry for the property whose name is given by <i>t_name</i> . If could not get the entry, it returns nil.
<i>lt_validObjects</i>	List of valid objects to associate with a property
nil	Could not get the entry.

See Also

[axIDBAddProp](#)

Example

The following example gets the "SIGNAL MODEL" property, and dumps its attributes.

Allegro SKILL Reference

Database Read Functions

```
myprop = axlDBGetPropDictEntry("SIGNAL_MODEL")
myprop->??
  (write nil useCount 0 units nil
    range nil objType "PropDict"
    name "SIGNAL_MODEL"
    dataType "STRING"
    readOnly t
  )
```

Allegro SKILL Reference

Database Read Functions

axlDBGetProperties

```
axlDBGetProperties (
  o_dbid
  [1t_type]
)
⇒ l_result/nil
```

Description

Gets the properties attached to a specified object. Returns the properties in an assoc list, that is, a list of lists, each of which contains a name and a value. The SKILL `assoc` function can operate using this list.

Arguments

<i>o_dbid</i>	<i>dbid</i> of the object from which to get the properties.
<i>1t_type</i>	List of strings qualifying the types of properties to be retrieved from <i>o_dbid</i> . "user" means retrieve user-defined properties only. "allegro" means retrieve Allegro PCB Editor defined properties only. <i>nil</i> means retrieve both user and Allegro PCB Editor.

Value Returned

<i>l_result</i>	List of name-value pairs. For each name-value pair: (<i>car</i>) is the property name (<i>cadr</i>) is the property value, including units.
<i>nil</i>	No properties found.

Example

The following example selects the component with refdes "U1," gets its properties using the axlDBGetProperties command, and prints the associated property list it returns. The properties are:

- ❑ ROOM with value D
- ❑ DFA_DEV_CLASS with value DIP
- ❑ LEAD_DIAMETER with value 23 mil.

```
axlClearSelSet()
axlSetFindFilter(?enabled '("noall" "alltypes") ?onButtons "alltypes")
    axlSingleSelectName("component" "U1")
myprops = axlDBGetProperties(car(axlGetSelSet()) '("user" "allegro"))
print myprops
==> ((ROOM "D")
      (DFA_DEV_CLASS "DIP")
      (LEAD_DIAMETER "23 MIL"))
```

axlDBGetDesignUnits

```
axlDBGetDesignUnits()  
⇒ l_value/nil
```

Description

Returns the design units and accuracy number of the active design.

Arguments

None.

Value Returned

l_value List containing the design units as a string and the accuracy number as an integer.

nil Failed to return the design units and accuracy number of the active design.

Example

```
(axlDBGetDesignUnits)  
⇒("millimeters" 3)
```

The design **Drawing Parameters** form shows *User Units* as Millimeter and *Accuracy* as 3.

ax1DBRefreshId

```
ax1DBRefreshId(  
    o_dbid/nil  
)  
⇒ o_dbid/nil
```

Description

Updates the attributes of the object specified by *o_dbid*. Subsequent attribute retrieval requests access the updated information.

Note: Because of performance considerations, refreshes only the object itself. If the object being refreshed has *dbids* in any of its attributes, those *dbids* are not refreshed. For example, a net branch has *children*, a list of paths, tees, vias, pins, and shapes. If another path is added to that list of paths due to connectivity change, `ax1DBRefreshId` of the branch does not update the *children*. If you move a via that is a child of the branch, then doing `ax1DBRefreshId` of the branch and accessing the via as child of branch may yield incorrect attributes of that child (via in this case).

Arguments

<i>o_dbid</i>	SKILL list of <i>dbids</i> of the objects whose attributes are to be refreshed.
---------------	---

nil	All ids are refreshed.
-----	------------------------

Note: Refreshing all ids may cause performance problems if done indiscriminately.

Value Returned

<i>o_dbid</i>	Refreshed <i>dbid</i> .
---------------	-------------------------

nil	Could not refresh.
-----	--------------------

Allegro SKILL Reference

Database Read Functions

Example

```
axlSetFindFilter( ?enabled
                  '("noall" "alltypes"))
axlSingleSelectName("net" "sclk1")
mynet = car(axlGetSelSet())
mybranch = car(mynet->branches)
mychildren = mybranch->children
foreach( thismember mychildren
          if( (thismember->objType == "via")
              then
                  axlDeleteObject(thismember)))
axlDBRefreshId(mybranch)
⇒ t
```

Finds *net "sclk1"* , walks all members of its first branch, deleting any vias. Then refreshes the branch.

If the refresh was not done, *mybranch* would still report having vias following the operation that deleted its vias.

axlDBGetLonelyBranches

```
axlDBGetLonelyBranches()  
⇒ l_dbid/nil
```

Description

Returns a list of the *standalone branch dbids* in the design. A *standalone branch* is a branch not associated with any net.

Arguments

None.

Value Returned

<i>l_dbid</i>	List of standalone branches.
<i>nil</i>	No standalone branches found.

Example

```
(axlDBGetLonelyBranches)  
⇒dbid:12051156 dbid:11994768 dbid:12002292 dbid:12000892 dbid:11999396  
dbid:11996652 dbid:11996048 dbid:11994476 dbid:11992964 dbid:11991564  
dbid:11989672 dbid:11989344 dbid:12072172 dbid:11895392 dbid:11892048  
dbid:11888704 dbid:11888744 dbid:11888804 dbid:11888844 dbid:11888884  
dbid:12074948 dbid:11888984 dbid:11889064 dbid:11889204 dbid:11889224  
dbid:11889856 dbid:11890036 dbid:11890056 dbid:11890236 dbid:11890256  
dbid:11886180 dbid:12011360 dbid:11886760 dbid:11887140 dbid:11887916 )
```

Gets list of standalone branch *dbids*.

axIDBGetConnect

```
axIDBGetConnect(  
    o_dbid  
    [t_full]  
)  
⇒ l_result/nil
```

Description

Finds all the elements, including pads and shapes, that are connected to a given *dbid*. Input can be a PIN, VIA, T, CLINE/CARC or CLINE/CARC SEGMENT, and shapes.

If the second argument is *nil* or is not present:

- For pins, vias or Ts, the function returns a list of connected clines.
- For path (clines) or line/arc (segments) returns list of objects connected to either end.
- For shapes same as *t_full=t*

If the second argument is set to *t*:

- For pins, vias and T, the command returns full connectivity which includes clines, shapes, pins, vias or T's.
- For path (clines) or line/arc (segments) return value is same as *t_full=nil*
- For shapes list of connected objects which may be clines, shapes, pins, vias or T's.

Note: You should set *t_full* to *t*. The *nil* option operates in its mode due to legacy considerations and is used by Allegro Package Designer applications.

If a segment is passed as an argument, the command does not report inter-path connectivity. Thus only the first and last segment of a path report any connectivity. Internal segments of a path always return nil. This is because the Allegro database connectivity model guarantees that internal segments are always connected to their adjacent segments. The list of segments reported in a path (cline) dbid is how the individual segments are connected.

Arguments

o_dbid A *dbid*, path(cline), line/arc (segment), shape, pin, via or T.

t_full *t*: For full connectivity of pins, vias, or Ts.
 nil: Returns connectivity including any connected SHAPES.
 Also supports segments.

Allegro SKILL Reference

Database Read Functions

Value Returned

<i>l_result</i>	List of <i>dbids</i> connected to <i>o_dbid</i> . If <i>o_dbid</i> is a CLINE or SEGMENT, then <i>l_result</i> = (list <i>list1</i> <i>list2</i>) where <i>list1</i> = nil or elements connected to the first end <i>list2</i> = nil or elements connected to the second end. For all other objects, returns a list of connections.
<i>nil</i>	Nothing connected to <i>o_dbid</i> .

axlDBIsFixed

```
axlDBIsFixed(  
    o_dbid  
    [g_showMessage]  
)  
⇒ nil or [dbid of 1st element that makes the item fixed]
```

Description

Verifies whether or not the specified database object is fixed. When the FIXED property is present if can either be directly on the object, on a parent (e.g. a CLINE is fixed if the NET is fixed) or on a child (e.g. a symbol is fixed if its place bounds is fixed).

An object can be fixed by the following:

- Object has the FIXED property or its parent or child objects have the FIXED property.
For example, group symbol
- The object (parent or child) has a private database fixed attribute
- Object is Read-only (typically due to partition enabled)
- Object is a symbol with test points and the FIXED test point flag is set.
- Object is a symbol and has one or more children with the FIXED property.

Returns the first item found that causes the element to be fixed (could be more then one).

Note: Using axlDBCloak with its '`ignoreFixed`' option is recommended.

Arguments

o_dbid *dbid* of the element to check.

g_showMessage Use `t` to have Allegro PCB Editor display the message if the item is fixed or `nil` to have no message display.

Value Returned

dbid *dbid* of the element causing the object to be fixed.

nil Object not fixed.

Example

```
p = axlSelectByname("SYMBOL" "U1")
ret = axlDBIsFixed(p)
```

See Also

[axlDBIgnoreFixed](#), [axlDBIsReadOnly](#), [axlDBCloak](#)

axlDBIsPackagePin

```
axlDBIsPackagePin(  
    rd_dbid  
)  
⇒ t/nil
```

Description

Verifies whether or not the given element is a *package pin*.

A *package pin* is a pin with a component class of `IO`.

Arguments

`rd_dbid` *dbid* of element to check.

Value Returned

`t` *rd_dbid* is a package pin.

`nil` *rd_dbid* is not a package pin.

axlGetModuleInstanceDefinition

```
axlGetModuleInstanceDefinition(  
    o_modinst  
)  
⇒ t_moddef/nil
```

Description

AXL interface to the C function that returns the name of the module definition used to create the module instance.

Arguments

<i>o_modinst</i>	AXL <i>dbid</i> of the module instance (the <i>dbid</i> returned by axlDBCreateModuleInstance.)
------------------	---

Value Returned

<i>t_moddef</i>	String containing the name of the module definition.
nil	Could not access the information.

Example

```
axlSetFindFilter(?enabled '("noall" "groups") ?onButtons '("noall" "groups" ))  
axlSingleSelectName("GROUP" "inst")  
modinst = car(axlGetSelSet())  
axlGetModuleInstanceDefinition(modinst)  
= "mod"
```

Gets the definition of a module instance named *inst*.

axlGetModuleInstanceLocation

```
axlGetModuleInstanceLocation(  
    o_modinst  
)  
⇒ l_loc/nil
```

Description

AXL interface to the C function that gets the current location of the module instance in the design.

Arguments

<i>o_modinst</i>	AXL <i>dbid</i> of the module instance (the <i>dbid</i> returned by axlDBCreateModuleInstance.)
------------------	---

Value Returned

<i>l_loc</i>	List of data describing the location of the module instance. The list syntax is as follows.
--------------	---

list(l_origin, x_rotation [g_mirror])

where

- *l_origin*: origin of module
- *x_rotation*: rotation in degress * 1000
- *[g_mirror]*: Is a n optional parameter, which is set to t when mirrored

Example

```
axlSetFindFilter(?enabled '("noall" "groups") ?onButtons '("noall" "groups" ))  
axlSingleSelectName("GROUP" "inst")  
modinst = car(axlGetSelSet())  
axlGetModuleInstanceLocation(modinst)  
--> ((500 1500) 0)
```

Gets the location of a module instance named *inst*.

axlGetModuleInstanceLogicMethod

```
axlGetModuleInstanceMethod(  
    o_modinst  
)  
⇒ i_logic/nil
```

Description

AXL interface to the C function that determines the logic method used by the module instance.

Arguments

<i>o_modinst</i>	AXL <i>dbid</i> of the module instance (the <i>dbid</i> returned by axlDBCreateModuleInstance.)
------------------	---

Value Returned

<i>i_logic</i>	Value of the logic method flag for the module instance. Legal values are: 0 - no logic 1 - logic from schematic 2 - logic from module definition
nil	Could not access the information.

Example

```
axlSetFindFilter(?enabled '("noall" "groups") ?onButtons '("noall" "groups" ))  
axlSingleSelectName("GROUP" "inst")  
modinst = car(axlGetSelSet())  
axlGetModuleInstanceLogicMethod(modinst)  
= 2
```

Gets the logic method of a module instance named inst.

axlGetModuleInstanceNetExceptions

```
axlGetModuleInstanceNetExceptions (
    o_modinst
)
⇒ l_nets/nil
```

Description

AXL interface to the C function that gets the net exception of the module instance in the design.

Arguments

<i>o_modinst</i>	AXL <i>dbid</i> of the module instance (the <i>dbid</i> returned by axlDBCreateModuleInstance.)
------------------	---

Value Returned

<i>l_nets</i>	List of names of the nets that are treated as exceptions in the module instance.
---------------	--

nil	Could not access the information.
-----	-----------------------------------

Example

```
axlSetFindFilter(?enabled '("noall" "groups") ?onButtons '("noall" "groups" ))
axlSingleSelectName("GROUP" "inst")
modinst = car(axlGetSelSet())
axlGetModuleInstanceNetExceptions(modinst)
= ("GND" "+5")
```

Gets the list of net exceptions of a module instance named *inst*.

axlIsDummyNet

```
axlIsDummyNet(  
    net_dbid)  
⇒ t/nil
```

Description

Determines if a given net is a Dummy net. Name of net is an empty string ("").

Arguments

net_dbid Net database object.

Value Returned

t *net_dbid* is a Dummy Net.

nil *net_dbid* is not a Dummy Net.

See Also

[axlIsPinUnused](#)

axlIsLayerNegative

```
axlIsLayerNegative(  
    t_layerName  
)  
⇒ t/nil
```

Description

Determines whether or not the given plane layer is negative.

Arguments

t_layerName Name of the conductor layer to check.

Value Returned

t Active layer is negative.

nil Active layer is not negative or is not an ETCH layer.

axlIsPinUnused

```
axlIsPinUnused(  
    pin_dbid  
)  
⇒ t/nil
```

Description

Determines if the given pin is unused, indicating that it is on a dummy net.

Arguments

pin_dbid Pin database object.

Value Returned

t Pin is unused.

nil Pin is used.

See Also

[axlIsDummyNet](#)

axlIsitFill

```
axlIsitFill(  
    t_layer  
)  
⇒ t/nil
```

Description

Determines if fill shape is allowed for a given class subclass.

Arguments

<i>t_layer</i>	Layer name, for example, ETCH/TOP.
----------------	------------------------------------

Value Returned

t	Fill shape is allowed.
---	------------------------

nil	Fill shape is not allowed.
-----	----------------------------

axlOK2Void

```
axlOK2Void(  
    t_layer  
)  
⇒ t/nil
```

Description

Determines if voids are allowed for a given *class/subclass*.

Arguments

t_layer Layer name, for example, ETCH/TOP.

Value Returned

t Voids are allowed.

nil Voids are not allowed.

ax1DBDynamicShapes

```
ax1DBDynamicShapes (
  g_value
)
⇒ x_count
```

Description

Queries and updates dynamic shapes. When *g_value* is *t*, updates all out of date dynamic shapes on the board regardless of the dynamic shape updating setting in the **Drawing Options** dialog. When *g_value* is *nil*, returns a count of out of date shapes.

Arguments

<i>g_value</i>	<i>t</i> = update dynamic shapes <i>nil</i> = return count of out of date shapes
----------------	---

Value Returned

<i>x_count</i>	Count of out of date shapes. If updating shapes, <i>x_count</i> is the number of out of date shapes before the update.
----------------	--

axlDBGetShapes

```
axlDBGetShapes(  
    t_layer  
)  
⇒ l_dbid/nil
```

Description

Provides quick access to shapes without access to visibility or find settings.

Arguments

<i>t_layer</i>	Layer name <i>nil</i> = all layers <i><class></i> = all subclasses of the class <i><class>/<subclass></i> = specified layer
----------------	--

Value Returned

l_dbid	List of shapes.
nil	Incorrect argument.

Examples:

- Returns all shapes on the design.

```
axlDBGetShapes(nil)
```

- Returns all shapes on the BOUNDARY layer.

```
axlDBGetShapes("BOUNDARY")
```

- Returns all shapes on ETCH GND.

```
axlDBGetShapes("ETCH/GND")
```

- Returns all shapes on ROUTE KEEPOUT.

```
axlDBGetShapes("ROUTE KEEPOUT")
```

ax1DBTextBlockCompact

```
ax1DBTextBlockCompact (
  t/nil
)
⇒ x_unusedBlocks
```

Description

Reports and/or compresses unused database text blocks. If compacting text blocks, it always updates database text to reflect the new text block numbers.

The database, even if new, must have at least one text block.

Note: You must force a *dbid* refresh on any text parameters and text type *dbids* in order for them to reflect the new numbering.

Arguments

t Compact the text blocks.

nil Report the number of text blocks that can be eliminated from the database.

Value Returned

x_unusedBlocks Count of text blocks that are unused.

Example

```
unused = ax1DBTextBlockCompact(nil)
printf("This database has %d unused text blocks\n" unused)
```

Allegro PCB Editor Interface Functions

Overview

This chapter describes the AXL/SKILL functions that give access to the Allegro PCB Editor interface. These include display control, cursor setup, and soliciting user input, such as text and mouse picks.

AXL-SKILL Interface Function Examples

This section gives examples of the following:

- Dynamic cursor functions used with the `axlEnter` functions
- `axlCancelEnterFun` and `axlFinishEnterFun` used with the popup functions in a command looping on the `axlEnterPath` command
- `axlHighlightObject` and `axlDehighlightObject`

Dynamic Cursor Examples

You use the AXL-SKILL dynamic cursor functions to build up and display Allegro PCB Editor database objects during interactive commands. Using dynamic cursor shows the effects of a command in use. For example, you can display a symbol and the etch lines connected to it, constantly showing where they would be in the drawing if the user clicked at their current position.

The two examples that follow show how to set up the dynamic cursor:

- A package symbol image with pins connected to other etch, with rubberband lines from its connected pins to the points where they had originally connected
- A package symbol image dynamically rotating enabling you to select an angle of rotation

Both examples use the `axlPath` functions described in [Chapter 15, “Database Create Functions,”](#) and the `axlAddSimpleXXXDynamics` functions described in this chapter.

Example 1: Dynamic Rubberband

This example loads two circular pads and, the outline of a resistor, and rubberband connections from its pins, one with a "path" rubberband, the other a "directline" rubberband into the dynamic cursor buffer.

```
axlClearDynamics()

; Create cross markers to show rubberband origins:
axlDBCreateLine(list(9150:4450 9050:4550) 0.
                 "board geometry/dimension")
axlDBCreateLine(list(9150:4550 9050:4450) 0.
                 "board geometry/dimension")
axlDBCreateLine(list(8550:4450 8450:4550) 0.
                 "board geometry/dimension")
axlDBCreateLine(list(8550:4550 8450:4450) 0.
                 "board geometry/dimension")

mypath = axlPathStart(list( -350:0)) ; Start circular pad
axlPathArcCenter(mypath, 0., -350:0, nil, -300:0)

; Load the first pad into the dynamic cursor buffer
axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)

mypath = axlPathStart(list( 350:0)) ; Start circular pad
axlPathArcCenter(mypath, 0., 350:0, nil, 300:0)
; Load the other pad into the dynamic cursor buffer
axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)
mypath = axlPathStart( ; Start resistor body outline
                      list( -200:-100 200:-100 200:100 -200:100 -200:-100))
; Load the resistor body outline in the dynamic cursor buf
axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)
; Load a "path" rubberband to the first pad
axlAddSimpleRbandDynamics(8500:4500 "path"
                           ?origin 8500:4500 ?var_point -300:0)
; Load a "directline" rubberband to the second pad
axlAddSimpleRbandDynamics(9100:4500 "directline"
                           ?origin 9100:4500 ?var_point 300:0)
;


mypoint = axlEnterPoint() ; Ask user for point
```

Allegro SKILL Reference

Allegro PCB Editor Interface Functions

Loads two circular pads, the outline of a resistor, and rubberband connections from its pins (one with a "path" rubberband, the other a "directline" rubberband) into the dynamic cursor buffer.

The following illustration shows the cursor in a typical position as `ax1EnterPoint` waits for selection of a point.



Example 2: Dynamic Cursor Rotation


```
axlClearDynamics() ; Clean out any existing cursor data  
  
mypath = axlPathStart(list( -350:0)) ; Start circular pad  
axlPathArcCenter(mypath, 0., -350:0, nil, -300:0)  
  
; Load the first pad into the dynamic cursor buffer  
axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)  
  
mypath = axlPathStart(list( 350:0)) ; Start circular pad  
axlPathArcCenter(mypath, 0., 350:0, nil, 300:0)  
  
; Load the other pad into the dynamic cursor buffer  
axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)  
  
mypath = axlPathStart( ; Start resistor body outline  
list( -200:-100 200:-100 200:100 -200:100 -200:-100))  
  
; Load the resistor body outline in the dynamic cursor buf  
axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)  
  
; Ask user to pick angle of rotation about (8500:4500):  
axlEnterAngle(8500:4500)
```

Loads two circular pads, the outline of a resistor, and rubberband connections from its pins, one with a "path" rubberband, the other a "directline" rubberband into the dynamic cursor buffer.

Allegro SKILL Reference

Allegro PCB Editor Interface Functions

The following illustration shows the dynamically rotating cursor in a typical position as `axlEnterAngle` waits for a user-selected point.



Enter Function Example

You use the AXL-SKILL `axlCancelEnterFun` and `axlFinishEnterFun` functions when you create an interactive command that loops on input, providing the option to end the command.

```
(defun axlMyCancel ()
  axlClearDynamics()
  axlCancelEnterFun()
  axlUIPopupSet(nil))

(defun axlMyDone ()
  axlClearDynamics()
  axlFinishEnterFun()
  axlUIPopupSet(nil))

mypopup = axlUIPopupDefine( nil
  (list (list "MyCancel" 'axlMyCancel)
    (list "MyDone" 'axlMyDone)))
axlUIPopupSet( mypopup)
; Clear the dynamic buffer
axlClearDynamics()
; Clear mypath to nil, then loop gathering user picks:
mypath = nil
while( (mypath = axlEnterPath(?lastPath mypath))
  progn(
    axlDBCreatePath(mypath, "etch/top")))
```

The Enter Function example does the following:

1. Defines the functions `axlMyCancel` and `axlMyDone`.
2. Defines a pop-up with those functions as the callbacks for user selections *Cancel* and *Done* from the pop-up.
3. Loops on the function `axlEnterPath` gathering user input to create a multi-segment line on "etch/top".

Selecting *Cancel* or *Done* from the pop-up ends the command.

You gather one user-selected point and extend the database path by that selection each time through the *while* loop. Selecting *Done* from the pop-up terminates the loop. Selecting *Cancel* at any time cancels. Segments added become permanent in the database when the loop ends.

axlHighlightObject and axlDehighlightObject Examples

You use the AXL-SKILL `axlHighlightObject` and `axlDehighlightObject` functions to highlight database elements during interactive commands.

Example 1

```
(defun highlightLoop ()
  mypopup = axlUIPopupDefine( nil
    (list (list "Done" 'axlFinishEnterFun)
          (list "Cancel" 'axlCancelEnterFun)))
  axlUIPopupSet( mypopup)
  axlSetFindFilter( ?enabled '("noall" "alltypes" "nameform")
                    ?onButtons "alltypes")
  (while (axlSelect)
    progn(
      axlHighlightObject( axlGetSelSet())
      ; Just a dummy delay to see what happens
      sum = 0
      for( i 1 10000 sum = sum + i)
      axlDehighlightObject( axlGetSelSet()))))
```

Example 1 does the following:

1. Defines the function `highlightLoop`.
2. Defines a popup with `axlFinishEnterFun` and `axlCancelEnterFun` as the callbacks for user selections *Done* and *Cancel* from the pop-up.
3. Loops on the function `axlSelect` gathering user selections to highlight.
4. Waits in a simple delay loop, then dehighlights.

Selecting *Cancel* or *Done* from the pop-up ends the command.

Example 2

```
axlDBControl('highlightColor 4)
axlHighlightObject(axlGetSelSet() t)
```

Permanently highlights an object using color 4.

Allegro PCB Editor Interface Functions

This section lists Allegro PCB Editor interface functions.

axlClearDynamics

```
axlClearDynamics(  
    )  
    => t
```

Description

Clears the dynamic cursor buffer. Call this function each time before you start setting up rubberband and dynamic cursor graphics.

Arguments

None.

Value Returned

t	Always returns t.
---	-------------------

Example

See dynamic cursor examples in the section [AXL-SKILL Interface Function Examples](#) on page 359.

axlAddSimpleRbandDynamics

```
axlAddSimpleRbandDynamics (
    l_fixed_point
    t_type
    ?origin      l_origin
    ?var_point   l_var_point
    ?lastPath    l_lastPath
    ?width       f_width
    ?color       g_color
)
⇒ t/nil
```

Description

Loads rubber band dynamics buffer with an element. If dynamics buffer is already loaded, the new element is simply added to the existing buffer. Dynamics buffer is not cleared until [axlClearDynamics](#) is called.

Rubber band dynamics means stretching of elements to the cursor from an anchor point called the `fixed_point`.

Arguments

<code>l_fixed_point</code>	Fixed point of rubber band. Anchor point from which the dynamic rubberband stretches. The rubberband cursor stretches dynamically from <code>fixed_point</code> to current position of the cursor, as moved by the user. The next argument, <code>t_type</code> , specifies the shape of the rubberband—part of a path, direct, z-line (a combination of horizontal and vertical), arc, circle, or box.
<code>t_type</code>	String specifying type of dynamic rubberband to be drawn. Can be one of the following: path, directline, horizline, vertline, arc, circle, or box. <code>directline</code> : add a single line to buffer between <code>fixed_point</code> and <code>var_point</code> . <code>origin</code> and variable point of <code>var_point</code>
	<code>horizline</code> : A single horizontal line.
	<code>vertline</code> : A single vertical line
	<code>arc</code> : Arc between <code>fixed_point</code> and <code>var_point</code> . Radius varies

Allegro SKILL Reference

Allegro PCB Editor Interface Functions

as cursor moves
"circle": Circle, fixed_point is center and var_point is initial radius.
"box": Add a box, fixed point is one corner and the var_point is the opposite corner.
"path": Add two segments whose behavior is controlled by the line lock attributes (axlSetLineLock).
"fixedline": Adds a constant line to cursor buffer, fixed_point and var_point are the two endpoints.

l_origin

Cursor origin. Useful only if you plan on rotating the object, this is the center of its rotation. Also on arcs to control tangency. In most cases this should be nil.

l_var_point

Variable point for rubberbanding.

l_lastPath

Previous path structure. Needed to calculate tangent point if rubberbanding starts at the end of an existing path.

f_width

Optional database width of the rband. Default is 0.0.

g_color

Optional arg for defining the dynamics' color. Possible choices are:

- A layer string (i.e. class/subclass) for the layer to be used for deriving the color.
- 'ratsnestColor - the color used for ratsnest lines will be used.
- 'activeSubclassColor - the color for the active class/subclass is used. If this changes, the color for this rband also changes.

Value Returned

t Successfully added data.

nil No data added.

Example

A file, `demo_dynamics.il`, in `<cdsroot>/share pcb/examples/skill` demonstrates the various t_type options.

This example loads two circular pad and, the outline of a resistor, and rubberband connections from its pins, one with a "path" rubberband, the other a "directline" rubberband into the dynamic cursor buffer:

```
axlClearDynamics() ; Clean out any existing cursor data
mypath = axlPathStart(list( -350:0)) ; Start circular pad
axlPathArcCenter(mypath, 0., -350:0, nil, -300:0); Load the first pad into the
dynamic cursor buffer
axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)
mypath = axlPathStart(list( 350:0)) ; Start circular pad
      axlPathArcCenter(mypath, 0., 350:0, nil, 300:0); Load the other pad
into the dynamic cursor buffer
      axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)
mypath = axlPathStart( ; Start resistor body outline
      list( -200:-100 200:-100 200:100 -200:100 -200:-100)); Loads
the resistor body outline in the dynamic cursor buffer
      axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)
; Ask user to pick angle of rotation about (8500:4500):
      axlEnterAngle(8500:4500)
```

See dynamic cursor examples in the section [AXL-SKILL Interface Function Examples](#) on page 359.

axlAddSimpleMoveDynamics

```
axlAddSimpleMoveDynamics (
    l_origin
    r_path
    t_type
    ?ref_point l_ref_point
    ?color g_color
)
⇒ t/nil
```

Description

Loads cursor buffer dynamics buffer with an element. If dynamics buffer is already loaded, the new element is simply added to the existing buffer. Dynamics buffer is not cleared until [axlClearDynamics](#) is called.

Cursor buffer dynamics means no stretching of elements. The loaded is attached to the cursor and moves with it.

Arguments

<i>l_origin</i>	Cursor origin. (see axlAddSimpleRbandDynamics)
<i>r_path</i>	Path structure containing display objects.
<i>t_type</i>	String specifying type of path: either <code>path</code> or <code>box</code> . Note that lines and arcs are represented as path. Circle is a special case of arc where the start, end points are the same.
<i>l_ref_point</i>	Element rotation reference point.
<i>g_color</i>	Optional argument for defining the dynamics' color. Possible choices are: <ul style="list-style-type: none">■ A layer string (class/subclass) for the layer to be used for deriving the color.■ '<code>ratsnestColor</code>' - the color used for ratsnest lines will be used.■ '<code>activeLayerColor</code>' - the color for the active class/subclass is used. If this changes, the color for this rband also changes.

Value Returned

t Returned if the data is successfully added.

nil No data added.

Example

See dynamic cursor examples, [Example 1: Dynamic Rubberband](#) and [Example 2: Dynamic Cursor Rotation](#), in the section [AXL-SKILL Interface Function Examples](#) on page 359.

axlDesignFlip

```
axlDesignFlip(  
    g_flip  
) t/nil
```

Description

Visually flips the design in the 'y' axis. Maintains current xy view.

Note: This command not available if OpenGL is disabled.

Arguments

t flipped on y axis

nil unflip

Value Returned

Old flip state. If t flipped (y) if nil normal top view state

See Also

[axlWindowFit](#)

Example

Syntax to implement toggle flipping

```
axlDesignFlip( !axlDesignFlip())
```

axlEnterPoint

```
axlEnterPoint(
    ?prompts      l_prompts
    ?points       l_points
    ?gridSnap     g_gridSnap
)
⇒ l_point/nil
```

Description

Prompts for and receives user-selected point. Returns the point data to the calling function.

Arguments

<i>l_prompts</i>	List containing one prompt message to display.
<i>l_points</i>	List of points. Returns one of these as the return value. <i>l_point</i> 's only use is, if passed a point, to immediately return with the point snapped to the nearest grid.
<i>g_gridSnap</i>	Flag to function: t means snap the point according to the current grid.

Value Returned

<i>l_point</i>	List of coordinates, if entered. If selected, this is a list of one point.
<i>nil</i>	User did not select a point.

Example

See Example 1 in the section [AXL-SKILL Interface Function Examples](#) on page 359.

axlEnterString

```
axlEnterString(  
    ?prompts      l_prompts  
)  
⇒t_string/nil
```

Description

Displays a dialog box that requires first entering a string, and then pressing *Return* on the keyboard or clicking *OK* or *Cancel*. Default prompt in the dialog box is “Enter String.” You can supply a prompt string with the `?prompts` keyword. The function returns the string entered, if any. Otherwise it returns `nil`.

Note: This function is a blocker. Allegro PCB Editor will not respond to any user input until the data requested by the dialog box is provided.

Arguments

<code>l_prompts</code>	List containing one prompt message. Displays only the first string if the list contains more than one string.
------------------------	---

Value Returned

<code>t_string</code>	String entered.
-----------------------	-----------------

<code>nil</code>	No string entered, dialog box dismissed by clicking <i>Cancel</i> , or the command failed.
------------------	--

Example

```
user_name = axlEnterString(  
    ?prompts list("Please enter your name:"))  
⇒"user name"
```

Prompts for name and collects the response in `user_name`.

Typing the name, then pressing the *Return* key returns the string entered:

axlEnterAngle

```
axlEnterAngle(  
    origin  
    ?prompts      l_prompts  
    ?refPoint     l_refPoint  
    ?angle        f_angle  
    ?lockAngle    g_lockAngle  
)  
⇒f_angle/nil
```

Description

Optionally prompts the user. Returns the angle value entered.

Arguments

<i>origin</i>	Fixed point where two lines making up the angle meet.
<i>l_prompts</i>	List containing one prompt message.
<i>l_refPoint</i>	End point of a line from the <i>origin</i> that acts as the fixed line of the angle.
<i>f_angle</i>	Angle value in. If non-nil, does not prompt for a user-selected point.
<i>g_lockAngle</i>	Initial lock angle for dynamic rotation.

Value Returned

<i>f_angle</i>	Selected angle expressed in degrees.
nil	No angle selected.

Example

See Example 1 in the section [AXL-SKILL Interface Function Examples](#) on page 359.

axlCancelEnterFun

```
axlCancelEnterFun()  
  ⇒ t/nil
```

Description

Terminates the wait for a user-selected point. Waiting function returns no data.

Arguments

None.

Value Returned

t	Terminates wait for user-selected point. Cancel succeeds.
nil	Fails to terminate wait for user-selected point.

Example

See the [Enter Function Example](#) on page 364.

axlFinishEnterFun

```
axlFinishEnterFun()  
  ⇒ t/nil
```

Description

Terminates the wait for a user-selected point. Waiting function returns no data. For a one-point function (for example, `axlEnterPoint`) behaves the same as `axlCancelEnterFun`.

Arguments

None.

Value Returned

t	Terminates wait for a user-selected point.
nil	Fails to terminate wait for a user-selected point.

Example

See the [Enter Function Example](#) on page 364.

axlGetDynamicsSegs

```
axlGetDynamicsSegs (
    l_point1
    l_point2
    r_lastPath/nil
) ->
```

Description

Normally used with dynamics to calculate arc tangency of two picks to a current *r_path*. Passed coordinates may be modified to preserve tangency. Depends on the current line lock state that you set or axlSetLineLock.

Arguments

<i>point1</i>	First pick before dynamics started.
<i>point2</i>	Second pick, after dynamics completes.
<i>lastPath</i>	Previous path to use for tangency calculations. Can pass nil if not applicable.

Value Returned

l_pointList
nil

See Also

[axlAddSimpleRbandDynamics](#), [axlMakeDynamicsPath](#), [axlSetLineLock](#)

Example

```
q = axlGetDynamicsSegs(10:10 100:100 nil)
-> (((10.0 10.0) (100.0 100.0) nil))
```

axIGetLineLock

```
axIGetLineLock(  
    s_name  
    [g_value]  
)  
==> g_currentValue/ls_names
```

Description

Gets the current settings of the line lock or dynamic control options. Equivalent items is the option control panel for "add" commands. Items currently supported:

- Name: arcEnable
Value: t/nil
Description: If t Lock Mode is arc, nil is line.
- Name: lockAngle
Value: 0, 45, 90
Description: In degrees where 0 is off (no lock).
- Name: minRadius
Value: float
Description: Minimum Radius in user units.
- Name: length45
Value: float
Description: Fixed 45 Length value in user units.
- Name: fixed45
Value: t/nil
Description: If t Fixed 45 length is enabled.
- Name: lengthRadius
Value: float
Description: Fixed radius value in user units.
- Name: fixedRadius
Value: t/nil
Description: If t in Fixed Radius mode
- Name: lockTangent
Value: t/nil
Description: If t tangent mode is on.

Arguments

s_name symbol name of control. nil returns all possible names

Value Returned

See above.

ls_names, If name is nil then returns a list of all controls.

See Also

axlSetLineLock

Example

- Return current lock tangent setting

```
axlGetLineLock('lockTangent)
```

- Get all names supported by this interface

```
listOfNames = axlGetLineLock(nil)
```

axlEnterBox

```
axlEnterBox(  
    ?prompts      l_prompts  
    ?points       l_points  
)  
⇒ l_box/nil
```

Description

Takes two points that define a box and returns them in *l_box*. Optionally prompts the user, if *l_prompts* contains no more than two strings. If *l_points* is nil, prompts for two points. If *l_points* contains one point, prompts only for the second point. If *l_points* contains both points, simply returns them as *l_box*.

Arguments

<i>l_prompts</i>	List that should contain two prompt messages. If list is nil, uses default Allegro PCB Editor prompts for soliciting a box. ("Enter first point of box" and "Enter second point of box") If list contains two strings, the first string prompts for the first point, and the second string prompts for the second point. If the list has only one string, the string prompts for both the first and the second points.
<i>l_points</i>	List of none, one, or two points. Solicits missing points interactively using the prompts given in <i>l_prompts</i> in order.

Value Returned

<i>l_box</i>	List of the lower left and upper right coordinates of the box.
nil	Failed to get box data.

Allegro SKILL Reference

Allegro PCB Editor Interface Functions

Example

```
axlDBCreateRectangle(  
    axlEnterBox(?prompts  
        list("First rectangle point, please..."  
            "Second rectangle point, please..."))  
        t "etch/top")  
    ⇒ (dbid:12134523 nil)
```

Asks for box input to create a filled rectangle on layer "etch/top".

axlEnterPath

```
axlEnterPath(  
    ?prompts      l_prompts  
    ?points       l_points  
    ?lastPath     r_path  
)  
⇒ r_path/nil
```

Description

Gets the start point and subsequent points for a path, interactively with optional prompting, or from the optional argument *l_points*. Sets the start point to the first value of *l_points*, if any, and the second point to the second value, if any. If *r_path* is given, connects the dynamic rubberband to its most recent segment. Use `axlEnterPath` recursively to build up the coordinates of a path interactively.

Arguments

<i>l_prompts</i>	List containing one prompt message to display.
<i>l_points</i>	List of none, one, or two coordinates to be used as input to <code>axlEnterPath</code> .
<i>r_path</i>	The previously gathered part of the path. Used to calculate the tangent point for the dynamic cursor.

Value Returned

<i>r_path</i>	Path containing segments constructed from the combined points in <i>l_points</i> and the interactive input to <code>axlEnterPath</code> .
<i>nil</i>	Failed to get points.

Example

See the [Enter Function Example](#) on page 364.

axlHighlightObject

```
axlHighlightObject(  
    [lo_dbid]  
    [g_permHighlight]  
)  
⇒ t/nil
```

Description

Highlights the figures whose *dbids* are in *lo_dbid*.

Fewer objects support permanent highlighting than support temporary highlighting.

Note: Setting `axlDebug(t)` enables additional informational messages.

Arguments

od_dbid List of the *dbids* of figures to be highlighted.

g_permHighlight Distinguishes temporary highlighting from permanent highlighting using color.

t - use PERM highlight color
nil - use TEMP highlight color

The default is `nil`.

Value Returned

`t` Highlighted at least one figure.

`nil` Highlighted no figures due to invalid *dbids* or objects already being highlighted.

Examples

You can use the AXL-SKILL `axlHighlightObject` and `axlDehighlightObject` functions to highlight database elements during interactive commands.

This example does the following:

Allegro SKILL Reference

Allegro PCB Editor Interface Functions

- a. Defines the function `highlightLoop`.
- b. Loops on the function `axlSelect` gathering user selections to highlight.
- c. Waits in a simple delay loop, then dehighlights.

You can stop the command at any time by selecting *Cancel* or *Done* from the pop-up.

```
(defun highlightLoop ()
  mypopup = axlUIPopupDefine( nil
    (list (list "Done" 'axlFinishEnterFun)
          (list "Cancel" 'axlCancelEnterFun)))
  axlUIPopupSet( mypopup)
  axlSetFindFilter( ?enabled '("noall" "alltypes" "nameform")
    ?onButtons "alltypes")
  (while (axlSelect)
    progn(
      axlHighlightObject( axlGetSelSet())
      ; Just a dummy delay to see what happens
      sum = 0
      for( i 1 10000 sum = sum + i)
      axlDehighlightObject( axlGetSelSet()))))
```

This example permanently highlights an object using color 4:

```
axlDBControl('highlightColor 4)
axlHighlightObject(axlGetSelSet() t)
```

Also see the [axlHighlightObject and axlDehighlightObject Examples](#) on page 365.

axlDehighlightObject

```
axlDehighlightObject(  
    [lo_dbid]  
    [g_permHighlight]  
)  
⇒ t/nil
```

Description

Dehighlights the figures whose *dbids* are in *lo_dbid*.

Arguments

lo_dbid List of *dbids* of figures to be dehighlighted.

g_permHighlight Distinguishes temporary highlighting from permanent highlighting using color.

t - use PERM highlight color
nil - use TEMP highlight color

The default is nil.

Value Returned

t Dehighlighted at least one figure.

nil Failed to dehighlight any figures.

Example

See [axlHighlightObject](#) on page 384 for examples.

axlMiniStatusLoad

```
axlMiniStatusLoad (
    s_formHandle
    t_formFile
    g_formAction
    [g_StringOption]
    [t_restrict]
)
⇒ r_form/nil
```

Description

Loads the Ministatus form with the form file provided in this call. Replaces the current Ministatus form contents. This function is a special case of `axlForms`. See [Chapter 11, “Form Interface Functions,”](#) for details on how AXL forms work.

When the command is finished, Allegro PCB Editor restores the Ministatus contents to the default values. Once the form is opened, you use normal `axlForm` functions to set or retrieve fields.

You typically use this to write a command requiring user interaction such as “swap component.”

Two reserved field names are available:

```
class -- enumerated list of CLASS layers
subclass -- enumerated list of SUBCLASS layers for the current active class.
```

If you make use of these fields use support changing the active class and subclass you also get (for free) color swatch support. The Form file fragment shown below can be added to your ministatus form file to get that support. The “subcolor” field is optional. You should adjust the position (FLOC) of the fields to suite your form layout.

Note: Using these reserved names will also cause `axlGetActiveLayer` to update when user changes the layer.

```
TEXT "Active Class and Subclass:"
FLOC 1 1
ENDTEXT
```

```
FIELD class
FLOC 5 4
ENUMSET 19
```

Allegro SKILL Reference

Allegro PCB Editor Interface Functions

```
OPTIONS prettyprint
POP "class"
ENDFIELD
```

```
# option

FIELD subcolor
FLOC 2 7
COLOR 2 1
ENDFIELD
```

```
FIELD subclass
FLOC 5 7
ENUMSET 19
OPTIONS prettyprint ownerdrawn
POP "subclass"
ENDFIELD
```

Arguments

t_restrict	This optional argument is a string that indicates class and subclass restrictions if the form contains "class" and "subclass" popup fields that have not been overridden with calls to axlFormBuildPopup. Possible values are:
"NONE"	- no restrictions
"TEXT"	- only layers that allow text
"SHAPES"	- only layers that allow shapes
"RECTS"	- only layers that allow rectangles
"ETCH"	- only etch layers
"ETCH_PIN_VIA"	- only etch, pin, and via layers
"ETCH_NO_WIREBOND"	- only non-wirebond etch layers

See Also

[axlFormCreate](#) on page 629 for further details.

Value Returned

r_form Upon success, *r_form* is returned.

nil Failure due to one of the following:

No interactive command is active or the active command is not of the type AXL registered interactive.

AXL Forms code encounters an error.

Example

See swap component example:

```
<install_dir>/share pcb/etc/skill/examples/swap
```

axlDrawObject

```
axlDrawObject(  
    lo_dbid  
)  
⇒ t/nil
```

Description

Processes a list of *dbids*.

Redraws any objects that were erased by `axlEraseObject`.

Arguments

<code>lo_dbid</code>	List of <i>dbids</i> or one <i>dbid</i> .
----------------------	---

Value Returned

<code>t</code>	One or more objects drawn.
----------------	----------------------------

<code>nil</code>	No valid <i>dbids</i> or all objects already at desired display state.
------------------	--

axlDynamicsObject

```
axlDynamicsObject (
  lo_dbid
  [l_ref_point]
)
⇒ t/nil
```

Description

Adds list of objects to the cursor buffer. These objects are attached to the cursor in xor mode. Origin point establishes cursor position relative to objects in the dynamics buffer.

Note: Adding too many objects to the cursor buffer dramatically affects performance.

Arguments

<i>lo_dbid</i>	List of AXL <i>dbids</i> or single <i>dbid</i> .
<i>l_ref_point</i>	Optional origin point (takes cursor position if not provided).

Value Returned

<i>t</i>	One or more objects added to the cursor buffer.
<i>nil</i>	No objects added to the cursor buffer.

Example

Adds a symbol to the cursor buffer with the symbol origin as a reference point:

```
axlDynamicsObject(symbol_id, symbol_id->xy)
```

axlEraseObject

```
axlEraseObject(  
    lo_dbid  
)  
⇒ t/nil
```

Description

Processes a list of *dbids* and erases them. Typically used with `axlDynamicsObject` to erase objects before attaching them to the cursor. Any objects erased are restored to their visibility when calling AXL shell or terminating the SKILL program.

Arguments

lo_dbid List of *dbids* or one *dbid*.

Value Returned

t One or more objects erased.

nil No valid *dbids* or all objects already at desired display state.

axlControlRaise

```
axlControlRaise(  
    g_option  
)  
⇒ t/nil
```

Description

Raises a tab in the control panel to the top. If you use this at the start of an interactive command, you override the environment variable, `control_auto_raise`.

Arguments

g_option Supported symbols are: 'options, 'find, 'visibility, and nil. nil returns a list of supported symbols.

Value Returned

t	Tab raised to top in control panel.
nil	Unknown symbol.

Example

```
axlControlRaise('options)
```

Raises the option panel to the top.

axlEnterEvent

```
axlEnterEvent(  
    l_eventMask  
    t_prompt  
    g_snap  
)  
⇒ r_eventId
```

Description

A lower level event manager than other `axlEnter` functions. Provides a Skill program with more user event details. See [Table 7-2](#) on page 395 for a list of events with descriptions.

Returns event structure containing the attributes described in [Table 7-1](#) on page 394. Event occurrence controls what attributes are set by all event types, and sets the `objType` and `time` attributes.

Table 7-1 Event Attributes

Attribute Name	Type	Description
objType	string	Type of object, in this case <code>event</code>
type	symbol	Event occurrence
xy	point	Location of mouse
xySnap	point	Location of mouse snapped to grid.
command	int/symbol	Returns the callback item of <code>axlUIPopupDefine</code>
time	float	time stamp (seconds.milliseconds)

Note: Do not put a default handler in your case statement since the event model will change in future releases.

Allegro SKILL Reference
Allegro PCB Editor Interface Functions

Table 7-2 Events


Event	Description	Attributes/Mask
PICK	User has selected a point (equal to <code>axlEnterPoint</code>)	
PICK_EXTEND	Same as PICK except has extend keyboard modifier.	
PICK_TOGGLE	Same as PICK except has toggle keyboard modifier.	xy, xySnap
DBLPICK	User has double picked at a location.	
DBLPICK_EXTEND	Same as DBLPICK except has extend keyboard modifier.	
DBLPICK_TOGGLE	Same as DBLPICK except has toggle keyboard modifier.	xy, xySnap
STARTDRAG	User starts a drag operation.	
STARTDRAG_EXTEND	Same as STARTDRAG except has extend keyboard modifier.	
STARTDRAG_TOGGLE	Same as STARTDRAG except has toggle keyboard modifier.	xySnap
STOPDRAG	User terminated the drag operation.	
STOPDRAG_EXTEND	Same as STOPDRAG except has extend keyboard modifier.	
STOPDRAG_TOGGLE	Same as STOPDRAG except has toggle keyboard modifier.	xy, xySnap, command

Table 7-2 Events

Event	Description	Attributes/Mask
DONE	User requests the command to complete.	This event cannot be masked.
CANCEL	Respond to this event by terminating your Skill program (don't call any more <i>axlEnter</i> functions.)	This event cannot be masked.

Notes

- You will get `PICK` before `DBLPICK` events. To differentiate between a `PICK` and `DBLPICK`, highlight the selected object. Do not output informational messages or perform time consuming processing.
- Never prompt user for a double click. Instead, format prompts for the next expected event.
- Events dispatched from `axlEnterEvent` are scripted by the system if scripts are enabled.
- The `done` and `cancel` callbacks optionally defined in `axlCmdRegister` are called before the `DONE` and `CANCEL` events are returned.
- The `extend` keyboard modifier is obtained by holding the `Shift` key while performing the mouse operation.
- The `toggle` keyboard modifier is obtained by holding the `Control` key while performing the mouse operation.



Tip

You can program more easily by providing a single mask set for your command and by not attempting to change the mask set after each event.

Arguments

<i>l_eventMask/nil</i>	List of events to expect.
<i>t_prompt/nil</i>	User prompt. If <i>nil</i> , the default prompt is used.
<i>g_snapGrid</i>	If <i>t</i> , grid snapping is enabled while the function is active. Otherwise no grid snapping is allowed. This affects the <i>xySnap</i> value that is returned as well as dynamics and the <i>xy</i> readout. If <i>nil</i> , <i>xySnap</i> is not snapped to the grid and is the same as <i>xy</i> .

Value Returned

<i>r_eventId</i>	Event structure containing attributes.
------------------	--

Example

```
let( (eventMask event, loop)
    eventMask = list( 'PICK 'DBLPICK )
    loop = t
    while( loop
        event = axlEnterEvent(eventMask, nil t)
        case(event->type

            ('PICK
                ...
            )
            ('DBLPICK
                ...
            )
            ('DONE
                ; cleanup
```

axlEventSetStartPopup

```
axlEventSetStartPopup (
    [s_callback]
)
⇒ t/nil
```

Description

Sets a SKILL callback function called prior to a popup being displayed on the screen. Allows AXL applications to reset the popup (see `axlUIPOPUPSetsee`), thus providing context sensitive popups support.

The callback function is passed a list structure the same as the return list in `axlEnterEvent`. Use this function with `axlEnterEvent`.

The callback function is removed when an AXL application is finished. Set this at the application start, if needed.

Arguments

<i>s_callback</i>	AXL callback function.
none	Unsets the callback function which disables the callback mechanism.

Value Returned

t	Set SKILL callback function.
nil	Failed to set SKILL callback function.

Example

```
(defun startpopupcallback (event)
  ...
  newpopup = get a new popup based on event x,y values
  axlUIPopupSet(newpopup)
)
axlEventSetStartPopup('startpopupcallback')
...

let( (eventMask event, loop)
  eventMask = list( 'PICK 'DBLPICK )
  loop = t
  while( loop
    event = axlEnterEvent(eventMask, nil)
    case(event->type

      ('PICK
       ...
      )
      ('DBLPICK
       ...
      )
      ('DONE
       loop = nil)
      ('CANCEL
       loop = nil)
    )
  )
)

...
axlEventSetStartPopup()
```

Typically used in conjunction with `axlEnterEvent`.

axlGetTrapBox

```
axlGetTrapBox(  
    l_point  
)  
⇒ l_window/nil
```

Description

Returns coordinates of the *Find* window.

Arguments

l_point Listing of the *x* and *y* coordinates

Value Returned

l_window ((x_l y_l) (x_u y_u)) - List of corner coordinates of the *Find* window.
 (x_l y_l) - List containing *x* and *y* coordinates of the lower left corner.
 (x_u y_u) - List of the *x* and *y* coordinates of the upper right corner.

nil *l_point* is null or in an incorrect format.

axlRatsnestBlank

```
axlRatsnestBlank(  
    rd_net  
)  
⇒ t/nil
```

Description

Blanks all ratsnest lines in a net.

Arguments

rd_net *dbid* of a net

Value Returned

t Ratsnest lines are blanked.

nil Ratsnest lines are not blanked.

axlRatsnestDisplay

```
axlRatsnestDisplay(  
    rd_net  
)  
⇒ t/nil
```

Description

Displays all ratsnest lines in a net.

Arguments

rd_net *dbid* of a net

Value Returned

t Ratsnest lines are displayed.

nil Ratsnest lines are not displayed.

axlSetDynamicsMirror

sets mirror option for dynamics

```
axlSetDynamicsMirror(  
    g_mirror  
) ==> g_olddmirror
```

Description

Sets the Dynamics mirroring.

Arguments

g_mirror g_mirror type.Possible Values are:

- GEOMETRY mirror geometry only (same layer)
- nil mirror none
- t mirror

Value Returned

old mirror value

See Also

[axlAddSimpleMoveDynamics](#)

Example

```
axlSetDynamicsMirror(t)
```

axlSetDynamicsRotation

```
axlSetDynamicsRotation(  
    f_angle/nil  
) ==> f_oldangle
```

Description

Sets the Dynamics rotation. If angle is nil then returns current rotation.

Arguments

f_angle	Floating point number
---------	-----------------------

Value Returned

old angle

See Also

[axlAddSimpleMoveDynamics](#)

Example

```
axlSetDynamicsRotation(45.0)
```

axlShowObjectToFile

```
axlShowObjectToFile(
  lo_dbid
  [t_file_name]
)
⇒ (t_file_name x_width x_line_count)
```

Description

Creates a temporary file with show element information on *dbids* specified in *lo_dbid*.

Arguments

lo_dbid List of *dbids* or a single *dbid*.

t_file_name File name to use instead of a temporary file.

Value Returned

List of items describing the file created (*t_file_name* *x_width* *x_line_count*):

t_file_name Name of the temporary file.

x_width Width, in characters, of the widest text line.

x_line_count Number of lines in the file.

nil Could not create file.

axlUICmdPopupSet

```
axlUICmdPopupSet(  
    r_popup  
)  
⇒ r_prevPopup
```

Description

Sets up a popup menu with all menu items required throughout the execution of the command. Call during the command's initialization process. Use of this procedure modifies the behavior of `axlUIPopupSet` so that it makes unavailable all popup items not in the defined popup.

Adds a `cmdPopupId` property to AXL user data which restores popup entries whenever the AXL command state is restored. The command popup is cleared when the Skill command ends.

Arguments

<i>r_popup</i>	Popup handle, obtained by calling <code>axlUIPopupDefine</code> . A nil value turns off this popup.
----------------	---

Value Returned

<i>r_prevPopup</i>	Popup set previously defined.
--------------------	-------------------------------

Note: This procedure does the same as `axlCmdPopupSet` for non-WXL UI's.

axlZoomToDbid

```
axlZoomToDbid(  
    o_dbid/lo_dbid  
    g_always  
)  
⇒ t/nil
```

Description

Processes a list of *dbids* and centers and zooms the display around them. Zoom is done so objects extents fill about 20% of the display.

Note: You should highlight the objects.

Note: If more than 20 objects are passed no zoom is done.

Arguments

o_dbid List of *dbids* or one *dbid*.

g_always If *t*, then ignores NO_ZOOM_TO_OBJECT environment variable.

Value Returned

t One or more objects zoomed.

nil No valid *dbids* or all objects are already at desired display state.

axlMakeDynamicsPath

```
axlMakeDynamicsPath(  
    l_formatedList  
)  
⇒ r_path/nil
```

Description

This is a convenience function to construct an *r_path* from a formatted list. axlDBCreate and axlPoly require an *r_path*.

Note: A circle is an arc segment with same end points.

Note: Caution: Passing an illegal format may result in a bad return.

Arguments

(*l_seg1* *l_seg2* ...) *g_clockwise* Each *l_seg* is:
(*l_startPoint* *l_endPoint* [*f_width*] [*l_center*] [*f_radius*])

where

l_startPoint Start point of path.

l_endPoint End point of path.

f_width Optional width (default of 0).

l_center Optional center point if *r_path* is an arc.

f_radius Optional radius if *r_path* is an arc.

If an arc *r_path*, both *l_center* and *f_radius* must be provided.

g_clockwise Direction to create arc:

t ⇒ create arc clockwise from start to endpoint.

nil ⇒ create counterclockwise. Default is counterclockwise.

Value Returned

r_path dbid of *r_path*.

Allegro SKILL Reference

Allegro PCB Editor Interface Functions

nil

No r_path constructed due to incorrect arguments.

Example

Simple r_path segment with a width of 20.

```
a = axlMakeDynamicsPath(list(list( 10:10 100:100 20)))
```

Allegro SKILL Reference
Allegro PCB Editor Interface Functions

Allegro PCB Editor Command Shell Functions

Overview

This chapter describes the AXL-SKILL functions that access the Allegro PCB Editor environment and command shell.

Command Shell Functions

This section lists Allegro PCB Editor command shell functions.

axlGetAlias

```
axlGetAlias(  
    t_alias/nil  
)  
⇒ t_value/lt_names/nil
```

Description

Requests the value of the specified Allegro PCB Editor alias, *t_alias*. If given a nil, returns a list of aliases currently set. For compatibility purposes, axlGetAlias returns funckey settings.

Arguments

t_alias Name of the Allegro PCB Editor environment alias.

Value Returned

t_value String value of the Allegro PCB Editor environment alias.

lt_names List of alias names.

nil Alias not set.

See Also

[axlSetAlias](#), [axlGetFuncKey](#)

Example 1

```
alias = axlGetAlias("SF2")  
⇒ "grid"
```

Gets the value of the alias assigned to shifted function key F2.

Example 2

```
list_alias = axlGetAlias(nil)  
⇒ ("F2" "F3" "F4" ...)
```

Returns all set aliases.

axlGetFuncKey

```
axlGetFuncKey(  
    t_alias/nil  
)  
==> t_value/nil
```

Description

Requests the value of the specified funkey, *t_alias*. If given *nil*, returns a list of currently set funkeys.

Arguments

t_alias Name of the environment funkey.

nil Returns list of all current funkeys

Value Returned

t_value/nil String value of the environment funkey. Returns *nil* if the funkey is not set.

1t_names If passed *nil*, returns list of funkeys names.

See Also

[axlSetFunckey](#), [axlGetAlias](#)

EXAMPLE 1

Gets the value of the funkey assigned to shifted function key m.

```
alias = axlGetFuncKey("m")  
==> "grid"
```

EXAMPLE 2

Return all set aliases.

```
list_alias = axlGetFuncKey(nil)  
==> ("-" "+" "m")
```

axlGetVariable

```
axlGetVariable(  
    t_variable  
)  
⇒ t_value/nil
```

Description

Requests the value of the specified Allegro PCB Editor environment variable, *t_variable*. Returns a list containing the string assigned to the variable or *nil* if the variable is currently not set in Allegro PCB Editor. Use `axlGetVariableList` where the variable stores a list of items (such as a PATH variable) to preserve any spaces in each item.

Note: Variable names are case insensitive.



Variable names and values can change from release to release.

Arguments

<i>t_variable</i>	String giving name of the Allegro PCB Editor environment variable.
-------------------	--

<i>nil</i>	If <i>nil</i> , returns a list of all set variables in Allegro PCB Editor
------------	---

Value Returned

<i>t_value</i>	List containing string value of the Allegro PCB Editor environment variable.
----------------	--

<i>nil</i>	Variable not set.
------------	-------------------

<i>lt_names</i>	List of variable names (returned when <i>nil</i> is passed)
-----------------	---

See Also

[axlUnsetVariable](#), [axlSetVariable](#), [axlGetVariableList](#), [axlReadOnlyVariable](#)
[axlSetVariableFile](#), [axlUnsetVariableFile](#)

Example

```
menu = axlGetVariable("menuload")
      ==> "geometry"
psmpath = axlGetVariable("psmpath")
      ==> ". symbols"
```

- Gets value of the current menu loaded.
Variable name is *menuload*.
- Gets the value of the library search path *libpath*.

axlGetVariableList

```
axlGetVariableList(  
    t_variable/nil  
)  
==> t_value/lt_value/nil
```

Description

Requests the value of the specified Allegro PCB Editor environment variable, *t_variable*. Unlike `axlGetVariable` this returns a list of strings, if the variable is an array, such as one of Allegro PCB Editor's path variables. If variable is a single item, the return is the same as `axlGetVariable`.

Since path variables can contain spaces, using the `axlGetVariable` interface and then using the Skill `parseString` command, to break them back to the component pieces will not give the correct result.

Note: Variable names are case insensitive.

Note: Variable names and values can change from release to release.

Arguments

<i>t_variable</i>	Name of the Allegro PCB Editor environment variable.
<i>nil</i>	If <i>nil</i> , returns a list of all set variables in Allegro PCB Editor.

Value Returned

<i>t_value</i>	String value of the Allegro PCB Editor environment variable.
<i>nil</i>	Returns <i>nil</i> if the variable is not set.
<i>lt_names</i>	list of variable names, returned when <i>nil</i> is passed as the argument

See Also

[axlGetVariable](#)

Allegro SKILL Reference

Allegro PCB Editor Command Shell Functions

Example

Gets the value of the Package Symbol search path:

```
path = axlGetVariableList("psmpath")
==> ( "." "symbols" "/cds/root/share pcb/allegrolib/symbols")
```

axlJournal

```
axlTempFile(  
    g_option  
)  
==> t_tempFileName
```

Description

This function manages the program's journal file. It has several modes of operation:

g_option = 'close'

closes current journal file; returns name of closed file

g_option = <t_filename>

close current journal file and opens no file, returns t if successful, nil if can't open file.
Side effect of failure is current journal file is closed.

g_option = 'name'

returns fullpath name of current journal file, nil if no active journal file



Typically the journal file is buffered. Reading the file while it is open may be unpredictable.

Argument

g_mode see above

Value Returned

See above

Example

Name of file

```
axlJournal('name')
```

Open new file in tmp in current directory

```
axlJournal("my_journal")
```

axlProtectAlias

```
axlProtectAlias(  
    t_alias  
    t/nil  
)  
⇒ t/nil
```

Description

Controls the read-only attribute of an alias.

Notes

- Do not unprotect F1 as this is fixed to *Help* by the operating system.
- You must define the alias before you can protect it.

Arguments

t_alias Name of the Allegro PCB Editor environment alias.

t/nil *t* protects the alias, and *nil* unprotects the alias.

Value Returned

t Successfully protected or unprotected the alias.

nil Alias is not set, or the function received invalid data.

Example

```
axlProtectAlias( "F2" t)
```

Protects the F2 function key.

axlIsProtectAlias

```
axlIsProtectAlias(  
    t_alias  
)  
⇒ t/nil
```

Description

Tests if the alias is read-only (or writeable). This may also be used with funkeys.

Arguments

t_alias Name of the Allegro PCB Editor environment alias.

Value Returned

t Alias is protected.

nil Alias is unprotected or not set.

See Also

[axlIsProtectAlias](#)

axlReadOnlyVariable

```
axlReadOnlyVariable(  
    t_variable  
    [g_Enable]  
)  
==> t/nil
```

Description

This sets, unsets or queries the read-only state of a Allegro PCB Editor environment variable. When you set a variable as read-only, it cannot be changed.

Note: Variable names are case insensitive.

Arguments

t_variable The name of the Allegro PCB Editor environment variable.

g_Enable *t* to set read-only; *nil* to make writable and do not provide if using to test variable read-only state.

Value Returned

t/nil In query mode (*no g_Enable option*) returns *t* if variable is read-only and *nil* if not. If changing the read-only mode, returns *t* if successful and *nil* if variable is not currently set.

See Also

[axlGetVariable](#)

Examples

The following example:

- Sets `psmpath` to read-only.
- Queries the setting.
- Resets `psmpath` to writable.

Allegro SKILL Reference

Allegro PCB Editor Command Shell Functions

Query the setting:

```
axlReadOnlyVariable("psmpath" t)
axlReadOnlyVariable("psmpath")
==> t
axlReadOnlyVariable("psmpath" nil)
axlReadOnlyVariable("psmpath")
==> nil
```

Query all read-only variables:

```
axlReadOnlyVariable("fxf" t)
axlReadOnlyVariable("psmpath" t)
axlReadOnlyVariable(nil)
==> ("psmpath" "fxf")
```

axlSetAlias

```
axlSetAlias(  
    t_alias  
    g_value  
)  
⇒ t/nil
```

Description

You can set the Allegro PCB Editor environment alias with the name given by the string *t_alias* to the value *g_value* using the `axlSetAlias` function. *g_value* can be a string, int, t, or nil. Returns the string assigned to the alias or `nil` if the alias cannot be set in Allegro PCB Editor.

You can use function keys F2-F12, most Alpha-numeric keys with the control modifier (although Control-C V and X are reserved for copy, paste, and cut) and the Navigation Keys (Home, Up arrow, Esc, etc.) You can modify these items as shown:

Modifier	Indicator	Example
Shift	S	SF2
Control	C (function keys)	CF2
Control	~ (alpha-numeric)	-N
Meta	A	AF2

Modifiers may be combined as shown in these examples:

CSF2	Control-Shift F2
ASF2	Meta-Shift F2
CAF2	Control-Meta F2
CASF2	Control-Meta-Shift F2
~SZ	Control-Shift Z
SUp	Shift-Up Arrow
CUp	Control-Up Arrow

Both `axlSetFunckey` and `axlSetAlias` share the same data storage.

Notes:

- Alias settings only apply to the current session. They are not saved to the user's local env file.
- Alias changes do not affect programs launched from Allegro PCB Editor, for example, import logic, refresh_symbol.
- To set funckeys, see `axlSetFunckey`, `axlGetAlias`, `axlProtectAlias`, `axlIsProtectAlias`, `axlSetAlias` `axlGetAlias`, `axlProtectAlias`, and `axlIsProtectAlias`.

Arguments

<i>t_alias</i>	Name of the Allegro PCB Editor environment alias.
<i>g_value</i>	Value to which the environment alias is to be set. Can be a string or <code>nil</code> .

Value Returned

<code>t</code>	Alias set.
<code>nil</code>	Invalid data or alias is marked read-only.

Example 1

```
axlSetAlias( "F2" "save")
```

Sets the F2 function key to the save command.

Example 2

```
axlSetAlias( "~S" nil)
```

Unsets the Ctrl-S alias.

axlSetAlias

```
axlSetAlias(  
    t_alias  
    g_value  
)  
⇒ t/nil
```

Description

You can set the Allegro PCB Editor environment alias with the name given by the string *t_alias* to the value *g_value* using the `axlSetAlias` function. *g_value* can be a string, int, t, or nil. Returns the string assigned to the alias or `nil` if the alias cannot be set in Allegro PCB Editor.

You can use function keys F2-F12, most Alpha-numeric keys with the control modifier (although Control-C V and X are reserved for copy, paste, and cut) and the Navigation Keys (Home, Up arrow, Esc, etc.) You can modify these items as shown:

Modifier	Indicator	Example
Shift	S	SF2
Control	C (function keys)	CF2
Control	~ (alpha-numeric)	-N
Meta	A	AF2

Modifiers may be combined as shown in these examples:

CSF2	Control-Shift F2
ASF2	Meta-Shift F2
CAF2	Control-Meta F2
CASF2	Control-Meta-Shift F2
~SZ	Control-Shift Z
SUp	Shift-Up Arrow
CUp	Control-Up Arrow

Both `axlSetFunckey` and `axlSetAlias` share the same data storage.

Notes:

- Alias settings only apply to the current session. They are not saved to the user's local env file.
- Alias changes do not affect programs launched from Allegro PCB Editor, for example, import logic, refresh_symbol.
- To set funckeys, see `axlSetFunckey`, `axlGetAlias`, `axlProtectAlias`, `axlIsProtectAlias`, `axlSetAlias` `axlGetAlias`, `axlProtectAlias`, and `axlIsProtectAlias`.

Arguments

<code>t_alias</code>	Name of the Allegro PCB Editor environment alias.
<code>g_value</code>	Value to which the environment alias is to be set. Can be a string or <code>nil</code> .

Value Returned

<code>t</code>	Alias set.
<code>nil</code>	Invalid data or alias is marked read-only.

Example 1

```
axlSetAlias( "F2" "save")
```

Sets the F2 function key to the save command.

Example 2

```
axlSetAlias( "~S" nil)
```

Unsets the Ctrl-S alias.

axlSetFunckey

```
axlSetFunckey(  
    _alias  
    g_value  
)  
==> t/nil
```

Description

Works similar to `axlSetAlias` except allows alpha-number keys to work like function keys (no Enter key required). See `axlSetAlias` for complete documentation.

- Funckey settings only apply to current session. They are not saved to user's local `env` file.
- Funckey changes do not affect programs launched from Allegro PCB Editor: for example, `import logic` or `refresh_symbol`.

Arguments

<code>t_alias</code>	name of the Allegro environment alias.
<code>g_value</code>	Value to which the environment alias is to be set. Can be a string, or nil.

Value Returned

<code>t</code>	Returns <code>t</code> if successful.
<code>nil</code>	Returns <code>nil</code> if invalid data type of alias is marked read only.

See Also

[axlGetFuncKey](#), [axlIsProtectAlias](#), [axlIsProtectAlias](#), [axlSetAlias](#)

Examples

Set the funckey alias to move

```
axlSetFunckey( "m" "move" t)
```

Unset the move

Allegro SKILL Reference

Allegro PCB Editor Command Shell Functions

```
axlSetFunckey( "m" nil)
```

axlSetVariable

```
axlSetVariable(  
    t_variable  
    [g_value]  
)  
⇒ t/nil
```

Description

Sets the Allegro PCB Editor environment variable with name given by the string *t_variable* to the value *g_value*. *g_value* can be a string, int, t, or nil. Returns the string assigned to the variable or nil if the variable cannot be set in Allegro PCB Editor.

Note: 511 is the maximum list long (*l t_variable*).

Notes:

- Variable names and values can change from release to release.
- Variable settings only apply to current session. They are not saved to local env file for the user.
- Variable changes do not effect programs launched from Allegro PCB Editor. For Example, import logic, refresh_symbol
- Many Allegro operations are done via batch operations such as items in File Import/Export, artwork, axlRunBatchDBProgram, and so on. These operations do NOT see variables changed (like PSMPATH) by this call or by the Allegro set command.

Arguments

<i>t_variable</i>	String giving the name of the Allegro PCB Editor environment variable.
<i>g_value</i>	Value to which the environment variable is to be set. Can be a string, int, t, or nil.

Value Returned

<i>t</i>	Environment variable set.
<i>nil</i>	Environment variable not set.

See Also

[axlGetVariable](#)

Example

Sets new library search path libpath.

```
(axlSetVariable "libpath" "/mytools/library")
⇒ t
libraryPath = (axlGetVariable "libpath")
⇒ "/mytools/library"
```

Using list mode.

```
axlSetVariable("psmpath" '("." "symbols"))
    ==> t
    axlGetVariableList("psmpath")
    ==> ("." "symbols")
```

axlSetVariableFile

```
axlSetVariableFile(  
    t_variable  
    g_value  
)  
==> t/nil
```

Description

Sets and saves to file Allegro environment variable. This operates the same as [axlSetVariable](#) except it also saves the setting to the user's local environment file.

Variable is added in the preference section of the env file.



Caution

On Windows, updating the environment file on disk can cause performance issues if this interface is used heavily.

Arguments

t_variable Name of the Allegro environment variable.

g_value Value to which the environment variable is to be set. Can be a string, int, t, or nil.

Values Returned

t/nil Returns *t* if successful. Returns *nil* if invalid data type of variable is marked read-only.

See Also

[axlSetVariable](#), [axlUnsetVariableFile](#)

axIShell

```
axlShell(  
    t_command  
)  
⇒ t
```

Description

Issues the Allegro PCB Editor command string *t_commands* to the connected editor. You can chain commands. This call is synchronous.



This function might not be portable across Allegro PCB Editor releases.

Arguments

t_command Allegro PCB Editor shell command or commands.

Value Returned

See Also

axlShellPost

Example 1

```
(axlShell "status")  
⇒ t
```

Displays Allegro PCB Editor Status form from AXL-SKILL.

Example 2

```
axlShell("zoom points; pick 0 0; pick 100 100")
```

Chained command example:

axIShellPost

```
axlShellPost( t_command ) ==> t
```

Description

This works similar to `ax1Shell` except it first requires a return from the Skill interpreter before executing the command(s). It should only be used in the special circumstance where you want to do some processing in Skill, execute an Allegro PCB Editor interactive command and have that command be left active for the user. If more than one command is embedded in post command then subsequent commands should be prefixed with an underscore to inhibit scripting. For example:

```
axlShellPost("zoom points; pick 10 20")
```



Do not

Do not attempt to use this as a method to override an existing Allegro PCB Editor command with Skill code and then call the original command. An infinite loop will result.



This function may not be portable across Allegro PCB Editor releases.

Arguments

t_command Allegro PCB Editor shell command or commands.

Value Returned

See Also

ax1Shell

EXAMPLES

Over the move command to print hello and then let user move objects.

```
axlCmdRegister( "mymove" 'testSkill ?cmdType "interactive")
procedure( testSkill()
    printf("Hello mymove\n")
    axlShellPost("echo hello from post; _move")
    printf("Hello after-mymove\n")

)
Output -- showing deferred execute:
Hello mymove
Hello aftermove
hello from post
Select element(s) to move.
```

axlUnsetVariable

```
axlUnsetVariable(  
    t_variable  
)  
⇒ t
```

Description

Unsets the Allegro PCB Editor environment variable with the name given by the string *t_variable*. The value of the named variable becomes `nil`.



Variable names and values can change from release to release.

Arguments

<i>t_variable</i>	String giving the name of the Allegro PCB Editor environment variable.
-------------------	--

Value Returned

t	Always returns t.
---	-------------------

Example

```
(axlUnsetVariable "libpath")  
⇒ "/mytools/library"  
libraryPath = (axlGetVariable "libpath")  
⇒ nil
```

Clears the library path `libpath` when its current value is `/mytools/library`.

axlUnsetVariableFile

```
axlUnsetVariableFile(  
    t_variable  
)  
==> t
```

Description

Unsets the value of specified Allegro environment variable. Works the same as [axlUnsetVariable](#) plus it also updates the local environment file of the user with the change.



On Windows, updating the environment file on disk can cause performance issues if this interface is used heavily.

Arguments

t_variable String giving the name of the Allegro environment variable.

Value Returned

t Always returns t.

See Also

[axlSetVariableFile](#)

SiP/APD Commands

Overview

This functions listed in this chapter are available only in Cadence IC Packaging tools; Allegro Package Designer (APD) and SiP Layout (CDNSIP).

axlChangeLayer

```
axlChangeLayer(  
    lo_dbid/o_dbid  
    t_newLayer  
    [o_padStackDbid]/[t_padstackname]  
)  
==> t/nil
```

Description

Changes layer for lines, clines or segments, shapes, and text. Functionality offered matches what the Allegro PCB Editor change command provides.

If moving clines or cline segments across layers, you should provide a via to be used to maintain connections. Via must meet constraint rules. For via to be accepted it must have:

- pads on start and destination layers
- be in the constraint via list for the net and location

If the provided padstack is not acceptable, system will select an acceptable padstack based upon the via list for net and location.

Note: If you need to change the layer of multiple etch objects, it is more efficient to pass them as a list of dbids then to call this function for each dbid.

Arguments

<i>lo_dbid/o_dbid</i>	a single dbid or list of dbids
<i>t_newLayer</i>	new layer for placing dbid
<i>o_padStackDbid</i>	if moving clines across layers, allegro will add a via to maintain connection. This is that via. If this argument is not provided the system default via is used.
<i>t_padstackName</i>	name of padstack to be used

Value Returned

t if succeeded, *nil* if failure

Failures

For debug purposes set axlDebug(t) to see additional messages.

- dbid is of a unsupported type
- illegal option types
- target layer matches object current layer

Examples

- Move an object to ETCH/BOTTOM

```
; ashOne is a selection utility found at <cdsroot>/pcb/examples/skill/ash-fxf/  
ashone.il  
dbid = ashOne()  
; pick an object (set find filter)  
result = axlChangeLayer(dbid "ETCH/BOTTOM")  
; or if moving clines  
result = axlChangeLayer(dbid "ETCH/BOTTOM" "PAD60SQ36D")
```

See Also

[axlTransformObject](#), [axlDBChangeText](#), [axlChangeWidth](#)

axlCreateDeviceFileTemplate

```
axlCreateDeviceFileTemplate (
    t_deviceName
    t_CLASS
    l_pinList
) -> t/nil
```

Description

This creates a template device file providing same functionality as the create device command in the symbol editor. Normally you would use [axIDBCreateComponent](#) to create a device file if in the board.

Arguments

<i>t_deviceName</i>	Name of device file (no file extension or path)
<i>t_CLASS</i>	Class of device (e.g. IC, IO, etc.)
<i>l_pinList</i>	List of pins. Can be any combination of either pin dbid or pin numbers. If a pin dbid will filter out mechanical pins

Value Returned

t - file created

nil - an issue

See Also

[axIDBCreateComponent](#)

axICompAddPin

```
axlCompAddPin(  
    o_comp  
    g_absLoc  
    o_pin/lo_pins  
) => t/nil
```

Description

This function adds one or more pins to the specified component. Pins are added to the corresponding component and symbol definition, with changes being reflected in all instances of those definitions.

Arguments

o_comp Dbid of component instance to which pins should be added.

g_absLoc If true, locations and rotations for pins are absolute values in the design space. If *nil*, these values are relative to the origin of the unmirrored, unrotated symbol definition.

o_pin/lo_pins Structure, or list of structures, defining the pins to be added. These objects are defstructs as defined below.

Defstruct used to define a pin. Use make_axlCompPinRecord.

Required Elements are:

- *s_pinUse* – Pin use code for this pin. Must be one of the following symbols:

- UNSPEC
 - POWER
 - GROUND
 - NC
 - LOADIN
 - LOADOUT
 - BI
 - TBI

- OCA
- OCL.

- *n_swapCode* – Swap group code for this pin. A swap code of 0 means this pin is not swappable. Otherwise, all pins with the same swap code are swappable. This value is not used for co-design components, as all co-design comp pins are considered swappable.
- *l_location* – X/Y coordinate location for the pin. Absolute or relative to the symbol def origin, as specified by *g_absLoc*.
- *n_rotation* – Angular rotation of this pin. Absolute or relative to the symbol definition origin, as specified by *g_absLoc*.

Optional Elements are:


- *pinNumber* – Physical pin number to assign to this pin. Must be unique across all pins of the component. If no pin number is provided, the pin number will be computed based on the pin numbering scheme for the component. If the numbering scheme is 'Customized', as is the default for co-design objects, then the tool will assign the first unused integer as the pin's number (1, 2...).
- *pinName* – Logical pin name for the pin. Not used for power/ground pins. If not provided, the pin name for signal pins will be the same as the physical pin number.
- *verilogPort* – Verilog port name for the pin. Not used for power/ground pins. If not provided, the verilog port name will match the logical pin name.
- *net* – Net name or dbid to assign this pin to when created. If nil, pin will be created on a dummy net and can be assigned later.
- *padstack* – Padstack name or dbid to use for this pin. If no padstack is supplied, the padstack already in use for pins of this component will be used for this pin as well.

Co-design Elements are:

- *codesignNet* – Net name for this pin in the secondary design space. For example:
 - For a co-design die in a package, this is the pin's net in the IC design.
 - For a co-design package in a board, this is the pin's net in the package.
- *codesignPad* – Pad/Cell name for this pin in the secondary design space. For example:
 - For a co-design die in a package, this is the pin's LEF bump macro.
 - For a co-design package in a board, this is the pin's padstack in the package.

Value Returned

- `t` if the pin(s) were added.
- `nil` if there was an error adding any of the pins, e.g. if a pin would be placed outside the extents of the symbol or drawing.



Tip

If many pins are to be added, it is more efficient to pass the entire list to this function to process them in one call than to call `axlCompAddPin` with each individual pin.

See Also

[axlCompDeletePin](#), [axlCompMovePin](#)

axlCompDeletePin

`axlCompDeletePin(o_pin/lo_pins) => t/nil`

Description

This function deletes the specified pin(s) from the parent component and symbol definition. As a result, the pin will also be deleted from all instances of these definitions and not just the instance the pin passed in belongs to.

Arguments

o_pin/lo_pins skill dbid of the pin to be deleted, or a list of pins to be deleted.

Value Returned

- `t` if the pin(s) were deleted.
- `nil` if there was an error deleting any of the pins, e.g. if a pin had the fixed property.

Note: If many pins are to be delete, it is more efficient to pass the entire list to this function to process them in one call than to call [axlCompDeletePin](#) with each individual pin.

See Also

[axlCompAddPin](#), [axlCompMovePin](#)

axlCompMovePin

```
axlCompMovePin(  
    o_pin/lo_pins  
    ?move          l_deltaPoint  
    ?groupMirror   t/nil  
    ?groupRotation f_angle  
    ?rotOrigin     l_rotatePoint  
    ?pinRotation   f_deltaAngle  
) => t/nil
```

Description

This function moves the specified pin(s) by the specified delta x/y, rotation, and mirror. Rotation and mirror, if provided, are applied around the `rotatePoint` (defaults to 0,0 if not provided). A rotation to apply to each individual pin may also be provided.

Arguments

<i>o_pin/lo_pins</i>	skill dbid of the pin to be moved, or a list of pins to be moved.
<i>move</i>	X/Y delta to move each pin in the set by.
<i>groupMirror</i>	<i>t</i> if the position of each pin in the group should be mirrored around the supplied <i>rotOrigin</i> .
<i>groupRotation</i>	angle of rotation that should be applied to each pin in the group to determine its new final location. Applied around <i>rotOrigin</i> .
<i>rotOrigin</i>	X/Y origin for group mirror and rotation application.
<i>pinRotation</i>	Rotation to apply to individual pins once placed at new location. For example, if you are moving a pin from the north side to west side, and the pin is rectangular, you may wish to specify a rotation of 90 degrees to keep the same orientation of the pin rectangle relative to the nearest die edge.

Value Returned

t if the pin(s) were moved.

nil if there was an error moving any of the pins, e.g. if a pin had the fixed property or would be placed outside the extents.

Notes:

- If many pins are to be moved, it is more efficient to pass the entire list to this function to process them in one call than to call axlCompMovePin with each individual pin.
- When applying multiple transforms at once to the set of pins, the operations are performed in the following order:
 - a. group mirror is performed for the group about the specified rotOrigin.
 - b. group rotation is then applied, also around the rotOrigin.
 - c. move delta is then applied.

This is important to keep in mind so that you achieve the desired end position for all pins being moved, and so that you use the correct rotOrigin point.

See Also

[axlCompAddPin](#), [axlCompDeletePin](#)

axlDBIsBondingWireLayer

```
axlDBIsBondingWireLayer(  
    t_layerName  
)  
⇒ t/nil
```

Description

This is an obsolete function. Bonding wire layers have been replaced by die stack layers. Use axlDBIsDieStackLayer to check whether a layer is a die stack layer.

Verifies if a layer is a bonding layer. This means that attribute of the “paramLayer” parameter *dbid* called “type” has a value of “BONDING _WIRE”.

This is normally used in the APD product.

Arguments

t_layerName Layer name, for example, "CONDUCTOR/<*subclass*>"
Note: CONDUCTOR is ETCH in Allegro PCB Editor.

Value Returned

t Layer is a bonding layer.

nil Layer is not a bonding layer.

See Also

[axlDBIsBondwire](#)

Example

```
axlDBIsBondingWireLayer("CONDUCTOR/TOP_COND") ⇒ nil
```

axIDBIsBondpad

```
axlDBIsBondpad(  
    o_dbid  
)  
    ⇒ t/nil
```

Description

Verifies whether or not the given element is a *bondpad*.

A *bondpad* (or *bondfinger*) is a “via” with the BOND_PAD property.

Arguments

o_dbid dbid of the element to be checked.

Value Returned

`t_o_dbid` is a bondpad.

nil *o_dbid* is not a bondpad.

axlDBIsBondwire

```
axlDBIsBondwire(  
    o_dbid  
)  
⇒ t/nil
```

Description

Verifies whether or not the given element is a *bonding wire*.

A *bonding wire* (or *bondingfinger*) is a "*via*" (can be through hole or blind/buried) with either the "*beginning*" or "*ending*" (if the via has been mirrored) layer type set to the *BondingWire* property.

Arguments

o_dbid *dbid* of the element to check.

Value Returned

t *o_dbid* is a bonding wire.

nil *o_dbid* is not a bonding wire.

axlDBIsDiePad

```
axlDBIsDiePad(  
    rd_dbid  
)  
⇒ t/nil
```

Description

Verifies whether or not the given element is a *die pad*.

A *die pad* is a pin with a component class of `IC`.

Arguments

rd_dbid *dbid* of the element to check.

Value Returned

t *rd_dbid* is a die pad.

nil *rd_dbid* is not a die pad.

axlDBIsPlatingbarPin

```
axlDBIsPlatingbarPin(  
    rd_dbid  
)  
⇒ t/nil
```

Description

Verifies whether or not the given element is a *plating bar pin*.

A *plating bar pin* is a pin with a component class of DISCRETE or PLATING_BAR.

Arguments

rd_dbid *dbid* of the element to check.

Value Returned

t *rd_dbid* is a plating bar pin.

nil *rd_dbid* is not a plating bar pin.

axlGetDieType

```
axlGetDieType(  
    componentDBID  
)  
==> t_dieType
```

Description

Returns the die attachment type for a given die component in a Cadence packaging tool (APD/SIP). A die is considered to be an IC class component in the database. Currently, the supported attachment types include the following:

- WIREBOND
- FLIP CHIP

Arguments

Component DBID *dbid* handle of the die component to query.

Value Returned

<i>t_dieType</i>	If successful.
<i>nil</i>	If failed (non-die object passed or not a packaging product).

Examples

```
axlGetDieType (myComp)  
==> "FLIP CHIP"
```

axlGetMetalUsageForLayer

```
axlGetMetalUsageForLayer (
    l_layers
    [l_extents]
    [g_positive]
)
==> resultStruct/nil
```

Description

This function compute the percentage metal coverage on the layers specified in *l_layer(s)* (combination of all layers listed) in the area specified in *l_extents*. If no extents are provided, then the drawing's substrate geometry outline extents will be used.

Negative layer metal coverage can be computed by passing nil for *g_positive*, if processing negative artwork layers such as solder mask layers.

Arguments

<i>l_layers</i>	A single layer or list of layers to compute the (combined) metal usage on. For example, passing list("CONDUCTOR/TOP" "PIN/TOP") will compute the coverage of all conductor + pin objects on the top layer. It will not compute the two individually.
<i>l_extents</i>	BBox region to compute metal coverage in. If not supplied, the tool will compute based on the substrate geometry outline's extents or, if no outline is present, the database extents.
<i>g_positive</i>	Whether the layer(s) being processed are positive or negative layers. Defaults to true.

Value Returned

- *resultStruct/nil* – *resultStruct* is a defstruct containing for elements:
- *areaUnits* – Units in which the area was computed and returned.
- *regionArea* – The area of the extents region the tool used (user supplied or drawing extents).
- *metalArea* – The total metal area in the region checked on the layers indicated.

Allegro SKILL Reference

SiP/APD Commands

- percentMetalCoverage – The percentage of the extents region covered by metal.
Calculated as ((metalArea / regionArea) * 100.0)
- nil is returned if there is an error, with error printed to command line.

axlGetWireProfileDefinition

list axlGetWireProfileDefinition(profileName)

Description

Given a bonding wire profile name, this will returns its definition information.

Arguments

profileName Name of the profile definition being queried. If this argument is *nil*, definitions of all profiles in design are retrieved.

Value Returned

Structure of information describing the profile definition (material, 3d points list, etc).

In case of failure, an error string is returned.

axlAddAutoAssignNetAlgorithm

```
axlAddAutoAssignNetAlgorithm(t_algorithm t_displayName)
==> t/nil
```

Description

This function allows the user to add custom auto net assignment algorithms to the list in the Logic -> Auto Assign Net command's algorithms list in the APD and SIP IC Packaging tools. This list will always contain the Cadence standard algorithms (Router-Based, Nearest Match, and Constraint-Driven).

These names cannot be duplicate or overwritten by the customer.

Specifying a pair with either a duplicate algorithm or display name will cause the currently-existing (user) entry to be replaced.

Arguments

t_algorithm Text string (case sensitive) containing the name of the skill function to be called for this algorithm. The function must take two parameters:

First parameter: List of source pins.

Second parameter: List of destination pins.

The function should return "FAIL" if it was unable to complete due to some manner of code failure, or else should return a list of source pins that are still unassigned.

t_displayName Text string (also case sensitive) that will be used as the name of this algorithm in the auto assign net command's pull-down menu for selecting the algorithm to use.

Value Returned

t if algorithm successfully registered.

nil if registration failed (function not defined, name in use, etc).

axlGetWireProfileDirection

```
axlGetWireProfileDirection(  
    profileName  
)  
==> "FORWARD"/"REVERSE"/nil
```

Description

This function returns the direction of a wire profile definition defined in the database. Profiles may be either forward or reverse. If the profile definition name provided does not exist in the design, the return value will be `nil`.

Arguments

profileName The name of the wire profile to query the direction of.

Value Returned

- "FORWARD" for forward-bond wire profile definitions.
- "REVERSE" for reverse-bond wire profile definitions.
- `nil` if the wire profile definition does not exist in the database.

axlGetAllVisibleProfiles

```
axlGetAllVisibleProfiles()  
  ==> list of profiles / nil
```

Description

Returns a list of all the bond wire profiles currently visible in the design.

Arguments

Nothing.

Value Returned

- list of profile names.
- nil if error or no profiles visible.

axlSetAllProfilesVisible

```
axlSetAllProfilesVisible(visible)
  ==> t / nil
```

Description

Turns all wire profiles in the design on or off.

Arguments

visible *t* to turn all profiles on, *nil* to turn them off.

Value Returned

t/nil to indicate success or failure.

axlImportWireProfileDefinitions

```
axlImportWireProfileDefinitions(  
    xmlFileName  
    setAsMaster  
)  
==> x/nil
```

Description

This function will import the bond wire profiles defined in the XML file specified. If a profile is defined both in the XML file and in the current design, the design's definition will be updated to match the new definition being imported.

Argument

<i>xmlFileName</i>	The name of the XML file on disk which includes the bond wire profile definitions to be read. If not in the current working directory, this should include the absolute or relative path to the XML file.
<i>setAsMaster</i>	If true, this XML file will be set as the master profile definitions file for this database. The master file is where the user can refresh profile definitions from if they are changed. Only one file is allowed to be the master.

Value Returned

- *x*, the number of profile definitions successfully imported.
- *nil* if an error occurred (message printed to status window).

axlSetDieStackData

```
axlSetDieData (
    g_stackId
    s_dataType
    g_newValue
)
==> t/nil
```

Description

This function sets the given data for the specified die.

Note: The command is available only in SIP products.

Arguments

g_stackId Name or dbid of the die stack to get the data for.

s_dataType Data type of the given value, one of the following:

```
' (DSA_CAVITY_DEPTH
  DSA_CAVITY_LAYER
  DSA_CAVITY_DIMENSION)
```

g_newValue New value for the specified data type.

Value Returned

t on success, otherwise *nil*

axlDBIsDieStackLayer

```
axlDBIsDieStackLayer (
    t_layerName
)
==> t or nil
```

Description

Verifies if layer is a die stack layer. This means that the attribute of the "paramLayer" parameter *dbid* called "type" has a value of "DIESTACK". This is normally used in the APD product.

Arguments

t_layerName Layer name "CONDUCTOR/<subclass>"

Note: CONDUCTOR is ETCH in Allegro PCB Editor

Value Returned

t If die stack layer.

nil If not.

See Also

[axlDBIsBondwire](#)

Examples

```
axlDBIsDieStackLayer ("CONDUCTOR/TOP_COND") -> nil
```

axlGetDieData

```
axlGetDieData (
    g_dieId
)
==> die-data defstruct/nil
```

Description

Gets the data for the given die and loads it into the a defstruct.

Only available in SIP products.

Arguments

g_dieName refdes or dbid of the given die.

Value Returned

dieData defstruct with data for the given die.

nil Die does not exist or there was an error.

defstruct fields:

dbid dbid of die

refId die refdes

memberType DSA_DIE

stackName parent die-stack name

stackPosition integer position of member in stack

layerNamedie pad layer

dieThickness die thickness (flipchip bumps not included)

totalThickness die thickness (flipchip bumps included)

stackHeightMin starting height within stack

stackHeightMax ending height within stack

Allegro SKILL Reference

SiP/APD Commands

origin die symbol x/y location

rotation rotation angle in degrees

extents unioned extents of all members in stack

type one of DSA_DIE_STANDARD or DSA_DIE_CODESIGN

attachType one of DSA_DIE_FLIPCHIP or DSA_DIE_WIREBOND

orientation one of DSA_DIE_CHIPUP or DSA_DIE_CHIPDOWN

bumpDiamAtPkg flipchip bump diameter at package

bumpDiamAtDie flipchip bump diameter at die

bumpDiamMax flipchip bump diameter maximum

bumpHeight flipchip bump height

bumpEcond flipchip electrical conductivity w/units

Example

```
data = axlGetDieData("FLIPCHIP_1")
printf("stack-pos = %L, layer-name = %L, attach-type = %L\n"
      data->stackPosition data->layerName data->attachType)

==> stack-pos = 1, layer-name = "TOP_COND", attach-type = DSA_DIE_FLIPCHIP
```

axlGetDieStackData

```
axlGetDieStackData (
  g_stackArg
)
==> stack-data defstruct/nil
```

Description

Gets the data for the given die-stack and loads it into a defstruct.

Only available in SIP products.

Arguments

g_stackArg	name or <i>dbid</i> of the given die-stack
------------	--

Value Returned

stackData	defstruct with data for the given die stack.
-----------	--

nil	Die stack does not exist or there was an error.
-----	---

defstruct fields:

dbid	dbid of member
------	----------------

refId	member name
-------	-------------

surface	one of DSA_SUBSTRATE_TOP, DSA_SUBSTRATE_BOTTOM, DSA_SUBSTRATE_CAVITY_TOP, DSA_SUBSTRATE_CAVITY_BOTTOM
---------	---

depth	for cavity-placed dies, gives the number of layers below the surface the stack is placed
-------	---

cavityClearance	For cavity-placed stacks, the clearance from the stack extents to the edge of the cavity on the lowest layer.
-----------------	--

cavityExpansion	For cavity-placed stacks, the amount by which the cavity grows on each subsequent layer (the "width" of the stadium step).
-----------------	---

Allegro SKILL Reference

SiP/APD Commands

stackHeightMin	starting height within stack
stackHeightMax	ending height within stack
rotation	rotation angle in degrees
extents	unioned extents of all members in stack

Example

```
data = axlGetDieStackData("DIESTACK1")
printf("name = %L, minHeight = %L, maxHeight = %L\n"
data->name data->stackHeightMin data->stackHeightMax)

==> name = "DIESTACK1", minHeight = 0.0, maxHeight = 496.0
```

axlGetDieStackMemberSet

```
axlGetDieStackMemberSet()  
  ==> list of die-stack member defstructs/nil
```

Description

Returns a list of defstructs - one for each member of the given die stack.

Only available in SIP products.

Arguments

g_stackArg	name or <i>dbid</i> of the die stack
------------	--------------------------------------

Value Returned

l_data	List of die-stack member data defstructs
--------	--

nil	in case of an error
-----	---------------------

defstruct fields:

dbid	<i>dbid</i> of member
------	-----------------------

refId	member name
-------	-------------

memberType	one of DSA_DIE, DSA_SPACER, DSA_INTERPOSER
------------	--

stackPosition	integer position of member in stack
---------------	-------------------------------------

layerName	etch object subclass of member
-----------	--------------------------------

nextMemberOnSameLayer flag indicating next member on same layer

prevMemberOnSameLayer flag indicating previous member on same layer

Example

```
data = axlGetDieStackMemberSet("DIESTACK1")  
foreach(member data
```

Allegro SKILL Reference

SiP/APD Commands

```
printf("refId = %L, memberType = %L\n" member->refId
      member->memberType)
)

==> refId = "FC1", memberType = DSA_DIE
     refId = "IPOSER_1", memberType = DSA_INTERPOSER
     refId = "WB1", memberType = DSA_DIE
     refId = "SPACER_1", memberType = DSA_SPACER
     refId = "WB2", memberType = DSA_DIE
```

axlGetDieStackNames

`axlGetDieStackNames() ==> list of die-stack names/nil`

Description

Returns a list of the names of all die stacks in the current design.

Only available in ICP products.

Arguments

None

Value Returned

List of die-stack names or `nil` if none exist

axlGetIposerData

```
axlGetIposerData(  
    g_iposerId  
)  
==> iposer-data defstruct/nil
```

Description

This function fetches the data for the given iposer and loads it into a defstruct.



Only available in SIP products.

Arguments

g_iposerName	name or <i>dbid</i> of the given interposer
--------------	---

Value Returned

iposerData	defstruct with data for the given iposer.
------------	---

nil	iposer does not exist or there was an error.
-----	--

defstruct fields:

dbid	<i>dbid</i> of interposer
------	---------------------------

refId	interposer ref-id
-------	-------------------

memberType	DSA_INTERPOSER
------------	----------------

stackName	parent die-stack name
-----------	-----------------------

stackPosition	integer position of member in stack
---------------	-------------------------------------

layerName	etch-object layer (vias/clines/shapes)
-----------	--

totalThickness	dielectric + conductor thickness
----------------	----------------------------------

stackHeightMin	starting height within stack
----------------	------------------------------

Allegro SKILL Reference

SiP/APD Commands

stackHeightMax	ending height within stack
origin	interposer symbol x/y location
rotation	rotation angle in degrees
extents	unioned extents of all members in stack
dielMatl	name of dielectric material used for substrate
dielThickness	thickness of dielectric material
condMatl	name of conductor material used for etch objects
condThickness	thickness of conductor material

Example

```
data = axlGetDieData("IPOSER_1")
printf("stack-pos = %L, layer-name = %L, thickness = %L\n"
      data->stackPosition  data->layerName data->totalThickness)

==> stack-pos = 4, layer-name = "IP1", thickness = 106.0
```

axlGetSpacerData

```
axlGetSpacerData(  
    g_spacerId  
)  
==> spacer-data defstruct/nil
```

Description

Gets the data for the given spacer and loads it into a defstruct.



Only available in SIP products.

Arguments

g_spacerName name or *dbid* of the given spacer

Value Returned

spacerData defstruct with data for the given spacer.

nil Spacer does not exist or there was an error.

defstruct fields:

dbid *dbid* of spacer

refId spacer ref-id

memberType DSA_INTERPOSER

stackName parent die-stack name

stackPosition integer position of member in stack

layerName etch-object layer (vias/clines/shapes)

totalThickness dielectric + conductor thickness

stackHeightMin starting height within stack

Allegro SKILL Reference

SiP/APD Commands

stackHeightMax	ending height within stack
origin	spacer symbol x/y location
rotation	rotation angle in degrees
extents	unioned extents of all members in stack
dielMatl	name of dielectric material used for substrate
dielThickness	thickness of dielectric material

Example

```
data = axlGetDieData("SPACER_1")
printf("stack-pos = %L, layer-name = %L, diel-matl = %L\n"
      data->stackPosition data->layerName data->dielMatl)

==> stack-pos = 4, layer-name = "SP1", diel-matl = "PHENOLIC"
```

axlGetWireProfileColor

```
axlGetWireProfileColor(t_profile)
==> color index / nil
```

Description

This function will retrieve the color index associated with a bond wire profile. If no profile matching the name supplied is found in the database, nil is returned.

Arguments

t_profile	Name of profile to retrieve color for.
-----------	--

Value Returned

Color number assigned to profile if the profile is found.

nil if an error occurred or profile not found.

axlGetWireProfileVisible

```
axlGetWireProfileVisible(t_profile)
  ==> t / nil
```

Description

This function will retrieve the visibility status of a bond wire profile. If no profile matching the name supplied is found in the database, nil is returned.

Arguments

t_profile	Name of profile to retrieve color for.
-----------	--

Value Returned

t : if wire profile exists and is visible.

nil : if profile is invisible or does not exist.

axlPackageDesignCheckAddCategory

```
axlPackageDesignCheckAddCategory(t_name t_bitmap t_description)
==> defstruct defining category.
```

Description

This function will register a new category inside the IC Packaging tools' "package integrity" command check tree.

You must define a category before adding checks to it. So, this function should always be called prior to [axlPackageDesignCheckAddCheck](#).

A newly added category will be inserted into the tree in alphabetically sorted order. Therefore, you do not need to manage the order categories are added by yourself.

Note: If the category name already exists, it will not be redefined.

Arguments

t_name Name of the category of checks as it should appear in the user interface. This name should be used when calling [axlPackageDesignCheckAddCheck](#) to add specific checks.

t_bitmap Name of the bitmap file which should be shown when this check category is active in the user interface. This should be a full path to the bitmap or else the bitmap must be resolvable through BMPPATH.

t_description The description to be displayed in the GUI when this category is highlighted.

Value Returned

Skill defstruct defining the category.

See Also

[axlPackageDesignCheckAddCheck](#)

axlPackageDesignCheckAddCheck

```
axlPackageDesignCheckAddCheck(  
    t_category t_name t_bitmap t_description  
    s_runCommand g_fixable  
) ==> defstruct defining check.
```

Description

This function will register a new check in the specified category of the IC Packaging tools' "package integrity" command check tree.

You must define a category before adding checks to it. So, this function should always be called after [axlPackageDesignCheckAddCategory](#).

A newly added check will be inserted into the tree in alphabetically sorted order. Therefore, you do not need to manage the order checks are added by yourself.

`s_runCommand` is the skill function which should be called if this check is selected to run. This function MUST adhere to the following guidelines:

1. It must take exactly one argument, which is whether to fix errors it encounters or not.
2. It must return an integer value for how many errors were found in the database.
3. It must call the following functions:

```
axlPackageDesignCheck.LogError(<error string> <fixed>)
```

and

```
axlPackageDesignCheckDrcError(<error location> <dbids>)
```

to report any errors it finds.

These restrictions are imposed to ensure that output is consistent across all checks run by this command.

Arguments

`t_category` Name of the category this check should be placed under in the user interface tree. This should be the same name as sent to [axlPackageDesignCheckAddCategory](#).

`t_name` Name of the check as it should appear in the user interface. This will be the name given to the check in the resulting log file, and will be the description for any external DRCs created.

Allegro SKILL Reference

SiP/APD Commands

<i>t_bitmap</i>	Name of the bitmap file which should be shown when this check is active in the user interface. This should be a full path to the bitmap or else the bitmap must be resolvable through <i>BMP PATH</i> .
<i>t_description</i>	The description to be displayed in the GUI when this check is highlighted. This description will also be printed to the log file ahead of any violations found for this check. As a result, the description should be as descriptive as possible in order to maximize its usefulness.
<i>s_runCommand</i>	A symbol representing the function to be called to check this rule. See description for details about the required format and return value of this function.
<i>g_fixable</i>	Boolean flag to tell the user on the interface whether problems found by this check can be automatically fixed or not.

Value Returned

Skill defstruct defining the check.

See Also

[axlPackageDesignCheckAddCategory](#), [axlPackageDesignCheckLogError](#),
[axlPackageDesignCheckDrcError](#)

axIPackageDesignCheckDrcError

```
axIPackageDesignCheckDrcError(l_location g_dbids)
==> nil
```

Description

This function will create an external DRC marker for an error found by the currently running package integrity check. The tool itself will track the check being run so that it knows the name to use for the rule violation.

Arguments

l_location Location at which to place the DRC marker.

g_dbids Optional list of database object ids which are associated with this error. Usually 0-2 objects are affected.

Value Returned

nil

See Also

[axIPackageDesignCheckAddCheck](#), [axIPackageDesignCheckLogError](#)

axIPackageDesignCheck.LogError

```
axIPackageDesignCheck.LogError(t_errorString g_fixed g_location)
==> nil
```

Description

This function will log an error found by this function to the log file if the log file is enabled. By using this interface, you are ensuring that the API will format your message consistently.

Arguments

<i>t_errorString</i>	String to be printed to the log file. This should have all variable substitutions already done and be a simple string. This function will take care of any formatting necessary.
<i>g_fixed</i>	Boolean indicating whether the error was fixed by the tool.
<i>g_location</i>	Location where the error occurred, if applicable. This is appended to your log entry for you, and is used to let the user zoom to the error location in the design. If the location is unknown or not applicable, pass nil for the location.

Value Returned

nil

See Also

[axIPackageDesignCheck.AddCheck](#), [axIPackageDesignCheck.DrcError](#)

axlSetDieData

```
axlSetDieData(  
    g_dieId  
    s_dataType  
    g_newValue  
)  
==> t/nil
```

Description

Sets the given data for the given die.



Only available in SIP products.

Arguments

g_dieName	name or <i>dbid</i> of the die to get the data for
s_dataType	data type of the given value, one of: ' (DSA_BUMP_PACKAGE_DIAM_DBREP DSA_BUMP_PACKAGE_DIAM_STRING DSA_BUMP_DIE_DIAM_DBREP DSA_BUMP_DIE_DIAM_STRING DSA_BUMP_MAX_DIAM_DBREP DSA_BUMP_MAX_DIAM_STRING DSA_BUMP_HEIGHT_DBREP DSA_BUMP_HEIGHT_STRING DSA_BUMP_ECOND_STRING DSA_DIE_THICKNESS_DBREP

Allegro SKILL Reference

SiP/APD Commands

DSA_DIE_THICKNESS_STRING)

g_newValue new value for the specified data type.

Value Returned

t on success, otherwise nil

axlSetDieType

```
axlSetDieType(  
    componentDBID  
    dieType  
)  
==> t/nil
```

Description

This function sets the attachment type for a die component to one of the available types. Currently, the supported attachment types are:

- WIREBOND
- FLIP CHIP

Arguments

componentDBID dbid handle of the die component to configure.

dieType Attachment type to configure this component as. Supported values are "WIREBOND" and "FLIP CHIP".

Value Returned

t if successful.

nil if failed (non-die object passed or not packaging product).

Example

```
axlSetDieType (myComp "WIREBOND")  
==> t
```

axlSetIposerData

```
axlSetIposerData(  
    g_iposerId  
    s_dataType  
    g_newValue  
)  
==> t/nil
```

Description

Sets the given data for the given iposer.

Only available in SIP products.

Arguments

g_iposerName	name or <i>dbid</i> of the given iposer
s_dataType	data type of the given value, one of: ' (DSA_CONDUCTOR_MATERIAL DSA_CONDUCTOR_THICKNESS_DBREP DSA_CONDUCTOR_THICKNESS_STRING DSA_DIELECTRIC_MATERIAL DSA_DIELECTRIC_THICKNESS_DBREP DSA_DIELECTRIC_THICKNESS_STRING DSA_PART_NUMBER)
g_newValue	new value for the specified data type

Value Returned


t on success, otherwise nil

axlSetSpacerData

```
axlSetSpacerData(  
    g_spacerId  
    s_dataType  
    g_newValue  
)  
==> t/nil
```

Description

This function sets the given data for the given spacer.



Only available in SIP products.

Arguments

g_spacerName	name or dbid of the spacer to get the data for
s_dataType	data type of the given value, one of: ' (DSA_DIELECTRIC_MATERIAL DSA_DIELECTRIC_THICKNESS_DBREP DSA_DIELECTRIC_THICKNESS_STRING DSA_PART_NUMBER) g_newValue
	new value for the specified data type.

Value Returned

t on success, otherwise nil

axlSetWireProfileColor

```
axlSetWireProfileColor(t_profile n_color)
==> t / nil
```

Description

This function will set the color of a wire profile to the given value.

Arguments

t_profile Name of profile to retrieve color for.

n_color Color index to assign to the profile.

Value Returned

t, if successful.

nil, if error (profile does not exist).

axlSetWireProfileVisible

```
axlSetWireProfileVisible(t_profile g_visible)
==> t / nil
```

Description

This function will make the identified wire profile visible or invisible.

Arguments

t_profile Name of profile to retrieve color for.

g_visible t for visible, nil for invisible.

Value Returned

- t, if successful.
- nil, if error (profile does not exist).

Allegro SKILL Reference
SiP/APD Commands

User Interface Functions

Overview

This chapter describes the AXL/SKILL functions you use to confirm intent for an action, prompt for text input, display ASCII text files, and flush pending changes in the display buffer.

Window Placement

Allegro PCB Editor encourages you to place windows in an abstract manner. For example, when you open a form, instead of specifying (x,y) coordinates you give a list of placement options. Allegro PCB Editor then calculates the placement location. An advantage of this method is that all windows automatically position themselves relative to the main Allegro PCB Editor window. Windows always position entirely onscreen even in violation of your placement parameters.

The following form placement options (strings with accepted abbreviations in parentheses) are available:

```
north (n) northeast (ne) east (e) southeast (se)  
south (s) southwest (sw) west (w) northwest (nw)  
center (c)
```

In addition you can modify the placement options with the following parameters:

Inner or Outer	Places the placement rectangle to the outside or the inside of the main window. The default is <code>inner</code> .
Canvas or Window	Uses the canvas (drawing) area or the entire window for the placement rectangle. The default is <code>Window</code> .
Border or NoBorder (Default Border)	Leaves a slight border around the placed window. If <code>noborder</code> is set, the window is set directly against the placement rectangle. The default is <code>Border</code> .
MsgLines (Default 1)	Sets the number of message lines at bottom of the placed window to 0 or 1.

Note: Only `forms` supports this parameter.

Syntax:

```
msglines #
```

Using Menu Files

You can use drawing menus, symbol menus, and shape menus in Allegro PCB Editor. Allegro tools typically support three menus; drawing, symbol and shape. The Allegro command set is very different between these three design editors. Also menu sets exist for different tools such as APD, SIP and the SI (Signal Integrity) products.

All of the tiering (product levels) within a product are managed via the "#ifdef" statements within a single menu file. Typically, the settings of environment variables controlling the tiering are documented at the top of file.

Note: You cannot strip out the `#ifdef` statements to gain access to the missing commands.

Allegro finds the menus with its `MENUPATH` environment variable. You can find the default Allegro PCB Editor menu files in:

```
<cdsroot>/share/pcb/text/cuimenus
```



**As new products are added in a release, new menu files may be added.
Cadence may change the name of any menu file in a release.**

Allegro SKILL Reference

User Interface Functions

The menus in this directory are as follows (due to the tools and software version you have loaded, some may not be present in your installation). You should not modify any other file type in this directory as only the menu files are supported for user modification.

Table 10-1 Allegro PCB Editor Menu Files

File Name	Description
allegro.men	Allegro PCB Editor menu for all Allegro PCB Editor .brd designs
pcb_symbol.men	Symbol menu for PCB products
partition.men	Partition menu for PCB products
specctragest.men	PCB SI menu
apd.men	APD menu
sip.men	SiP menu
icp_symbol.men	APD/SIP symbol editor menu
apd_partition.men	APD Partition editor menu
sip_partition.men	SIP Partition editor menu
apd_si.men	APD SI menu
padlayout.men	Pad Designer in the board graphics editor
padlaystn.men	Pad Designer (standalone)
allegro_free_viewer.men	Allegro/SIP Free Viewer
viewlayout.men	Allegro Viewer Plus

Menu Terms

- Menu bar - the menu items seen at the top of a Window
- Menu item - a menu line; may either be a command, separator or a submenu.
- Separator - a horizontal line drawn to visually group menu items.
- Submenu - a pulldown (from the menu bar) or a pull-right (from another submenu). Submenus may only have a display and command association is not supported.

Menu Design Considerations

- Certain dynamic items may exist. These are currently the MRU (most recently used files) and Quick reports.
 - Do not attempt to modify these items.
- Do not use spaces in the display for the menu bar.
- All menu bar items should be submenus. Do not add a command menu item at this level.
- Do not add excessive items to the menu bar. If the menu bar displays on two lines for a typical window width you may have too many items.
- Keep the display text relatively short, especially on the menu bar.

MENU CUSTOMIZATION METHODS

- Provide your own customization menu via CDS_SITE. Replace the Cadence provided menu (.men file) with your own.
 - Advantages: Relatively easy and no Skill programming required.
 - Disadvantages: For new releases need to merge your menu changes with new Cadence menus. May need to modify multiple menus
- Overload your menu customizations on Cadence menus via Skill [axlUIMenuRegister](#).
 - Advantages: Relatively easy with minimal Skill programming. Depending on your site's additions may be immune to many Cadence menu changes.
 - Disadvantages: Cannot delete Cadence menu items or restrict your changes to a one Cadence menu.
- Register a axl menu Trigger notification via [axlTriggerSet](#).
 - Advantages: Almost as much flexibility as overriding the default menu file including targeting specific menus.
 - Disadvantages: Need to examine your Skill code with new Cadence releases. Requires much more Skill programming knowledge.

Dynamically Loading Menus

All tools support overriding their default menus by putting your menu file before the default Cadence menu file via the `MENUPATH`. Programs that support AXL-Skill allow menus to be dynamically changed while the program is running. You do this using the `axlUIMenuLoad` Skill function. This is not supported in `allegro_pc` and `allegro_viewer`.

Tools support dynamically (via Skill) modifying menus. For information, see [axlUIMenuFind](#).

Understanding the Menu File Format

You can have only one menu definition per file. The following shows the menu syntax in BNF format. The use of indentation reflects hierarchy in the .men file.

Menu file grammar reflects the following conventions:

Convention	Description
[]	Optional
{ }	May repeat one or more times.
< >	Supplied by the user
	Choose one or the other
:	Definition of a token
CAPS	Items in caps are keywords

Allegro SKILL Reference

User Interface Functions

The following defines the menu file format:

FILE:

```
[comment]
[ifdef]
<name>MENU DISCARDABLE
BEGIN
    {popup}
END
```

popup:

```
POPUP "<display>"
BEGIN
    {MENUITEM "<display>" "<command>"}
    [{separator}]
    {[popup]}
END
```

{//} - comment lines

separator:

```
MENUITEM SEPARATOR
```

- this inserts a separator line at this spot in the menu. This is not supported at the top level menubar.

name: This text is ignored. Use the file name without the extension.

comment: Double slash (//) can be used to start a comment.

display: Text shown to the user.

& - This is used to enable keyboard access to the menus. For this to work, each menu level must have a unique key assigned to it. Use double ampersand (&&) to display a "&".

... - The three dots convention signifies that this command displays a form.

command: This is any Allegro command, sequence of Allegro commands, or Skill statement. The Allegro command parser acts on this statement so it offers considerable flexibility. The command should be placed within a set of double quotes (""). Double quotes are not supported within this command string.

ifdef: Use #ifdef/#endif and #ifndef/#endif to make items conditionally appear in the menu, depending on whether or not a specified environment variable is set.

An #ifdef causes the menu item(s) to be ignored unless the environment variable is set. A #ifndef causes the menu item(s) to be ignored if the environment variable is not set. You must have one #endif for each #ifdef or #ifndef to end the block of conditional menu items. Also, #ifdef, #ifndef, and #endif must start at the first column of the line in the menu file.

The #ifndef is the negation of #ifdef.

Allegro SKILL Reference

User Interface Functions

```
>      environment variable is set. A #ifdef will cause the menu item(s)
>      to be ignored if the environment variable is not set. You must
>      have one #endif for each #ifdef or #ifndef to end the block of
>      conditional menu items. Also, the #ifdef, #ifndef and #endif must
>      start at the first column of its line in the menufile.
<      The condition syntax supports multiple variables with OR '||' or
<      AND '&&' conditions. Also the negation character '!' is supported
<      for the variables:
```

Allegro SKILL Reference

User Interface Functions

These statements may be nested. The simple syntax for #ifdef follows:

```
#ifdef <env variable name>
[menu items which appear if the env variable is set]
#endif

#ifndef <env variable name>
[menu items which appear if the env variable is not set]
#endif

<           # logically equivalent to above state using negation character
<           #ifdef !<env variable name>
<           [menu items which appear if the env variable is NOT set]
<           #endif
<
<           Also logical statements
<           1) if variable1 and variable2 are both set do the included statement
<               #ifdef <var1> && <var2>
<                   [menu items which appear if both variables are set]
<               #endif
<
<           2) if either variable1 or variable2 is do the included statement
<               #ifdef <var1> || <var2>
<                   [menu items which appear if either variable is set]
<               #endif
```

The items between the #if[n]def/#endif can be one or more MENUITEMS or could be a POPUP.

Example 1

```
#ifdef menu_enable_export
    POPUP "&Export"
    BEGIN
        MENUITEM "&Logic...", "feedback"
    END
#endif
```

The *Export* popup appears in the menu only if the `menu_enable_export` environment variable is set.

Example 2

```
#ifndef menu_disable_product_notes
    MENUITEM "&Product Notes", "help -file algpn"
#endif
```

The *Product Notes* menu item appears in the menu only if the `menu_disable_product_notes` environment variable is NOT set.

Allegro SKILL Reference

User Interface Functions

Example 3 - Simple Menu Example

```
DISPLAY (indents reflect the various pulldown levels)
FileHelp
    OpenContents
    ExportProduct Notes
        LogicKnown Problems and Solutions
    Exit-----
        About Allegro...
FILE:
simple MENU DISCARDABLE
BEGIN
    POPUP "&File"
    BEGIN
        MENUITEM "&Open", "open"
        POPUP "&Export"
        BEGIN
            MENUITEM "&Logic...", "feedback"
        END
        MENUITEM "&Exit", "exit"
    END
    POPUP "&Help"
    BEGIN
        MENUITEM "&Contents", "help"
        MENUITEM "&Product Notes", "help -file algpn"
        MENUITEM "&Known Problems and Solutions", "help -file alkpns"
        MENUITEM SEPARATOR
        MENUITEM "&About Allegro...", "about"
    END
END
```

A simple menu and the simple file required to display the menu.

AXL-SKILL User Interface Functions

This section lists the user interface functions.

axlCancelOff

See axlCancelOn.

axlCancelOn

```
axlCancelOn()  
    )  
    => t  
  
axlCancelOff()  
    => t  
  
axlCancelTest()  
    => t/nil
```

Description

Allows Skill code to test for when a user clicks *Cancel*.

When cancel is enabled, the traffic light is yellow.

Although you can nest cancel calls, you should make an equal number of cancel off calls as cancel on calls.

Note: To avoid problems, always place the cancel on/off call pairs in the same function.

These calls do not work from the Skill or Allegro PCB Editor command line because Allegro PCB Editor immediately disables cancel when exiting the Skill environment to prevent the system from hanging.

Notes:

- Only enable cancel processing when you are sure there is no user interaction. Having cancel enabled when the user has to enter information is not supported and will hang the system.
- Calling `axlCancelTest` can adversely impact your program's performance.

Arguments

None

Value Returned

Only axlCancelTest returns meaningful data.

t	User click cancel.
nil	User did not click cancel.

Examples

```
count = 0
axlCancelOn()
while ( count < 50000 && !axlCancelTest()
    printf("Count = %d\n" count)
    count++
)
axlCancelOff()
```

axlCancelTest

See [axlCancelOn](#).

axICursorGet

```
axICursorGet (   
    g_pixel  
) ==> l_xy
```

Description

This command is used to obtain the current cursor position either in pixels (screen units) or converted into current design units. The mapping from pixels to design units takes into account the current window view and zoom factor of the design.

Accessing this in non-graphic mode is undefined.

Arguments

g_pixel

If the value is set to `t`, the xy coordinates are specified in pixels.

If the value is set to `nil`, current cursor position as it stands in current design is returned.

Value Returned

The cursor position either in pixels (integer) or design units (floating point).

See Also

[axICursorWarp](#), [axIUIControl](#)

axICursorWarp

```
axICursorWarp ( g_pixel l_xy ) ==> t/nil
```

Description

Use this command to set the cursor position. May set the cursor either by pixel or design units. If setting by design units the new value must be within the current viewable window ([axIWindowBoxGet](#)).

Note: See [axICursorGet](#) for a discussion between pixel and design units.

Arguments

<i>g_pixel</i>	If <i>t</i> return <i>xy</i> in pixels else return cursor position where it stands in current design.
<i>l_xy</i>	The <i>xy</i> values may be specified in pixel (<i>g_pixel=t</i>) or design units (<i>g_pixel=nil</i>)

Value Returned

<i>t</i>	If moved cursor
<i>nil</i>	If bad arguments or moved cursor outside of main window.

See Also

[axICursorGet](#), [axIWindowBoxGet](#)

axIMeterCreate

```
axIMeterCreate(
    t_title
    t_infoString
    g_enableCancel
    [t_formname]
    [t_infoString2]
    [g_formCallback]
-> t/nil
```

Description

Starts progress meter with optional cancel feature.

Note: Always call `axIMeterDestroy` when done with meter.

Arguments

<code>t_title</code>	Title bar of meter.
<code>t_infoString</code>	One line of 28 characters used for anything you want (can be updated at meter update).
<code>g_enableCancel</code>	<code>t</code> enable the application <i>Stop</i> button on graphical UI-based applications. When enabled and the user picks the <i>Stop</i> button, a true is returned by the call to <code>axIMeterIsCancelled()</code> .
<code>t_formname</code>	(Optional) The name of an alternate form that can be used with these functions which has an info field named <i>progressText</i> and a progress field named <i>bar</i> . <code>axIMeterIsCancelled</code> will also notice if a <i>Cancel</i> menu button has been pressed. If you do not give a form name <code>axIprogress.form</code> will be used.
<code>t_infoString2</code>	(Optional) By Default "".
<code>g_formCallback</code>	(Optional) The name of a Callback function that you want called for any buttons or fillings etc you may have on your form. This works the same as <code>g_formAction</code> in <code>axIFormCreate</code> .

Value Returned

`t` On success; otherwise nil.

See Also

[axIMeterCreate](#), [axIMeterIsCancelled](#), [axIMeterDestroy](#) and [axIFormCreate](#)

Example

```
axIMeterCreate("SigNoise Design Audit", "", t)
total = <total nets>
done = 0
while(<still next net> && (!axIMeterIsCancelled()))
    < do work >
    axIMeterUpdate( (100 * ++done)/total
        sprintf(nil "Check %d of %d nets" done total))
)
axIMeterDestroy()
```

axIMeterDestroy

`axIMeterDestroy() -> t/nil`

Description

Closes the progress meter form and shuts off Cancel mode if enabled.

Arguments

None

Value Returned

`t` If meter was destroyed; otherwise `nil`.

See Also

[axIMeterCreate](#)

axlMeterIsCancelled

```
axlMeterIsCancelled(  
    ) -> t/nil
```

Description

If cancel was enabled at meter creation, the status of cancel is returned (`t` if cancelled; otherwise `nil`).

If a field named *Cancel* was hit, it is cancelled

Arguments

None

Value Returned

<code>t</code>	If meter was cancelled; otherwise <code>nil</code> .
----------------	--

See Also

[axlMeterCreate](#)

axIMeterUpdate

```
axIMeterUpdate(  
    x_percentDone  
    t_infoString  
    [t_infoStr2]  
) -> t/nil
```

Description

Updates progress meter bar and/or info text. The percent done and/or the info string may be updated.

Arguments

<i>x_percentDone</i>	Integer task percent done (0-100)
<i>t_infoString</i>	Update text for progress meter info text line. Value is one of: nil - leave info text as it is. "" - clear info string field.
<i>newText</i>	Update field with new text.
<i>t_infoStr2</i>	(optional) Text for second line.

Value Returned

<i>t</i>	On success; otherwise nil.
----------	----------------------------

See Also

[axIMeterCreate](#)

axlUIMenuLoad

```
axlUIMenuLoad (
    t_menufile
)⇒ t_previousMenuName/nil
```

Description

Loads the main window menu from the file *t_menuFile*. Adds a default menu file name extension if *t_menuFile* has none. The `MENUPATH` environment variable is used to locate the file if *t_menuFile* does not include the entire path from the root drive.

Note: The intent of this procedure is to allow a custom menu to be loaded for debugging purposes.

Arguments

<i>t_menuFile</i>	Name of the file to which the menu is dumped. If <i>t_menuFile</i> is <code>nil</code> , the file name is based on the program's default menu name, which may vary based on the current state of the program.
-------------------	---

Value Returned

<i>t_previousMenuName</i>	Name of the previous menu.
<code>nil</code>	Menu not be located.

See Also

[axlUIMenuFind](#)

axlUIPopupMenu

```
axlUIPopupMenu (
  t_MenuFile
) => t_previousMenuName/nil
```

Description

Dumps the main window's current menu to the file *t_menuFile*. Adds default menu file name extension if *t_menuFile* has none.

Notes:

- There is no user interaction when an existing file is overwritten.
- This function is for the Windows-based GUI only.

Arguments

<i>t_menuFile</i>	Name of the file to which the menu is dumped. If <i>t_menuFile</i> is <i>nil</i> , the file name is based on the program's default menu name, which may vary based on the current state of the program.
-------------------	---

Value Returned

<i>t_previousMenuName</i>	Full name of the file that is written.
---------------------------	--

<i>nil</i>	No file is written.
------------	---------------------

axlUIColorDialog

```
axlUIColorDialog(  
    r_window/nil  
    l_rgb  
) -> l_rgb/nil
```

Description

Invokes standard color selection dialog box. You must provide a parent window, Allegro PCB Editor defaults to the main window of the application. The *l_rgb* is a red, green, or blue palette list. Each item is an integer between the values of 0 and 255. 0 indicates color is off, and a value of 255 indicates color is completely on. For example, 255 255 255 indicates white.

Arguments

<i>r_window</i>	Parent window. If <i>nil</i> , use main program window. Return handle of axlFormCreate is of type <i>r_window</i> .
<i>l_rgb</i>	Seeded red, green, or blue.

Value Returned

<i>l_rgb</i>	User selected values.
<i>nil</i>	User canceled dialog box.

See Also

[axlColorSet](#), [axlColorGet](#)

Examples

Get color 1 and change it:

```
rgb = axlColorGet(1)  
rgb = axlUIColorDialog(nil rgb)  
when(rgb  
    axlColorSet(1 rgb)  
    axlVisibleUpdate(t))
```

axlUIConfirm

```
axlUIConfirm(  
    t_message  
    [s_level]  
)  
==> t
```

Description

Displays the string *t_message* in a confirm window.

The user must respond before any further interaction with Allegro PCB Editor. Useful mainly for informing the user about a severe fatal error before exiting your program. Use this blocker function very rarely.

Note: If environment variable `noconfirm` is set, we immediately return.

Arguments

<i>t_message</i>	Message string.
<i>s_level</i>	Option level symbol; default is info level, other levels are warn and error.

Value Returned

<i>t</i>	Always returns <i>t</i> .
----------	---------------------------

Example

Inform user when a significant transition is being made:

```
axlUIConfirm( "Returning to Allegro. Please confirm." )
```

Alert user to an error:

```
axlUIConfirm( "Selected object has FIXED property." 'error' )
```

See also

[axlUIPrompt](#), [axlUIYesNo](#), [axlUIYesNoCancel](#), [axlUIConfirmEx](#)

axlUIConfirmEx

```
axlUIConfirmEx(  
    t_message  
    t_key/nil  
    [s_level]  
)  
==> t
```

Description

Displays the string `t_message` in a confirmator window with an optional check box to never show the box again.

Functions same as `axlUIConfirm` except allows a check box to never show confirmator again. System remembers this selection so if user has indicated they do not want the box the call immediately returns.

Requires a unique `t_key` string which is used to remember the selection.

The optional `s_level` argument changes the info displayed to the user.

On program start/exit writes a file to `<HOME>/pcbenv/remember_<program>.txt`

Arguments

<code>t_message</code>	Message string.
<code>t_key</code>	Unique key to remember user selection. If value of this parameter is nil, the command works like <u>axlUIConfirm</u> .
<code>s_level</code>	Option level symbol; default is <code>info</code> level, other levels are ' <code>warn</code> ' and ' <code>error</code> '.

Value Returned

`t`: Always returns `t`

See Also

[axlUIConfirm](#)

Examples

Inform user when a significant transition is being made:

```
axlUIConfirmEx( "Use this command at your own risk." "mynewcommand")
```

axlUIControl

```
axlUIControl(
    s_name
    [g_value]
)
==> g_currentValue/ls_names
```

Description

Inquire about graphics canvas. Inquires and sets the value of graphics. If setting a value, the return is the old value of the control.

A side effect of most of these controls is if a form is active that is displaying the current setting it may not be updated. Additional side effects of individual controls are listed. Items will be added over time. Items currently supported:

Name: screen
Value: (x_width x_height)
Set?: No
Description: Retrieves the screen's width and height in pixels
Equiv: none
Side Effects: none

Name: vscreen
Value: (x_width x_height)
Set?: No
Description: Retrieves the screen's virtual width and height in pixels. This will not be the same as 'screen' if running Windows XP and enabled monitor spanning option. Also requires multiple monitors and graphic card(s) capable of supporting multiple monitors.
Equiv: none
Side Effects: On UNIX always returns the same size as screen.

Name: monitors
Value: x_number
Set?: No
Description: Retrieves the number of monitors available.
Equiv: none
Side Effects: On UNIX always returns 1 since we currently do not support multi-monitors on UNIX.

Name: pixel2UserUnits
Value: f_number
Set?: No
Description: Returns number user units per pixel taking into account the current canvas size and zoom factor. Changes with the current zoom factor.
Equiv: none
Side Effects: none

Arguments

s_name Symbol name of control. `nil` returns all possible names.

s_value Optional symbol value to set. Usually a `t` or a `nil`.

Value Returned

ls_names If name is `nil` then returns a list of all controls.

See above

See Also

[axIOSControl](#)

Examples:

Get screen size:

```
size = axlUIControl('screen)
-> (1280 1024)
```

Get pixel to user units:

```
axlUIControl('pixel2UserUnits)
-> 17.2
```

axlUIPopupMenuChange

```
axlUIPopupMenuChange (
  x_menuId
  s_option
  g_mode
  ... <pairs of s_option/g_mode>
) -> t/nil
```

Description

This changes one or more parameters of an existing menu item.

Unlike other menu commands this function can be safely done outside of the menu trigger callback if the menu command is associated with your Skill code.

Changes allowed are a variable set of new value pairs:

Table 10-2

	s_option	g_mode
Enable/Disable menu	'enable	t/nil
Set/Unset Check mark	'check	t/nil
Change display text	'display	<new text display>
Change command text	'command	<new command string>

You should not attempt to change any separator menu items. Also do not attempt to assign command text to a submenu.

Note: See discussion in [axlUIPopupMenuFind](#) about menu changes.

Arguments

x_menuId The menuld from [axlUIPopupMenuFind](#)

s_option/g_mode pairs See [Table 10-2](#) on page 518

Value Returned

t, if menu item is changed, and nil if the command failed to change the menu item.

See Also

[axlUIMenuFind](#)

Examples

- Set menu to be disabled

```
q = axlUIMenuFind( nil "add rect")
axlUIMenuChange(q 'enable nil)
```

- Enable and set check mark from previous example

```
axlUIMenuChange(q 'enable t 'check t)
```

axlUIMenuDebug

```
axlUIMenuDebug(  
    [g_option]  
) => ll_menu/t/nil
```

Description

A debug function for axl Menu Trigger. This helps debug issues with [axlUIMenuRegister](#).

Arguments

g_option	data to query/clear 'clear = clear the list of menus to load 'list = return list of menus to be loaded (nil no menus) 'trigger = clear the menu trigger callback and menus loaded
----------	--

Value Returned

t, call succeeded

nil, failed or if clear no menus present

ll_menu, current list of menus queued

See Also

[axlUIMenuRegister](#)

axIUIMenuDelete

```
axlUIMenuDelete( x_menuId ) t/nil
```

Description

This deletes a single menu item or submenu based upon what is the current find menu item.

Note: See discussion in [axlUIMenuFind](#) about menu changes.

Arguments

`x_menuId` the menuId from `axlUIMenuFind`

Value Returned

`t`, if menu item is deleted else `nil` if failed to delete menu item

See Also

axlUIMenuFind

Example

- Delete add rect command menu (add rect command is still available from command line)

```
q = axlUIMenuFind( nil "add rect")  
axlUIMenuDelete(q)
```

- Delete entire edit menu (assumes 2 menu item in menu bar)

```
q = axlUIPopupMenuFind( nil 1)  
axlUIPopupMenuDelete(q)
```

axlUIMenuFind

```
axlUIMenuFind(  
    x_menuId/nil  
    t_cmdName/x_location  
    [g_menuOption]  
) ==> x_menuId/nil
```

Description

Finds a menu item by location or a command. The location (`x_location`) is 0 based. The 0 location is the left or top most menu item. (Typically, this is the *File* menu item on the menu bar). A negative number may be used to specify a menu counting from the right side with a -1 indicating the menu furthest to the left or bottom.

Two modes are possible:


1. Find by name, finds menu item by command name.

This method cannot find menu bar items such as *File*. When finding by name you should pass `nil` as the first argument.

2. Find by `x_location`, identifies a menu item off the menu bar (`menuId = nil`) or submenu.

Menu searching is controlled via a menu stack. The first argument, `x_menuId`, controls the stack. For most operations, you should pass a `nil` to this argument. Typically, searching via the menu stack would use `x_location` as the second argument since the `t_cmdName` method is sufficient to find commands multi-levels deep in the menu hierarchy. If you have a nested search active then passing a `nil` will reset the stack. The stack is also popped if you provide a `menuId` older than the last id.

The `g_menuOption` when used in location mode returns the top or bottom of the indexed sub-menu (see below).



Tip

Examples shown below provide typical uses.



CAUTIONS (release to release portability)

- While not frequent, command names may change from release to release.
- Certain products or product tiers may not have a command.

Allegro SKILL Reference

User Interface Functions

- Menus may be reorganized so expecting to find a command on a particular submenu may not return the expected result in a new release.
- As always, adding Allegro commands or scripts to menus may require updates in a new release.
- See introduction of this section on menu recommendations.

Arguments

x_menuId	menuId return of previous call or nil to search from menu root.
x_location	Find item by location. Location is 0 based. Therefore, the "File" menu is location 0. Negative numbers may be used where -1 is the right-most (or bottom-most) menu item.
t_cmdName	Find item by command name. This may not be just a command but is really a command line. For example, if the command is registered as " <i>echo hello</i> " then you must find by " <i>echo hello</i> " and not "echo".
g_menuOption	Permitted values are top or bottom. If used with find by command returns the top or bottom of the menu where the command exists. Bottom option also indicates to axlUIMenuInsert to that a new menu item should be appended to end of the menu. If used with find by location and the item is a submenu returns the top or bottom of that submenu.

Value Returned

If successful returns a menu number else failure is indicated by a nil.

See Also

[axlUIMenuInsert](#), [axlUIMenuChange](#), [axlUIMenuDelete](#), [axlUIMenuDump](#), [axlUIMenuLoad](#), [axlUIMenuRegister](#), [axlTriggerSet](#)

Example

- To add to end of "Add" menu either of the following are equivalent (assumes add line exists on 3rd item of menu bar):

```
l = axlUIMenuFind(nil 3 'bottom)  
l = axlUIMenuFind(nil "add line" 'bottom)
```

- Find Help menu, useful for adding a new sub-menu before the help menu

```
l = axlUIMenuFind(nil -1 nil)
```

- Find Top of Help menu, useful for adding new help menu items.

```
l = axlUIMenuFind(nil -1 'top)
```

- Find file menu

```
l = axlUIMenuFind(nil 0 nil)
```

- Find bottom of File – Import Menu

```
l = axlUIMenuFind(nil "load plot" 'bottom)
```

axlUIMenuInsert

- Command to add menu item

```
axlUIMenuInsert(  
    x_menuId  
    t_display  
    t_command  
) -> t/nil
```

- Command to add Separator

```
axlUIMenuInsert(  
    x_menuId  
    'separator  
) -> t/nil
```

- Command to add Sub-menu

```
axlUIMenuInsert(  
    x_menuId  
    'popup  
    t_display  
) -> x_subMenuItemId/nil
```

- Command to add Sub-menu end (optional)

```
axlUIMenuInsert(  
    x_menuId  
    'end  
) -> t/nil
```

- Command to add multiple items

```
axlUIMenuInsert(  
    x_menuId  
    ll_items  
) -> t/nil
```

Description

Inserts menu items to an existing menu. Several modes are supported:

1. Add a new menu item which dispatches a command when selected by user.
 - a. Add a new visual separator to menu.
2. Add a new sub-menu item. Assumption is that it will be populated by additional menu insert calls.

- a. End a sub-menu. This is optional, see menu stack discussion below.

3. Add multiple menu items.

This is implemented using a menu stack. [axlUIMenuFind](#) resets the stack and each submenu created increments the stack. The 'end mode (submenu) decrements the stack. The menu stack allows the building of a menu tree with very little coding overhead. The stack depth is restricted to 8.



Menu items should not be created outside a menu trigger. See discussion in [axlUIMenuFind](#). For development purposes you can create menu items outside of the menu trigger.

Arguments

x_menuId	menu id which can be obtained from axlUIMenuFind or creating a submenu via this API. If nil uses the current menu on the menu stack
t_display	text that is shown in the menu. Possible values are: <code>separator</code> - add a separator (horizontal line) <code>popup</code> - create a new submenu
t_command	command to run <ul style="list-style-type: none">■ this is ignored for a 'separator'■ this is the display string for 'popup' option 'end'■ pops the menu stack if creating a menu tree
ll_items	This is a list of t_display/t_command value pairs that instruct this interface to add multiple menu items and submenus in a single call. Both the ' <code>separator</code> ' and ' <code>end</code> ' options do not have to be a list.

Value Returned

t - successful

nil - failed

x_menuId - if creating a new submenu, the nesting id of new submenu

See Also

[axlUIMenuFind](#)

Example

- Add a separator before the add rect command

```
q = axlUIMenuFind( nil "add rect")
z = axlUIMenuInsert(q 'separator )
```

- Add a web link at the top of the help menu

```
q = axlUIMenuFind( nil -1 'top)
z = axlUIMenuInsert(q "Google" "http http://google.com" )
```

- Add a new submenu to the right of the help menu with two commands

```
q = axlUIMenuFind( nil -1)
; the nil is intention in here since it demonstrates
; the use of the current menu from find.
z = axlUIMenuInsert(q 'popup "MyMenu")
; the nil is required for the next 2 calls since we want to
; insert these items into MyMenu
z = axlUIMenuInsert(z "1" "echo hello 1" )
z = axlUIMenuInsert(z "2" "echo hello 2" )
```

- More nested menu

See <cdsroot>/share pcb/examples/skill/ui/menu.il

axlUIMenuRegister

```
axlUIMenuRegister(  
    t_command/x_location  
    ll_menu  
    [g_menuOption]  
) => t/nil
```

Description

This allows you to register menu items to be loaded when Allegro loads a new menu. It is a combination of [axlUIMenuFind](#) and [axlUIMenuInsert](#).

If more elaborate menu configuration is required consider calling [axlTriggerSet](#) directly.



Tip
Use [axllsSymbolEditor](#) function if you need to filter commands based upon symbol versus design editors.



- See [axlUIMenuFind](#) for cautions about portability across releases.
- When multiple menu registers are done, there may be dependencies.
For example, if the first menu register adds a new submenu before the File menu the result will be not as expected if the second attempts to add a new item to the Edit menu via the location method.
- This API must never be called from within a [axlTriggerSet](#) callback function.

Arguments

t_command	Command to insert menu before (see axlUIMenuFind)
x_location	Location before to insert menu (see axlUIMenuFind)
ll_menu	List of menu items to load (see format 3 option of axlUIMenuInsert)
g_menuOption	Indication to add to top or bottom of menu (see axlUIMenuFind)

Value Returned

`t`, if register function for indicated callback, `nil`, if the command failed to register trigger

See Also

[axlUIMenuFind](#), [axlUIMenuInsert](#), [axlTriggerSet](#), [axlUIMenuDebug](#), [axlIsSymbolEditor](#)

Example

See `<cdsroot>/share pcb/examples/skill/ui/menu.il`

axlUIPrompt

```
axlUIPrompt(  
    t_message  
    [t_default]/'password  
)  
==> t_response/nil
```

Description

Displays the string *t_message* in a form. The user must type a response into the field. Displays the argument *t_default* in brackets to the left of the field. The user presses the *Return* key or clicks the *OK* button in the window to accept the value of *t_default* as the function return value. If the user selects the *Cancel* button, the function returns *nil*.

This function is a blocker. The user must respond before any further interaction with Allegro PCB Editor.

Arguments

<i>t_message</i>	Message string displayed.
<i>t_default</i>	Default value displayed to the user and returned if user presses only the <i>Return</i> key or clicks <i>OK</i> .
'password:	Obscure and do not script user input.

Value Returned

<i>t_response</i>	User response or default value.
<i>nil</i>	User selected <i>Cancel</i> .

Example

```
axlUIPrompt( "Enter module name" "demo" )
⇒ "mymcm"
```

Prompts for a module name with a default `demo`. Typing `mymcm` overrides the default.

A text field displays, with the default value “`demo`”. To accept the default value, you may either press *Return* or select *OK*. Otherwise, type a new value in the text field and press *Return* or click *OK*. In this example, enter “`mymcm`” in the text field and click *Return*.

`axlprompt` returns the following:

```
==> "mymcm"
```

Password prompt:

```
ret = axlUIPrompt( "Enter password" 'password' )
```

See also

[axlUIConfirm](#)

axlUIWCloseAll

```
axlUIWCloseAll(  
)  
==> t / nil
```

Description

This closes all temporary windows (dialogs and text view windows). A temporary window is a dialog that closes if you open another design (e.g. brd). Via Skill this window attribute is set by the axlUIWPerm API. The constraint manager is currently considered a permanent window but this may change in future releases. A blocking window (e.g. File Browser dialogs) cannot be closed via this call.

Arguments

None

Value Returned

<i>t</i>	always
----------	--------

See Also

[axlUIWPerm](#)

axlUIWMove

```
axlUIWMove(  
    r_window/nil  
    l_xy  
)  
-> t/nil
```

Description

Moves a window. New location (*l_xy*) which is upper left corner, is specified in pixels.

Arguments

<i>r_window</i>	Window id or if nil the main window.
<i>l_xy</i>	(<i>x_X</i> <i>x_Y</i>)

Value Returned

<i>t</i>	window moved
<i>nil</i>	Error, handle is not a window

See Also

[axlUIWSize](#)

Example

Move main window to upper left corner of the display.

```
axlUIWMove(nil 0;0)
```

axlUIWSize

```
axlUIWSize(  
    r_window/nil  
)  
-> ll_rect
```

Description

Returns outer size of a window. Size is in pixels. x and y coordinates are upper left corner of window.

On UNIX/Linux, the `y` value will typically include an offset due to title bar height.

Arguments

`r_window` Window id or if `nil` the main window.

Value Returned

`ll_rect` (`(x_X x_Y) (x_Width x_Height)`)

`nil` Error, handle is not a window

See Also

[axlUIWMove](#)

axlIsViewFileType

```
axlIsViewFileType(  
    g_userType  
)  
⇒ t/nil
```

Description

Tests whether *g_userType* is a long message window type.

Arguments

g_userType Argument to test.

Value Returned

t *g_userType* is of type *r_windowMsg*.

nil *g_userType* is not of type *r_windowMsg*.

Example

```
logWindow =  
    axlUIViewFileCreate("batch_drc.log" "Batch DRC Log" t)  
    axlIsViewFileType(logWindow)  
⇒ t
```

- Creates a window using `axlUIViewFileCreate` (See [axlUIViewFileCreate](#) on page 536.)
- Tests whether the window is a view file type.
- Returns t.

See Also

[axlUIViewFileCreate](#)

axlUIViewFileCreate

```
axlUIViewFileCreate(
  t_file
  t_title
  g_deleteFile
  [lx_size]
  [lt_placement]
  [g_formToExpose]
)
⇒ r_windowMsg/nil
```

Description

Opens a file view window to display a file (*t_file*), it is an error for file not to exist. Window should be given a title (*t_title*).

If *g_deleteFile* is set to *t*, the file is deleted when view window is quit or reused. It is suggested that applications not delete view files themselves as the Save and Print buttons will not work.

Size of viewable window is controlled by *lx_size*. Default size is 24x80. Unpredictable results may occur for large row/column values.

Placement of window is handled by *lt_placement* list. If this value is *nil*, the window is centered on editor.

Window may be deleted via program control via [axlUIWClose](#) function.

Arguments

t_file Name of the ASCII file to display. If the value is "" then last registered log file is displayed.

t_title Title to be display in window title bar.

g_deleteFile Deletes the file when the user quits the window or another task reuses the window.

lx_size Initial size of the window in character rows and columns. The default is 24 by 80. Setting a large window size may cause unpredictable results.

Allegro SKILL Reference

User Interface Functions

<i>lt_placement</i>	Window placement hints. See the section on Window Placement .
<i>g_formToExpose</i>	Optional handle of another window. If specified then this window is brought to the top of the desktop when the view file window is closed. If not specified then the main program window is the parent.

Value Returned

r_windowMsg Window *r_windowMsg*.

nil *r_windowMsg* not displayed.

Example

- Displays the batch DRC log file, saving the window id.
- Deletes the file `drc.log` when the user exits the window.

```
logWindow = axlUIViewFileCreate("batch_drc.log" "Batch DRC Log" nil)
```

The log file displays in a window. When the user chooses *Close*, deletes the file `batch_drc.log`.

axlUIViewFileReuse

```
axlUIViewFileReuse (
  r_windowMsg
  t_file
  t_title
  g_deleteFile
  [g_formToExpose]
)
⇒ t/nil
```

Description

Reuses the view window to display a file (*t_file*). Error is thrown if the file does not exist. Window is given a title (*t_title*).

Expects *r_windowMsg* to be type of view window. If user quit the window it will re-open it at the old size/position.

File is deleted is *g_deleteFile* is *t* when view window is quit or reused. It is suggested that applications not delete view files themselves as the Save and Print buttons will not work.

Arguments

<i>r_windowMsg</i>	<i>dbid</i> of the existing view window created earlier with <i>axlUIViewFileCreate</i> .
<i>t_file</i>	Name of the ASCII file to display.
<i>t_title</i>	Title to display in window title bar.
<i>g_deleteFile</i>	Deletes file when the user quits the window or another task reuses the window.
<i>g_formToExpose</i>	Optional argument that defines the handle of a window to be exposed when the text file window is closed. Default is the parent set by <i>axlUIViewFileCreate</i> . Normally you should not use this argument.

Value Returned

<i>t</i>	File displayed.
----------	-----------------

nil File not displayed.

Example

```
(axlUIViewFileReuse logWindow "ncdrill.log" "NC Drill Log" nil)
```

- Displays the file `ncdrill.log`, reusing the window `logWindow` created when displaying `batch_drc.log` in the `axlUIViewFileCreate` example.
- Exiting the window automatically deletes the file `ncdrill.log`.

axlUIYesNo

```
axlUIYesNo (  
    t_message  
    [t_title]  
    [s_default]  
)  
==> t/nil
```

Description

Provides a dialog box displaying the message *t_message*. Returns *t* if you choose Yes and *nil* for No.

This function is a blocker. You must respond before any further interaction with Allegro PCB Editor.

Note:

- If environment variable `noconfirm` is set, we immediately return *t* for yes and *nil* for no.

Arguments

t_message Message string to display.

Value Returned

t User responded Yes.

nil User responded No.

See Also

[axlUIConfirm](#)

Examples

The following examples are a typical overwrite question.

Allegro SKILL Reference

User Interface Functions

```
axlUIYesNo( "Overwrite module?" )

axlUIYesNo( "Overwrite module?" nil 'no )

axlUIYesNo( "Overwrite module?" "My Skill Program" )
```

A confirmer window is displayed. If the user selects Yes, the function returns t, otherwise it returns nil.

**/

```
list
axlUIYesNo(int argc, list *argv)
{
    char *str, *title;
    int dflt;

    str = axluGetString(NULL, argv[0]);
    title = (argc>1) ? axluGetString(NULL, argv[1]) : NULL;
    dflt = (argc>2) ? DfltrResponse(argv[2]) : MN_YES;

    return(MNYesNoWTTitle(str, title, dflt) ? ilcT : ilcNil);
}

/*
#endif DOC_C
```

axlUIWExpose

```
axlUIWExpose(  
    r_window/nil  
)  
⇒t/nil
```

Description

Opens and redisplays a hidden or iconified window, bringing it to the front of all other current windows on the display. If `nil`, the main window is displayed.

Arguments

`r_window` Window *dbid*.

Value Returned

`t` Window opened and brought to front.

`nil` *dbid* was not of a window.

Example

```
logWindow =  
    axlUIViewFileCreate("batch_drc.log" "Batch DRC Log" t)  
; Other interactive code, possibly  
; causing Batch DRC Log window to be covered  
; Uncover the log window:  
axlUIWExpose(logWindow)  
⇒t
```

- Displays a window using `axlUIViewFileCreate`.
- Interactively moves window behind one or more other windows using the *back* selection of your window manager.
- Calls `axlUIWExpose`.

Window comes to the top above all other windows.

axlUIWClose

```
axlUIWClose(  
    r_window  
)  
⇒ t/nil
```

Description

Closes window *r_window*, if it is open.

Arguments

r_window Window *dbid*.

Value Returned

t Window closed.

nil Window already closed, or *dbid* is not of a window.

Example

```
logWindow =  
    axlUIViewFileCreate("batch_drc.log" "Batch DRC Log" t)  
; Other interactive code  
;  
axlUIWClose(logWindow)  
⇒t
```

- Displays window using `axlUIViewFileCreate`.
- Closes window using `axlUIWClose`.

axlUIWHelpRegister

- Command to register new help file

```
axlUIWHelpRegister(  
    t_cmd  
    t_helpFile  
) -> t/nil
```

- Query if help file registered for command

```
axlUIWHelpRegister(  
    t_cmd  
) -> t_file
```

- Delete help file registered for command

```
axlUIWHelpRegister(  
    t_cmd  
    ""  
) -> t/nil
```

- Lists all cmds registered for help

```
axlUIWHelpRegister(  
    nil  
) -> lt_cmds
```

Description

This registers a help document for a user written skill command or form (dialog). This is typically used in conjunction with axlCmdRegister. You should make this call at the time you do a axlCmdRegister instead of waiting until the skill code associated with the command executes.

You can also add the registrations via the `help_config.txt` file (see `<cdsroot>/share/pcb/help/help_config.txt`) placed at the site or pcbenv directory.

The document types (determined via file extension) supported on all platforms are:

- .txt - a plain text file displayed via Allegro's internal long message window
- .html - html browser displayed via a web browser
- .pdf - Acrobat file displayed by a Acrobat reader

On Windows other extensions are typically supported which are determined by what programs are installed on the computer (e.g. doc for Word and ppt for PowerPoint).

Arguments

t_cmd Command name or form.<formname> for registering help for form buttons

t_helpFile Document to display. Variable expansion is supported so you can embed Allegro env variables to make the installed location of the files relative to the variable setting.

Value Returned

`t` for success, `nil` for failure (invalid arguments)

See Also

[axlCmdRegister](#)

Examples

Override add line help with contents of Allegro's env file

```
axlCmdRegister("add line" "$TELEENV")
```

axlUIWPrint

```
axlUIWPrint(  
    r_window/nil  
    t_formatString  
    [g_arg1 ...]  
)  
⇒ t/nil
```

Description

Prints a message to a window other than the main window. If *r_window* does not have a message line, the message goes to the main window. This function does not buffer messages, but displays them immediately. If the message string does not start with a message class (for example `le`), it is treated as a text (`lt`) message. (See [axlMsgPut](#) on page 748) If *nil*, displays the main window.

Arguments

<i>r_window</i>	Window <i>dbid</i> .
<i>t_formatString</i>	Context message (<code>printf</code> -like) format string.
<i>g_arg1...</i>	Any number of substitution arguments to be printed using <i>t_formatString</i> . Use as you would a C-language <code>printf</code> statement.

Value Returned

<i>t</i>	Message printed to window.
<i>nil</i>	<i>dbid</i> is not of a window.

Example

```
axlUIWPrint(nil "Please enter a value:")  
Please enter a value:  
⇒t
```

Prints a message in the main window.

axlUIWRedraw

```
axlUIWRedraw(  
    r_window/nil  
)  
⇒ t/nil
```

Description

Redraws the indicated window. If the window *dbid* is *nil*, redraws the main window.

Arguments

r_window Window *dbid* or, if *nil*, the main window.

Value Returned

t Window is redrawn.

nil *dbid* is not of a window.

axlUIWBlock

```
axlUIWBlock(  
    r_window  
)  
⇒ t/nil
```

Description



Caution

This function is not compatible with the g_nonBlock = nil option to axlFormCreate. If using this function with axlFormCreate you must set a callback on the g_formAction.

This places a block on the indicated window until it is destroyed. All other windows are disabled. It may be called recursively, unlike the block option in `axlFormCreate`.

Once you enter a blocking mode you should not bring up a window that is non-blocking. This behavior is not defined and is not supported.

If you block, you should set the block attribute `block` in the Window Placement list `lt_placement` so that the title bar shows it is a blocking window.

If you have a window callback registered you must allow the window to close since the unblock facility unblocks other windows upon close so that the correct window will get the focus after the blocked window is destroyed.

Note: You should set the block symbol option using the `lt_placement` option in the function that creates the window to visually indicate that the window is in blocking mode.

Arguments

`r_window` Window *dbid*.

Value Returned

`t` Success

`nil` Failure (For example, the window is closed or the *dbid* is not of a window).

axlUIEditFile

```
axlUIEditFile(  
    t_filename  
    t_title/nil  
    g_block  
)  
⇒ r_window/t/nil
```

Description

Allows the user to edit a file in an OS independent manner (works under both UNIX and Windows.)

User may override the default editor by setting either the `VISUAL` or `EDITOR` environment variables.

Windows notes

- The default editor is *Notepad*.
- The title bar setting is not supported.

Unix notes

- The default editor is `vi`.
- An additional environment variable, `WINDOW_EDITOR`, allows the user to specify an X-based editor such as `xedit`. The title bar is not supported in this mode.

Note: In blocking mode, the windows of the main program do not repaint until the file editor window exits.

Only `axlUIWClose` supports the `r_window` handle returned by this function.

Arguments

`t_filename` Name of file to edit.

`t_title` Title bar name, or `nil` for default title bar.

`g_block` Flag specifying blocking mode (`t`) or non-blocking mode (`nil`).

Allegro SKILL Reference

User Interface Functions

Value Returned in Non-blocking Mode

r_window Success

nil Failure

Value Returned in Blocking Mode

t Success

nil Failure

axlUIMultipleChoice

```
axlUIMultipleChoice(  
    t_question  
    lt_answers  
    [t_title]  
)  
⇒ x_answer/nil
```

Description

Displays a dialog box containing a question with a set of two or more answers in a list. You must choose one of the answers to continue. Returns the chosen answer.

Arguments

<i>t_question</i>	Text of the question for display.
<i>lt_answers</i>	A list of text strings that represent the possible answers.
<i>t_title</i>	Optional title. If not present, a generic title is provided.

Value Returned

<i>x_answer</i>	An integer number indicating the answer chosen. This value is zero-based, that is, a zero represents the first answer, a one the second answer, and so on.
<i>nil</i>	An error is detected.

Example

```
ret = axlUIMultipleChoice("Pick a choice"  
    '("Pick me" "No Pick me" "I'm here!") "Cmd title")
```

axlUIViewFileScrollTo

```
axlUIViewFileScrollTo(  
    r_windowMsg  
    x_line/nil  
)  
⇒ x_lines/nil
```

Description

Scrolls to a specified line in the file viewer. A value of -1 goes to the end of the viewer.

Note: The number of the line in the view window may not match the number of lines in the file due to line wrapping in the viewer.

Arguments

<i>r_windowMsg</i>	Existing view window.
<i>x_line</i>	Line to scroll: 0 is top of the file, -1 is bottom of the file, -2 returns the number of lines in the viewer.

Value Returned

<i>x_lines</i>	Number of lines in the view window.
<i>nil</i>	No view file window.

Example

```
pm = axlUIViewFileCreate("topology.log" "Topology" nil)  
axlUIViewFileScrollTo(pm -1)
```

- Displays the file topology.log
- Scrolls to the end of the file

axlUIWBeep

```
axlUIWBeep(  
)  
⇒ t
```

Description

Sends an alert to the user, usually a beep.

Arguments

None

Value Returned

None

Example

```
axlUIWBeep()
```

axlUIWDisableQuit

```
axlUIDisableQuit(  
    o_window  
)  
⇒ t/nil
```

Description

Disables the system menu *Quit* option so the user cannot choose it to close the window.

Arguments

o_window Window handle.

Value Returned

t Window handle is valid.

nil Window handle is invalid.

axlUIWExposeByName

```
axlUIWExposeByName(  
    t_windowName  
)  
⇒ t/nil
```

Description

Finds a window by name and exposes it (raises it to the top of the window stack and restores it to a window state if it is an icon).

You can use the `setwindow` command argument to get Allegro PCB Editor window names via scripting. If the window is a form, you get the name by removing the `form.` prefix from its name.

Note: Names of windows may change from release to release.

To raise an item in the control panel, (for example, *Options*,) use the `axlControlRaise()` function.

Arguments

`t_windowName` Window name.

Value Returned

`t` Window is found.

`nil` Window is not found.

axlUIWPerm

```
axlUIWPerm(  
    r_window  
    [t/nil]  
)  
⇒ t/nil
```

Description

Normally forms and other windows close automatically when another database opens. This function allows that default behavior to be overridden.

Notes:

- When you use this function, consider that windows automatically close when a new database opens because the data the windows display may no longer apply to the new database.
- If you do not provide a second argument, returns the current state of the window.

Arguments

<i>r_window</i>	Window id.
<i>t/nil</i>	<i>t</i> - set permanent <i>nil</i> - reset permanent.

Value Returned

<i>t</i>	Window exists.
<i>nil</i>	Window does not exist.

Example 1

```
handle = axlFormCreate('testForm "axlform" nil 'testFormCb, t nil)
axlUIWPerm(handle t)
```

Opens a test form and makes it permanent.

Example 2

```
ret = axlUIWPerm(handle)
```

Tests whether the window is permanent.

axIUIWSetHelpTag

```
axIUIWSetHelpTag(  
    r_window  
    t_tag  
)  
⇒ t/nil
```

Description

This has been mostly replaced by [axIUIWHelpRegister](#) that works for commands and forms.

Attaches the given help tag to a pre-existing dialog with a port. This function supports subclassing of the help tags, that is, if a help tag is already associated with the dialog, it will not be replaced. This functions adds the new help tag. Adding a new help tag to a pre-existing one is done by concatenating the two with a dot.

For example:

Pre-existing Help Tag:	myOldTag
New Help Tag:	myNewTag
Resulting Help Tag:	myOldTag.myNewTag

Arguments

<i>r_window</i>	Window id.
<i>t_tag</i>	Subclass of the help string.

Value Returned

<i>t</i>	Help tag attached.
<i>nil</i>	Invalid arguments.

See Also

[axIUIWHelpRegister](#)

axlUIWSetParent

```
axlUIWSetParent(  
    o_childWindow  
    o_parentWindow/nil  
)  
⇒ t/nil
```

Description

Sets the parent of a window. When a window is created, its parent is the main window of the application, which is sufficient for most implementations. To run blocking mode on a form launched from another form, set the child form's parent window to be the launched form.

Setting the parent provides these benefits:

- Allows blocking mode to behave correctly.
- If the parent is closed, then the child is also closed.
- If the parent is iconified, then the child is hidden.
- The child stays on top of its parent in the window stacking order.

Arguments

o_childWindow Child window handle.

o_parentWindow Parent window (if *nil*, then the main window of the application which is normally the default parent.)

Note: A parent and child cannot be the same window.

Value Returned

t Parent is successfully set.

nil Could not set the parent due to an illegal window handle.

axlUIWShow

```
axlUIWShow(  
    r_window/nil  
    s_option  
)  
⇒ t/nil
```

Description

Shows or hides a window depending on the option passed. If the window id passed is `nil`, the function applies to the main window.

Notes:

- Using the `showna` option on a window may make the window active.
- Using the `show` option on a window that is already visible may not make it active.

Arguments

r_window The window id. If `nil`, signifies the main window.

s_option One of the following:

'show	Show and activate the window
'showna	Show but don't activate the window.
'hide	Hide the window.
nil	Show available options.

Value Returned

`t` Window shown or hidden.

`nil` Window id not correct or an invalid option given.

axlUIWTimerAdd

```
axlUIWTimerAdd(  
    o_window  
    x_timeout  
    g_oneshot  
    u_callback  
)  
⇒ o_timerId/nil
```

Description

Adds or removes a callback for an interval timer.

This is not a real-time timer. It is synchronous with the processing of window based messages. The actual callback interval may vary. The timer does not go off (and call you back) unless window events for the timer window (*o_window*) are being processed. You must be waiting in a UI related call (for example, axlEnter*, a blocking axlFormDisplay, axlUIWBlock, etc.)

To receive callbacks return to the main program message processing. Another window in blocking mode, however, can delay your return to the main program.

You may add properties to the returned *timerId* to store your own data for access in your timer callback as shown:

```
procedure( YourSkillProcedure()  
    ; set up a continuous timer using the main window  
    timerId = axlUIWTimerAdd(nil 2000 nil 'YourTimerCallback)  
  
    timerId->yourData = yourdata  
)  
procedure( YourTimerCallback( window timerId elapsedTime)  
    ; your time period has elapsed. do something.  
)
```

Arguments

o_window The window the timer is associated with. If *o_window* is nil, the timer is associated with the main window.

Allegro SKILL Reference

User Interface Functions

x_timeout Timeout in milliseconds before the timer is triggered and calls your callback procedure. Timeout is not precise because it depends on processing window messages.

g_oneshot Controls how many times the timer triggers. Use one of these values:

- t* - Timer goes off once and automatically removes itself.
- nil* - Timer goes off at the set time interval continuously until it is removed by `axlUIWTimerRemove`.

u_callback Procedure called when the timer goes off. Called with these arguments with its return value ignored:

```
u_callback(  
    o_window  
    o_timerId  
    n_elapsedTime  
)
```

o_window Window you provided to `axlUIWTimerAdd`

o_timerId Timer id which returned by `axlUIWTimerAdd`.

x_elapsedTime Approximate elapsed time in milliseconds since the timer was added.

Value Returned

o_timerId The identifier for the timer. Use this to remove the timer. This return value is subject to garbage collection when it goes out of scope. When the garbage is collected, the timer is removed. Don't count on garbage collection to remove the timer, however, because you do not know when garbage collection will start. If you need a timer that lasts forever, assign this to a global variable.

nil No timer added.

axlUIWTimerRemove

```
axlUIWTimerRemoveSet(  
    o_timerId  
)  
⇒ t/nil
```

Description

Removes a timer added by axlUIWTimerAdd.

Arguments

<i>o_timerId</i>	Id returned by axlUIWTimerAdd.
------------------	--------------------------------

Value Returned

t	Timer removed.
---	----------------

nil	Timer id invalid.
-----	-------------------

axlUIWUpdate

```
axlUIWUpdate(  
    r_window/nil  
)  
⇒ t/nil
```

Description

Forces an update of a window. If you made several changes to a window and are not planning on going back to the main loop or doing a SKILL call that requires user interaction, use this call to update a window. You could use this, for example, if you are doing time-consuming processing without returning control to the UI message pump.

Note: This is required for Bristol based code. In other implementations it has no effect.

Arguments

<i>r_window</i>	Window id or <code>nil</code> if the main window.
-----------------	---

Value Returned

<code>t</code>	Window updated.
<code>nil</code>	Window already closed or invalid window id.

axlUIYesNoCancel

```
axlUIYesNoCancel(  
    t_message  
    [t_title]  
    [s_default]  
)  
⇒ x_result
```

Description

Displays a blocking *Yes/No/Cancel* dialog box with the prompt message provided.

Arguments

<i>t_message</i>	Message to display.
<i>t_title</i>	Optional. What to put in the title bar of confirm. The default is the program display name.
<i>s_default</i>	Optional. May be either <code>yes</code> , <code>no</code> or <code>cancel</code> to specify default response. The default is <code>yes</code> .

Value Returned

<i>x_result</i>	Number based on the user's choice: 0 for <i>Yes</i> 1 for <i>No</i> 2 for <i>Cancel</i>
-----------------	--

Examples

axlUIDataBrowse

```
axlUIDataBrowse(  
    s_datatype  
    ls_options  
    t_title  
    g_sorted  
    [t_helpTag]  
    [l_callback]  
    [g_args]  
)  
⇒ lg_return
```

Description

Analyzes all objects requested by the caller function, passing each through the caller's callback function. Then puts the objects in a single-selection list.

This list blocks until a user makes a selection. Once the user selects an object, it is passed back to the caller in a list containing two objects: the selected name and, for a database object, the AXL dbid of the object.

Arguments

<i>s_datatype</i>	One of the following: <ul style="list-style-type: none">'NET'PADSTACK'PACKAGE_SYMBOL'DEVICE'PARTNUMBER'REFDES'BOARD_SYMBOL'FORMAT_SYMBOL'SHAPE_SYMBOL'FLASH_SYMBOL'BRD_TEMPLATE'SYM_TEMPLATE'TECH_FILE
-------------------	---

<i>ls_options</i>	List containing at least one of the following:
-------------------	--

'RETRIEVE_OBJECT	Object selected returns its dbid
------------------	----------------------------------

'RETRIEVE_NAME	Object selected returns its name
----------------	----------------------------------

Allegro SKILL Reference

User Interface Functions

' EXAMINE_DATABASE	Initially look in the database for list of objects
' EXAMINE_LIBRARY	Initially use env PATH variable when looking for list of objects
' DATABASE_FIXED	Read-only check box for the database
' LIBRARY_FIXED	Read-only check box for files (library)
<i>t_title</i>	Prompt for the title of the dialog
<i>g_sorted</i>	Switch indicating whether or not the list should be sorted
<i>t_helpTag</i>	Help tag for the browser
<i>l_callback</i>	Callback filter function which takes the arguments name, object, and <i>g_arg</i> passed in. Returns t or nil based on whether or not the object is eligible for browsing.
<i>g_arg</i>	Generic argument passed through to <i>l_callback</i> as the third argument.

Value Returned

<i>t_name o_dbid</i>	Selection was made and RETRIEVE_OBJECT used.
<i>t_name nil</i>	Selection was made and RETRIEVE_NAME used.

Examples

```
axlUIDataBrowse('NET '(RETRIEVE_NAME) "hi" t)
axlUIDataBrowse('PADSTACK '(RETRIEVE_NAME) "hi" t)
axlUIDataBrowse('PACKAGE_SYMBOL '(EXAMINE_DATABASE EXAMINE_LIBRARY
    RETRIEVE_NAME)"hi" t)
axlUIDataBrowse('PACKAGE_SYMBOL '(EXAMINE_LIBRARY RETRIEVE_OBJECT) "hi" t)
axlUIDataBrowse('PACKAGE_SYMBOL '(EXAMINE_LIBRARY RETRIEVE_NAME) "hi" t)
axlUIDataBrowse('PARTNUMBER '(RETRIEVE_OBJECT) "Part Number" t)
```

Allegro SKILL Reference
User Interface Functions

Form Interface Functions

Overview

This chapter describes the control types and functions you use to create Allegro PCB Editor forms (dialogs) and interact with users through them.

Allegro PCB Editor AXL forms support a variety of field types. See [Callback Procedure: formCallback](#) on page 664 and [Using Forms Specification Language](#) on page 579 for a complete description of field types.

The Skill implementation of the forms package does not support the all functionality present in the core form package; short fields and variable tile forms.

See Also

[axlFormCreate](#) - open a form

[axlFormCallback](#) - callback model for interaction with user

[axlFormBNFDoc](#) - Backus Naur Form, form file syntax, demos

[axlFormTest](#)

Programming


It is best to look at the two form demo.

- basic controls -- `axlform.il/axlform.form`
- grid control - `fgrid.il/fgrid.form`
- multi-select grid control - `fgrid-msel.il/fgrid.form`

The first step is to create form file. Use `axlFormTest` to ensure fields are correctly positioned.

The following procedure is generally used.

1. Open form (axlFormCreate)
2. Initialize fields (axlFormSetField)
3. Display Form (axlFormDisplay)
4. Interactive with user (axlFormCallback)
5. Close Form (axlFormClose)



Tip

- ❑ Many users find that it is easier to distribute their program using a form if they embed the form file in their Skill code. In this case use Skill to open a temporary file and print the statements, open for form, then delete the file.
- ❑ Use axlFormTest("<form file>") to interactively adjust of fields.
- ❑ You can use "ifdef", "ifndef", and Allegro environment variables (axlSetVariable) to control appearance of items in the form file.

Field / Control

Most interaction to the controls are via axlFormSetField, axlFormGetField, axlFormSetFieldEditable, and axlFormSetFieldVisible. Certain controls have additional APIs which are noted in the description for the control.

Most controls support setting their background and foreground colors. See `axlColorDoc` and `axlFormColorize` for more information.

Following is a list of fields and their capabilities.

TABSET / TAB

A property sheet control. Provides the ability to organize and nest many controls on multiple tabs.

Unlike other form controls you nest other form controls within TAB/ENDTAB keywords. The size of the tab is control is specified by the FLOC and FSIZE keywords used as part of the TABSET definition. The single option provided to the TAB keyword serves the dual purpose

of being both the display name and the tab label name. The TABSET has a single option which is the fieldLabel of the TABSET.

The TABSET has a single option – tabsetDispatch.

When a user picks on a TAB, by default, it is dispatched to the application as the with the fieldLabel set to the name of the tab and the fieldValue as a 't'. With this option we use the fieldLabel defined with the TABSET keyword and the fieldValue as the tab name. In most cases you do not need to handle tab changes in your form dispatch code but when you do each dispatch method has its advantages.

Note: TABSETS cannot be nested.

GROUP

A visible box around other controls. As such, you give it a width, height and optional text. If width or height is 0, we draw the appropriate horizontal or vertical line. Normally the group text is static but you can change it at run-time by assigning a label to the group.

TEXT

Static text, defined in the form file with the keyword "TEXT". The optional second field (use double quotes if more than one word) is any text string that should appear in the field. An optional third field can be used to define a label for run-time control. In addition the label INFO can be used to define the field label and text width.

Multi-line text can be specified by using the FSIZE label with a the height greater than 2. If no FSIZE label is present then a one-line text control is assumed where the field width is specified in the INFO label.

OPTIONS include (form file)

any of:

- bold - text is displayed in bold font
- underline - text is displayed with underline
- border - text is displayed with a sunken border
- prettyprint - make text more read-able using upper/lower case

and one of justification:

- left - left justified (default)

center - center text in control

right - right justify text

STRFILLIN

Provides a string entry control. The STRFILLIN keyword takes two required arguments, width of control in characters and string length (which may be a larger or smaller value then the width of the control).

There are three variations of the fillin control.

- single line text
- single line text with a drop-down (use POP keyword).
The drop-down provides the ability to have pre-defined values for the user.
- multi-line text control. Use a FSIZE keyword to indicate field width and height.

INTFILLIN

Similar to a STRFILLIN except input data is checked to be an integer (numbers 0 to 9 and + and -). Use the LONGFILLIN keyword with two arguments; field width and string length.

It only supports variations 1 and 2 of STRFILLIN.

It also supports a minimum and maximum data verification. This can be done via the form file with the MIN and MAX keywords or at run-time via `axlFormSetFieldLimits`.

INTSLidebar

This is a special version of the INTFILLIN, it provides an up/down control to the right of the field that allows the user to change the value using the mouse. You should use MIN/MAX settings to limit the allowed value.

REALFILLIN

Similar to INTFILLIN except supports floating point numbers. Edit checks are done to only allow [0 to 9 .+-]. If addition to min/max support you can also provide number of decimals via the DECIMAL keyword or at run-time via `axlFormSetDecimal`.

MENUBUTTON

Provides a button control. Buttons are stateless. The MENUBUTTON keyword takes two options; width and height.

A button has one option – multiline.

If button text cannot fit on one line wrap it. Otherwise text is centered and restricted to a single line.

A button can have a popup by inserting the "POP" label.

With no popup pressing the button dispatches a value of 1. If it is a button with a popup then the dispatch is the dispatch entry of the popup.

Standards:

- use "..." if button brings up a file browser
- append "..." to text of button if button brings up another window
- use these labels for:
 - close - to Close dialog without
 - done/ok - to store changes and close dialog
 - cancel - to cancel dialog without making any changes
 - help - The is reserved for cdsdoc help
 - print - do not use (will get changed to Help).

CHECKLIST

Provides a check box control (on/off). Two variants are supported:

- a check box
- a radio box

For both types the CHECKLIST control takes an argument for the text that should appear to the right of the checkbox.

A radio box allows you to several checkboxes to be grouped together. The form package insures only one radio box be set. To enable a radio grouping provide a common text string


as a third argument to the CHECKLIST keyword. An idiosyncrasy of a radio box is that you will be dispatched for both the field being unset and also for the field being set.

ENUM (*sometimes called combo box*)

Provides a drop-down to present the user a fixed set of choices. The drop-down can either be pre-defined in the form file via the POPUP keyword or at run-time with axlFormBuildPopup. Even if you choose to define the popup at run-time, you must provide a POPUP placeholder in the form file.

POPUP entries are in the form of display/dispatch pairs. Your setting and dispatching of this field must be via the dispatch item of the popup (you can always make both the same). This technique allows you to isolate what is displayed to the user from what your software uses. The special case of nil as a value to axlFormSetField will blank the control.

Two forms of ENUM field are supported, the default is single line always has the drop-down hidden until the user requests it. In this case only define the ENUMSET with the width parameter. A multi-line version is available where the drop-down is always displayed. To enable the multi-line version specify both the width and height in ENUMSET keyword.



Tip
FILLIN fields also offer ENUM capability, see below.

OPTIONS include (form file)

- prettyprint – make text more read-able using upper/lower case.
- ownerdrawn – provided to support color swatches next.to subclass names. See axlSubclassFormPopup.
- dispatchsame – Normally if user selects same entry that is currently shown it will not dispatch.

LIST

A list box is a control that displays multiple items. If the list box is not large enough to display all the list box items at once, the list box provides the required horizontal or vertical scroll bar.

We support two list box types; single (default) and multi-selection. You define a multi-select box in form file with a "OPTIONS multiselect" List boxes have a width and height specified by the second and third options to the LIST keyword. The first option to the LIST keyword is ignored and should always be an empty string ("").

List box options are:

SORT - alphabetical sort.

ALPHANUMSORT - takes in account trailing numbers so a NET2 appears before a NET10 in the list.

PRETTYPRINT - case is ignored and items are reformatted for readability.

Special APIs for list controls are: `axlFormListOptions`, `axlFormListDeleteAll`, `axlFormListSelect`, `axlFormListGetItem`, `axlFormListAddItem`, `axlFormListDeleteItem`, `axlFormListGetSelCount`, `axlFormListGetSelItems`, `axlFormListSelAll`.

For best performance in loading large lists consider passing a list of items to `axlFormSetField`.

THUMBNAIL

Provides a rectangular area for bitmaps or simple drawings. You must provide a FSIZE keyword to specify the area occupied by the thumbnail.

In bitmap mode, you can provide a bitmap as an argument to the THUMBNAIL keyword or at run time as a file to `axlFormSetField`. In either case, BMPPATH and a .bmp extension is used to locate the bitmap file. The bitmap should be 256 colors or less.

For bitmaps one OPTION is supported:

stretch - draw bitmap to fill space provided. Default is to center bitmap in the thumbnail region.

In the drawing mode you use the APIs provided by `axlGRPDoc` to perform simple graphics drawing.

TREEVIEW

Provides a hierarchical tree selector. See [axlFormTreeViewSet](#).

GRID

This provides a simple spreadsheet like control. See `axlFormGridDoc` for more info.

COLOR

Provides a COLOR swatch. Can be used to indicate status (for example: red, yellow, green). The size of the color swatch is controlled by a width and height option the COLOR keyword.

Add the INFO_ONLY keyword to have a read-only color swatch. Without INFO_ONLY the color swatch provides CHECKBOX like functionality via its up/down appearance.

With COLOR swatches you can use predefine colors or Allegro database colors. See axlColorDoc.

TRACKBAR

Provides a slider bar for setting integer values. The TRACKBAR keyword takes both a width and height and the bar may be either horizontal or vertical.

It is important to set both a minimum and maximum integer value. This can be done from the form file with the MIN and MAX keywords or at run-time by `axlFormSetFieldLimits`.

PROGRESS

Provides a progress bar usually used to indicate status of time consuming operations. For setting options to the progress meter pass of list of 3 items to `axlFormSetField` which are (<step value> <number of steps> <initial position>). A subsequent nil passed to `axlFormSetField` will step the meter by the <step value>.

PROGRESS keyword provides for both a width and height of the bar. Bar should be horizontal.

Allegro SKILL Reference

Form Interface Functions

You get information from the user using forms that support the following modes:

Table 11-1 Form Modes

Form Mode	Description
Blocking with no callback	<p>Easy to program. Limited to user interaction, such as checking that the information entered for each field uses syntax acceptable to the form's package. Your program calls <code>axlUIWBlock</code> after displaying the form. The user can close a form that has the standard <i>OK</i> or <i>Cancel</i> button.</p> <p>After <i>OK</i> or <i>Cancel</i> is selected, <code>axlUIBlock</code> returns allowing you to query field values using <code>axlFormGetField</code>.</p> <p>Note: Use this programming model only with simple forms.</p>
Blocking with callback	<p>Prevents use of Allegro PCB Editor until the user enters information in the dialog. The form callback you provide lets your interactive program accept the data entered.</p>
Callback with no blocking	<p>Works like many native Allegro PCB Editor forms. The user can work with both the form and other parts of Allegro PCB Editor.</p> <p>With Allegro PCB Editor database transactions, the programming is more complex. You can use transactions while the form is open by declaring your command interactive. You end your command when another Allegro PCB Editor command starts by using <code>axlEvent</code>.</p>
Options form	<p>Allegro PCB Editor window to the left of the canvas. The options (ministatus) form is non-blocking and restricted to the Options panel size. See <code>axlMiniStatusLoad</code> for details.</p>

Do not attempt to set the Button field (except *Done*, *Cancel* and *Help*), as it is designed to initiate actions. Consequently, having buttons in a form without a callback function registered renders those buttons useless.

Note: AXL-SKILL does not support the short fields and variable tiles which are part of the Allegro PCB Editor core form package.

You can set background and foreground color on many form fields. For more information, see [axlFormColorize](#) on page 670. For information on color specific to grids, see [Using Grids](#) on page 593.

Examples

These examples, especially the basic one, help you understand how the forms package works:

basic Demonstrates basic form capabilities.

grid Demonstrates grid control capabilities.

wizard Demonstrates use of a form in Wizard mode.

Use the examples located in `<cdsroot>/share/pcb/examples/form` as follows:

1. Copy all the files from one of the directories to your computer.
2. Start Allegro PCB Editor.
3. From the Allegro PCB Editor command line, change to the directory to which you copied the files as shown:

```
cd <directory>
```

4. Load the SKILL file in the directory.

Note: The SKILL file has the .il extension.

```
skill load "<filename>"
```

5. Start the demo by typing on the Allegro PCB Editor command line as shown:


For basic demo:

```
skill formtest
```

For grid demo:

```
skill gridtest
```

6. Examine the SKILL code and form file.



Tip

Setting the Allegro PCB Editor environment variable TELSKILL opens a SKILL interpreter window that is more flexible than the Allegro PCB Editor command area. On UNIX, if you set this variable before starting the tool then the SKILL type-in area is the X terminal you used to start Allegro PCB Editor. See the enved tool to configure the width and height of the window.

Using Forms Specification Language

Backus Naur Form (BNF) is a formal notation used to describe the syntax of a language. Form File Language Description is the BNF grammar for the Forms Specification Language. Forms features in new versions are not backwards compatible.

Allegro SKILL Reference

Form Interface Functions

The following table shows the conventions used in the form file grammar:

Convention	Description
[]	Optional
{ }	May repeat one or more times
< >	Supplied by the user
	Choose one or the other
:	Definition of a token
CAPS	Items in caps are keywords

The BNF format definition follows.

```
BNF:
form:
    FILE_TYPE=FORM_DEFN VERSION=2
    FORM [form_options]
    formtype
    PORT w h
    HEADER "text"
    form_header
    {tile_def}
    ENDFORM

formtype:   FIXED | VARIABLE
            - FIXED forms have one unlabeled TILE stanza
            - VARIABLE forms have one or more label TILE stanzas
            - Skill only supports FIXED form types.

PORT:
        - Width and height of the form. Height is ignored for fixed forms
          which auto-calculate required height. Width must be in character
          units.

HEADER:
        - Initial string used in the title bar of the form. This may be
          overridden by the application.

form_header:
        [{default_button_def}]
        [{popup_def}]
        [{message_def}]

default_button_def:
```

Allegro SKILL Reference

Form Interface Functions

```
DEFAULT <label>
- Sets the default button to be <label>. If not present, the form
  sets the default button to be one of the following: ok (done),
  close, or cancel.
- Label must be of type MENU BUTTON.

popup_def:
  POPUP <><popupLabel>> {"<display>","<dispatch>"}.
  - Popups may be continued over several lines by using the backslash
    (\) as the last character on a line.

message_def:
  MESSAGE messageLabel messagePriority "text"

form_options:
  [TOOLWINDOW]
  - This makes a form a toolwindow which is a floating toolbar. It is
    typically used as a narrow temp window to display readouts.

  [FIXED_FONT]
  - By default, forms use a variable width font. This option sets the
    form to use a fixed font. Allegro PCB Editor uses mostly variable
    width while SPECCTRAQuest and SigXP use fixed width fonts.

  [AUTOGREYTEXT]
  - When a fillin or enum control is greyed, grey static text to the
    left of it.

  [UNIXHGT]
  - Works around a problem with Mainsoft in 15.0 where a button is
    sandwiched vertically between 2 combo/fillin controls. The
    button then overlaps these controls. This adds extra line spacing
    to avoid this. You should only use this option as a last resort.
    In a future release, it may be treated as a Nop. On Windows, this
    is ignored.

tile_def:
  TILE [<titleLabel>]
  [TPANEL tileType]
  [{text_def}]
  [{group_def}]
  [{field_def}]
  [{button_def}]
  [{grid_def}]
  [{glex_def}]
  END TILE

tabset_def:
  TABSET [label]
  [OPTIONS tabsetOptions]
  FLOC x y
  FSIZE w h
  {tab_def}
```

Allegro SKILL Reference

Form Interface Functions

```
ENDTABSET
tab_def:
    TAB "<display>" [<label>]
    [{text_def}]
    [{group_def}]
    [{field_def}]
    [{grid_def}]
    ENDTAB
text_def:
    TEXT "display" [label]
    FLOC x y
    [FSIZE w h]
    text_type
    [OPTIONS textOptions]
    ENDTEXT
text_type:
    [INFO label w] |
    [THUMBNAIL [<bitmapFile>|#<resource>] ]
group_def:
    GROUP "display" [label]
    FLOC x y
    [INFO label]
    FSIZE w h
    ENDGROUP
field_def:
    FIELD label
    FLOC x y
    [FSIZE w h]
    field_type
    field_options
    ENDFIELD
button_def:
    FIELD label
    FLOC x y
    [FSIZE w h]
    MENUBUTTON "display" w h
    button_options
    ENDFIELD
grid_def:
    GRID fieldName
    FLOC x y
```

Allegro SKILL Reference

Form Interface Functions

```
FSIZE w h
[OPTIONS INFO | HLINES | VLINES | USERSIZE ]
[POP "<popupName>"]

[GHEAD TOP|SIDE]
[HEADSIZE h|w]
[OPTION 3D|NUMBER]
[POP "<popupName>"]
[ENDGRID]
ENDGRID

field_type:
    REALFILLIN w fieldLength |
    LONGFILLIN w fieldLength |
    STRFILLIN w fieldLength |
    INTSLIDE BAR w fieldLength |
    ENUMSET w [h] |
    CHECKLIST "display" ["radioLabel"] |
    LIST "" w h |
    TREEVIEW w h |
    COLOR w h |
    THUMBNAIL [<bitmapFile>|#<resource>] |
    PROGRESS w h
    TRACKBAR w h

field_options:
    [INFO_ONLY]
        - Sets field to be read-only

    [POP "<popupName>"]
        - Assigns a popup with the field.
        - A POPUP definition by the same name should exist.
        - Supported by field_types: xxxFILLIN, INTSLIDE BAR, MENUBUTTON, and
          ENUMSET.

    [MIN <value>]
    [MAX <value>]
        - Assigns a min and/or max value for the field.
        - Both supported by field types: LONGFILLIN, INTSLIDE BAR,
          REALFILLIN.
        - Value either an integer or floating point number.
```

Allegro SKILL Reference

Form Interface Functions

```
[DECIMAL <accuracy>]
  - Assigns a floating min and/or max value for the field.
  - Assigns the number of decimal places the field has (default is 2)
  - Both supported by field_types: REALFILLIN

[VALUE "<display>"]
  - Initial field value.
  - Supported by field_types: xxxFILLIN

[SORT]
  - Alphanumeric sorted list (default order of creation)
  - Supported by field_type: LIST

[OPTIONS dispatchsame]
  - For enumset fields only
  - If present, will dispatch to application drop-down selection even
    if the same as current. By default, the form's package filters
    out any user selection if it is the same as what is currently
    displayed.

[OPTIONS prettyprint]
  - For enumset fields only.
  - Displays contents of ENUM field in a visually pleasing way.

[OPTIONS ownerdrawn]
  - For enumset fields only.
  - Used to display color swatches in an ENUM field. See
    axlFormBuildPopup.

x:
y:
w:
h:
  - Display geometry (integers)
  - All field, group and text locations are relative to the start of the
    tile they belong or to the start of the form in the case of FIXED
    forms.
  - x and h are in CHARHEIGHT/2 units.
  - y and w are in CHARWIDTH units.

button_options:
  [MULTILINE]
    - Wraps button text to multiple lines if text string is too long for a
      single line.

dispatch:
  - String that is dispatched to the code.

display:
  - String that is shown to the user.
```

Allegro SKILL Reference

Form Interface Functions

bitmapFile:

- Name of a bmp file. Finds the file using BITMAPPATH

resource:

- Integer resource id (bitmap must be bound in executable via the resource file). '#' indicates it is a resource id.
- Not supported in AXL forms.

fieldLength:

- Maximum width of field. Field scrolls if larger than the field display width.

label:

- Name used to access a field from code. All fields should have unique names.
- Labels should be lower case.

messageLabel:

- Name used to allow code to refer to messages.
- Case insensitive.

messagePriority:

- Message priority 0 - (not in journal file), 1 - information, 2 - warning, 3 - error, 4 - fatal (display in message box)

radioLabel:

- Name used to associate several CHECKLIST fields as a radio button set. All check fields should be given the same radioLabel.
- Should use lower case.

textOptions:

[RIGHT | CENTER | BORDER | BOLD | UNDERLINE]

- TEXT/INFO field type
 - text justification, default is left
 - BORDER: draw border around text
- [STRETCH]
- THUMBNAIL field type
 - Stretch bitmap to fit thumbnail rectangle, default is center bitmap.

tabsetOptions:

[tabsetDispatch]

Allegro SKILL Reference

Form Interface Functions

- By default, tabs dispatch individual tabs as separate events. This is not always convenient for certain programming styles. This changes the dispatch mode to be upon the tabset where a selection of a tab causes the event:

```
field=tabsetLabel value=tabLabel
```

The default is:

```
field=tabLabel value=t
```

Script record/play remains based upon tab in either mode.

tileLabel:

- Name used to allow code to refer to this tile.
- Should use lower case.
- Only applies to VARIABLE forms.
- Not supported with AXL forms.

tileType[0|1|2]

- 0 top tile, 1 scroll tile, 2 bottom tile
- Only applies to VARIABLE FORMS.
- Region where tile will be instantiated. Forms have the following regions: top, bottom, and scroll (middle).
- Not supported with AXL forms.

flex_def: Rule based control sizing upon form resize (see axlFormFlex)

```
[FLEXMODE <autorule>]  
[FLEX <label> fx fy fw fh]
```

FLEXMODE <autoRule>

```
FLEX fx fy fw fz  
- see axlFormFlexDoc
```

autorule:- Generic sizing placement rule.

fx:

fh:

- Floating value between 0 and 1.0



Follow these rules when using BNF format:

- FILE_TYPE line must always appear as the first line of the form file in the format shown.
- Form files must have a .form extension.
- There may only be one FORM in a form file.
- There must be one and only one TILE definition in a FIXED form file. <tileLabel> and TPANEL are not required.
- Unless otherwise noted, character limits are as follows:
 - labels - 128
 - title - 1024
 - display - 128 except for xxxFILLIN types which are 1024
- Additional items may appear in existing form files (FGROUP) but they are obsolete and are ignored by the form parser. REALMIN and REALMAX are obsolete and replaced by MIN and MAX respectively. They will still be supported and are mapped to MIN and MAX.
- For *grid_def*, two headers (side and top) are maximum.
- FSIZE - Most controls determine the size from the text string.
You must provide FSIZE for GROUP, GRID, TREEVIEW and LIST controls. For TEXT controls, if FSIZE is provided, it overrides the width calculated by the text length and, if present, the INFO width. If using the INFO line, put the FSIZE line after it.
- Both TEXT and GROUP support the optional label on their definition line. This was added as a convenience in supporting FLEX capability. If the application wishes to dynamically modify the text, the INFO keyword is normally used. When both are present, the INFO keyword takes precedence.
- If the optional label for TABS is not provided, the field display name is used. Any spaces within the field display name are replaced by underscores ("_").
- The height ([*h*]) for ENUMSET is optional. When not set (the default), the drop-down is only presented under user control. When height is greater than 1, the drop-down is always visible (Microsoft SIMPLE drop-down). Only use this feature in forms that can afford the space consumed by the drop-down.

The forming syntaxes are NOT supported by the form editor.

This syntax is supported and may be placed anywhere in the form file to support conditional processing of the form file:

```
#ifdef <variable>
{ }

{ #elseif <variable>
}
{ #else
{ } }
```

Moving and Sizing Form Controls During Form Resizing

You can use the axlFormFlexDoc command to move and size controls within a form based on rules described in the form file. Rules may either be general (**FLEXMODE**) or specific to a single control (**FLEX.**) Flex adjusting of the controls is adjusting the form larger than its base size. Sizing the form smaller than the base size disables flex sizing.

Controls are divided into the following classes:

- Containers
Containers can have other controls as members, including other containers. To be a container member is automatic; the control's *xy* location must be within the container. Container controls of the form are TABSETS and GROUPS.
- All others, including containers

All controls except TABS, which are locked to their TABSET, may be moved when a form is resized. Sizing width or height is control dependent as shown:

Table 11-2 Controls - Resizing Options

Control	Resizing Options
REALFILLIN	width
LONGFILLIN	width
STRFILLIN	width
INTSLIDE BAR	width

Table 11-2 Controls - Resizing Options, *continued*

Control	Resizing Options
ENUMSET	width
PROGRESS	width
TRACKBAR	width
LIST	width and height
GRID	width and height
TREEVIEW	width and height
THUMBNAIL	width and height
GROUP	width and height
TABSET	width and height
<others>	no change in size

Using Global Modes or FLEXMODE

FLEXMODE represents the general rules that apply to all controls in the form except those with specific overrides (FLEX). Only a single FLEXMODE is supported per form. The last encountered in the form file is used. The following rules are supported:

- EdgeGravity
All controls have an affinity to the closest edge of their immediate container. Exceptions are: <xxx>FILLIN and INTSLIDE BAR controls. The edge gravity, for these, is based upon a TEXT control positioned to the left of the control.
- EdgeGravityOne
Similar to EdgeGravity except that controls are only locked to the right or bottom edge, but not both. The closest edge is used.
- StandButtons
Only effects button controls. Uses the same logic as EdgeGravityOne.

FLEXMODE can have an optional pair of additional arguments that specify the minimum form width and height for flexing. The argument values are in character units. Flexing will stop in the given direction when the width/height goes below the specified value.

Managing Sizing and Movement of Individual Controls

You use the `FLEX` parameter to manage the sizing and movement of individual controls as shown:

```
FLEX fx fy fw fh
```

The `FLEX` parameter overrides any `FLEXMODE` in effect for that control, and is based upon parameters (fx , fy , fw , fh). These values, which are floating point numbers between 0.0 and 1.0, control the fraction of the change in container size that the control should move or change in size:

fx and fy Parameters

0	Control remains locked to the left or top edge of its container.
1	Control remains locked to the right or bottom edge of its container.

fw and fh Parameters

0	Control is not resized.
1	Control is resized in width or height based upon the size change of its container.

A container's position and size effect the container's member controls. Containers are hierarchical. Make sure the container of the control also has a `FLEX` constraint. The sum of the width and height of the immediate controls of a container should not be greater than 1 to prevent overlapping. TABSETS are slightly different since sizing of their member controls is also based on the TAB they belong to.



It is possible to create FLEX constraints that result in overlapping controls. FLEX does not protect against this.

FLEX Restrictions

- The form must be `FIXED`.
- While `FLEX` rules may appear anywhere in the form file, they should be grouped together immediately before the `<ENDTITLE>`

- Range errors for FLEX option or applying width or height to controls not supporting them are silently ignored.

Example 1

```
FLEXMODE standbuttons  
FLEX list 0 0 1 1
```

Simple list-based form with buttons (label of LIST is list.) The list gets all of form sizing.

Example 2

```
FLEXMODE EdgeGravity  
FLEX a 0 0 0.33 1  
FLEX b 0.33 0 0.67 1  
FLEX c 0.67 0 1 1
```

Form containing 3 lists (a, b, and c) positioned equally across the form. Each list gets the total change in height, but shares in the increase in form width. Thus, if the form changes width, each control gets 1/3 of this change. Since the list's widths change, the list must move to the right.

Example 3

```
FLEX 11 0 0 1 0.5  
FLEX g1 0 0.5 1 0.5  
FLEX 12 0 0 1 1
```

Form has a group (g1) containing a list (12). These are at the bottom of another list (11). Both lists share in any change of the form size. The second list (12) is a member of the group container (g1), so it moves if the group moves (0 for y) and it gets all of the group resizing (h is 1).

Example 4

```
FLEX g1 1 1 0 0  
FLEX 11 0 0 1 1
```

Form has a group (g1) with a list member (11), but the list doesn't resize because the list is a member of the group which has 0 : 0 sizing. Though the list has 1 : 1 sizing, it never changes in size because its container never changes in size. Both the group and its member list move because the group has a 1 : 1 x/y factor.

Example 5

```
FLEX t1 0 0 1 1  
FLEX 11 0 0 1 1  
FLEX 12 0 0 1 1
```

Form is a tabset (`t1`) with 2 tabs. Each tab controls a list (`11` and `12`) that accommodates the maximum change in the form size.

- Use `axlFormTest(<formname>)` to experiment with your form.

Using Grids

Grids offer tabular support and the following features:

- Optional side and top headers
- Several data types on a per column basis: Text (info), Checkbox with optional text, Enum (Drop-drop) and Fillin (text box with built-in types: string, integer, and real.)
- Row and column indexing which is 1-based

Grids have the following limits:

- Maximum of 200 columns
- Maximum rows of 1,000,000
- Maximum field string length per column of 256 characters
- Column creation only at grid initialization time.

Form File Support for Grids

The following defines the form file structure relating to grids.

GRID

 Standard items

 FLOC- x, y location
 FSIZE- width and height including headers if used
 POP - Optional right button popup for body. Also requires application to set the GEVENT_RIGHTPOPUP option.

 OPTIONS:

 INFO- Entire grid is info-only even if it contains typeable fields
 HLINES- Draw horizontal lines between columns
 VLINES- Draw vertical lines between rows
 USERSIZE-Allow user to resize columns.
 MULTISELROWAllows multi-row select (also set via Skill API, axlFormGridEvents)

HEADERS (GHEAD)

 - Specified within GRID section.
 - TOP and SIDE header (only one per type allowed in a grid)
HEADSIZE-Height (TOP) or width (SIDE) for the header.

 OPTIONS:

 3D - Display raised.

Allegro SKILL Reference

Form Interface Functions

NUMBER- For side header, display row number if application does not provide text.

POP - Optional right mouse button popup. One per header. Requires application to set GEVENT_RIGHTPOPUP for the header.

Programming Support for Grids

The following Grid APIs are available:

axlFormGridInsertCol	Insert a column.
axlFormGridInsertRows	Insert one or more rows.
axlFormGridDeleteRows	Delete one or more rows.
axlFormGridEvents	Set grid events.
axlFormGridOptions	Miscellaneous grid options.
axlFormGridNewCell	Obtain structure for setting a cell.
axlIsGridCellType	Is item a cell data type.
axlFormGridSetBatch	For setting multiple cells.
axlFormGridGetCell	For getting cell data.
axlFormGridBatch	Used with axlFormGridSetBatch
axlFormGridUpdate	Update display after changes.
make_formGridCol	For defstruct formGridCol
copy_formGridCol	For defstruct formGridCol

Allegro SKILL Reference

Form Interface Functions

In addition, the following standard form APIs may be used:

<code>axlFormSetFieldVisible</code>	Set grid visibility
<code>axlFormIsFieldVisible</code>	Is field visible
<code>axlFormSetFieldEditable</code>	Set grid editability
<code>axlFormIsFieldEditable</code>	Is field editable
<code>axlFormBuildPopup</code>	Change a popup
<code>axlFormSetField</code>	Set individual cell.
<code>axlFormRestoreField</code>	Restore last cell changed. Restore supports undoing last <i>change</i> event. Adding, deleting, or right mouse event reset restore.

Multi-row select support functions:

<code>axlFormGridSetSelectRows</code>	control selection of rows
<code>axlFormGridSelectedCnt</code>	number of rows selected
<code>axlFormGridSelected</code>	list of rows selected

Data Structures

<code>r_cell</code>	User data type for cell update (see axlFormGridNewCell on page 688)
<code>r_formGridCol</code>	Defstruct to describe column (see axlFormGridInsertCol on page 682)

Column Field Types

Grids support the assignment of data types by column. You may change an editable cell into a read-only cell by assigning it a `s_noEdit` or `s_invisible` attribute. See `axlFormGridInsertCol` for a complete description of column attributes and `axlFormGridSetBatch` for a discussion of cell attributes.

<code>TEXT</code>	Column is composed of display only text.
-------------------	--

Allegro SKILL Reference

Form Interface Functions

STRING	Column supports editable text. See edit-combo.
LONG	Column supports numeric data entry cells. See edit-combo.
REAL	Column supports numeric floating point entry cells. See edit-combo.
ENUMSET	Column supports combo-box (drop-down) cells. Must have a popup attribute on the column.
CHECKITEM	Column has checkbox cells with optional text.
EDIT-COMBO	By assigning a popup attribute at the column and/or at the cell level, you can change STRING, LONG, and REAL types to support the original text editing field with the addition of a drop-down.

Initializing the Grid

Once a grid is defined in the form file, you can initialize the grid as follows:

1. Create required columns using `axlFormGridInsertCol`
2. Create initial set of rows using `axlFormGridInsertRows`
3. Create initial grid cells and headers using `axlFormGridSetBatch`, then on callback, use:
 - a. `axlFormGridNewCell`
 - b. `axlFormGridSetBatch`
4. Set event filters using `axlFormGridOptions`.
5. Display the grid using `axlFormGridUpdate`.

See `grid.il` and `grid.form` for a programming example. You can find these in the AXL Shareware area:

```
<CDS_INST_DIR>/share/pcb/etc/skill/examples/ui
```

Dispatching Events

Unlike other form controls, an application can specify what events are dispatched. You control this using the `axlFormGridEvents` API which documents the usage. Also, the form callback structure has new fields for grids (see [axlFormGridEvents](#) on page 677.)

By default, you create a grid with the 'rowselect enabled which is typically appropriate for a multi-column table.

Multi-row Selection

A super-set of row selection is the multi-row selection option. With this option the user can select multiple rows. Grids running in this mode do now support cell select or change options.

This is set in Skill via:

```
axlFormGridEvents (<form> <grid> '(mrowselect))
```

or from the formfile by adding the `MULTISELROW` option to the grid's `OPTION` line.

Standard selection model is supported (not extended). This means:

- left click selects a row
- shift-left click selects all rows between the initial and current row
- ctrl-left click on to selection of row that is currently selected, it de-selects
- control-a selects all rows

APIs are provided (see above) to get current selected rows and set or clear row selections.

Finally, since multiple rows may be selected the standard form callback mechanism only informs you of a selection event. You need to utilize `axlFormGridSetSelectRows` to determine the current selection.

Using Scripting with Grid Controls

Unlike most other form controls where the programmer needs no concern over scripting, grid programmers should address scripting. By default, the grid uses the event type and row/column number for scripting. Depending on your application, this may create scripts that do not replay given different starting data. Grids support assigning script labels to rows, to columns, and on a per cell basis.

You label by setting the `scriptLabel` attribute from the application code with the `axlFormGridInsertCol` function for a column or the `axlFormGridNewCell` function for a row, column, or per cell basis. You can also change this dynamically. Note that `(row=0, col=n)` sets the `scriptLabel` for the column using `axlFormGridNewCell` and `(row=n, col=0)` allows setting for row script labels.

The grid script line format extends upon the standard form scripting as shown:

Allegro SKILL Reference

Form Interface Functions

FORM <formname> [<titleLabel>] <fieldLabel> <event> <glabel> [<value>]

where

```
FORM <formname> [<titleLabel>] <fieldLabel>
- standard form script form fieldLabel is the grid label
<event> is the grid event. Grid events include:
    rowselect:= GEVENT_ROWSELECT
    cellselect:= GEVENT_CELLSELECT
    change:= GEVENT_CELLCHANGE
    rpopup:= GEVENT_RIGHTPOPUP
    rprepopup:= GEVENT_RIGHTPOPUPPRE
    lpopup:= GEVENT_LEFTPOPUPPRE
<glabel> label corresponds to the location in the grid the event
occurred.
[<value>] optional value depending upon event.
```

Depending on the event, the rest of the script line appears as follows:

```
rowselect<glabel:=row>
cellselect<glabel:=cell>
change<glabel:=cell> <value>
rpopup<glabel:=cell> <popup value>
rprepopup<glabel:=cell>
lpopup<glabel:=cell>
```

Allegro SKILL Reference

Form Interface Functions

The `glabel` has several format options depending on the event:

`row` If the row has a `scriptLabel`, it is used, otherwise the row number is used.

`cell` If the cell has a label, that is used. If the cell does not have a label, the row and /or column labels are used. If either the row or column does not have labels, the row and/or column number is used.

When you set a `scriptLabel` to `row`, `col`, or `cell`, the following character set is enforced: case insensitive, no white space or comma or \$. Labels with these characters are replaced by an underscore (_). You may use pure numeric strings, but if you do not label everything, scripts may fall back and use the row/grid number to resolve a number not found as a script label string.

Notes

- If you use `row` and `col` as the `glabel`, use a comma (,) to delineate between the row and column name and number.
- Do not turn on events that you do not plan to process since scripts record them. For instance, if you only process on `rowselect` (no editable cells), then only enable `rowselect`. As a side benefit, you do not have to label columns or cells since row label is sufficient.
- If you use a row and/or column heading, you may use that for assigning `scriptLabels`.

Examples

- If grids replace the text parameter form, you need not label the columns. A column number is sufficient. You can label the columns for script readability. This application does not require cell labeling.
- If grids replace the color form for certain color grids, like stackup, you would need to label each cell. Each class grouped in the stackup grid is not row consistent. For example, depending on design, subclasses are not the same going across the rows. Other groupings require labeling on class for `col` and subclass for `row` since it is orthogonal.

See [Using Grids](#) on page 593 for a grid overview.

Headers


You can set column (top) headers either using `axlFormGridInsertCol` at column creation time, or using `axlFormGridSetBatch` if you need to change the header using row number 0.

Row (side) headers default to automatic run numbers with this option set in the form file. Using `axlFormGridSetBatch`, you can set the text for individual rows using col number 0.

Allegro SKILL Reference

Form Interface Functions

AXL Forms: Example 1



```
FILE_TYPE=FORM_DEFN VERSION=2
FORM
FIXED
PORT 50 11
HEADER "Extract Selector"
TILE
TEXT "Select View File to Extract"
TLOC 12 1
ENDTEXT
TEXT "View File:"
TLOC 1 12
ENDTEXT
FIELD view_file
FLOC 12 12
STRFILLIN 24 24
ENDFIELD
FIELD file_list
FLOC 5 3
LIST "" 40 5
ENDFIELD
FIELD cancel
FLOC 5 15
MENUBUTTON "Cancel" 8 3
ENDFIELD
FIELD done
FLOC 15 15
MENUBUTTON "Done" 9 3
ENDFIELD
FIELD print
FLOC 25 15
MENUBUTTON "Print" 9 3
ENDFIELD
FIELD script
FLOC 35 15
MENUBUTTON "Script" 11 3
```

Allegro SKILL Reference

Form Interface Functions

```
ENDFIELD  
ENDTILE  
ENDFORM
```

- Uses a form file (expected to be in the current directory) that can display a selection list.
- Gets the list of available extract definition (view) files pointed to by the TEXTPATH environment variable.
- Displays the list in the form.

The user can then select any filename listed, and the name displays in the *View File* field.

Selecting the *Done* button causes the form to call `axlExtractToFile` with the selected extract filename as the view file, and `myextract.dat` as the extract output filename, and closes the form. Selecting *Cancel* cancels the command and closes the form.

The form file has `FIELD` definitions for the selection list, the *View File* field, and each of the buttons (*Cancel*, *Done*, *Print* and *Script*).

Allegro SKILL Reference

Form Interface Functions

```
; myExtractViews.il
;           -- Displays a form with a selection list of
;           the available extract definition files
;           -- Lets the user select any of the files on
;           the list as the "View file"
;           -- Starts Allegro extract process with the
;           user-selected View file when
;           the user picks Done from the form.

; Function to extract user selected view to the output file.
(defun myExtractViews (viewFile outFile)
  axlExtractToFile( viewFile outFile)
); defun myExtractViews
; Function to start the view extraction
(defun _extract ()
  myExtractViews(
  buildString(list(cadr(parseString(
    axlGetVariable("TEXTPATH")))) selectedFile) "/")
  "myextract.dat")
); defun _extract
; Form callback function to respond
(defun _formAction (form)
  (case form->curField
    ("done"
      (axlFormClose form)
      (axlCancelEnterFun)
      (_extract)
      t)
    ("cancel"
      (axlFormClose form)
      (axlCancelEnterFun)
      nil)
    ("view_file"
      (if form->curValue
        (progn
          ; Accept user input only if on list
          if(member( form->curValue fileList)
            then axlFormSetField( form
              "view_file" form->curValue)
            else axlFormRestoreField(
              form "view_file")))
        t)
      ("file_list"
        (axlFormSetField form "view_file"
          form->curValue)
        selectedFile = form->curValue
        t)); case
    ); defun formAction
; User-callable function to set up and
; display the Extract Selector form
(defun myExtract ()
  fileList = (cdr (cdr (getDirFiles
    cadr( parseString( axlGetVariable("TEXTPATH"))))))
  form = axlFormCreate( (gensym)
    "extract_selector.form" '("E" "OUTER")
    ' formAction t)
  axlFormTitle(_form "Extract Selector")
  axlFormSetField( form "view_file" (car fileList))
  selectedFile = (car fileList)
  foreach( fileName fileList
    axlFormSetField( form "file_list" fileName))
  axlFormDisplay( form)
); defun myExtract
```


- Creates a form named `form` with the callback function `_formAction` that analyzes user action stored in `form->curField` and responds appropriately.

Allegro SKILL Reference

Form Interface Functions

- Loads the example AXL program shown.
- Enters the command `myExtract()`.

SKILL displays the **Extract Selector** form, as specified in the form file `extract_selector.form` that this code created when it first loaded. This is a non-blocking form—you can enter other SKILL and Allegro PCB Editor commands while the form displays.



The program shows how to analyze the user selection when control passes to the callback function `_formAction`. Name of the field selected by the user is in `form->curField`. In this case, that is one of the strings `done`, `cancel`, `view_file`, or `file_list`. The value of the field is in `form->curValue`. This has a value for the `view_file` and `file_list` fields.

The actions in the callback `_formAction` are

"done"	The user selected the <i>Done</i> button. Closes the form, clears input using <code>axlCancelEnterFun</code> , and calls the <code>_extract</code> function to execute the data extract.
"cancel"	The user selected the <i>Cancel</i> button. Closes the form, clears input using <code>axlCancelEnterFun</code> , and calls the <code>_extract</code> function to execute the data extract.
"view_file"	The user selected the <i>View File</i> field, possibly typed an entry, and pressed <i>Return</i> . Sets the <code>view_file</code> name to the current

value of the *View File* field, letting the user type in a name.
Name must be a name on the list displayed.

"file_list"
The user picked a name from the displayed list of view file
names. Name picked is *form->curValue*, and the program
sets *selectedFile* (the name of the currently selected
extract file) to the new value, and displays it in the *View File*
field.

The *Print* and *Script* buttons have pop-ups that call predefined Allegro PCB Editor functions.

AXL Forms: Example 2

The form file *popup.form* for this is shown:

```
FILE_TYPE=FORM_DEFN VERSION=2
FORM
FIXED
PORT 50 5
HEADER "Popup Selector"
POPUP <PRINTP>
    "to File""0","to Printer""1","to Script""2".
POPUP <SCRIPTP>
    "Record""record","Replay""replay","Stop""stop".
POPUP <MYPOPUP>
    "MyPopup1""myPopup1","MyPopup2" "myPopup2".
TITLE
TEXT "My Popup Here:"
TLOC 1 1
ENDTEXT
FIELD my_popup
FLOC 12 3
ENUMSET 24
POP "MYPOPUP"
ENDFIELD
FIELD change_pop
FLOC 5 6
MENUBUTTON "Change" 8 3
ENDFIELD
FIELD done
FLOC 15 6
MENUBUTTON "Done" 9 3
ENDFIELD
FIELD print
FLOC 25 6
MENUBUTTON "Print" 9 3
POP "PRINTP"
ENDFIELD
FIELD script
FLOC 35 6
MENUBUTTON "Script" 11 3
POP "SCRIPTP"
ENDFIELD
ENDTILE
ENDFORM
```

Allegro SKILL Reference

Form Interface Functions

Uses a form file (expected to be in the current directory) to create a pop-up. The sample program also displays in the pop-up field the value returned whenever the user selects a pop-up.

The form field `my_popup` originally has the popup values specified by the file `popup.form` (`MyPopup1` and `MyPopup2`). The AXL program responds to the *Change* button by building the pop-up display and returning the values.

```
list( list( "MyPop 1" "myPopValue1")
      list( "MyPop 2" "myPopValue2"))
```

A list of lists of display and dispatch string pairs.

```
list( list( "MyPop 12" 12) list( "MyPop 5" 5))
```

A list of lists of display and dispatch pairs, where the display value is a string, and the dispatch value is an integer.

```
list( "MyPopValue1" "MyPopValue2")
```

A list of strings, which means that each string represents both the display and dispatch values of that popup selection.

```
; formpop.il - Create and display a form with a popup
; Form call back function to respond to user selection of any field in the form
(defun _popAction (form)
  (case form->curField
    ("done"
     (axlFormClose form)
     (axlCancelEnterFun)
     t)
    ("change_pop"
     (case already_changed
       (0;Use display/dispatch string pairs
        axlFormBuildPopup(form "my_popup"
                          list(
                            list("NewPopup A" "mynewpopup_a")
                            list("NewPopup B" "mynewpopup_b"))))
        axlFormSetField(form "my_popup"
                       "My First Popups")
      )
      (1;Display string/dispatch integer pairs
       axlFormBuildPopup(form "my_popup"
                         list( list("NewPopup 12" 12)
                               list("NewPopup 5" 5)))
       axlFormSetField(form "my_popup"
                      "My Second Popups")
      )
      (t;String is both display and dispatch
       axlFormBuildPopup(form "my_popup"
                         list( "MyPopNValue1"
                               "MyPopNValue2"))
       axlFormSetField(form "my_popup"
                      "My Third Popups")
      )
    ))
```


Allegro SKILL Reference

Form Interface Functions

```
)  
    already_changed++  
    t)  
  ("my_popup"  
   printf( "Got my_popup event:  
           form->curValue %s", form->curValue)  
   if( form->curValue  
       (progn  
        axlFormSetField( form "my_popup"  
                        form->curValue)))  
   t)  
); case  
)  
;  
; defun _popAction  
; User-callable function to set up and  
; display the Extract Selector form  
(defun myPop ()  
  form = axlFormCreate( gensym) "popup.form"  
  '("E" "OUTER") '_popAction t)  
  if( axlIsFormType(form)  
      then (print "Created form successfully.")  
      else (print "Error! Could not create form."))  
  axlFormTitle( form "Try My Popup")  
  mypopvalue = "my_start_popup"  
  axlFormSetField( form "my_popup" mypopvalue)  
  axlFormDisplay( form)  
  already_changed = 0  
); defun myPop
```

Sets the field *my_popup* to the value selected by the user and prints it.

1. Enter `myPop()` on the SKILL command line to display the **Try My Popup** form.
2. Press the middle mouse button over the pop-up field to display the original pop-up specified by the file `popup.form`.




3. Click *Change*.

Allegro SKILL Reference

Form Interface Functions

The form displays the first set of pop-up values set by the program. The first pop-up values also display when you press the middle mouse button over the field.




4. Make a selection.

If, for example, you selected *NewPopup B*, the program prints the following on the SKILL command line:

```
Got my_popup event: form->curValue mynewpopup_b
```

The following form is displayed.




5. Click *Change*.

Allegro SKILL Reference

Form Interface Functions

The program displays the third set of pop-ups.



AXL-SKILL Form Interface Functions

This section lists the form interface functions.

axlFormBNFDoc

This is the BNF grammar for the Forms Specification Language. New options and field types are added every release. Form files are always upwards compatible but may NOT be backwards compatible if you take advantage of a new feature. Thus, a form file created in 12.0 Allegro works in 13.0 Allegro. However, if you take advantage of the TAB control (13.0) or the RIGHT justification of TEXT (13.5), you will have a form file that will not function with 12.0 of Allegro.

The following outlines the conventions used in the grammar:

[]	Optional
{}	May repeat one or more times.
<>	Supplied by user.
	Choose one or the other.
:	Definition of a token.
CAPS	Items in caps are keywords (note form parser is case insensitive)
(#)	Note: See number at end of this documentation.

BNF

form

```
FILE_TYPE=FORM_DEFN VERSION=2 (1)
FORM [form_options] (3)
formtype
PORT w h
HEADER "text"
form_header
{tile_def}
ENDFORM
```

formtype FIXED / VARIABLE

- FIXED forms have a one unlabeled TILE stanza
- VARIABLE forms have one or more label TILE stanzas
- Skill only supports FIXED form types.

PORt

- width and height of form. Height is ignored for fixed forms which auto-calculates required height. Width must be in character units.

HEADER

- initial string used in title bar of form (may be overridden by application).

form_header

```
  [{default_button_def}]  
  [{popup_def}]  
  [{message_def}]
```

default_button_def

DEFAULT <label>

- sets the default button to be <label>. If not present form sets default button to one of the following:
ok (done), close, cancel.
- label must be of type MENU_BUTTON.

popup_def

POPUP <>popupLabel><> {"<display>","<dispatch>"}.

- popups may be continued over several lines by using the backslash (\) as the last character on line.

- popups work slightly differently when applied to fillin versus other supporting fields, such as, ENUMs and BUTTONs. With Fillin fields, such as, Strings and long, the display portion is always sent back to the application while other supporting field types, such as, ENUMs, send the dispatch portion.

The same applies with setting the field. For ENUMs, you must call the form API with the dispatch value while fillins expect the display string.

message_def

MESSAGE messageLabel messagePriority "text".

form_options

[TOOLWINDOW]

- this makes a form to be a tool window which is a floating toolbar. It is typically used as a narrow temp window to display readouts.

[FIXED_FONT]

- by default forms use a variable width font, this sets this form to use a fixed font. Allegro PCB Editor uses mostly variable width while Allegro PCB SI and SigXplorer use fixed width fonts.

[AUTOGREYTEXT]

- when a fillin or enum control is greyed, grey static text to the left of it.

[NOFOCUS]

- when a form opens focus is set to form window which allows you to immediately enter data. If you create a form with no editable fields or don't wish to have the form grab focus set this option.

[UNIXHGT]

- works around a problem with Mainsoft in 15.0 where a button is sandwiched vertically between 2 combo/fillin controls. The button then overlaps these controls. This adds extra line-2-line spacing to avoid this. You should only use this option as a last resort. In a future release it may be treated as a Nop. On Windows this is ignored.

Allegro SKILL Reference

Form Interface Functions

tile_def

```
TILE [<titleLabel>]      (4)
[TPANEL tileType]
{{text_def}}
{{group_def}}
{{list_def}}
{{field_def}}
{{button_def}}
{{grid_def}}
{{flex_def}}
ENDTILE
```

tabset_def

```
TABSET [label]
[OPTIONS tabsetOptions]
FLOC x y
FSIZE w h
{tab_def}
ENDTABSET
```

tab_def

```
TAB "<display>" [<label>]      (10)
{{text_def}}
{{group_def}}
{{field_def}}
{{grid_def}}
ENDTAB
```

text_def

```
TEXT "display" [label] (9)
FLOC x y
[FSIZE w h]          (8)
text_type
[OPTIONS textOptions]
ENDTEXT
```

Allegro SKILL Reference

Form Interface Functions

text_type

```
[INFO label w] |
[THUMBNAIL [<bitmapFile>|#<resource>] ]
```

group_def

```
GROUP "display" [label] (9)
FLOC x y
FSIZE w h      (8)
[INFO label]
ENDGROUP
```

list_def

```
FIELD label
FLOC x y
LIST "" w h
list_options
ENDFIELD
```

field_def

```
FIELD label
FLOC x y
[FSIZE w h]      (8)
field_type
field_options
ENDFIELD
```

button_def

```
FIELD label
FLOC x y
[FSIZE w h]      (8)
MENUBUTTON "display" w h
button_options
ENDFIELD
```

Allegro SKILL Reference

Form Interface Functions

grid_def

```
GRID fieldName
FLOC x y
FSIZE w h           (8)
[OPTIONS INFO | HLINES | VLINES | USERSIZE | MULTISELROW ]
[POP "<popupName>"]

[GHEAD TOP|SIDE]
[HEADSIZE h|w]
[OPTION 3D|NUMBER|MULTI]
[POP "<popupName>"]
[ENDGREADH]
ENDGRID
```

field_type

```
REALFILLIN w fieldLength |
LONGFILLIN w fieldLength |
STRFILLIN w fieldLength |
INTSLIDE BAR w fieldLength |
ENUMSET w [h] |           (11)
CHECKLIST "display" ["radioLabel"] |
LIST "" w h |
TREEVIEW w h |
COLOR w h |
THUMBNAIL [<bitmapFile>|#<resource>] |
PROGRESS w h |
TRACKBAR w h
```

field_options

The OPTIONS line permits multiple options

- [INFO_ONLY]
 - sets field to be read only.
- [POP "<popupName>"]
 - assigns a popup with the field.
 - a POPUP definition by the same name should exist.
 - supported by field_types: xxxFILLIN, INTSLIDE BAR, MENUBUTTON, ENUMSET

Allegro SKILL Reference

Form Interface Functions

[MIN <value>]

[MAX <value>]

- assigns a min and/or max value that field might have.
- both supported by field_types: LONGFILLIN, INTSLIDE BAR, REALFILLIN.
- value by either an integer or floating point number.

[DECIMAL <accuracy>]

- assigns a floating min and/or max value that field might have.
- assigns number of decimal places field has (default is 2)
- both supported by field_types: REALFILLIN

[VALUE "<display>"]

- initial field value.
- supported by field_types: xxxFILLIN

[SORT]

- alphanumeric sorted list (default order of creation)
- supported by field_type: LIST

[OPTIONS dispatchsame]

- for enumset fields only.
- if present will dispatch to application drop-down selection even if the same as current. By default, the form's package filters out any user selection if it is the same as what is currently displayed.

[OPTIONS prettyprint]

- for enumset fields only
- displays contents of ENUM field in a visually pleasing way

[OPTIONS ownerdrawn]

- for enumset fields only
- used to display color swatches in an ENUM field. See axlFormBuildPopup .

[OPTIONS space]

- string type only
- preserves leading and trailing white space. By default this is stripped.

[OPTIONS dropfile]

- string and multiline types only
- Allows a file to be dropped into the field (Windows drag and drop)
Shortcuts are not resolved.

list_options

[OPTIONS sort|alphanumsort|prettyprint|multiselect]
sort - conversion alphabetical sort
alphanumsort - sort so NET10 appears after NET2
prettyprint - make more readable, convert case.
All dispatch entries will be upper case multiselect - multi-select list box.
User can select more than one item (follows Microsoft selection model).

x
y
w
h

- display geometry (integers).
- all field, group and text locations are relative to the start of the tile they belong or to the start of the form in the case of FIXED forms.
- x & h are in CHARHEIGHT/2 units.
- y & w are in CHARWIDTH units.

button_options

[MULTILINE]
- wraps button text to multiple lines if text string is too long for a single line.
[BITMAP [<bitmapFile>|#<resource>]]
– display a bitmap for this button.

dispatch

- string that is dispatched to the code.

display

- string that is shown to user

bitmapFile

- name of a bmp file. Assumes can be found via BITMAPPATH

Allegro SKILL Reference

Form Interface Functions

resource

- integer resource id (bitmap must be bound in executable via the resource file). '#' indicates it is a resource id.
- not support in AXL forms.

fieldLength

- maximum width of field. Field will scroll if larger than field display width.

label

- named used to access field from code. All fields should have unique names.
- should use lower case.

messageLabel

- name used to allow code to refer to messages.
- case insensitive

messagePriority

- message priority 0 - info (not in journal file), 1 - info, 2 - warning, 3 - error, 4 fatal (display in message box).

radioLabel

- named used to associate several CHECKLIST fields as a radio button set. All check fields should be given the same radioLabel.
- should use lower case.

textOptions

RIGHT | CENTER | BORDER | BOLD | UNDERLINE]

- TEXT/INFO field type.
- text justification, default is left.
- BORDER: draw border around text.

Allegro SKILL Reference

Form Interface Functions

[STRETCH]

- THUMBNAIL field type.
- stretch bitmap to fit thumbnail rectangle, default is center bitmap.

[MAP3DCOLORS]

THUMBNAIL field type.

- search the color table of the .bmp and replace the following shades of gray with corresponding 3D color:

dk gray RGB(128,128,128) - COLOR_3DSHADOW

gray RGB(192,192,192) - COLOR_3DFACE

lt gray RGB(223,223,223) - COLOR_3DLIGHT

This option is typically used to blend the .bmp's background color with the user's dialog background. If using this option, don't reserve these 3 gray colors for background only.

tabsetOptions

tabsetDispatch]

- By default tabs dispatch individual tabs as separate events. This is not always convenient for certain programming styles. This changes the dispatch mode to be upon the tabset where a selection of a tab causes the event field=tabsetLabel value=tabLabel.

The default is:

field=tabLabel value=t

Script record/replay remains based upon tab in either mode.

gridOptions:

Several of these options can also be controlled at run-time via UIFGridVarEvents or UIFGridVarOptions:

- INFO - grid is for info only; can be scrolled but items cannot be selected
- HLINES - display horizontal separator lines
- VLINES - display vertical separator lines
- USERSIZE - user can resize columns
- MULTISELROW - grid is opened in multi-select row mode

gHeadOptions:

- 3D - display header in 3d mode
- NUMBER - auto-number side header (default is blank)
- MULTI - display top header as multiple lines (default single line with clipping)

tileLabel

- name used to allow code to refer to this tile.
- should use lower case.
- only applies to VARIABLE forms.
- not support with AXL forms.

tileType [0/1/2]

- 0 top tile, 1 scroll tile, 2 bottom tile.
- only applies to VARIABLE FORMS.
- region where tile will be instantiated. Forms have 3 regions top, bottom and scroll (middle).
- not support with AXL forms.

flex_def - rule based control sizing upon form resize (see [axlFormFlex](#))

[FLEXMODE <autorule> [minWidth minHeight]]
[FLEX <label> fx fy fw fh]

FLEXMODE <autoRule> [minWidth minHeight]

FLEX fx fy fw fz

- see [axlFormFlexDoc](#)

autorule - generic sizing placement rule

fx
fy
fw
fh

Allegro SKILL Reference

Form Interface Functions

- floating value between 0 and 1.0

#ifdef:

#ifndef:

#else:

#endif:

- Conditionally read portions of the form file based upon the settings of Allegro environment variables
- These statements may be nested.

- Note the negation character '!' was added in 15.7. Forms using this capability will not function correctly in earlier releases.

Use #ifdef/#endif and #ifndef/#endif to make items conditionally appear in the menu depending on whether a specified environment variable is set.

An #ifdef causes the form item(s) to be ignored unless the environment variable is set. You must have one #endif for each #ifdef or #ifndef to end the block of conditional menu items. Also, the #ifdef, #ifndef and #endif must start at the first column of its line in the formfile. The #ifndef is the negation of #ifdef.

The #else statement may be inserted between the #if/#endif statements.

The condition syntax supports multiple variables with OR '||' or AND '&&' conditions. Also the negation character '!' is supported for the variables:

The simple syntax is:

```
#ifdef <env variable name>  
[form items which appear if the env variable is set]  
#endif  
  
#ifndef <env variable name>  
[form items which appear if the env variable is NOT set]  
#endif  
  
# logically equivalent to above state using negation character
```

Allegro SKILL Reference

Form Interface Functions

```
#ifdef !<env variable name>  
    [form items which appear if the env variable is not set]  
#endif  
  
#ifdef <env variable name>  
    [form items which appear if the env variable is set]  
#else  
    [form items which appear if the env variable is set]  
#endif
```

Also logical statements:

1) if variable1 and variable2 are both set do the included statement

```
#ifdef <var1> && <var2>  
    [form items which appear if both variables are set]  
#endif
```

2) if either variable1 or variable2 is do the included statement

```
#ifdef <var1> || <var2>  
    [form items which appear if either variable is set]  
#endif
```

Note:

- ❑ FILE_TYPE line must always appear as the first line of form file in format shown.
- ❑ Form files must have a .form extension.
- ❑ There may only be one FORM in a form file.
- ❑ There must be one and only one TILE definition in a FIXED form file. <tileLabel> and TPANEL are not required.
- ❑ Unless otherwise noted limits are as follows:
labels - 128

title - 1024

display - 128 except for xxxFILLIN types which are 1024

- ❑ Additional items may appear in existing form files (FGROUP) but they are obsolete and are ignored by the form parser. REALMIN & REALMAX are obsolete and replaced by MIN and MAX respectively. They will still be supported and are mapped to MIN and MAX.
- ❑ For grid_def two headers (side and top) are maximum.
SIZE - most controls determine the size from the text string. You are required to provide FSIZE for GROUP, GRID, TREEVIEW and LIST controls. For TEXT controls if FSIZE is provided after it overrides the width calculated by the text length and if present the INFO width. If the INFO line appears you should put the FSIZE line after it.
- ❑ Both TEXT and GROUP support optional label on their definition line. This was added as a convenience in supporting FLEX capability. If application wishes to dynamically modify the text the INFO keyword is normally used. When both are present the INFO keywords takes precedence.
- ❑ If the optional label for TABS is not provided, the field display name is used. Any spaces within the field display name are replaced by underscores ("_").
- ❑ The height ([h]) for ENUMSET is option. When not set (the default) the drop-down is only presented under user control. When height greater than 1 then the drop-down is always visible (Microsoft SIMPLE drop-down). You only want to use this feature in forms that can afford the space consumed by the drop-down.

The forming syntaxes are NOT supported by the form editor.

This following syntax is supported and may be placed anywhere in the form file to support conditional processing of the form file:

```
#ifdef <variable>
{ }

{ #elseif <variable>
  }

{ #else
{} }
```

axlFormCallback

```
formCallback(  
    [r_form]  
)  
==> t
```

Description

This is not a function but documents the callback interface for form interaction between a user and Skill code. The Skill program author provides this function.

When the user changes a field in a form the Allegro form processor calls the procedure you specified as the `g_formAction` argument in `axlFormCreate` when you created that form. The form attribute `curField` specifies the name of the field that changed. The form attribute `curValue` specifies the current value of the field (after the user changed it). If you set `g_stringOption` to `t` in your call to `axlFormCreate` when you created that form, then `curValue` is a string. If `g_stringOption` was `nil` (the default), then `curValue` is the type you specified for that field in the form file.

Note: The term `formCallback` used in the title of this callback procedure description is a dummy name. The callback function name must match the name or symbol name you used as the `g_formAction` argument in `axlFormCreate` when you created the form.

If you specify the callback name (`g_formAction`) as a string in your call to `axlFormCreate`, SKILL calls that function with no arguments. If you specify `g_formAction` as a symbol, then SKILL calls that function with the form handle as its single argument.

The callback must call `axlFormClose` to close the form and to continue in the main application code if form mode is blocking.

All form information is provided by the `r_form` argument which is a form data type. Applications can extend the data stored on this type by adding their own attributes. Capitalize the first letter of the attribute name to avoid conflicts with future additions by Cadence to this structure. Tables 1 and 2 show the available field types and how they impact the `r_form` data type.

Table 1

Form Field Types:

Type	What the field is commonly known to the user.
------	---

Allegro SKILL Reference

Form Interface Functions

Keyword	How the field is declared in the form file (see <code>axlFormBNFDoc</code>).
curValue	The data type seen in the form dispatch and <code>axlFormGetField</code> (see <code>axlFormCallback</code>).
curValueInt	If <code>curValue</code> can be mapped to an integer. For certain field types provides additional information.

Type	Keyword	cuValue	curValueInt
Button	MENUBUTTON (6)	t	1
Check Box	CHECKLIST (1)	t / nil	1 or 0
Radio Box	CHECKLIST (1)	t / nil	1 or 0
Long (integer)	INTFILLIN	integer	integer
Real (float)	REALFILLIN	floating point	N/A
String	STRFILLIN	string	N/A
Enum (popup)	ENUMSET	string	integer (2)
List	LIST	string	index
Color well	COLOR	t / nil	1 or 0
Tab	TABSET/TAB	string or t (3)	N/A or 1/0
Tree	TREEVIEW	string	See: <code>axlFormTreeViewSet</code>
Text	INFO (4)	N/A	N/A
Graphics	THUMBNAIL (5)	N/A	N/A
Trackbar	TRACKBAR	integer	integer
Grid	GRID		See: <code>axlFormGridDoc</code>

Note:

- ❑ What distinguishes between a radio button and check box is that radio buttons are a group of check boxes where only one can be set. To relate several check boxes as a set of radio buttons, use supply the same label name as the third field (`groupLabel`) in the form file description:

```
CHECKLIST <fieldLabel> <groupLabel>
```

Allegro SKILL Reference

Form Interface Functions

When a user sets a radio button the button be unset will dispatch to the app's callback with a value `nil`.

- ❑ Enum will only set `curValueInt` on dispatch when the dispatch value of their popup uses an integer. Otherwise this field is `nil`.
- ❑ Tabs can dispatch in two methods:
 - default when a tab is selected your dispatcher receives the tab name in the `curField` and `curValue` is `t`.
 - If `OPTIONS tabsetDispatch` is set in the TABSET of the form file then when a tab is selected your app dispatcher receives the TABSET as the `curField` and the `curValue` being the name of the TAB that was selected.
- ❑ INFO fields can be static where the text is declared in the form file or dynamic where you can set the text via the application at run-time. To achieve dynamic access enter the following in the form file:

```
TEXT "<optional initial text>"
```

```
INFO <fieldLabel>
```

... reset of TEXT section ...

- ❑ Thumbnails support three methods:
 - Static bitmap declared via form file.
 - Bitmaps that can by changed by the application at run-time.
 - Basic drawing canvas (see `ax1GRPDoc`).
- ❑ Buttons are stateless. The application cannot set the button to the depressed state. You can only use `ax1FormSetField` to change the text in the button. Several button fieldLabels are reserved. Use them only as described:

Done or Ok

Do action and close form.

Cancel

Cancel changes and close form.

Print

Print form; do not use.

Help

Call `cdsdoc` for help about form. Do not use.

Allegro SKILL Reference

Form Interface Functions

Table 2

Attribute Name	Set?	Type*	Description
curField	no	string	Name of form field (control) that just changed.
curValue	no	See->	Value dependant upon field type (2).
curValueInt	no	See->	Value dependant upon field type (2).
doneState	no	int	0 = action; 1 = done; 2 = cancel; 3 = abort (1)
form	no	string	Name of this form (form file name).
isChanged	no	t / nil	t = user has changed one or more fields.
isValueString	no	t / nil	t all field values are strings. nil one or more fields are not strings.
objType	no	string	Type of object; in this case form.
type	no	string	Always fixed.
fields	no	list of strings	All fields in the form (3).
infos	no	list of strings	All info. fields in form (3).
event	no	symbol	List, tree and grid control only. See <code>axlFormGridDoc</code> for grid info, otherwise see bullets 4 and 5 in the following Note section.
row	no	integer	Grid control only.
col	no	integer	Grid control only.
treeViewSelState	no	integer	Tree control only.

Note:

- ❑ The doneState shows 0 for most actions. If a button with *Done* or *Ok* is pushed, then the done state is set. A button with the *Cancel* label sets the cancel state. In either the Done or Cancel state, you need to close the form with `axlFormClose`. If the abort state is set, the form closes even if you do not issue an `axlFormClose`.
- ❑ Data type is dependant upon the field type, see Table 1.
- ❑ The difference between the fields and infos list is that items appearing in the infos list are static text strings that can be changed by the program at the run-time. All other labels appear in the fields list and can be changed by the user (even buttons, tabs, greyed and hidden fields).
- ❑ Event for list box is `t` if item is selected, `nil` if deselected. This is always `t` for single select list box while the multi-select option can have both states.
- ❑ Event and `treeViewSelState` for a tree control see `axlFormTreeViewAddItem`.

Arguments

r_form Form dbid.

Value Returned

`t` Always returns `t`.

Examples

See `axlFormCreate` and `axlFormBuildPopup` examples.

axlFormCreate

```
axlFormCreate(  
    s_formHandle  
    t_formfile/(t_formName t_contents)  
    [1t_placement]  
    g_formAction  
    g_nonBlock  
    [g_stringOption]  
)  
⇒ r_form/nil
```

Description

Creates a form structure based on the form descriptive file *t_formfile*. This call only supports forms of type “fixed” and will fail if *t_formfile* contains any variable tiles. This function does not display the form. Use `axlFormDisplay` to display a form.

An alternative interface is supported that allows embedding the contents of the form file with the skill code. Instead of passing the external form file name provide the name (*t_formName*) for scripting purposes and form file contents (*t_contents*) as string. The packaged skill code has a example of this method at the end of the `<cdsroot>/share/pcb/examples/form/axlform.il` file.

Two things to remember when creating this form content string:

- Each form file line must end with a - \n

Example:

```
FILE_TYPE=FORM_DEFN VERSION=2\n
```

- Any embedded quotes must be backslashed

Example:

```
MENUBUTTON \"Ok\" 10 3\n
```

Note: If *s_formHandle* is an existing *r_form*, then `axlFormCreate` does not create a new form, but simply exposes and displays the existing form, *s_formHandle*, and returns nil.

Arguments

s_formHandle

Global SKILL symbol used to reference form.

Allegro SKILL Reference

Form Interface Functions

Note: Do not use the same symbol to reference different form instances.

t_formfile

Filename of the form file to be used to define this form. `axlFormCreate` uses the Allegro PCB Editor environment variable, `FORMPATH`, to find the file, if *t_formfile* is not a full path. The filename, by convention, should use the `.form` extension.

Alternative interface to embed form file into Skill code:

- *t_formName*: Name of form (used for scripting)
- *t_contents*: contents of form file

1 t_placement

Form placement. Allegro PCB Editor uses its default placement if this argument is `nil`. See [Window Placement](#) on page 489

Allegro SKILL Reference

Form Interface Functions

g_formAction Specifies the SKILL commands (callbacks) to execute after every field change (Note that this is very different from Opus forms). You can set this to one of the formats shown:

g_formAction Options

Option	Description
<i>t_callback</i>	String representation of the SKILL command to be executed.
<i>s_callback</i>	Symbol of the SKILL function to be called (passes the <i>r_form</i> returned from <code>axlFormCreate</code> as its only parameter.)
<i>nil</i>	<code>axlFormDisplay</code> blocks until the user closes the form. You must place a <i>Done</i> button (field name <code>done</code>) and optionally a <i>Cancel</i> button (field name <code>cancel</code>) in the form for <i>g_formAction</i> to function properly. The user can access all of the fields and values using the <i>r_form</i> user type.

g_nonBlock If *g_nonBlock* is `t`, the form runs in non-blocking mode. In blocking mode (the default), `axlFormDisplay` blocks until the user closes the form. Blocking is an easier programming mode but might not be appropriate for your application. If the callback (*g_formAction*) is *nil*, then `axlFormDisplay` ignores *g_nonBlock*, and the form runs in blocking mode.

Use of blocking mode blocks the progress of the SKILL code, but does not prevent other Allegro PCB Editor events from occurring. For example, if blocked, users can start the *Add Line* command from Allegro PCB Editor menus.

g_stringOption If `t`, the form returns and accepts all values as strings. By default, it returns and accepts values in the format declared in the form file.

Value Returned

r_form *dbid* of form created.

nil No form created.

Example

See [AXL Forms: Example 1](#) on page 601.

axlFormClearMouseActive

```
axlFormClearMouseActive(  
    r_form  
)  
==> t/nil
```

Description

Clears the option to dispatch the MouseActive event on a form.

Arguments

r_form Handle for the form

Value Returned

t Option was cleared

nil r_form does not reference a valid form

axlFormClose

```
axlFormClose (
    r_form
)
⇒ t/nil
```

Description

Closes the form *r_form*. Unless the form is running without a callback handler, you must make this call to close the form. Without a registered dispatch handler, Allegro PCB Editor closes the form automatically before returning to the application from `axlFormDisplay`.

Note: `axlUIWClose` also performs the same function.

Arguments

r_form Form *dbid*.

Value Returned

t Closed the form.

nil Form was already closed.

Example

See [AXL Forms: Example 1](#) on page 601:

```
(case form->curField
  ("done"
   (axlFormClose form)
   (axlCancelEnterFun)
   (_extract)
   t))
```

axlFormDisplay

```
axlFormDisplay(  
    r_form  
)  
⇒ t/nil
```

Description

Displays the form *r_form* already created by `axlFormCreate`. For superior display appearance, set all the field values of the form before calling this function. A form in blocking mode blocks until the user closes the form.

If a form is already displayed, this function simply exposes it.

Arguments

r_form Form *dbid*.

Value Returned

t Successfully opened or exposed the form.

nil Failed to open or expose the form.

Example

See [AXL Forms: Example 1](#) on page 601.

```
axlFormDisplay( form)
```

axlFormBuildPopup

```
axlFormBuildPopup(  
    r_form  
    t_field  
    l_pairs  
)  
⇒ t/nil
```

Description

This provides the ability to dynamically change popups of fields that have them. These fields are enum (or pop-up) and other fields that have a popup icon. Buttons, optionally, may also have a popup if they have a right arrow. Attempting this call on a field without a popup is an error.

Arguments

<i>r_form</i>	a form handle
<i>t_field</i>	Name of form field.
<i>l_pairs</i>	May be one of four formats where each element is a single popup entry. A maximum of 256 popup entries are allowed. <ul style="list-style-type: none">■ normal<ul style="list-style-type: none">((t_display t_dispatch) ...)■ alternative normal<ul style="list-style-type: none">(t_displayNdispatch ...)■ for enum field types<ul style="list-style-type: none">((t_display x_dispatch) ...)■<ul style="list-style-type: none">((t_display t_dispatch/x_dispatch options) ...)

Options can be 1 or 2 additional list options that are S_color/x_color for enum field types with color; bold or underline for bold or underlined items.

Note: All entries in an *l_pairs* argument must be the same type of format. That is, you cannot have a list containing, for example, both display/dispatch strings and display/enum types, or display/dispatch and single-string entries.

Allegro SKILL Reference

Form Interface Functions

Must be one of the formats described. Each list object defines a single popup entry.

Table 11-3 `I_pairs` Format Options

Option	Description	Example
List of lists of string pairs	The first member of each string pair list is the display value—the string displayed in the pop-up. The second member of each string pair is the dispatch value—the string value returned as <i>form->curValue</i> when the user selects that pop-up entry.	(list (list "MyPop A" "myvalue_a") list("MyPop B" "myvalue_b"))
List of lists of pairs	List of lists of pairs where the first member of each pair is a string giving the display value, and the second member is an integer that is the dispatch value, returned as <i>form - curValue</i> when the user selects that pop-up entry. You can use the return value as an index into an array.	(list (list "MyPop A" 5) list("MyPop B" 7))
List of strings	Uses each string both for display value and the return value.	(list "MyPop A" "MyPop B")

Allegro SKILL Reference

Form Interface Functions

Table 11-3 `I_pairs` Format Options

Option	Description	Example
Optional field	<p>Specifies a color swatch. This is currently only supported by ENUM field types (it is ignored by other field types). With an ENUM you need to add OPTIONS ownerdrawn in the form file for the FIELD in question to see the color swatch in the popup. You can use either pre-defined color names (see <code>axlColorDoc</code>) or Allegro board colors (see <code>axlLayerGet</code>).</p>	<p>You can't mix this color type in a single popup.</p> <pre>'(("Green" 1 green) ("Red" 2 red) ("Yellow" 3 yellow))</pre> <p>If instead of a color or Allegro color number, you provide a nil, then that popup entry will not have a color swatch.</p> <pre>'(("None" 0 nil) ("Green" 1 green) ("Red" 2 red) ("Yellow" 3 yellow))</pre> <p>Font type of bold or underline can be specified via:</p> <pre>'(("Top" "top" bold) ("Gnd" "gnd" underline) ("Bottom" "btm"))</pre> <p>When font type is combined with color it looks like:</p> <pre>'(("Top" "top" "Green" bold) ("Gnd" "gnd" "Red" underline))</pre>

Notes:

- Allows a maximum of 1000 pop-up entries in one pop-up.
- If creating a dynamic popup (entries created under program control) a dummy entry must exist in the form file or build popup will fail. Example:
`<popupname> """".`
- The field name is actually a search mechanism. We first search the fields for the field name with a popup and then search the popup names. Since the only way to change grid

Allegro SKILL Reference

Form Interface Functions

column or cell based popups is by popup name you may run into failures if that popup name has the same name as another field in the form.

Value Returned

t	Field set.
nil	Field not set.

Example

See [AXL Forms: Example 2](#) on page 605.

axlFormGetField

```
axlFormGetField(  
    r_form  
    t_field  
)  
⇒ g_value/nil
```

Description

Gets the value of *t_field* in the open form *r_form*. The value is a string if *g_stringOption* was set in `axlFormCreate`. Otherwise the value is in the field type declared in the form file.

Arguments

r_form Form *dbid*.

t_field Name of field.

Value Returned

g_value Current value of the field.

nil Field does not exist, or false if boolean field such as check box or radio button.

Example

1. Load the example code given in [AXL Forms: Example 1](#) on page 601.
2. Enter the command `myExtract()` on the SKILL command line.


The command displays the **Extract Selector** form, listing all available extract view files.

3. Select any file in the list, or type a name into the *View File* field.

Allegro SKILL Reference

Form Interface Functions

allegro2rlb_view.txt is entered.



```
axlFormGetField( form "view_file")
  ⇒ "allegro2rlb_view.txt"
```

Examines the value of "*view_file*".

axlFormGridSelected

```
axlFormGridSelected(  
    r_form  
    t_field  
) -> lx_selected/nil
```

Description

This returns the selected item in a multi-select grid control. This should only be used if grid is running with the multi-select row option.

Arguments

r_form	standard form handle
t_field	standard field name

Value Returned

Returns list of selected items in a multi-select grid or nil if not the correct control.

See Also

[axlFormGridNewCell](#)

Examples

See fgrid.il in <CDSROOT>/share pcb/examples/skill/form/grid

Pseudo code:

```
axlFormGridEvents(fg "grid" 'mrowselect)  
;; select items  
selected = axlFormGridSelected(fg "grid")  
; if form select rows 5,6,7 (click on 5, then Shift click on 7)  
;; select items  
selected = axlFormGridSelected(fg "grid")  
-> (5 6 7)
```

axlFormGridSelectedCnt

```
axlFormGridSelectedCnt(  
    r_form  
    t_field  
) -> x_cnt/nil
```

Description

This returns the count of rows selected in a multi-select grid control. This should only be used if grid is running with the multi-select row option.

Argument

<i>r_form</i>	standard form handle
<i>t_field</i>	standard field name

Value Returned

Returns count of selected items or `nil` if wrong type of control

See Also

[axlFormGridNewCell](#)

Examples

See `fgrid.il` in `<CDSROOT>/share pcb/examples/skill/form/grid`

Pseudo code:

```
axlFormGridEvents(fg "grid" 'mrowselect)  
; if form select rows all rows (Ctrl-A in grid)  
;; select items  
selected = axlFormGridSelectedCnt(fg "grid")  
-> 16
```

axlFormGridSetSelectRows

```
axlFormGridSetSelectRows (
    r_form
    t_field
    x_min
    x_max
    g_option
) -> x_cnt/nil
```

Description

This allows setting, clearing or toggling of selection state for a grid in multi-select row mode.

Arguments

<i>r_form</i>	standard form handle
<i>t_field</i>	standard field name
<i>x_min</i>	min row number
<i>x_max</i>	max row number
<i>g_option</i>	what to do t – set row as selected nil – clear row as selected 'toggle – toggle selected state of row

Value Returned

t if succeeded, *nil* if not a grid field or not in multi-row select mode

See Also

[axlFormGridNewCell](#)

Examples

See `fgrid.il` in `<CDSROOT>/share pcb/examples/skill/form/grid`

Allegro SKILL Reference

Form Interface Functions

Pseudo code:

```
axlFormGridEvents(fg "grid" 'mrowselect)  
■ set row 4 as selected  
  axlFormGridSetSelectRows(fg "grid" 4 4 t)  
■ clear rows 4 thru 8 being selected  
  axlFormGridSetSelectRows(fg "grid" 4 8 t)  
■ clear all rows  
  axlFormGridSetSelectRows(fg "grid" -1 -1 nil)  
■ toggle state of row 1  
  axlFormGridSetSelectRows(fg "grid" 1 1 'toggle)
```

axlFormListDeleteAll

```
axlFormListDeleteAll(  
    r_form  
    t_field  
)  
⇒ t/nil
```

Description

Deletes all the items from the form list field, *t_field*. Use `axlFormListDeleteAll` to clear an entire list field to update it using `axlFormSetField`, then display it using `axlFormSetField` on the field with a `nil` field value.

Arguments

r_form Form *dbid*.

t_field Name of field.

Value Returned

t All items deleted properly.

nil All items not deleted.

Examples

In this example you do the following:

1. Use the `axlFormCreate` examples to create and display the Extract Selector dialog box shown in [Figure 11-1](#) on page 647.
2. On the SKILL command line, enter:

```
axlFormListDeleteAll(form "file_list")  
==> nil
```

The list is removed from the dialog box as shown in [Figure 11-2](#) on page 647.

3. On the SKILL command line, enter:

```
axlFormSetField(form "file_list" "fu")
```

Allegro SKILL Reference

Form Interface Functions

```
axlFormSetField(form "file_list" "bar")
axlFormSetField(form "file_list" nil)
==> t
```

The Extract Selector dialog box is displayed with new list as shown in [Figure 11-3](#) on page 648.

Figure 11-1 Extract Selector Dialog Box






Figure 11-2 Extract Selector Dialog Box - List removed



Allegro SKILL Reference

Form Interface Functions

Figure 11-3 The Extract Selector dialog box - Displayed with a new list



axlFormListSelect

```
axlFormListSelect(  
    r_form  
    t_field  
    t_listItem/nil  
)  
⇒ t/nil
```

Description

Highlights, and if not visible in the list, shows the designated item. Since Allegro PCB Editor forms permit only one item to be visible, it deselects any previously selected item. If `nil` is passed for `t_listItem` the list is reset to top and the selected list item is deselected.

Arguments

<code>r_form</code>	Form id
<code>t_field</code>	Name of field.
<code>t_listItem/nil</code>	String of item in the list. Send <code>nil</code> to deselect any selected item and set list back to top.

Value Returned

<code>t</code>	Highlights item. Arguments are valid.
<code>nil</code>	Arguments are invalid.

axlFormSetEventAction

```
axlFormSetEventAction(  
    r_form  
    g_callback  
) -> t/nil
```

Description

This function allows the user to register a callback function to be called whenever the user changes to a new active cell in the form. The callback registered during axlFormCreate dispatches events only when the user modifies a field value on the form (on exit from the field). This function allows the caller to receive an event when a field is first entered.

Arguments

<i>r_form</i>	Form <i>dbid</i>
<i>g_callback</i>	Specifies the SKILL command(s) (callback(s)) to be executed whenever a new field is activated. The setting can be one of two formats: <i>t_callback</i> : the string representation of the SKILL command(s) to be executed <i>s_callback</i> : the symbol of the SKILL function to be called (the function is passed the <i>r_form</i> returned from axlFormCreate as its only parameter).

See Also

[axlFormBNFDoc](#) and [axlFormCreate](#)

Value Returned

<i>t</i>	Field set to desired value.
<i>nil</i>	Field not set to the desired value due to invalid arguments.

Allegro SKILL Reference

Form Interface Functions

Example

```
form = axlFormCreate( MyForm  
    "extract_selector.form"  ' ("E"  "OUTER")  
    '_formAction t)  
axlFormSetEventAction( form '_formEventAction)
```

axlFormSetField

```
axlFormSetField(  
    r_form  
    t_field  
    g_value/nil  
)  
⇒ t/nil
```

Description

Sets *t_field* to value *g_value* in open form *r_form*. Must pass the correct type, matching the entry in the form value or string type. Value type is dependent upon type of field type. For a complete discussion of field types, see the discussion at the front of this section.

Special notes for certain controls:

■ LIST TYPE

Value may be a string, integer or real. Items are converted to strings before being displayed. A *nil* is needed to display the list.

Alternatively, value may be a list of strings. This results in better performance when you have many items to display.

■ COLOR TYPE

g_value parameter may have several types:

<i>s_colorSymbol</i>	Set field to predefined color
<i>x_number</i>	Set field to product color
<i>t</i> or <i>nil</i>	Depress or raise field
<i>l_both</i>	A list allows setting both check and value; pass a list of the color set

s_colorSymbol may be black, white, red, green, yellow.

x_number is an integer between 1 and 24 with 0 being background.

■ CHECKBOX

The values that unset the checkbox are: *nil*, 0, "nil", "false" and "no". All other values set the checkbox.

Arguments

<i>r_form</i>	Form <i>dbid</i> .
<i>t_field</i>	Name of field. Field name is a string or symbol.
<i>g_value</i>	Desired value of field. may be a string, boolean, integer or floating point number or a list; function of field type.

Value Returned

<i>t</i>	Field set to desired value.
<i>nil</i>	Field not set to the desired value due to invalid arguments.

Examples

See [AXL Forms: Example 1](#) on page 601.

```
axlFormSetField( form "file_list" fileName)
```

List Field (field is named "list")

```
; display 3 items in list
axlFormSetField(fw, "list", "a")
axlFormSetField(fw, "list", "b")
axlFormSetField(fw, "list", "c")
; nil required first time list is displayed
axlFormSetField(fw, "list", nil)

; display 3 items in list - alternative
axlFormSetField(fw, "list", '("a" "b" "c"))
```

Color field (field is named "color")

```
; sets the color field to pre-defined color "red"
axlFormSetField(fw, "color", `red)
; sets the color field to product color 1
axlFormSetField(fw, "color", 1)
; visually depresses the color field if not greyed
```

Allegro SKILL Reference

Form Interface Functions

```
axlFormSetField(fw, "color", t)
;; visually depresses the color field and set to
;;      pre-defined green color
axlFormSetField(fw, "color", '(green t))
```

Tab field (field is named "tab")

```
; puts the tab on top
axlformSetField(fw, "tab", nil)
```

axlFormSetInfo

```
axlFormSetInfo(  
    r_form  
    t_field  
    t_value  
)  
⇒ t/nil
```

Description

Sets info *t_field* to value *t_value* in open form *r_form*. Unlike `axlFormSet`, user cannot change an info field.

Note: You can also use `axlFormSetField` for this function.

Arguments

<i>r_form</i>	Form <i>dbid</i> .
<i>t_field</i>	Name of field.
<i>t_value</i>	Desired value of field.

Value Returned

<i>t</i>	Field was set to desired value.
<i>nil</i>	Field not set to desired value due to invalid arguments.

Example

See the use of `axlFormSetField` in the [“AXL Forms: Example 1”](#) on page 601.

```
axlFormSetInfo( form "file_list" fileName)
```

axlFormSetMouseActive

```
axlFormSetMouseActive(  
    r_form  
)  
==> t/nil
```

Description

Sets the option to dispatch the MouseActive event on a form.

Arguments

r_form Handle for the form

Value Returned

t Option was set

nil *r_form* does not reference a valid form

axlFormTest

```
axlFormTest(  
    t_formName  
) r_form/nil
```

Description

This is a development function for test purposes. Given a form file name this opens a form file to check for placement of controls. If form uses standard button names (for example, *ok*, *done*, *close*, *cancel*), you can close it by clicking the button. Otherwise, use the window control. If form is currently open, exposes form and returns.

Arguments

t_formName Name of form.

Value Returned

Form handle if successfully opens.

Example

Open Allegro PCB Editor drawing parameter form:

```
axlFormTest("status")
```

axlFormRestoreField

```
axlFormRestoreField(  
    r_form  
    t_field  
)  
⇒ t/nil
```

Description

Restores the *t_field* in the open form *r_form* to its previous value. The previous value is only from the last user change and not from the form set field functions. This is only useful in the *form callback* function.

Use in the *form* callback to restore the previous value when you detect the user has entered an illegal value in the field.

Arguments

r_form Form *dbid*.

t_field Name of field.

Value Returned

t Field restored.

nil Field not restored and may not exist.

Example

See “[AXL Forms: Example 1](#)” on page 601 where the callback function checks that the user has entered a filename that is on the list of available extract view filenames. If the user-entered value is not on the list, then the program calls `axlFormRestoreField` to restore the field to its previous value.

```
(case form->curField
  ("view_file"
    (if form->curValue
      (progn
        ; Accept user input only if on list
        if(member( form->curValue fileList)
          then axlFormSetField( form
            "view_file" form->curValue)
          else axlFormRestoreField(
            form "view_file")))))
  t)
```

axlFormTitle

```
axlFormTitle(  
    r_form  
    t_title  
)  
⇒ t/nil
```

Description

Overrides title of the form.

Arguments

<i>r_form</i>	Form <i>dbid</i> .
<i>t_title</i>	String to be used for new form title

Value Returned

<i>t</i>	Changed form title.
<i>nil</i>	No form title changed.

Example

See “[AXL Forms: Example 1](#)” on page 601.

```
axlFormTitle( form "Extract Selector")
```

axlIsFormType

```
axlIsFormType(  
    g_form  
)  
⇒ t/nil
```

Description

Tests if argument *g_form* is a form *dbid*.

Arguments

g_form *dbid* of object to test.

Value Returned

t *r_form* is the *dbid* of a form.

nil *r_form* is not the *dbid* of a form.

Example

```
form = axlFormCreate( (gensym)  
    "extract_selector.form" ' ("E" "OUTER")  
    ' formAction t)  
if( axlIsFormType(form)  
    then (print "Created form successfully.")  
    else (print "Error! Could not create form.))
```

Checks that the form you create is truly a form.

axlFormSetFieldVisible

```
axlFormSetFieldVisible(  
    r_form  
    t_field  
    x_value  
)  
⇒ t/nil
```

Description

Sets a form field to visible or invisible.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	Form field name (string).
<i>x_value</i>	1 - set field visible or 0 - Set field invisible

Value Returned

t	Form field set visible.
nil	Form field set invisible.

axlFormIsFieldVisible

```
axlFormIsFieldVisible(  
    r_form  
    t_field  
)  
⇒ t/nil
```

Description

Determines whether a form field is visible.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	Form field name (string).

Value Returned

t	Form field is visible.
nil	Form field is not visible.

Callback Procedure: formCallback

```
formCallback(  
    [r_form]  
)  
⇒ t
```

Description

This is not a function but documents the callback interface for form interaction between a user and SKILL code. The SKILL programmer provides this function.

When the user changes a field in a form, the Allegro PCB Editor form processor calls the procedure you specified as the *g_formAction* argument in `axlFormCreate` when you created that form. The form attribute *curField* specifies the name of the field that changed. The form attribute *curValue* specifies the current value of the field (after the user changed it). If you set *g_stringOption* to `t` in your call to `axlFormCreate` when you created that form, then *curValue* is a string. If *g_stringOption* was `nil` (the default), then *curValue* is the type you specified for that field in the form file.

Note: The term `formCallback` used in the title of this callback procedure description is a dummy name. The callback function name must match the name or symbol name you used as the *g_formAction* argument in `axlFormCreate` when you created the form.

If you specify the callback name (*g_formAction*) as a string in your call to `axlFormCreate`, SKILL calls that function with no arguments. If you specify *g_formAction* as a symbol, then SKILL calls that function with the form handle as its single argument.

The callback must call `axlFormClose` to close the form and to continue in the main application code if form mode is blocking.

All form information is provided by the *r_form* argument which is a form data type. Applications can extend the data stored on this type by adding their own attributes. Please capitalize the first letter of the attribute name to avoid conflicts with future additions by Cadence to this structure. [Table 11-4 on page 665](#) and [Table 11-5 on page 667](#) show the available field types and how they impact the *r_form* data type.

[Table 11-4 on page 665](#) describes Form Field Types using the following:

Type	What the user calls the field
Keyword	What the form file calls the field

Allegro SKILL Reference

Form Interface Functions

curValue	Data type seen in the form dispatch and axlFormGetField. See Callback for more information.
curValueInt	Additional information for certain field types that can be mapped to integers.

Table 11-4 Form Field Types

Type	Keyword	curValue	curValueInt
Button	MENUBUTTON	dispatch action only (t)	1
Check Box	CHECKLIST	t/nil	0 or 1
Radio Button	CHECKLIST	t/nil	0 or 1
Long (integer)	INTFILLIN	integer number	Integer
Real (float)	REALFILLIN	float number	n/a
String	STRFILLIN	string	n/a
Enum (popup)	ENUMSET	string	Possible integer ¹
List	LIST	string	Offset from start of list (0 = first entry).
Color well	COLOR	t/nil	1 or 0
Tab	TABSET/TAB	string or t	n/a or 1/0
Tree	TREEVIEW	string	see axlFormTreeViewSet
Text	INFO	n/a	n/a
Graphics	THUMBNAIL	n/a	n/a
GRID	GRID	see Using Grids on page 593	

¹. Integer if the dispatch value of the pop-up is an integer.

Notes:

- What distinguishes between a radio button and a check box is that radio buttons are a group of boxes where only one can be set. To relate several check boxes as radio buttons, supply the same label name as the third field (groupLabel) in the form file description:

```
CHECKLIST <fieldLabel> <groupLabel>
```

Allegro SKILL Reference

Form Interface Functions

When a user sets a radio button, the button being unset will dispatch to the application's callback with a value of nil.

- Enum will only set curValueInt on dispatch when their dispatch value of their popup uses an integer. Otherwise this field is nil.
- Tabs can dispatch in two methods:
 - Default when a tab is selected, your dispatcher receives the tab name in the curField and curValue is t.
 - If "OPTIONS tabsetDispatch" is set in the TABSET of the form file, then when a tab is selected your application dispatcher receives the TABSET as the curField and the curValue being the name of the TAB that was selected.
- INFO fields can be static where the text is declared in the form file or dynamic where you can set the text via the application at run-time. To achieve dynamic access, enter the following in the form file:

```
TEXT "<optional initial text>"  
INFO <fieldLabel>  
... reset of TEXT section ...
```

- Thumbnails support the following methods:
 - static bitmap declared via the form file
 - bitmaps that can be changed by the application at run-time
 - basic drawing canvas -- see [Chapter 12, “Simple Graphics Drawing Functions”](#)
- Buttons are stateless. The application cannot set the button to the depressed state. You can only use axlFormSetField to change the text in the button. Several button fieldLabels are reserved. Use them only as described:

done or OK	Do action and close the form.
cancel	Cancel changes and close the form.
print	Print the form -- do not use.
help	Call cdsdoc for help about the form -- do not use.

Allegro SKILL Reference

Form Interface Functions

Table 11-5 Form Attributes

Attribute Name	Set?	Type*	Description
<i>curField</i>	no	string	Name of form field just changed
<i>curValue</i>	no	See -->	Depends on value of <i>curField</i> (string, int, float, boolean)
<i>curValueInt</i>	no	See -->	Depends on value of <i>curField</i> field
<i>doneState</i>	no	int	0 = action; 1 = done; 2 = cancel; 3 = abort
<i>form</i>	no	string	Name of this form
<i>isChanged</i>	no	t/nil	t = user has changed one or more fields in form.
<i>isValueString</i>	no	t/nil	t = all field values are strings nil = one or more fields are not strings
<i>objType</i>	no	string	Type of object, in this case "form"
<i>type</i>	no	string	Form type, always "fixed"
<i>fields</i>	no	list of strings	All fields in the form.
<i>infos</i>	no	list of strings	All info fields in the form.
<i>event</i>	no	symbol	Grid control only -- see Using Grids on page 593
<i>row</i>	no	integer	Grid control only
<i>col</i>	no	integer	Grid control only
<i>treeViewSelState</i>	no	integer	Tree control only

* You can add your own attribute types to the form type. It is recommended you capitalize the first letter of the name to avoid conflict with future Allegro PCB Editor releases.

Notes:

- The *doneState* shows 0 for most actions. Selecting a *Done* or *OK* button sets the done state. Selecting a *Cancel* button sets the cancel state. With the done or cancel state set, you use `axlFormClose` to close the form. Setting the abort state closes the form, even if you do not issue an `axlFormClose` command.

- Data type is dependant on the field type. See [Table 11-4](#) on page 665 for more information on Form Field Types.
- The infos list is different from the fields list. The infos list comprises static text strings that the program can change at run-time. The fields list comprises all other labels which can be changed by the user including even those on buttons and tabs, greyed and hidden fields.

Arguments

r_form Form *dbid*.

Value Returned

t Always returns *t*.

Example

See [axlFormCreate](#) on page 629 and [axlFormBuildPopup](#) on page 636 for examples.

axlFormAutoSize

```
axlFormAutoSize(  
    r_form  
)  
⇒ t/nil
```

Description

Resizes a form to fit its controls. Recalculates the required width and height and resizes the form based on the current visibility of the form's fields.

Arguments

r_form Form handle.

t_field Form field name (string).

Value Returned

t Form resized.

nil *r_form* does not reference a valid form.

axlFormColorize

```
axlFormColorize(  
    o_form  
    t_field  
    g_option  
    g_color  
)  
⇒ t/nil
```

Description

Allows the override of background and/or text color of a control. Only the following controls are supported:

- STRFILLIN
- READFILLIN
- LONGFILLIN
- INTSLIDE BAR
- ENUMSET
- CHECKLIST
- TEXT or INFO

These names appear in the form BNF file syntax.

These controls use the default system colors:

'background Set background of control

'text Set text of control

The *g_color* argument is either a color symbol (for non DB options), a number for DB color options, or *nil* (for restoring to system default). See [Accessing Allegro PCB Editor Colors with AXL-SKILL](#) on page 69 for the allowed values.

Other form controls support color as a fundamental part of their interface. These are *COLOR* (See [Accessing Allegro PCB Editor Colors with AXL-SKILL](#) on page 69) and *GRID* (See [Using Grids](#) on page 593) controls.



Please note the following restrictions:

- Setting the same or close text and background colors can cause readability issues.
- Setting the background of CHECKLIST controls is not supported on UNIX.
- Dialog boxes with popups do not correctly show color.

Arguments

<i>o_form</i>	Form handle.
<i>t_field</i>	Field name.
<i>g_option</i>	Option (see above)
<i>g_color</i>	Color (see <code>axlColorDoc</code>) or nil

Value Returned

<i>t</i>	Color changed.
<i>nil</i>	Error due to an incorrect argument.

Example 1

You can find an example in `axlform.il`.

```
axlFormColorize(f1s "string" 'text 'red)
```

Sets text of string control to red.

Example 2

```
axlFormColorize(f1s "string" 'background 'green)
```

Sets background of string control to green.

Allegro SKILL Reference

Form Interface Functions

Example 3

```
axlFormColorize(f1s "string" 'text nil)  
axlFormColorize(f1s "string" 'background nil)
```

Sets control back to default.

Example 4

```
axlFormColorize(f1s "string" 'background 1)
```

Sets control background to Allegro PCB Editor database color 1

axlFormGetActiveField

```
axlFormGetActiveField(  
    r_form  
)  
⇒ t/nil
```

Description

Gets the form's active field.

Arguments

r_form Form's *dbid*.

t_field Form field name (string).

Value Returned

t_field Active field name.

nil No active field.

axlFormGridBatch

```
axlFormGridBatch(  
    r_cell  
)  
⇒ t/nil
```

Description

Always used with `axlFormGridSetBatch`. Sets many grid cells efficiently.

Arguments

r_cell	Obtained from <code>axlFormGridNewCell</code> .
--------	---

Value Returned

t	Grid cells set.
---	-----------------

nil	No grid cells set.
-----	--------------------

axlFormGridCancelPopup

```
axlFormGridCancelPopup (
  r_form
  t_field
)
⇒ t/nil
```

Description

After any change to grid content, the application must tell the grid that the changes are complete. The grid then updates itself to the user. Changes include: adding or deleting columns and changing cells.

Arguments

r_form Form handle.

t_field Field name.

Value Returned

t Success.

nil Failure due to incorrect arguments.

axlFormGridDeleteRows

```
axlFormGridDeleteRows (
  r_form
  t_field
  x_row
  x_number
)
⇒ t/nil
```

Description

Deletes *x_number* rows at *x_row* number. *x_row=,n>*, *x_number=-1* deletes the entire grid. *x_row=-1*, *x_number-1* may be used to delete the last row in the grid.

Arguments

<i>r_form</i>	Form handle.
<i>t_field</i>	Field name.
<i>x_row</i>	Row number to start delete.
<i>x_number</i>	Number of rows to delete.

Value Returned

<i>t</i>	Rows deleted.
<i>nil</i>	No rows deleted.

axlFormGridEvents

```
axlFormGridEvents (
  r_form
  t_field
  s_event/(s_event1 s_event2 ...)
)
⇒ t/nil
```

Description

Sets user events of interest. It is critical for your application to only set the events that you actually process since enabled events are scripted.

Grid events include the following:

'rowselect	Puts grid into row select mode. This is mutually exclusive with cellselect.
'mrowselect	Puts grid into multi-row select mode. This is mutually exclusive with cellselect. Use axlFormGridSelected to determine what rows are selected.
'cellselect	Puts grid into cell select mode. This is mutually exclusive with rowselect and mrowselect.
'change	Enables cell change events. Use this option if you have check box and text box type cells.
'rightpopup	Enables right mouse button popup. A popup must have been specified in the form file.
'rightpopupPre	Enables callback to application before a right mouse popup is displayed. This allows the user to modify the popup shown. Also requires 'rightpopup be set.
'leftpopupPre	Enables callback to application before a left mouse popup is displayed. This allows the user to modify the popup shown. Left mouse popups are only present in the drop down cell type.

By default, the grid body has `rowselect` enabled while the headers have nothing enabled.

Allegro SKILL Reference

Form Interface Functions

The form callback structure (*r_form*) has the following new attributes that are only applicable for grid field types:

Event	Row	Col	<Data Fields>
rowselect	<row>	1	No
cellselect	<row>	<col>	Yes (1)
change	<row>	<col>	Yes (1)
rightpopup	<row>	<col>	Yes
rightpopupPre	<row>	<col>	No (2) (3)
leftpopupPre	<row>	<col>	No (2) (3)

where:

<row> Row number (1 based)

<col> Column number (1 based)

<Data fields> Setting of the *r_form* attributes *curValue*, *curValueInt* and *isValueString*.

- Communicates the value of the data *before* the field is changed. The change event sends the value *after* the field is changed.
- Events are sent immediately before a popup is displayed so the application has the opportunity to modify it. See [axlFormGridEvents](#) on page 677 to set this and other event options.
- If using events rightpopupPre or leftpopupPre, the popup may be cancelled by calling `axlFormGridCancelPopup` when you receive one of these events.

See [Using Grids](#) on page 593 for a grid overview.

Note: Assigning events to a grid overrides the previous assignment. Therefore, Following do not work:

```
axlFormGridEvents(fw "grid 'change")
axlFormGridEvents(fw "grid 'cellselect")
```

Instead, use the following command.

```
axlFormGridEvents(fw "grid '(cellselect change) )
```

Arguments

r_form Form handle.

t_field Field name.

s_events See above.

Value Returned

t User event set.

nil No user event set.

See Also

[axlFormGridNewCell](#)

axlFormGridGetCell

```
axlFormGridGetCell(  
    r_form  
    t_field  
    r_cell  
)  
⇒ r_cell/nil
```

Description

Returns grid cell data for a given row and column. All associated data for the cell is returned.

Note: The cell value is always returned as a string except for REAL and LONG data types which are returned in their native format.

If row or cell number of 0 is used then top or side heading data is returned (if present.)

Note: For best performance, reuse the cell if accessing multiple cells.

Arguments

<i>r_form</i>	Form handle.
<i>t_field</i>	Field name.
<i>r_cell</i>	Grid cell from axlFormGridNewCell().

Value Returned

<i>r_cell</i>	Cell data.
nil	Invalid form id, field label or cell doesn't exist in the grid.

Allegro SKILL Reference

Form Interface Functions

Example

```
cell = axlFormGridNewCell()  
cell->row = 3  
cell->col = 1  
axlFormGridInsertRows(form, "grid" cell)  
printf("cell value = %L\n", cell)
```

Returns the value of cell - (1,3).

axlFormGridInsertCol

```
axlFormGridInsertCol(  
    r_form  
    t_field  
    r_formGridCol  
)  
⇒ t/nil
```

Description

Adds a column with the indicated options (*g_options*) to a grid field. The *g_options* parameter is based on the type `formGridCol`. The `formGridCol` structure has default behavior for all settings.

Note: For more information on using this function, see [Using Grids](#) on page 593 for an overview.

[Table 11-6](#) on page 682 describes the `FormGridCol` attributes.

Table 11-6 FormGridCol Attributes

Attribute	Type	Default	Description
fieldType	symbol	TEXT	Field types include: TEXT, STRING, LONG, REAL, ENUMSET, and CHECKITEM.
fieldLength	integer	16	Maximum data length.
colWidth	integer	0	Width of column.
headText	n/a	n/a	If the grid has a top heading, sets the heading text. Can also set using <code>axlFormGridSet</code> .

Alignment Types (left, right, and center) :

align	symbol	Left	Column alignment.
topAlign	symbol	Center	Column header alignment.

Allegro SKILL Reference

Form Interface Functions

Table 11-6 FormGridCol Attributes

Attribute	Type	Default	Description
scriptLabel	string	<row number>	Column scripting name. If the column entry can be edited, you can provide a name which is recorded to the script file. For fieldTypes of TEXT, this option is ignored. Case is ignored and text should not have white space or the symbol '!'.
popup	string	n/a	Name of the associated popup. May be applied to columns or cells of types ENUMSET, STRING, LONG, or REAL.
decimals	integer	n/a	Number of decimal places.
max	integer or float	n/a	Maximum value.
min	integer or float	n/a	Minimum value.

Note: Accuracy support is only applicable for LONG and REAL column types. If used, you must set both min and max values.

Note: You can add columns to a grid field only at creation time. Once rows have been added to a grid, no new columns may be added. This is true, even if you delete all rows in the grid.

Arguments

- r_form* Form handle.
- t_field* Field name.
- r_formGridCol* Instance of type `formGridCol`.

Value Returned

- t* Column added.

Allegro SKILL Reference

Form Interface Functions

nil Failure due to a nonexistent form or field, field not of type GRID, errors in the *g_options* defstruct, or grid already had a row added.

Examples

For a complete grid programming example, see: <cdsroot>/share pcb/examples/skill/ui.

Example 1

```
options = make_formGridCol
options->fieldType = 'TEXT
options->align = 'center
axlFormGridInsertCol(r_form "grid" options)
```

Adds the first column of type TEXT (non-editable) with center alignment.

Example 2

```
options->fieldType = 'ENUMSET
options->popup = "grid2nd"
options->colWidth = 10
options->scriptLabel = "class"
axlFormGridInsertCol (r_form "grid" options)
```

Adds the second column of type ENUM (non-editable) with column width of 10 and center alignment, assuming that the form file has a popup definition of *grid2nd*.

axlIsGridCellType

```
axlIsGridCellType(  
  r_cell  
)  
⇒ t/nil
```

Description

Tests the passed symbol to see if its user type is of the form "grid cell".

Arguments

r_cell Symbol

Value Returned

t Symbol is of the type form grid cell.

nil Symbol is not of the type form grid cell.

axlFormGridInsertRows

```
axlFormGridInsertRows (
  r_form
  t_field
  x_row
  x_number
)
⇒ t/nil
```

Description

Inserts *x_number* rows at *x_row* number location. Rows are inserted empty. A -1 may be used as *x_row* to add to end of the grid. Since grids are 1 based, a 1 inserts at the top of the grid.

Arguments

<i>r_form</i>	Form handle.
<i>t_field</i>	Field name.
<i>x_row</i>	Row number of insertion point.
<i>x_number</i>	Quantity of rows to add.

Value Returned

<i>t</i>	One or more rows inserted.
<i>nil</i>	No rows inserted.

axlFormGridNewCell

```
axlFormGridNewCell(  
    )  
    ⇒ r_cell
```

Description

Creates a new instance of *r_cell* which is required as input to [axlFormGridBatch](#) or [axlFormSetField](#) for form grid controls. As a convenience, the consuming APIs do not modify the cell attributes. You need not reset all attributes between API calls.

See [axlFormGridDoc](#) for grid overview.

See [axlFormGridSetBatch](#) on page 690 for a complete description of cell attributes.

Arguments

None.

Value Returned

<i>r_cell</i>	New list gridcell handle.
---------------	---------------------------

See Also

[axlIsGridCellType](#), [axlFormGridInsertRows](#), [axlFormGridDeleteRows](#),
[axlFormGridCancelPopup](#), [axlFormGridEvents](#), [axlFormGridOptions](#), [axlFormGridSetBatch](#),
[axlFormGridBatch](#), [axlFormGridGetCell](#), [axlFormGridReset](#), [axlFormGridSelected](#),
[axlFormGridSelectedCnt](#), [axlFormGridSetSelectRows](#)

axlFormGridReset

```
axlFormGridReset(  
    r_form  
    t_field  
)  
⇒ t/nil
```

Description

Resets grid to its unloaded state. Application should then set the columns, then rows, to the same state as when they initially loaded the windows.

Changes the number of columns after the grid has already been initialized.

Arguments

r_form Form handle.

t_field Field name.

Value Returned

t Grid reset.

nil Grid not reset.

Example

For a programming example, see `fgrid.il` in `<cdsroot>/share pcb/examples/skill/`

Pseudo code:

```
axlFormGridReset(fg "grid")  
initCols()  
initRows()  
axlFormGridUpdate(fg "grid")
```

axlFormGridSetBatch

```
axlFormGridSetBatch (
  r_form
  t_field
  s_callback
  g_pvtData
)
⇒ t/nil
```

Description

Changes grid cells much faster than `axlFormSetField` when changing multiple cells. Both APIs require a grid cell data type (`axlFormGridNewCell`).

Grid performs single callback using `s_callback` to populate the grid. You must call `axlFormGridBatch` in the callback in order to update grid cells.

See the programming example, `grid.il` at `<cdsroot>/share/pcb/examples/skill/ui`. Create rows and columns before calling this batch API.

Within the callback, use only `axlFormNewCell` and `axlFormGridBatch` from the `axlForm` API.

After changing cells, update the display using `axlFormGridUpdate` outside of the callback.

Grid Cell Data Type (r_cell) Attributes

<code>x_row</code>	Row to update.
<code>x_col</code>	Column to update.
<code>g_value</code>	Value (may be string, integer, or float) if <code>nil</code> , preserve current grid setting for the cell.
<code>s_backColor</code>	Optional background color.
<code>s_textColor</code>	Optional text color.
<code>s_check</code>	Set or clear check mark for <code>CHECKITEM</code> cells. Ignored for non-check cells. Value may be <code>t</code> or <code>nil</code> .
<code>s_noEdit</code>	If cell is editable, disables edit. Ignored for <code>TEXT</code> columns since they are not editable. Current settings are preserved.

Allegro SKILL Reference

Form Interface Functions

<code>s_invisible</code>	Make cell invisible. Current cell settings are preserved by the grid.
<code>s_popup</code>	Use popup name in the form file to set this, or "" to unset. If enum, string, long, or real cell, then overrides column popup, else restores back to popup of the column. Ignored for all other cell types.
<code>t_objType</code>	Object name "r_cell" (read-only)

Note: Previous grid cell settings are overridden by values in `s_noEdit` and `s_invisible`.

Column and Row access:

Rows and columns are 1 based. To set the cell in the first column and row, you set the row and col number to 1.

You can control header and script text with reserved row and column values as follows:

(`<row>`, 0) Set side header display text.

(`<row>`, -1) Set side header scripting text.

Note: Case is ignored, and text must not contain spaces or the '!'.

(0, `<col>`) Set top header display text. You may also set the top header at column creation time using `axlFormGridInsertCol`.

(0, 0) Setting not supported.

For headers and script text, `g_value` is the only valid attribute other than `row` and `col`.

Colors available for `s_backColor` and `s_textColor`:

- nil - use system defaults for color, typically white for background and black for text
- black
- white
- red
- green
- yellow
- button - use the current button background color

Arguments

`r_form` Form handle.

`t_field` Field name.

`t_callback` Function to callback. Takes a single argument: `g_pvtData`

`g_pvtData` Private data (Pass `nil` if not applicable.)

Value Returned

`t` Grid cell changed.

`nil` No grid cell changed, or application callback returned `nil`.

axlFormGridUpdate

```
axlFormGridUpdate(  
    r_form  
    t_field  
) -> t/nil
```

Description

Unlike the form lists control you must manually notify the grid control that it must update itself. You should use this call in the following situations:

- Inserting a row or rows
- Deleting a row or rows
- Changing cell(s)

You should make the call at the end of all of changes to the grid.



Do not make this call inside the function you use with axlFormGridSetBatch. Make it after axlFormGridSetBatch returns.

Arguments

r_form Standard form handle.

t_field Standard field name.

Value Returned

Returns *t* for success, *nil* for failure.

See Also

[axlFormGridNewCell](#)

axlFormInvalidateField

```
axlFormInvalidateField(  
    r_form  
    t_field  
)  
⇒ t/nil
```

Description

Invalidates the form's field. Allows Windows to send a redraw message to the field's redraw procedure.

Use only for thumbnail fields.

Arguments

r_form Form handle.

t_field Field name.

Value Returned

t Field invalidated.

nil No field invalidated.

axlFormIsFieldEditable

```
axlFormIsFieldEditable(  
    r_form  
    t_field  
)  
⇒ t/nil
```

Description

Checks whether the given form field is editable. If the field is editable, *t* is returned. If the field is greyed, then *nil* is returned.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	Field name.

Value Returned

<i>t</i>	Field is editable.
<i>nil</i>	Field is greyed, or not editable.

axlFormListAddItem

```
axlFormListAddItem(  
    r_form  
    t_field  
    t_listItem/lt_listItems/nil  
    g_index  
)  
⇒ t/nil
```

Description

Adds an item to a list at position *x*. To add many items efficiently, pass the items as a list.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	Field name.
<i>t_listItem</i>	String of items in the list. If adding to list for the first time, you must send a <code>nil</code> to display the list.
<i>lt_listItems</i>	List of strings to add.
<i>g_index</i>	0 = First item in the list. -1 = Last item in the list.

Value Returned

<i>t</i>	One or more items added to list.
<i>nil</i>	No items added to list due to incorrect arguments.

Example 1

```
axlFormListAddItem(f1, "list" "a" -1)  
axlFormListAddItem(f1, "list" "b" -1)  
axlFormListAddItem(f1, "list" "c" -1)  
; since first time, send a nil to display the list  
axlFormListAddItem(f1, "list" nil, -1)
```

Adds three items to the end of a list.

Example 2

```
axlFormListAddItem(f1, "list" ' ("a" "b" "c"), -1)
```

Adds three items to the end of a list (alternate method).

axlFormListDeleteItem

```
axlFormListDeleteItem(  
    r_form  
    t_field  
    t_listItem/x_index/lt_listItem/nil  
)  
⇒ t/x_index/nil
```

Description

Deletes indicated item in the list. You can delete by a string or by position. Deleting by string works best if all items are unique. Position can be problematic if you have the list sort the items that you add to it.

To quickly delete multiple items, call this interface with a list of items.

Note: Delete by list only supports a list of *strings*.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	Field name.
<i>x_index</i>	Position of the item to be deleted. 0 is the first item in the list, -1 is the last item in the list.
<i>t_listItem</i>	String of item to delete.
<i>lt_listItems</i>	List of items to delete.
<i>nil</i>	Deletes the last item.

Allegro SKILL Reference

Form Interface Functions

Value Returned

<code>x_index</code>	If using strings (<code>t_listItem</code>) to delete items, returns the index of strings deleted. Useful for allowing the code to automatically select the next item in the list.
<code>t</code>	If deleting by index (<code>x_index</code>), it returns <code>t</code> if successful in deleting the item.
<code>nil</code>	Failed to delete the item.

axlFormListGetItem

```
axlFormListGetItem(  
    r_form  
    t_field  
    x_index  
)  
⇒ t_listItem/nil
```

Description

Returns the item in the list at index (*x_index*.) Lists start at index 0. If -1 is passed as an index, returns the last item in the list.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	Field name.
<i>x_index</i>	Offset into the list. 0 = First item in the list. -1 =Last item in the list.

Value Returned

<i>t_listItem</i>	String of item in the list.
nil	Index not valid, or no item at that index.

axlFormListGetSelCount

```
axlFormListGetSelCount (
    r_form
    t_field
)
==> x_count/nil
```

Description

This only applies to a multi-select list box (OPTIONS multiselect in form file). Returns a count of number of items selected in a multi-select list box.

Arguments

r_form Form control.

t_field Name of the field.

Values Returned

nil If not a multi-list box.

x_count Number of items selected.

See Also

[axlFormListGetSelItems](#)

Example

See `axlform.il` example.

axlFormListGetSelItems

```
axlFormListGetSelItems (
  r_form
  t_field
)
==> lt_selected/nil
```

Description

This only applies to a multi-select list box (OPTIONS multiselect in form file).

For a multi-select list box returns list of strings for items selected. If no items selected or this is not appropriate for control returns nil.

Arguments

r_form Form control.

t_field Name of the field.

Value Returned

lt_selected List of strings for items selected.

nil Error or nothing selected.

See Also

[axlFormListGetSelCount](#), [axlFormListSelAll](#)

Example

See `axlform.il` example.

axlFormListOptions

```
axlFormListOptions (
  r_form
  t_field
  s_option/ (s_option1 s_option2 ... )
)
⇒ t/nil
```

Description

Sets options for a list control. The following options are supported:

'doubleClick Enable double-click selection. Passing a *nil* for an option sets default list behavior. Default is single click.

Double-click events are handled as follows:

- Receive the first click as an event with the item selected and the result is:
doubleClick = *nil*.
- Receive the second click as an event with the item selected and the result is:
doubleClick = *t*.

Suggested use model:

On first click do what would normally happen if the user clicks only once. The second click is a natural extension. For example, on a browser the first click selects the file. The second click does what the *OK* button would do: send the file to the application and close the form.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	Field name.
<i>s_option</i>	Sets option for list control. <i>nil</i> resets to default.

Value Returned

t	Options set.
nil	No options set due to incorrect arguments.

Example 1

```
axlFormListOptions(form "list" 'doubleClick)
```

Enables double-click for a list.

Example 2

```
axlFormListOptions(form "list" nil)
```

Disables double-click for a list.

axlFormListSelAll

```
axlFormListSelAll(  
    r_form  
    t_field  
    g_set  
)  
==> t/nil
```

Description

This only applies to a multi-select list box (OPTIONS multiselect in form file).

This either selects or deselects all items in list box.

Arguments

<i>r_form</i>	Form control.
<i>t_field</i>	Name of the field.
<i>g_set</i>	t to select all; nil to deselect all.

Value Returned

t if successful, nil field is not a mutli-select list box

See Also

[axlFormListGetSelItems](#)

Examples

Select all items in multi-list control; mlistfield.

```
axlFormListSelAll(fw "mlistfield" t)
```

De-Select all items in multi-list control; mlistfield.

```
axlFormListSelAll(fw "mlistfield" nil)
```

axlFormMsg

```
axlFormMsg(  
    r_form  
    t_messageLabel  
    [g_arg1 ...]  
)  
⇒ t_msg/nil
```

Description

Retrieves and prints a message defined in the form file by message label (*t_messageLabel*.) Form file allows definitions of messages using the "MESSAGE" keyword (see [Using Forms Specification Language](#) on page 579.) Use this to give a user access to message text, but no access to your SKILL code.

Messages are only printed in the status area of the form owning the message (*r_form*.) You cannot access message ids from one form file and print to another. The main window is used for forms with no status lines.

You use standard formatting and argument substitution (see `printf`) for the message.

Arguments

<i>r_form</i>	Form <i>dbid</i> .
<i>t_messageLabel</i>	Message label defined in form file by the MESSAGE keyword.
<i>g_arg1</i> ...	Substitution parameters (see <code>printf</code>)

Value Returned

<i>t_msg</i>	Message that prints.
<i>nil</i>	No message with the given name found in this form file.

Examples

```
Form file (level: 0 is info, 1 is info with no journal entry, 2 is warning, 3  
is error, and 4 is fatal.);  
MESSAGE drccount 0 "Drc Count of %d for %s"  
MESSAGE drcerrors 2 "Drc Errors"  
  
axlFormMsg(fw "drccount" 10 "spacing")  
axlFormMsg(fw "drcerrors")
```

axlFormGetFieldType

```
axlFormGetFieldType (
  r_form
  t_field
)
⇒ g_fieldType/nil
```

Description

Returns the control type for a form field. See the keywords in [Callback Procedure: formCallback](#) on page 664 for a list of supported field types.

Arguments

r_form Form *dbid*.

t_field Field name.

Value Returned

g_fieldType One of the control types.

nil Field does not exist or is not one of the types supported.

axlFormDefaultButton

```
axlFormDefaultButton(  
    r_form  
    t_field/g_mode  
)  
⇒ t/nil
```

Description

Forms normally automatically set a *default button* in a form with the `DEFAULT` section in the form file or with the `OK` and `DONE` labels. When the user hits a carriage return, the *default button* is executed.

A form can have, at most, one default button. Only a field of type `BUTTON` can have the default button attribute.

Note: If default buttons are disabled in a form, then attempts to establish a new default button are ignored. You can only change the default button if the capability in the form is enabled.

Arguments

<code>r_form</code>	Form <i>dbid</i> .
<code>t_field</code>	Field name to establish as new button default.
<code>g_mode</code>	<code>t</code> to enable the default button in the form, <code>nil</code> to disable it.

Value Returned

<code>t</code>	Default button set.
<code>nil</code>	Field does not exist.

Allegro SKILL Reference

Form Interface Functions

Example 1

```
axlFormDefaultButton(form nil)
```

Sets no default button in form.

Example 2

```
axlFormDefaultButton(form "cancel")
```

Sets the default button to be Cancel instead of the default OK.

axlFormGridOptions

```
axlFormGridOptions (
  r_form
  t_field
  s_name
  [g_value]
)
⇒ t/nil
```

Description

Miscellaneous grid options. See [Using Grids](#) on page 593 for a grid overview.

Arguments

<i>r_form</i>	Form handle.
<i>t_field</i>	Field name.
<i>s_name/g_value</i>	Supported options shown.

s_name/g_value Supported Options

`['goto x_row']` Puts the indicated row on display, scrolling the grid if necessary.

Note: -1 signifies the last row.

`['goto x_row:x_col']` Sends grid to indicated row and column.

Note: -1 signifies the last row or column.

`['select x_row']` Selects (highlights) indicated row.

`['select x_row:x_col']` Selects (highlights) indicated cell. Grid must be in cell select mode else row is selected instead of cell. See `axlFormGridEvents` for more information.

`['deselectAll']` Deselect any selected grid cells or rows.

Value Returned

t	Selected grid option performed.
nil	Selected grid option not performed.

Example 1

```
axlFormGridOption(fw, "mygrid" 'goto 10)
```

Makes row 10 visible.

Example 2

```
axlFormGridOption(fw, "mygrid" 'goto 5:2)
```

Makes row 5 column 2 visible.

Example 3

```
axlFormGridOption(fw, "mygrid" 'deselectAll)
```

Deselects anything highlighted in the grid.

axlFormSetActiveField

```
axlFormSetActiveField(  
    r_form  
    t_field  
)  
⇒ t/nil
```

Description

Makes the indicated field the active form field.

Note: If you do an `axlFormRestoreField` in your dispatch handler on the field passed to your handler, then that field remains active.

Arguments

r_form Form *dbid*.

t_field Field name.

Value Returned

t Field set active.

nil Failed to set the field active.

axlFormSetDecimal

```
axlFormSetDecimal(  
    o_form  
    g_field  
    x_decimalPlaces  
)  
⇒ t/nil
```

Description

Sets the decimal precision for real fill-in fields in the form. If *g_field* is nil, sets the precision for all real fill-in fields in the form.

Arguments

<i>o_form</i>	Form handle.
<i>g_field</i>	Field label, or nil for all fields.
<i>x_decimalPlaces</i>	Number of decimal places - must be a positive integer.

Value Returned

t	Successfully set new decimal precision.
nil	Error due to invalid arguments.

axlFormSetFieldEditable

```
axlFormSetFieldEditable(  
    r_form  
    t_field  
    g_editable  
)  
⇒ t/nil
```

Description

Sets individual form fields to editable (*t*) or greyed (*nil*).

Arguments

<i>r_form</i>	Form <i>dbid</i> .
<i>t_field</i>	Field name.
<i>g_editable</i>	Editable (<i>t</i>) or greyed (<i>nil</i>).

Value Returned

<i>t</i>	Set form field to editable or greyed.
<i>nil</i>	Failed to set form field to editable or greyed.

axlFormSetFieldLimits

```
axlFormSetFieldLimits(  
    o_form  
    t_field  
    g_min  
    g_max  
)  
⇒ t/nil
```

Description

Sets the minimum or maximum values a user can enter in an integer or real fill-in field. If a nil value is provided, that limit is left unchanged.

For a REAL field, the type for *g_min* and *g_max* may be int, float, or nil. For an INT or LONG, the type must be int or nil.

Arguments

<i>o_form</i>	Form handle.
<i>t_field</i>	Field label.
<i>g_min</i>	Minimum value for field.
<i>g_max</i>	Maximum value for field.

Value Returned

<i>t</i>	Set max or min.
nil	Error due to invalid argument(s).

axlFormTreeViewAddItem

```
axlFormTreeViewAddItem(
    r_form
    t_field
    t_label
    g_hParent
    g_hInsertAfter
    [g_multiSelectF]
    [g_hLeafImage]
    [g_hOpenImage]
    [g_hClosedImage]
)
⇒ g_hItem/nil
```

Description

Adds an item to a treeview under *parent* and after *insertAfter* sibling. If sibling is *nil*, the item is added as the last child of a parent. If parent is *nil*, item is created as the root of the tree.

Note: This is the only interface for adding an item to a tree. `axlFormSetField` is disabled for Tree controls.

Applications must keep the returned handle `l_hItem` since a handle will be passed as `form->curValueInt` when the item is selected from tree view. The string associated with the selected item is also passed as `form->curValue`, however the string value may not be unique and cannot be used as a reliable identifier for the selected treeview item.

The tree view defaults to single selection mode. There is no checkbox associated with items in the tree view to make multiple selections. To make a tree view item multi select, pass one of the following values for `t_multiSelectF`:

- `nil` or '`TVSELECT_SINGLE` for no selection state checkbox
- `t` or '`TVSELECT_2STATE` for 2 state checkbox
- '`TVSELECT_3STATE` for 3 state checkbox

If an item is defined as multi select, a check box appears as part of the item. The user can check/uncheck (2 state) this box to indicate selection or select checked/unchecked/disabled modes for a 3 state checkbox. When the user makes any selection in the checkbox, its value is passed to application code in `form->treeViewSelState`. In this case, `form->curValue` is *nil*.

Callback Values

In the callback function for the form, the first argument *form*, has the following properties relevant to treeviews:

<i>form->curValue</i>	Contains the label of a treeview item. This is set in single select mode and in multi select mode when the user selects the item. In this case, the <i>result->tree.selectState</i> is -1.
<i>form->curIntValue</i>	Contains id of the selected treeview item.
<i>form->selectState</i>	In multi select mode, when the user picks the selection checkbox, this field will contain: 0 if selection checkbox is not checked 1 if selection checkbox is checked 2 if selection checkbox is disabled ((3 state mode only) In this case the <i>result->string</i> is empty. In all other cases the value is -1.
<i>form->event</i>	If event property is set to "rightpopup", treeview control has a popup and the user has selected an item in the popup. In this case, <i>form->curValue</i> is set to the popup index selected, and <i>form->selectState</i> is set to -1. <i>form->curIntValue</i> is set to the treeview item id. You add popups to treeview fields in a form like you add any other field in a form. For all non-popup operations, event is set to "normal."

Arguments

<i>r_form</i>	Form <i>dbid</i> .
<i>t_field</i>	Field name.
<i>t_label</i>	String of item in the treeview.
<i>g_hParent</i>	Handle of the parent. If <i>null</i> , item created as the root of the tree.

Allegro SKILL Reference

Form Interface Functions

<i>g_hInsertAfter</i>	Handle of the sibling to add the item after. If <code>null</code> , item added at the end of siblings of the parent.
<i>t_multiSelectF</i>	If <code>t</code> , the item has a checkbox for multi selection.
<i>g_hLeafImage</i>	Handle of the image to use whenever this item is a leaf node in the tree view. If <code>nil</code> or not supplied, the default pink diamond image is used.
<i>g_hOpenImage</i>	Handle of image to be used whenever this item is an expanded parent node in the tree view. If <code>nil</code> or not supplied, the default open folder image is used.
<i>g_hClosedImage</i>	Handle of image to use whenever the item is an unexpanded parent node in the tree view. If <code>nil</code> or not supplied, the default closed folder image is used.

Value Returned

<i>g_hItem</i>	Item is added to the tree view control.
<code>nil</code>	No item is added to the tree view control due to an error.

Example

```
see <cdsroot>/share pcb/examples/skill/form/basic/axlform.il
```

axlFormTreeViewChangeImages

```
axlFormTreeViewChangeImages (
    r_form
    t_field
    g_hItem
    [g_hLeafImage]
    [g_hOpenImage]
    [g_hClosedImage]
)
⇒ t/nil
```

Description

Modifies various bitmap images associated with a given tree view item.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	Field name.
<i>g_hItem</i>	Handle of item in tree view. Handle was returned as a result of the call to <code>axlFormTreeViewAddItem</code> when item was initially added.
<i>g_hLeafImage</i>	Handle of the image to use whenever item is a leaf node in the tree view. If <code>nil</code> or not supplied, the default pink diamond image is used.
<i>g_hOpenImage</i>	Handle of image to use whenever item is an expanded parent node in the tree view. If <code>nil</code> or not supplied, the default open folder image is used.
<i>g_hClosedImage</i>	Handle of image to use whenever item is an unexpanded parent node in the tree view. If <code>nil</code> or not supplied, the default closed folder image is used.

Allegro SKILL Reference

Form Interface Functions

Value Returned

t Tree view item's images are modified.

nil Failed to modify tree view item's images.

axlFormTreeViewChangeLabel

```
axlFormTreeViewChangeLabel (
    r_form
    t_field
    g_hItem
    t_label
)
⇒ t/nil
```

Description

Modifies text of a given treeview item.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	Field name.
<i>g_hItem</i>	Handle of item in the tree view. This handle was returned as a result of the call to <code>axlFormTreeViewAddItem</code> .
<i>t_label</i>	New label.

Value Returned

<i>t</i>	Tree view item's label is modified.
<i>nil</i>	Failed to modify tree view item's label.

axlFormTreeViewGetImages

```
axlFormTreeViewGetImages (
  r_form
  t_field
  g_hItem
)
⇒ l_hImage/nil
```

Description

various bitmap image handles that refer to images used by a specified item in the tree view.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	Field name.
<i>g_hItem</i>	Handle of item in the tree view. This handle was returned as a result of the call to <code>axlFormTreeViewAddItem</code> when this item was initially added.

Value Returned

<i>l_hImage</i>	List of three image handles. The first is the handle of the image used when this item is a leaf node. The second is the handle of the image used when this item is an expanded parent node. The third is the handle of the image used when this item is an unexpanded parent node.
<i>nil</i>	Error due to invalid arguments.

axlFormTreeViewGetLabel

```
axlFormTreeViewGetLabel (
  r_form
  t_field
  g_hItem
)
⇒ t_label/nil
```

Description

Returns text of a given treeview item.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	Field name.
<i>g_hItem</i>	Handle of item in the tree view. This handle was returned as a result of the call to <code>axlFormTreeViewAddItem</code> when this item was initially added.

Value Returned

<i>t_label</i>	Text of given tree view item.
nil	Failed to get text of given tree view item due to invalid arguments.

axlFormTreeViewGetParents

```
axlFormTreeViewGetParents (
  r_form
  t_field
  g_hItem
)
⇒ lg_hItem/nil
```

Description

Returns a list of all the ancestors of a treeview control item, starting from the root of the tree. Helps in search operations in SKILL. Applications can traverse their tree list following parent lists to a given item instead of searching the whole tree for an item.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	Field name.
<i>g_hItem</i>	Handle of item in the tree view. This handle was returned as a result of the call to <code>axlFormTreeViewAddItem</code> when this item was initially added.

Value Returned

<i>lg_hItem</i>	List containing all parents, starting from the root.
<i>nil</i>	Failed to obtain list due to invalid arguments.

axlFormTreeViewGetSelectState

```
axlFormTreeViewGetSelectState(  
    r_form  
    t_field  
    g_hItem  
)  
⇒ x_selectState
```

Description

In multi select mode, returns the select state of a treeview item. This is different than the current selected item in single select tree views. In multi select mode, users can change the select state by clicking on the select checkbox associated with each item.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	Field name.
<i>g_hItem</i>	Handle of item in the tree view. This handle was returned as a result of the call to <code>axlFormTreeViewAddItem</code> when this item was initially added.

Value Returned

In multi select mode:

0	Checkbox is unchecked.
1	Checkbox is checked.
2	Checkbox is disabled.
-1	Single select mode or failure due to invalid arguments.

axlFormTreeViewLoadBitmaps

```
axlFormTreeViewLoadBitmaps (
    r_form
    t_field
    lt_bitmaps
)
⇒ l_hImage/nil
```

Description

Allows an application to load one or more bitmaps into Allegro PCB Editor for use in specified tree view.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	Field name.
<i>lt_bitmaps</i>	Either a string containing the name of the bitmap file to load, or a list of strings, each of which is the name of a bitmap file to load.

Notes:

- Bitmap images must be 16 x 16 pixels.
- A bitmap file may contain more than one image provided they are appended horizontally (for example, a bitmap file containing n images will be $(16*n)$ x 16 pixels).
- Color RGB (255,0,0) is reserved for the transparent color. Any pixel with this color is displayed using the background color.

Value Returned

<i>l_hImage</i>	List of image handles that the caller will use to reference the images in subsequent <code>axlFormTreeViewAddItem</code> calls. List is ordered to correspond with the order that the images were listed in the <i>lt_bitmaps</i> parameter.
<i>nil</i>	One or more of the bitmap files could not be found, or an error was encountered while adding images.

Example

Given the file `myBmp1.bmp` is a 16×16 bitmap and `myBmp2.bmp` is a 32×16 bitmap.

```
(axlFormTreeViewLoadBitmaps (list "myBmp1" "myBmp2"))
```

This might return the following:

```
(6 7 8)
```

You can interpret the returned handles as follows:

- Image handle 6 refers to `myBmp1.bmp`.
- Image handle 7 refers to the left half of `myBmp2.bmp`.
- Image handle 8 refers to the right half of `myBmp2.bmp`.

axlFormTreeViewSet

```
axlFormTreeViewSet(  
    r_form  
    t_field  
    s_option  
    g_hItem  
    [g_data]  
)  
⇒ t/nil
```

Description

Allows an application to change global and individual items in a tree view control.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	Field name as a string
<i>s_option</i>	<i>s_option</i> is one of the symbols listed.
<i>g_hItem</i>	Tree view user data type.
[<i>s_data</i>]	<i>optional symbol</i>

Each *s_option* is paired with *g_hItem*, the handle of an item in the tree view control. If the option you are setting is global, you use *nil* in place of *g_hItem*. The pairs of different values of *s_option* with *g_hItem* is in the following manner.

<i>s_option</i>	<i>g_hItem</i>
TV_REMOVEALL	<i>nil</i>
TV_DELETEITEM	<i>g_hItem</i>
TV_ENSUREVISIBLE	<i>g_hItem</i>
TV_EXPAND	<i>g_hItem (4)</i>
TV_EXPAND_TOP	<i>nil (5)</i>
TV_COLLAPSE	<i>g_hItem (4)</i>
TV_COLLAPSE_TOP	<i>nil (5)</i>

Allegro SKILL Reference

Form Interface Functions

TV_SELECTITEM	<i>g_hItem</i> (2) (3)
TV_SORTCHILDREN	<i>g_hItem</i>
TV_NOEDITLABEL	nil - disables in place label editing
TV_NOSELSTATEDISPA TCH	nil - check box selection not dispatched
TV_ENABLEEDITLABEL	nil - enable in place label editing
TV_MULTISELTYPE	<i>g_hItem</i> (1)
TV_NOSHOWSELALWAYS	nil
TV_SHOWSELALWAYS	nil

Notes:

- For TV_MULTISELTYPE, you can also use the option *g_data* which is one of the following: TVSELECT_SINGLE, TVSELECT_2STATE, TVSELECT_3STATE. Default is TVSELECT_SINGLE.
- *g_hItem* is the Handle of item in the tree view control. Its value can be received in the following ways:
 - Call axlFormTreeViewAddItem.
 - Call axlFormTreeViewGetParents.
 - Change a tree control that causes a form dispatch. Then the form User Type attributes *curValue* and *curValueInt* are the *g_hItem*.
- You can pass nil for *g_hItem* in some cases. Pass nil for TV_SELECTITEM option to deselect the item that is currently selected.
- If nil is passed for TV_EXPAND or TV_COLLAPSE then all levels (including) children are expanded or collapse.
- The two _TOP options, TV_EXPAND_TOP and TV_COLLAPSE_TOP, respectively, expand and collapse all top level tree items. Children tree item states are preserved.

Value Returned

t	Changed one or more items in tree view control.
nil	Failed to change items in tree view control.

Example

- Delete selected treeview item in a form.

```
(axlFormTreeViewSet form form->curField 'TV_DELETEITEM form->curValue)
```

- Expand all levels including children:

```
axlFormTreeViewSet (form "tree" 'TV_EXPAND nil)
```

- Collapses all expanded top levels:

```
axlFormTreeViewSet (form "tree" 'TV_COLLAPSE_TOP nil)
```

For more examples see <cdsroot>/share pcb/examples/skill/form/basic

axlFormTreeViewSetSelectState

```
axlFormTreeViewSetSelectState(  
    r_form  
    t_field  
    g_hItem  
    g_state  
)  
⇒ t/nil
```

Description

In multi select mode, sets the select state. This is different than the current selected item in single select tree views. In multi select mode, users can change the select state by clicking on the select checkbox associated with each item.

Arguments

<i>r_form</i>	Form id.
<i>t_field</i>	The name of the field.
<i>g_hItem</i>	Handle of the item in the tree view. This handle was returned as a result of the call to <code>axlFormTreeViewAddItem</code> when this item was initially added.
<i>g_state</i>	Select state to set. <ul style="list-style-type: none"><input type="checkbox"/> Select state is unchecked if <i>g_state</i> is nil or 'TVSTATE_UNCHECKED<input type="checkbox"/> Select state is checked if <i>g_state</i> is t or 'TVSTATE_CHECKED<input type="checkbox"/> Select state is disabled if <i>g_state</i> is 'TVSTATE_DISABLED

Value Returned

<i>t</i>	Set select state.
nil	Failed to set select state.

Simple Graphics Drawing Functions

Overview

This chapter describes the AXL-SKILL functions related to Simple Graphics Drawing. You use these drawing utilities for drawing into bitmap areas such as thumbnails within the UIF forms package.

`axlGRP` is the AXL interface to a Simple Graphics Drawing utility.

You can simplify application drawing into thumbnails within forms as follows:

1. Specify the thumbnail field within the form file. This should not have a bitmap associated with it.
2. Call the `axlGRPDrwInit` function with the form, field name, and a callback function. Keep the handle returned by this function so you can use it in later processing.
3. Using the functions provided, redraw the image. The callback function is invoked with the graphics handle as the parameter.
4. Use the `axlGRPDrwUpdate` function to trigger the callback function.

Note: The application *cannot* set bitmaps or graphics callbacks using the facilities outlined in the Thumbnail documentation while using this package.

Simple Graphics Drawing package supports the following:

- Rectangles (Filled and unfilled)
- Polygons (Filled and unfilled)
- Circles (Filled and unfilled)
- Simple Lines
- Poly Lines
- Bitmaps
- Text

This package supports a mappable coordinate system. With the `GRPDrwMapWindow` function, you can specify a rectangle that gets mapped to the actual drawing area. An aspect ratio of 1 to 1 is maintained.

The zero point of the drawing area is the upper left point of the drawing:



Note: Objects drawn earlier are overlapped by objects drawn later. The application must manage this.

Setting Option Properties on the `r_graphics` Handle

You can set option properties on the `r_graphics` handle before calling the drawing functions. These properties, if applicable, are used by the drawing properties.

Table 12-1 `r_graphics` Option Properties

Option	Default	Description	Available Settings
--------	---------	-------------	--------------------

Allegro SKILL Reference

Simple Graphics Drawing Functions

Table 12-1 r_graphics Option Properties

color	black	Applies to all elements.	black, white, red, green, yellow, blue, lightblue, rose, purple, teal, darkpink, darkmagenta, aqua, gray, olive, orange, pink, beige, navy, violet, silver, rust, lime, brown, mauve, magenta, lightpink, cyan, salmon, peach, darkgray, button (represents the current button color)
fill	unfilled	Applies only to rectangles and polygons.	filled, filled_solid, unfilled
width	0	Applies only when geometric elements are unfilled.	
text_align	left	Text justification. Applies only to text.	left, center, right
text_bkmode	transparent	Text background display mode. Applies only to text.	transparent, opaque

Examples

See `<cdsroot>/share/pcb/examples/skill/form/basic/axlform.il` for a complete example.

Functions

axlGRPDrwBitmap

```
axlGRPDrwBitmap(  
    r_graphics  
    t_bitmap  
)  
⇒ t/nil
```

Description

Loads a bitmap into the drawing area in the graphics field. More drawing can take place on top of the bitmap.

Arguments

<i>r_graphics</i>	Graphics handle.
<i>t_bitmap</i>	Name of bitmap file. File must be on the BMPPATH, with .bmp as the extension.

Value Returned

t	Bitmap loaded into drawing area in the graphics field.
nil	No bitmap loaded into the drawing area in the graphics field due to invalid arguments.

axlGRPDrwCircle

```
axlGRPDrwCircle(  
    r_graphics  
    l_origin  
    x_radius  
)  
⇒ t/nil
```

Description

Draws a circle into the area identified by the *r_graphics* handle, at the origin specified, and with the specified radius. Option properties attached to the *r_graphics* handle are applied when drawing the circle.

Arguments

<i>r_graphics</i>	Graphics handle.
<i>l_origin</i>	List noting the <i>x</i> and <i>y</i> coordinates of the origin.
<i>x_radius</i>	Integer noting the radius of the circle.

Value Returned

t	Circle drawn.
nil	No circle drawn due to invalid arguments.

axlGRPDrwInit

```
axlGRPDrwInit(  
    r_form  
    t_field  
    t_func  
)  
⇒ r_graphics/nil
```

Description

Sets up necessary data structures for triggering the graphics callback into the graphics field.

Arguments

<i>r_form</i>	Handle of the form.
<i>t_field</i>	Name of field into which the package should draw. (Only THUMBNAIL fields are supported.)
<i>t_func</i>	Name of the drawing callback function. Callback function is invoked with the graphics handle as the parameter.

Value Returned

<i>r_graphics</i>	Graphics package handle.
<i>nil</i>	Failed to set up necessary data structures for triggering the graphics callback due to invalid arguments.

axlGRPDrwLine

```
axlGRPDrwLine(  
    r_graphics  
    l_vertices  
)  
⇒ t/nil
```

Description

Draws a line into the area identified by the *r_graphics* handle and the list of coordinates. Option properties attached to the *r_graphics* handle are applied when drawing the line.

Arguments

<i>r_graphics</i>	Graphics handle.
<i>l_vertices</i>	List of coordinates describing the line.

Value Returned

t	Line drawn.
nil	No line drawn due to invalid arguments.

axlGRPDrwMapWindow

```
axlGRPDrwMapWindow(  
    r_graphics  
    x_hgt  
    x_width  
)  
⇒ t/nil
```

Description

Allows the application to denote the coordinate system that is mapped into the drawing area of the graphics field.

Arguments

<i>r_graphics</i>	Graphics handle.
<i>x_hgt</i>	Height of drawing window.
<i>x_width</i>	Width of drawing window.

Value Returned

t	Successful
nil	Error occurred due to invalid arguments.

axlGRPDrwPoly

```
axlGRPDrwPoly(  
    r_graphics  
    l_vertices  
)  
⇒ t/nil
```

Description

Draws a polygon into the area identified by the *r_graphics* handle and the list of coordinates. Option properties attached to the *r_graphics* handle are applied when drawing the polygon. If the coordinates do not form a closed polygon, the first and last coordinates in the list are connected by a straight line.

Arguments

<i>r_graphics</i>	Graphics handle.
<i>l_vertices</i>	List of coordinates describing the line.

Value Returned

t	Polygon or line drawn.
nil	No polygon or line drawn due to invalid arguments.

axlGRPDrwRectangle

```
axlGRPDrwRectangle(  
    r_graphics  
    l_upper_left  
    l_lower_right  
)  
⇒ t/nil
```

Description

Draws a rectangle into the area identified by the *r_graphics* handle and the *upper_left* and *lower_right* coordinates. Option properties attached to the *r_graphics* handle are applied when drawing the rectangle.

Arguments

<i>r_graphics</i>	Graphics handle.
<i>l_upper_left</i>	List noting the coordinate of the upper left point of the rectangle.
<i>l_lower_right</i>	List noting the coordinate of the lower right point of the rectangle.

Value Returned

t	Rectangle drawn.
nil	No rectangle drawn due to incorrect arguments.

axlGRPDrwText

```
axlGRPDrwText(  
    r_graphics  
    l_origin  
    t_text  
)  
⇒ t/nil
```

Description

Draws text into the area identified by the *r_graphics* handle at the origin specified. Option properties attached to the *r_graphics* handle are applied when drawing the text.

Arguments

<i>r_graphics</i>	Graphics handle.
<i>l_origin</i>	List noting the <i>x</i> and <i>y</i> coordinate of the origin.
<i>t_text</i>	Text string to be drawn.

Value Returned

<i>t</i>	Text drawn.
<i>nil</i>	No text drawn due to incorrect arguments.

axlGRPDrwUpdate

```
axlGRPDrwUpdate(  
    r_graphics  
)  
⇒ t/nil
```

Description

Triggers calling of the application supplied callback function.

Arguments

r_graphics Graphics handle.

Value Returned

t Application supplied callback function called.

nil No callback function called due to an incorrect argument.

Message Handler Functions

Overview

This chapter describes the AXL-SKILL message handler system and functions. The message handler system allows you to write AXL-SKILL code that does not have to deal explicitly with errors after each call to a lower level routine, but rather checks at only one or two points. This contrasts with application programs that do not have a buffering and exception-handling message facility, where you must test for and respond to errors and exceptions at each point of possible occurrence in your code. Using the functions described in this chapter, you can do the following:

- Establish a *context* for your application messages.

A context is a logical section of your application during which you want to buffer and test for the potential errors and warnings you provided for in the lower levels of your application code.

- Write messages to the user with one of five levels of *severity*:

Severity Level	Type	Type Description and Response by AXL Message Handler
0	Text	Data created by the application, such as a log or report. Writes to journal and the user interface without being buffered.
1	Info	Such as “10% done,” “20% done”... Writes to user interface only, <i>not</i> to context message buffer nor to the journal.
2	Warning	Such as “Connect line is 5 mils wider than allowed.” Writes to context message buffer and journal with a “W” warning tag.


Allegro SKILL Reference

Message Handler Functions

Severity Level	Type	Type Description and Response by AXL Message Handler
3	Error	Such as “Cannot find symbol DIP24_200 in library.” Beeps and writes to context message buffer and journal with an “E” error tag.
4	Fatal	Such as “Disk read error. Cannot continue.” Double beeps and writes to context message buffer and journal with an “F” fatal tag.

- Test and change the severity level of the messages created and buffered in a context.
- Check for specific messages in the message buffer, and respond appropriately to anticipated conditions detected by lower-level functions.
- Close a context.

The following illustration shows how `axlMsg` functions move messages to and from a context message buffer and the SKILL user interface.



Message Handler Example

```
context = axlMsgContextStart("My own context.")
axlMsgPut(list("My warning" 2))
axlMsgPut(list("My error" 3))
printf("Message severity %d",axlMsgContextTest(context))
axlMsgPut(list("My fatal error %s" 4) "BAD ERROR")
if( axlMsgContextInBuf(context "My error")
    printf("%s\n" "my error is there"))
printf("Message severity %d",axlMsgContextTest(context))
axlMsgContextPrint(context)
axlMsgContextFinish(context)
⇒ t
```

1. Starts a context with `axlMsgContextStart`
2. Puts a warning, an error, and a fatal error message using `axlMsgPut`
3. Checks for the error message with `axlMsgContextInBuf`
4. Tests for the context severity level with `axlMsgContextTest`
5. Prints the context buffer with `axlMsgContextPrint`
6. Ends with `axlMsgContextFinish`

When you load the SKILL program shown above, the SKILL command line outputs the following:

```
W- My warning
E- My error
F- My fatal error BAD ERROR
Message severity 3
my error is there
Message severity 4
t
```

General usage of the `axlMsg` System

- Messages first go to the context buffer
- `axlMsgContextPrint` prints them to the SKILL command line
- The contents of the output buffer from any `print` and `printf` data write to the command line when control returns to the command line. That is why the messages "Message severity 3," "my error is there" and "Message severity 4" follow the buffered messages ("W- My warning" ...)

Message Handler Functions

This section lists message handler functions.

axlMsgPut

```
axlMsgPut(  
    g_message_format  
    [g_arg1 ...]  
)  
⇒ t
```

Description

Puts a message in the journal file. Use this function to “print” messages. It buffers any *errors* or *warnings*, but processes other message classes immediately.

Arguments

g_message_format Context message (`printf` like) format string. See [“Overview”](#) on page 745 for a description of messages and valid arguments.

g_arg1 ... Values for substitution arguments for the format string.

Value Returned

t Always returns *t*.

Example

See the [“Message Handler Example”](#) on page 747.

```
axlMsgPut(list("Cannot find via %s" 3) "VIA10")  
⇒ t
```

axlMsgContextPrint

```
axlMsgContextPrint(  
    r_context  
)  
⇒ t
```

Description

Prints the buffered messages and removes them from the message buffer.

Arguments

<i>r_context</i>	Context handle from axlMsgContextStart. Prints messages only for this context (or any children). An argument of <i>nil</i> causes axlMsgContextPrint to look through all contexts.
------------------	--

Value Returned

<i>t</i>	Always returns <i>t</i> .
----------	---------------------------

Example

See the “[Message Handler Example](#)” on page 747 in the beginning of this chapter.

```
axlMsgContextPrint(context)  
⇒ t
```

Prints the buffered messages in that context to SKILL command line:

```
W- My warning  
E- My error  
F- My fatal error BAD ERROR
```

axIMsgContextGetString

```
axIMsgContextGetString(  
    r_context  
)  
⇒ lt_messages/nil
```

Description

Gets the messages in the message buffer and removes them from the buffer. Call `axIMsgContextGetString` subsequently to communicate those messages to the user (for example, in a log file).

Arguments

<i>r_context</i>	Context handle from <code>axIMsgContextStart</code> . Gets messages only for this context (or any children). An argument of <code>nil</code> causes <code>axIMsgContextGetString</code> to look through all contexts.
------------------	---

Value Returned

<i>lt_messages</i>	List of the text strings of the buffered messages.
--------------------	--

<code>nil</code>	No buffered messages found.
------------------	-----------------------------

Example

See the “[Message Handler Example](#)” on page 747.

```
axIMsgContextGetString(context)  
⇒ ("My warning" "My error" "My fatal error BAD ERROR")
```

axlMsgContextGet

```
axlMsgContextGet(  
    r_context  
)  
⇒ lt_format_strings/nil
```

Description

Gets the format strings of the buffered messages. (*Not* the messages themselves. Compare the example here and the one shown for `axlMsgContextGetString`.) Does not remove the messages from the message buffer, rather it simply provides the caller an alternative to making a number of `axlMsgContextInBuf` calls.

Arguments

<i>r_context</i>	Context handle from <code>axlMsgContextStart</code> . Gets messages only for this context (or any children). An argument of <code>nil</code> causes <code>axlMsgContextGet</code> to look through all contexts.
------------------	---

Value Returned

<i>lt_format_strings</i>	List of format strings of the buffered messages.
--------------------------	--

<code>nil</code>	No buffered messages found.
------------------	-----------------------------

Example

See the “[Message Handler Example](#)” on page 747.

```
mylist = axlMsgContextGet(context)  
⇒ ("My warning" "My error" "My fatal error %s")
```

axlMsgContextTest

```
axlMsgContextTest(  
    r_context  
)  
⇒ x_class
```

Description

Returns the most severe message class of the messages in the context message buffer. See [axlMsgContextInBuf](#) on page 753 to check for a particular message class.

Arguments

<i>r_context</i>	Context handle from <code>axlMsgContextStart</code> . Looks only for messages for this context. If <i>r_context</i> is nil, <code>axlMsgContextTest</code> looks through all contexts.
------------------	--

Value Returned

<i>x_class</i>	The most severe message class of the messages in the message buffer of the given context.
----------------	---

Example

See the [Message Handler Example](#) on page 747.

```
printf("Message severity %d\n" axlMsgContextTest(context))  
⇒ Message severity 4
```

axlMsgContextInBuf

```
axlMsgContextInBuf(  
    r_context  
    t_format_string  
)  
⇒ t
```

Description

Checks whether message *t_format_string* is in the message buffer of context *r_context*. Gives the application the ability to control code flow based on a particular message reported by a called function. The check is based on the original format string, not the fully substituted message.

Arguments

<i>r_context</i>	Context handle from <code>axlMsgContextStart</code> . Looks only for messages in this context (or any children). If <i>r_context</i> is <code>nil</code> , <code>axlMsgContextInBuf</code> looks through all contexts.
<i>t_format_string</i>	Format string of the message.

Value Returned

<code>t</code>	Specified message is in the buffer.
<code>nil</code>	Specified message is not in the buffer.

Example

See the “[Message Handler Example](#)” on page 747.

```
if( axlMsgContextInBuf(context "My error")  
    printf(%s\n" "My error is there"))
```

axIMsgContextRemove

```
axIMsgContextRemove (
  r_context
  t_format_string
)
⇒ t
```

Description

Removes a message (or messages) from the buffered messages. Lets you remove messages (usually warnings) from the buffer that you decide, later in a procedure, that you do not want the user to see.

Arguments

<i>r_context</i>	Context handle from <code>axIMsgContextStart</code> . Removes messages for only this context (or any children). If <i>r_context</i> is <code>nil</code> , <code>axIMsgContextRemove</code> looks through all contexts.
<i>t_format_string</i>	Format string of the message. The match for the message in the buffer ignores the substitution parameters used to generate the full text of the message.

Value Returned

<i>t</i>	Always returns <i>t</i> .
----------	---------------------------

Example

See the [“Message Handler Example”](#) on page 747.

```
axIMsgContextRemove(context, "My fatal error %s")
⇒ t
```

axlMsgContextStart

```
axlMsgContextStart(  
    g_format_string  
    [g_arg1 ...]  
)  
⇒ r_context
```

Description

Indicates the start of a message context. Prints any buffered messages for the context.

Arguments

g_format_string Context message (`printf` like) message format string.

g_arg1 ... Values for the substitution arguments for the format string. Use `axlMsgClear` (and `Test/Set`) functions to control code flow if the function returns insufficient values.

Value Returned

r_context Context handle to use in subsequent `axlMsgContext` calls.

Example

See the “[Message Handler Example](#)” on page 747.

```
context = axlMsgContextStart("Messages for %s" "add line")  
Messages for add line  
5
```

axlMsgContextFinish

```
axlMsgContextFinish(  
    r_context  
)  
⇒ t
```

Description

Indicates the finish of a message context. Prints any buffered messages in the context and clears the context buffer.

Arguments

r_context Context handle from `axlMsgContextStart`.

Value Returned

t Always returns *t*.

Example

See the “[Message Handler Example](#)” on page 747.

```
context = axlMsgContextStart()  
... do some things ...  
axlMsgContextFinish(context)
```

axIMsgContextClear

```
axIMsgContextClear(  
    r_context  
)  
⇒ t
```

Description

Clears the buffered messages for a context.

Note: You should not normally use this function. Use functions that print (axIMsgContextPrint) or retrieve (axIMsgContextGetString) messages and then clear them, or use a context finish (axIMsgContextFinish) that forces the messages to be printed.

Arguments

<i>r_context</i>	Context handle from axIMsgContextStart. If <i>r_context</i> is nil, clears all messages in all contexts.
------------------	--

Value Returned

t	Always returns t.
---	-------------------

Example

See the “[Message Handler Example](#)” on page 747.

```
context = axIMsgContextStart()  
... do some things ...  
axIMsgContextClear(context)
```

axIMsgCancelPrint

```
axIMsgCancelPrint()  
    ⇒ t
```

Description

Prints a message informing the user that he requested *cancel*. Since the severity of this message is *Error* (3), AXL writes it to the context buffer as it does other warning, error, and fatal messages. Call this function only from a routine that requests user input.

Arguments

None

Value Returned

t	Always returns t.
---	-------------------

Example

See the “[Message Handler Example](#)” on page 747.

```
axIMsgCancelPrint()
```

Sets severity level to 2 (warning) and puts the following into the message buffer (if axIMsgSys messages are in English):

```
User CANCEL received
```

axlMsgCancelSeen

```
axlMsgCancelSeen()  
  ⇒ t/nil
```

Description

Checks to see if the `axlMsgCancelPrint` message was printed. Does not poll the input stream for a *CANCEL* key. Checks the buffer of current messages for the occurrence of the `axlSsgSys.cancelRequest` message.

Arguments

None

Value Returned

t	Requested <i>cancel</i> has been seen.
nil	No requested <i>cancel</i> has been seen.

Example

See the “[Message Handler Example](#)” on page 747.

```
if( axlMsgCancelSeen()  
  ; clear input and return  
  ...
```

axIMsgClear

`axlMsgClear()`
 $\Rightarrow t$

Description

Clears the current error severity level. You can reset the severity by first saving it using `axlMsgTest`, then setting it using `axlMsgSet`.

Arguments

None

Value Returned

Example

See the [“Message Handler Example”](#) on page 747.

`ax1MsgClear()`

axIMsgSet

```
axIMsgSet(  
    x_class  
)  
⇒ t
```

Description

Sets the current error severity level. Use only to reset the severity cleared using axIMsgClear.

Arguments

x_class Severity level.

Value Returned

t Always returns t.

Example

See the [“Message Handler Example”](#) on page 747.

```
level = axIMsgTest()  
; Do something  
...  
axIMsgSet(level)
```

axIMsgTest

```
axIMsgTest()  
⇒ x_class
```

Description

Determines the current error severity level. Returns a single number giving the severity level of the most severe message that has been printed since the last `axIMsgClear` or `axIMsgContextClear/Print/GetMsg` call.

Arguments

None.

Value Returned

<i>x_class</i>	Highest severity level of all the messages currently in the message buffer.
----------------	---

Example

See the “[Message Handler Example](#)” on page 747.

```
level = axIMsgTest()  
⇒ 4
```

Design Control Functions

AXL-SKILL Design Control Functions

The chapter describes the AXL-SKILL functions you can use to get the name and type of the current design.

axlCurrentDesign

```
axlCurrentDesign(  
    )  
    ⇒ t_design
```

Description

Returns the name of the currently active layout. This is the drawing name in the main window's title bar.

Arguments

None.

Value Returned

axlCurrentDesign Returns the current design name as a string. There is always a current name, even if it is "unnamed" (`unnamed.brd`).

See Also

[axlGetDrawingName](#), [axlOpenDesign](#)

Example

```
axlCurrentDesign () ⇒ "mem32meg"
```

Gets the name of the currently active layout.

axlDesignType

```
axlDesignType(  
    g_detailed  
)  
⇒ t_type
```

Description

Returns a string giving the type of the active design. The level of the type returned depends on the argument *g_detailed*, as described below.

Arguments

g_detailed If *g_detailed* is nil, returns the high-level types "LAYOUT" to denote a layout design, and "SYMBOL" to denote a symbol definition design. If *g_detailed* is t, returns a detailed value describing the design as follows:

For a layout type design: "BOARD", "MCM", "CIO", "MDD" (module), or "TIL" (tile).

For a symbol type design: "PACKAGE", "MECHANICAL", "FORMAT", "SHAPE", or "FLASH".

Value Returned

t_type One of the string values described.

See Also

[axllsSymbolEditor](#)

Example

- Gets the high-level design type of the current active layout.

```
axlDesignType(nil)  
⇒ "LAYOUT"
```

- Gets the detailed design type.

```
axlDesignType(t)  
⇒ "BOARD"
```

axlCompileSymbol

```
axlCompileSymbol(  
    ?symbol t_name  
    ?type t_type  
)  
⇒ t_symbolName/nil
```

Description

Compiles and edit checks the current (symbol) design and saves the compiled version on disk under the name *t_name*. If *t_name* is not provided, then *t_name* is the current drawing name. If *t_name* is provided as *nil*, you are prompted for the name. Uses the symbol type in determining some of the edit checks.

Arguments

<i>t_name</i>	Name of the compiled symbol.
<i>t_type</i>	Type of symbol, the default is the current symbol type (see axlDesignType).

Value Returned

<i>t_symbolName</i>	Name of the symbol.
<i>nil</i>	Error due to incorrect arguments.

Note: This function is only available in the symbol editor. This is a SKILL interface to the Allegro PCB Editor “*create symbol*” command and thus has the same behavior.

Allegro SKILL Reference

Design Control Functions

axlSetSymbolType

```
axlSetSymbolType(  
    t_symbolType  
)  
⇒ t_symbolType/nil
```

Description

Sets the Allegro PCB Editor symbol type. Has some minor effect on the commands available and the edit checks performed when the symbol is “compiled” ([axlCompileSymbol](#)).

Use [axlDesignType](#) to determine current symbol type.

Arguments

<i>t_symbolType</i>	"package", "mechanical", "format" , "shape" or "flash"
---------------------	---

Value Returned

<i>t_symbolType</i>	Symbol exists.
---------------------	----------------

nil	Error due to incorrect argument.
-----	----------------------------------

Note: This function is only available in the symbol editor. This is a SKILL interface into the change symbol type in the Drawing Parameters dialog box in *allegro_symbol*.

See Also

[axlCompileSymbol](#), [axlDesignType](#)

axIDBControl

```
axIDBControl(  
    s_name  
    [g_value]  
)  
g_currentValue/ls_names
```

Description

Inquires and/or sets the value of a special database control. If the setting is a value, the return is the old value of the control.

A side effect of most of these controls is that, if an active dialog box displays the current setting, the setting may not be updated. Additional side effects of individual controls are listed.

Note: Several display options have been moved to axIDBDisplayControl but for backward compatibility are still supported via this interface.

Items currently supported for *s_name* include the following:

Name: *busRats*

Value: t or nil

Set?: Yes

Description: Queries and changes the bus rats option

Equivalent: Prmed Display group

Side Effects: If changing should do ratsnestDistance first

Name: *drcEnable*

Value: t or nil

Set?: Yes

Description: Enables or Disables DRC/CBD system.

Equivalent: Same as status dialog box drc on/off buttons.

Side Effects: Does not perform batch DRC.

Name: *ratnestDistance*

Value: t or nil

Set?: Yes

Description: Accesses the ratsnest display mode.

t - pin to pin

nil - closest dangling net cline/via

Equivalent: Same as status dialog box Ratsnest Dist control.

Side Effects: Will recalculate the display when this is changed.

Allegro SKILL Reference

Design Control Functions

Name: *activeTextBlock*

Value: 1 to *maxTextBlock*

Set?: Yes

Description: Accesses the active text block number.

Equivalent: Same as status dialog box text block.

Side Effects: None

Name: *maxTextBlock*

Value: 16 to 64

Set?: No

Description: Reports the maximum text block number.

Equivalent: None

Side Effects: None

Name: *activeLayer*

Value: <class> / <subclass>

Set?: Yes

Description: Accesses the current class/subclass. To obtain subclass do

```
cadr(parseString(axlDBControl('activeLayer "/')))
```

Equivalent: Same as ministatus display.

Side Effects: None

Name: *activeAltLayer*

Value: <subclass>

Set?: Yes

Description: Accesses the current alternative etch layer

Equivalent: Same as ministatus display when in add connect.

Side Effects: None

Name: *defaultSymbolHeight*

Value: float

Set?: Yes

Description: Sets the default symbol height in the database.

Equivalent: Prmed from DRC Symbol Height.

Side Effects: Will set DRC out of date, and does not update status dialog box if it is present.

Name: *symbolRotation*

Value: float

Set?: Yes

Description: Sets the initial symbol rotation

Equivalent: Prmed form's symbol angle

Side Effects: None

Allegro SKILL Reference

Design Control Functions

Name: *symbolMirror*

Value: t/nil

Set?: Yes

Description: Sets the initial symbol mirror.

Equivalent: Prmed form's Symbol mirror.

Side Effects: None

Name: *schematicBrand*

Value: none/concepthd1, capture, scald

Set?: No

Description: Queries current database schematic branding.

Equivalent: See netin in the Allegro PCB Editor dialog.

Side Effects: None.

Name: *cmgrEnabledFlow*

Value: t or nil

Set?: Yes (only if flag is set)

Description: Reports if board is in constraint manager enabled flow. Only valid in HDL

Concept Flow.t - Cadence schematic Constraint Manager flow enabled (5 .pst files required)

nil - traditional Cadence schematic flow (3 .pst files)

Equivalent: Import Logic Branding shows "Constraint Manager Enabled Flow"

Side Effects: It is not advisable to clear this flag. This interface is provided for those customers who enabled the flow and want to restore the traditional flow. You need to do additional work on the schematic side to clear the option.

Name: *cdszFile*

Value: t or nil

Set?: t or nil

Description: Reports if a single .cdsz file was used by netrev instead of multiple .pst files.

If t, then genfeed format will output a .cdsz file.

Name: *schematicDir*

Value: directory path

Set?: Yes

Description: Queries/changes the Cadence schematic directory path. This is the directory location for the Cadence .pst files. This does not support 3rd party netlist location. If database is unbranded (see above), then the directory location is not stored. Existence of location is not verified.

Equivalent: Import Logic Branding Cadence Tab

Side Effects: none

Name: *testPointFixed*

Value: t or nil

Set?: Yes

Allegro SKILL Reference

Design Control Functions

Description: Sets global flag to lock test points. `t` - test points fixed `nil` - test points not fixed

Equivalent: Same as `testprep` param "Fixed test points"

Side Effects: None

Name: `ecsetApplyRipupEtch`

Value: `t` or `nil`

Set?: Yes

Description: If enabled, and the schedule is anything other than min tree, ripup any etch that disagrees with the schedule. Etch may be ripped up when a refdes is renamed due to this option. Only applicable with Allegro PCB Design XL tools. Applies setting at system level to all open designs.

`t` - ripup etch

`nil` - preserve etch

Equivalent: Same as Constraint Manager Tools — Options — "Rip up etch..."

Side Effects: None

Name: `maxEtchLayers`

Value: number

Set?: No

Description: Returns maximum number of etch subclasses.

Equivalent: none

Side Effects: none

Name: `dynamicFillMode`

Value: `wysiwyg`, `rough`, `nil` (Disabled)

Set?: Yes

Description: Controls filling of dynamic shapes.

Equivalent: shape global param

Side Effects: Disabled in symbol editor.

Name: `maxLength`

Value: number

Set?: Yes

Description: Sets maximum name length. Minimum is 31 and maximum is 255. For designs, you cannot set it lower than the current length. For new designs, the initial value is set by the value in the env variable `allegro_long_name_size`.

Equiv: Design Parameter Editor, Long Name Size

Name: `dynamicFillMode`

Value: `wysiwyg`, `rough`, `nil` (Disabled)

Set?: Yes

Description: Controls filling of dynamic shapes

Allegro SKILL Reference

Design Control Functions

Equiv: shape global param

Side Effects: Disabled in symbol editor

Name: *dynamicFilletsOn*

Value: t nil

Set?: Yes

Description: Controls filling of dynamic shapes

Equiv: Gloss param fillet - dynamic fillets option

Side Effects: Disabled in symbol editor and lower level PCB tools. When enabled will update design with fillets.

Name: *newFlashMode*

Value: t/nil

Set?: Yes

Description: Returns if board is running old style (nil) or new style (t) flash mode (WYSIWYG negative artwork using fsm files) Note WYSIWYG is now Smooth in the display.

Equiv: none

Side Effects: If you change the mode to t without updating flash symbols, wrong artwork may occur. You should only change the mode at design creation time before any padstacks with flashes are loaded into the design.

Name: *maxAttachmentSize*

Value: integer value in bytes

Set?: No

Description: Returns the largest attachment size (`axlCreateAttachment`) that may attach to the database.

Equivalent: None.

Side Effects: None.

Name: *dbSize*

Value: int

Set?: No

Description: returns current database size (memory footprint)

Equiv: none

Side Effects: none

Name: *retainElecCnsOnNets*

Value: t or nil

Set?: Yes

Description: Queries and changes the retain electrical constraints on nets

Equiv: netrev based option

Side Effects: This should only be set on new designs. With populated designs existing Electrical constraints will remain at xnet level. Setting the option will not promote existing settings to the xnet.

Name: *mirrorUserMask*

Value: t or nil

Set?: t or nil

Description: Most designs with padstack user mask layers offer Allegro mirror capability (layers with suffix _TOP will mirror to layer suffix _BOTTOM and vice versa). When padstack user mask layers was introduced in 16.2, they did not offer this capability. New designs will offer this capability but designs containing user mask layers that were created in 16.2 or 16.3 will have this mirror option disabled. a cdsz file.

Arguments

s_name Symbol name of control. nil returns all possible names.

g_value Optional symbol value to set. Usually a t or a nil.

Value Returned

See above.

ls_names If name is nil, then returns a list of all controls.

Example

1. Sets DRC system off.

```
old = axlDBControl('drcEnable, nil)
```

2. Gets current value of pin-2-pin ratsnest.

```
current = axlDBControl('ratsnestDistance)
```

3. Gets all names supported by this interface.

```
listOfNames = axlDBControl(nil)
```

See Also

[axlDBDisplayControl](#)

axlDBGetExtents

```
axlDBGetExtents(o_dbid  
    g_visibleOnly  
)  
==> bBox/nil
```

Description

Provides the extents of a physical database object. You choose between getting the extents of the entire object (even if it is currently not visible) or just the current visible objects.

With the visible option the extents may be smaller than the `bBox` attribute of the element `dbid` `bBox`.

If a list of `dbids` is provided, the union of the extents is returned.

Arguments

`o_dbid` dbid of an element.

`lo_dbid` list of dbids

`visible_only` t return the extents of visible parts of the element.
nil return the extents of the entire element.

Value Returned

`bBox` The extents of the element. This might be zero extents, if the object has no extents visible or does not have extents (for example, nets).

`nil` Error; bad arguments

axlDBIgnoreFixed

```
axlDBIgnoreFixed(  
    [g_ignore]  
) -> t/nil
```

Description

Provides similar functionality to that offered by many Allegro batch programs which allow FIXED and LOCKED properties to be ignored (for example: netrev -z).

If g_ignore is t, FIXED testing is ignored; nil restores FIXED testing. No argument reports the current state of FIXED testing.

This does not disable READ-ONLY states. A parent can be locked, which means the children cannot be modified (symbols locked to prevent editing of its components). READ-ONLY objects are typically seen when you are in the partition editor.



It is important that FIXED property testing be restored. Allegro automatically restores FIXED testing if your Skill program returns to Allegro. This includes calling axlShell.

Note: Recommend using axlDBCloak since that API catches any Skill errors and restores the mode.

Arguments

g_ignore If t, turn off FIXED testing; nil restore.

no argument Return current state of FIXED testing.

Value Returned

old fixed (nil FIXED is enable, t is enabled)

See Also

axlDBIsFixed, axlDBCloak

Examples

```
; Select an object  
p = ashOne()  
  
; Add fixed property  
axlDBAddProp(p, '("FIXED" t))  
  
; Attempt to delete it  
axlDeleteObject(p)  
  
; now delete it  
axlDBIgnoreFixed(t)  
axlDeleteObject(p)  
axlDBIgnoreFixed(nil)
```

axlDBIsReadOnly

```
axlDBIsReadOnly(  
    o_dbid  
) -> t/nil
```

Description

This API command checks if indicated database object is read-only.

An example of why an object is marked read-only due to a partition being active.

Arguments

o_dbid dbid of the element to be checked.

Value Returned

- *t* – object is read-only
- *nil* – not read-only or not a dbid

See Also

[axlDBIsFixed](#)

Example

```
p = axlSelectByname("SYMBOL" "U1")  
ret = axlDBIsReadOnly(p)
```

axlDBSectorSize - Obsolete

```
axlDBSectorSize(  
    [f_size]  
)  
==> nil
```

Description

This is obsolete. It is kept for backwards compatibility. It now calls [axlDBTuneSectorSize](#). Tuning sectors is now built into dbdoctor.

axlGetDrawingName

```
axlGetDrawingName(  
    )  
    => t_drawingPathName
```

Description

Retrieves the full path of the drawing.

Arguments

None

Value Returned

t_drawingPathName Full path of the drawing.

See Also

[axlCurrentDesign](#)

Example

```
axlGetDrawingName() => "/net/nile/home/neeti/testboards/test1.brd"
```

axlIgnoreFixed

See [axlDBIgnoreFixed](#).

axlInTrigger

```
axlInTrigger(  
) ==> t/nil
```

Description

Tests if the application or the utility in a axlTrigger callback. Returns `t` if currently in a trigger call. This function is only required in rare cases when you might have a utility that you want to run differently if called as part of a axlTrigger callback.

Arguments

None

Value Returned

`t` if in a trigger callback, `nil` otherwise

See Also

[axlTriggerSet](#)

axlIsSymbolEditor

`axlIsSymbolEditor() -> t/nil`

Description

Returns `t` if in symbol editor, `nil` for all other editors.

When loading custom menus you might want to differentiate between the symbol editor and design editor.

Arguments

None.

Value Returned

Returns `t` if symbol editor.

Ses Also

[axlDesignType](#)

Example

`axlIsSymbolEditor()`

axlKillDesign

```
axlKillDesign()  
⇒ t/nil
```

Description

Same as (`axlOpenDesign <unnamed> "wf"`), where `<unnamed>` is the standard Allegro PCB Editor name provided for an unnamed design. If the specific name is important, you can determine it using the [axlCurrentDesign](#) command.

Arguments

None

Value Returned

t	New design opened, replacing current design.
nil	No new design opened.

Note

This will void all `axl dbid` handles and clear the selection set.

See Also

[axlOpenDesign](#)

axlOpenDesign

```
axlOpenDesign(  
    ?design t_design  
    ?mode t_mode  
    ?noMru g_noMru  
)  
⇒ t_design/nil
```

Description

Opens a design. The new design replaces the current design. If the current design has unsaved edits, you are asked to confirm before discarding them unless the current design was opened in "r" mode (not supported in this release) or unless *g_mode* is "wf". If you cancel the confirmers, the function returns *nil* and the current design remains open.

If *t_design* is not provided, you are prompted for the name of the design to open.

If *t_design* does not exist on disk, the standard Allegro PCB Editor Drawing Parameters dialog box appears.

The new design is of the same type as the current design. To reset the design type, specify the appropriate extension with the design name. For example, use a .dra extension to open a file with design type set to SYMBOL, or use a .brd or .mcm extension to open a file with design type set to LAYOUT.

Arguments

<i>t_design</i>	Name of the new design to edit
<i>g_mode</i>	"w" or "wf" (see above) add a "1" to disable Allegro file locking example: "w1" for no locking
<i>g_noMru</i>	If t does not update the Most Recently Used file list. (Default is to update.)

Value Returned

<i>t_design</i>	New design name.
<i>nil</i>	No design opened due to incorrect argument.

Allegro SKILL Reference

Design Control Functions

Note: Functions the same as the Allegro PCB Editor *open* command, except you can set the *t_mode* to "wf" in order to discard the current edits without confirmation.

Since confirmation uses the standard Allegro PCB Editor confirmers, using the "wf" mode is the same as setting the NOCONFIRM environment variable.

This will void all *axl dbid* handles and clear the selection set.

See Also

[axlCurrentDesign](#), [axlKillDesign](#), [axlRenameDesign](#), [axlSaveDesign](#),
[axlSetSymbolType](#), [axlRunBatchDBProgram](#), [axlSaveEnable](#),
[axlCompileSymbol](#)

Allegro SKILL Reference

Design Control Functions

axlOpenDesignForBatch

```
axlOpenDesignForBatch(
    ?design t_design
    ?mode t_mode
)
==> t_design/nil
```

Description

Opens a design. The new design replaces the current design. Since this is for batch usage, commands and menus are not changed. If the current design has unsaved edits, then you are asked to confirm the discard unless the current design was opened in "*r*" mode (not supported in this release) or *g_mode* is "*wf*". If you cancel the confirmmer, then the function returns *nil* and the current design is left open.

If *t_design* is not provided, then you are prompted for the name of the design to open.

If *t_design* does not exist on the disk, then the standard Allegro Drawing Parameters form appears.

The *designType* of the new design is set the same as the current design. It can be changed using *axlSetDesignType*.

Arguments

<i>t_design</i>	The name of the new design to edit
<i>g_mode</i>	" <i>w</i> " or " <i>wf</i> " (see above) add a "I" to disable Allegro file locking example: "wl" for no locking

Value Returned

axlOpenDesignForBatch *t_design* if opened, or *nil* if error

Note: This command functions the same as the Allegro *edit* command, except the *t_mode* can be set to "*wf*" in order to discard the current edits without confirmation. Since confirmation uses the standard Allegro confirmmer, the "*wf*" mode is the same as setting the NOCONFIRM environment variable.

This will void all *axl dbid* handles and clear the selection set.

axlRenameDesign

```
axlRenameDesign(  
    t_design  
)  
⇒ t_design/nil
```

Description

Changes the current design name. Has no effect on the existing disk version of the current design. The new current design name will be displayed in the window border and becomes the default name for axlSaveDesign.

Arguments

t_design New current design name (without file extension).

Value Returned

t_design New current design name.

nil Error due to incorrect argument.

See Also

[axlOpenDesign](#)

Examples

```
axlRenameDesign("test1")
```

axlSaveDesign

```
axlSaveDesign(  
    ?design t_design  
    ?mode t_option  
    ?noMru g_noMru  
    ?noConfirm g_noConfirm  
    ?writeModel g_write  
)  
⇒ t_design/nil
```

Description

Saves the design with the name specified (*t_design*). If *t_design* is not specified, the current design name is used. If *t_design* is provided but the value is *nil*, you are prompted for the name. If *t_option* is "nocheck", the database "quick check" is not provided. Use this option only when there is a very compelling reason.

NOTES

- This is essentially the Allegro "save" command.
- This will clear all axl dbid handles and the selection set.
- Use axlRunBatchDBProgram, if the intent is to save the design to run another program.

Arguments

<i>t_design</i>	Name for the saved design.
<i>t_option</i>	"nocheck" - No database check performed.
<i>g_noMru</i>	If <i>t</i> does not update the Most Recently Used file list. (Default is to update.)
<i>g_noConfirm</i>	If <i>t</i> does not present a confirm for overwriting an existing design. File is overwritten.
<i>g_write</i>	If <i>t</i> uses allegro write file model. This means file is written to disk with provided name but current drawing name is not updated.

Value Returned

<i>t_design</i>	Name for the saved design.
-----------------	----------------------------

nil Error due to incorrect argument(s).

Note: Essentially the Allegro PCB Editor *save* command. The current design name is not changed. Use `axlRenameDesign` to change the current design name.

This will void all `axl dbid` handles and clear the selection set.

See Also

[axlOpenDesign](#), [axlRenameDesign](#), [axlRunBatchDBProgram](#)

axlSaveEnable

```
axlSaveEnable(  
    [g_saveEnable]  
) -> t/nil
```

Description

This queries or sets the design to save design. When `t`, the *File – Save design* menu command is enabled. If `nil`, it is disabled.

If no arguments are provided, then returns the current status. If `g_saveEnable` is `t`, then enables save menu (reset of next database save). If `g_saveEnable` is `nil`, disables the save menu.

It is not recommended that you unset the save enable.

Arguments

`g_saveEnable` `t`

If not provided, just does query.

Value Returned

Returns current save setting if query and previous setting if changing the value.

See Also

[axlSaveDesign](#)

Examples

1) Query state of save

```
state = axlSaveEnable()
```

2) Set state of save to t (enable save menu)

```
oldState = axlSaveEnable(t)
```

axlDBChangeDesignExtents

```
axlDBChangeDesignExtents (
    l_bBox
)
⇒ t/nil
```

Description

Changes design extents. This may fail if an object falls outside the new extents or if the extents exceed the database range.

Arguments

l_bBox New design extents.

Value Returned

t Size changed.

nil Failed to change size.

Note: This function may take extra time on large designs.

Example 1

```
extents = axlExtentDB('obstacle)
axlDBChangeDesignExtents(extents)
```

Reduces the database to its smaller extent.

Example 2

```
extents = axlExtentDB('obstacle)
extents = bBoxAdd(extents '((-100 -100) (100 100))
axlDBChangeDesignExtents(extents)
```

To reduces the database to its minimum size plus 100 mils all around.

axlDBChangeDesignOrigin

```
axlDBChangeDesignOrigin(  
    l_point  
)  
⇒ t/nil
```

Description

Changes the origin of the design. This may fail if the new design origin falls outside the maximum integer range.

This is an offset. A negative number moves the database left or down and a positive number moves the database to the right or up.

Note: This may take extra time on large designs.

Arguments

l_point X/Y offset.

Value Returned

t Changed the origin of the design.

nil Failed to change the origin of the design due to an incorrect argument.

Example

```
axlDBChangeDesignOrigin(900:900)
```

Moves the origin.

axlDBChangeDesignUnits

```
axlDBChangeDesignUnits(  
    t_units/nil  
    x_accuracy/nil  
    x_drcCount/nil  
)  
⇒ x_drcCount/nil
```

Description

Changes the units and accuracy of the design. To maintain the current design value, use `nil` for `t_units` or `x_accuracy`.

When you change units, also change accuracy to maintain adequate precision within the database. Reference the following table to determine the appropriate accuracy.

Units	Min Accuracy	Max Accuracy	Delta
mils	0	4	0
inches	2	4	3
microns	0	2	0
millimeters	1	4	3
centimeters	2	4	4

- Decreasing accuracy is not recommended.
- Switching units between Metric and English is not recommended due to inevitable rounding issues.
- Use the new `DELTA` to decide what the accuracy should be when changing units.

```
new acc = orig acc + (new delta - old delta)
```

This example shows mils to millimeters with a current accuracy of 1.

```
new acc = orig acc+ (millim delta- mils delta)  
4      = 1      +  3      -  0
```

- When changing from one English unit to another or from one Metric unit to another, the default accuracy must match that of the previous unit. For example, if your design uses `MILS 0` and you change to `INCHES`, the accuracy must be set to 3.

Allegro SKILL Reference

Design Control Functions

- If you change from an English unit to a Metric unit or from a Metric unit to an English unit, then the accuracy must be set to a number that is at least as accurate as the current database. For example, if the design is in MILS 0 and you change to MILLIMETERS, then the accuracy must be set to 2. Then if you change to INCHES, the accuracy must be set to 3 (inches and 3 = mils and 0.)
- If the accuracy needed is not allowed due to a limitation on the number of decimal places allowed for a particular unit, or if you reduce the level of accuracy, the error message, "E-Accuracy will be decreased, database round-offs may occur," displays. For example, if your design is in MICRONS and an accuracy of 1 and you change to CENTIMETERS, you get an error since CENTIMETERS are not allowed with an accuracy of 5.

Arguments

t_units Mils, inches, millimeters, centimeters, or microns.

x_accuracy Range is 0 to 4, according to the table shown.

Value Returned

x_drcCount drc count.

nil Failed to change design units.

Notes:

- This function may take extra time on large designs.
- This function reruns DRC if enabled.

Example 1

```
ax1DBChangeDesignUnits("millimeters" 4)
```

Changes a design from mils/0 to millim/4 (accuracy maintains database precision).

Example 2

```
ax1DBChangeDesignUnits(nil 2)
```

Increases accuracy from 0 to 2 and keeps the same units.

axlDBCheck

```
axlDBCheck(  
    g_option/lg_options  
    [p_file]  
)  
⇒ (x_errors x_warnings) /nil
```

Description

Runs *dbdoctor* on the current database. By default, no log file is produced. You can specify the '*log*' option which writes the standard *dbdoctor.log* file. A port descriptor can be the second argument to write the *dbdoctor* output to an external file.

Arguments

g_option/lg_options

Option	Function
'general	Performs a full database check.
'links	Performs a full database check.
'branch	Performs a full database check.
'shapes	Checks shapes (autovoid) <ul style="list-style-type: none">■ May be slow for complicated shapes.■ Normally fast.■ Slow on large databases.
'all	Performs a full check and fix. Does not perform a shape check.
'drc	Performs a batch DRC.
'log	Uses the standard <i>dbdoctor.log</i> file for output.
<i>p_file</i>	Port to write dbcheck logging.

Value Returned

(*x_errors x_warnings*) Results of the check.

Examples

```
res = axlDBCheck ('all)
printf ("errors = %d; warnings = %d", car (res), cadr (res);

p = outfile ("mylogfile")
res = axlDBCheck('(links shapes) p)
close (p)
```

axIDBCopyPadstack

```
axIDBCopyPadstack(  
    rd_dbid  
    l_startEnd  
    [g_dontTrim]  
)  
⇒ o_dbid/nil
```

Description

Creates a new padstack from an existing padstack. The name for the new padstack automatically derives from the existing name by adding a post fix that does not collide with any existing names. The padstack is marked in the database as derived from its starting padstack.

You must provide legal, etch, start and end layers, but `g_dontTrim` must be `t`. If trim is enabled, the new padstack only has pads between the list layers.

Trimming only restricts resulting padstack to between the two indicated layers. If the starting padstack does not already span between the two layers then it will not expand to fill those layers.

Arguments

<code>o_dbid</code>	<code>dbid</code> of the padstack to copy from.
<code>l t_startEnd</code>	List of start (<i>class/subclass</i>) and stop (<i>class/subclass</i>) layers.
<code>g_dontTrim</code>	Use <code>t</code> if you do not want the padstack trimmed, or <code>nil</code> to trim the padstack if necessary.

Value Returned

<code>dbid</code>	<code>dbid</code> of the new padstack.
<code>nil</code>	Failed to create new padstack.

Example

- 1) To derive an exact copy:

```
newPadId = axlDBCopyPadstack(padId, ' ("ETCH/TOP" "ETCH/BOTTOM") )
```

- 2) To derive and trim to only connect from top layer to 2

```
newPadId = axlDBCopyPadstack(padId, ' ("ETCH/TOP" "ETCH/2") t)
```

axIDBDelLock

```
axIDBDelLock(  
    [t_password]  
)  
⇒ t/nil
```

Description

Deletes a lock on the database. If the database is locked with a password, you must supply the correct password to unlock it.

Arguments

t_password Optional password string no longer than 20 characters.

Value Returned

t Lock is removed or there is no lock to remove.

nil Failed to remove lock due to an incorrect password.

See Also

[axIDBSetLock](#), [axIDBGetLock](#)

Example 1

```
axIDBDelLock()
```

Deletes a lock with no password.

Example 2

```
axIDBDelLock("mypassword")
```

Deletes a lock with the password, mypassword.

axIDBGetLock

```
axIDBGetLock()  
⇒ nil/l_info
```

Description

Returns information about a lock on the database. You retrieve the following information:

<i>t_userName</i>	User login who locked the database.
<i>t_lockDate</i>	Date the database was locked.
<i>t_systemName</i>	System on which the database was locked.
<i>t_export</i>	String representing the current setting for enabling/disabling the ability to export design data to other formats.
<i>t_comments</i>	Comments optionally set by the user who locked the database.

You can also determine whether or not a database is locked as this function returns `nil` when the database is unlocked, and returns a list of information when the database is locked.

Arguments

none

Value Returned

<code>nil</code>	Database is unlocked.
<code>l_info</code>	List (<i>t_userName t_systemName t_export [t_comments]</i>). Database is locked.

axIDBMemoryReclaim

```
axIDBMemoryReclaim( )  
-> x_sizeReclaimed
```

Description

Reclaims database memory for reuse by the Allegro database. Normally in Skill memory of deleted database objects is not reused until Skill code returns to the main processing loop.

Should only be used in special cases since the default programming model works for most all Skill programs. For a well written Skill program this is typically not required.

Before utilizing this API, first try the following techniques:

- use axIDBCloak if are adding/deleting objects that are etch based (vias, clines, etch shapes, pings (e.g. like moving a symbol)).
- insure that you do not have any long running db transactions (axIDBTransactionStart). E.g. commit all transactions you have active. Transactions can be nested so you should commit all the way to the initial transaction.

The one known programming model that uses this API is the "try-it" model. This is where a program adds an object to the database, performs a test and then deletes it (e.g. utilizes axlAirGap to get distances to other db objects).

For the API to be most effective make sure:

- Are not inside an axIDBCloak.
- The most memory can be reclaimed if you have no active db transactions.

Memory reclaimed is returned to the database for reuse. It is not be returned to the program's memory pool nor returned to the OS. The program's memory usage at the OS level is NOT reduced.

As a side effect some of the dbids that are checked-out may be reclaimed since they actually link to deleted db objects. They are reported as "dbid:remove".

Note: Do NOT use instead axl trigger callbacks.

Arguments

none

Value Returned

Amount of memory reclaimed (bytes).

See Also

[axIDBCloak](#), [axIDBTransactionStart](#)

axIDBSetLock

```
axIDBSetLock(  
    ['password t_password]  
    ['comments t_comments]  
    ['exports "disabled"/"enabled"]  
)  
⇒ t/nil
```

Description

Locks the database against future changes. After setting the lock, you must save the database in order to save the lock. After saving the lock, you can no longer save changes to the database.

User is warned when opening a locked database. Attempts to save the database fail with the exceptions of saving the initial lock and uprev.

For simple lock, provide no arguments.

If a nil is provided, returns list of options to this function.

Arguments

t_password If provided, you need this to unlock the database. If you forget the password, you cannot unlock the database. The password must be 20 characters or fewer. The following characters are not allowed in the password: (\ whitespace) or leading dash (-)

t_comments Free form comments. You may embed carriage returns (\r) in the string to force a new line in the locking user interface.

'exports Default is to allow exporting data to other formats. If disabled, the following exports are prevented: techfile write, dump_libraries, and create modules.

Note: Upreving the database from one version to the next ignores the lock flag.

Value Returned

t	Locked database.
nil	Failed to lock database.

Example 1

```
axlDBSetLock()
```

Locks the database (basic lock).

Example 2

```
axlDBSetLock('comments "I locked the database"
              'exports "disabled")
axlSaveDesign(?design "locked_data")
printf("Locked info %L\n" axlDBGetLock())
```

Locks the database, includes comments, and disables data export.

axlDBTuneSectorSize

```
axlDBTuneSectorSize( )  
==> nil/l_result
```

Description

This tune's Allegro's sector size for better performance. Normally, this occurs automatically via dbdoctor or performance advisor. In addition, it is done periodically during design open.

Allegro's optimal sector size changes over the course of a design cycle. As the design becomes complete a smaller sector size typically results in better performance at a cost of a slightly higher memory requirement.

Note: For the current release, the sector size is in dbunits, future releases may change this to design units.

Arguments

None

Value Returned

- nil: If no tuning is required
- a disembody property list: If tuning was required. The a disembody property list contains:
 - old sectors
 - their size
 - new sectors
 - new sector size

axlTechnologyType

axlTechnologyType()
⇒ *t_technology*

Description

Returns the type of design technology in use.

Arguments

none

Value Returned

t_technology Technology type as shown:

Technology Type

Product

"mcm"

Allegro Package Designer L or Allegro Package SI XL

"pcb"

Allegro PCB Editor

axlTriggerClear

```
axlTriggerClear(  
    s_trigger  
    s_function  
)  
⇒ t/nil
```

Description

Removes a registered callback trigger. You pass the same arguments you passed as you registered the trigger.

Arguments

<i>s_trigger</i>	Trigger type. See <code>axlTriggerSet</code> .
<i>s_function</i>	Trigger function to remove - the same as you passed to <code>axlTriggerSet</code> .

Value Returned

t	Trigger removed.
nil	Failed to find a trigger by the specified name.

Example

See `axlTriggerSet` for an example.

axlTriggerPrint

```
axlTriggerPrint()  
    ⇒ t
```

Description

Debug function that prints what is registered for triggers.

Arguments

none

Value Returned

t	Always returns t.
---	-------------------

axlTriggerSet

```
axlTriggerSet(  
    s_trigger  
    s_function  
)  
⇒ t/nil  
  
axlTriggerSet(  
    nil  
    nil  
)  
⇒ (ls_listOfSupportTriggers)
```

Description

Allows an application to register interest in events that occur in Allegro PCB Editor. When called with both arguments as *nil*, returns a list of supported triggers.

Restrictions

Unless otherwise indicated, in you Skill callback trigger you cannot:

- open, save or close the current database.
- call axlShell.
- call any of the axlEnter functions or any of the Select.
- object functions to request a user pick.

You should restrict any user interaction to blocking dialogs (forms).

Notes

- All trigger functions take a single argument. If you provide a function that does not match this standard, your trigger is **not** called.
- Any processing you do in triggers increases the time to open or save a database. So it is recommended that you must keep these short. If it must be longer, inform the user regarding the processing delay using *axlUIWPrint*.
- You can register multiple functions for a single trigger, but each registration must have a different function. The order that these functions are called when the trigger occurs is undefined.

- Allegro PCB Editor sends a close trigger when Allegro PCB Editor exits normally. Abnormal exits such as crash, user kill, etc. result in this trigger not being generated.
- You can do user interface work in triggers. You must have the user enter all information before returning from the trigger. Opening a dialog box may involve returning before getting data from the user. To avoid this problem, call `axlUIWBlock` after `axlFormDisplay`. This ensures you do all processing inside the trigger. For correct dialog box display, use the block option in `axlFormCreate`, the *lt_placement* parameter.
- You should use caution when using `axlShell` API within a trigger function. Cadence advises against this and does not support it. For example, calling Allegro commands or running scripts is not supported. Using `axlShell` API within a trigger function can cause the following:
 - Allegro may block in the script resulting in trigger failures.
 - Messages may appear to the user that you cannot suppress.
 - Scripts, commands and command behavioral can change from release to release.
 - User can also issue commands to different functionality.
- The triggers for opening and saving the database are generally not called when the database needs to do temporary saves, for example, `axlRunBatchDBProgram`, `reports`, or `netrev`.
- You can disable triggering by setting the environment variable `dbg_noskilltriggers`. If you suspect that applications running on triggers are causing problems, set this environment variable to help you debug.

Arguments

<code>s_trigger</code>	Trigger type as shown:
s_trigger Option	Description
<code>'open (t_database g_existing)</code>	Called immediately after a database is opened. Passed a list of two items: the name of the database and <code>t</code> if existing or <code>nil</code> if a new database. Restrictions: You should not open, save, and close the current database.

s_trigger Option	Description
'save (<i>t_oldName</i> <i>t_newName</i>)	Called before a database is saved to disk. Passed a list of two items: the old name of the database and the new name of the database. If these are the same, then the database was overwritten. This is not called when autosaving.
'close <i>t_name</i>	Called before another database is opened. The single item is the name of the database being discarded.
'exit <i>x_status</i>	called when program is exiting except if it is an abnormal termination. <i>x_status</i> is a number where 0 indicates a clean exit, 1 indicates warnings, and 2 is exiting due to an error.
	Note: GUI programs do not currently exit with warnings but this may change in the future.
	Trigger is provided for applications to clean-up the environment. For database specific work, use save or close trigger.
	Restrictions: <ul style="list-style-type: none">■ Do not read or change the database.■ Do not display dialogs or blocking confirmers.
'menu <i>t_menuName</i>	called when a new menu is loaded in the main tool window. Targeted at application code to modify the menu.
	Restrictions: <ul style="list-style-type: none">■ While a database is active do not change the database.■ Do not display dialogs or blocking confirmers.■ Do not call axlUIMenuLoad.

Allegro SKILL Reference

Design Control Functions

s_trigger Option

'xprobe (s_mode
lo_dbid)

Description

Called when object(s) is highlighted or dehighlight s_mode is a symbol which may be highlight or dehighlight and lo_dbid is a list of dbids. This is the same interface used to cross-probe to ConceptHDL/Capture.

This is targeted to allow sending messages to external tools.

Restrictions:

- Do not change the database
- Do not invoke a dialog or blocking confirmers
- Keep processing at a minimum since this will impact user interactive performance.

s_function

Callback function for the event. Each trigger should have its own function. If you use the same function for multiple triggers you can not determine what function caused the trigger.

Value Returned

t Trigger is registered for the indicated callback.

nil Trigger is not registered for the indicated callback.

See Also

[axlTriggerClear](#), [axlTriggerPrint](#), [axlInTrigger](#)

Examples

See <cdsroot>/share pcb/examples/skill/trigger for an example.

Example 1

In ilinit, add:

```
procedure( MyTriggerOpen( t_open)
    let( (brd old)
        brd = car(t_open)
```

```
old = cadr(t_open)
if (old then
    old = "Existing"
else
    old = "New"
)
printf("SKILLCB Open %s database %s\n" old brd)
t
))
axlTriggerSet('open 'MyTriggerOpen)
```

Shows how to use this with ~/pcbenv/allegro.ilinit to be notified when your user opens a new board. Echoes a print every time a user opens a new database.

Example 2

```
( isCallable('axlTriggerSet) axlTriggerSet('open 'MyTriggerOpen))
```

To be compatible with pre-14.1 software, substitute for `axlTriggerSet` in `allegro.ilinit`.

axlGetActiveLayer

```
axlGetActiveLayer()  
    ⇒ t_layer
```

Description

Retrieves active class and subclass of the design.

Note: This function is obsolete and is kept for compatibility reasons. Use `axlDBControl`.

Arguments

None

Value Returned

t_layer Returns a string denoting the active class and subclass.

Example

```
axlGetActiveLayer()  
    ⇒ "MANUFACTURING/PHOTOPILOT_OUTLINE"
```

axlGetActiveTextBlock

```
axlGetActiveTextBlock()  
⇒ _textBlock
```

Description

Gets the current active text block, equivalent to the status dialog box.

Arguments

None

Value Returned

_textBlock Returns the current active text block number.

axlSetActiveLayer

```
axlSetActiveLayer(  
    t_layer  
)  
⇒ t/nil
```

Description

Sets the active class and subclass of the design.

Note: This function is obsolete and is kept for compatibility reasons. Use `axlDBControl`.

Arguments

t_layer String with the format: `<class>/<subclass>`.

Value Returned

t Set the given active class and subclass successfully.

nil Failed to set active the given class and subclass.

Example

```
axlSetActiveLayer( "MANUFACTURING/PHOTOPLOT_OUTLINE")  
⇒ t
```

axlWFMAnyExported

```
axlWFMAnyExported()  
==> t/nil
```

Description

Reports if there are any exported partitions.

Use axlDesignType to see if the design is currently a partition.

Arguments

None

Value Returned

t, if one or more partitions are currently exported

nil, if no partitions exported

See Also

[axlDesignType](#)

Examples

```
axlWFMAnyExported()
```

axlDBDisplayControl

```
axlDBDisplayControl(
  s_name
  [g_value]
)
==> g_currentValue/ls_names
```

Description

This command is used to inquire and set the display database controls. When used for setting a value, the command returns the old value of the control.

Note: For most of these controls, if the form that is displaying the current setting is active, it may not be updated. Additional side effects of individual controls are listed.

Use the [axlColorGet](#) and [axlColorSet](#) commands to change the background color.

Items currently supported are listed in [Table 14-1](#) on page 818.

Table 14-1 Supported Controls

Name	Value	Set	Description	Equivalent	Side Effects
connectPointSize	dbrep	Yes	Changes the size of connect points (diamond figures)	prmed Display group	Call axlVisibleUpdate to update display.
connectPointEnabled	t/nil	Yes	Changes visibility of connect points (diamond figures)	prmed Display group	Call axlVisibleUpdate to update display.
customColorEnabled	t/nil	Yes	Changes the display of custom colors	color192 dialog ("Enable Custom Colors")	Call axlVisibleUpdate to update display.
displayNetNames	t/nil	Yes	Enables the display of net names on etch. OpenGL must be enabled.	prmed Display group	Call axlVisibleUpdate to update display.

Allegro SKILL Reference

Design Control Functions

Table 14-1 Supported Controls, *continued*

Name	Value	Set	Description	Equivalent	Side Effects
drcMarkerSize	dbrep	Yes	Changes the size of DRC markers	prmed Display group	Call axlVisibleUpdate to update display.
editingTime	int	Reset	Reports editing time of design in minutes	status form	Can reset time by passing g_value == t
endcapsEnable	t or nil	Yes	Controls display of line endcaps	prmed Display group	Call axlVisibleUpdate to update display.
filledPadsEnable	t or nil	Yes	Pads are displayed filled or hollow	prmed Display group	Call axlVisibleUpdate to update display.
gridColor	1 to < <i>maxColor</i> >	Yes	Changes the grid color Note: You can find the < <i>maxColor</i> > by running the command, maxColor = axlColorGet(`count)	color dialog Display group	Call axlVisibleUpdate to update display.
gridEnable	t or nil	Yes	Queries and changes the grid visibility	Color form, Display Group, Grids	Call axlVisibleUpdate to update display.
highlightColor	1 to < <i>maxColor</i> >	Yes	Queries/changes the permanent highlight color. Can be used with axlHighlightObject	Color form, Display Group, Permanent highlight	Call axlVisibleUpdate to update display.

Allegro SKILL Reference

Design Control Functions

Table 14-1 Supported Controls, *continued*

Name	Value	Set	Description	Equivalent	Side Effects
holeColor	1 to <code><maxcolor></code>	Yes	Queries/changes the drill hole color.	Color form, Display Group	Call <u>axlVisibleUpdate</u> to update display.
lastSaveUser	string	No	Reports last user login who saved design. This may be an empty string, if the design was never saved.	Status form	None
nonPlatedHolesEnable	1 to <code><maxcolor></code>	Yes	Queries and changes the non-plated holes visibility. Unlike in the prmed dialog, setting this option to t does not set padlessHolesEnable to t.	Color form, Display Group, Grids	Call <u>axlVisibleUpdate</u> to update display.
padlessHolesEnable	t or nil	Yes	Queries and changes the padless holes visibility	Color form, Display Group, Grids	Call <u>axlVisibleUpdate</u> to update display.
platedHolesEnable	t or nil	Yes	Queries and changes the plated visibility. Unlike in the prmed dialog, setting this option to t does not set padlessHolesEnable to t.	Color form, Display Group, Grids	Call <u>axlVisibleUpdate</u> to update display.

Allegro SKILL Reference

Design Control Functions

Table 14-1 Supported Controls, *continued*

Name	Value	Set	Description	Equivalent	Side Effects
tempColor	1 to <code><maxcolor></code>	Yes	Queries/changes the temporary highlight color. Can be used with <code>axlHighlightObject</code>	Color form, Display Group, Temporary highlight	Call <u>axlVisibleUpdate</u> to update display.
ratsnestColor	1 to <code><maxcolor></code>	Yes	Queries/changes the ratsnest color for top to bottom ratsnest. In pre-16.2 releases, this set the color for all ratsnest.	Color form, Display Group, Ratsnest Color	Call <u>axlVisibleUpdate</u> to update display.
ratsnestBBColor	1 to <code><maxcolor></code>	Yes	Queries/changes the ratsnest color for bottom to bottom ratsnest.	Color form, Display Group, Ratsnest Color	Call <u>axlVisibleUpdate</u> to update display.
ratsnestTTCOLOR	1 to <code><maxcolor></code>	Yes	Queries/changes the ratsnest color for top to top ratsnest.	Color form, Display Group, Ratsnest Color	Call <u>axlVisibleUpdate</u> to update display.
ratsnestJog	t/nil	Yes	Queries/changes the ratsnest jog option.	prmed form, Display Group, Ratsnest Jog	None
ratTSize	dbrep	Yes	Changes the size of RatT markers	prmed Display group	Call <u>axlVisibleUpdate</u> to update display.
thermalPadEnable	t/nil	Yes	Queries and changes the thermal pads. Only applicable for negative planes.	prmed Display group	Call <u>axlVisibleUpdate</u> to update display.

Allegro SKILL Reference

Design Control Functions

Table 14-1 Supported Controls, *continued*

Name	Value	Set	Description	Equivalent	Side Effects
transparencyGlobal	1 to 255	Yes	Changes the OpenGL global transparency where 1 is completely translucent and 255 is solid.	prmed Display group	Call axlVisibleUpdate to update display.
transparencyShape	1 to 255	Yes	Changes the OpenGL shape transparency where 1 is completely translucent and 255 is solid.	prmed Display group	Call axlVisibleUpdate to update display.
viaLabel	t/nil	Yes	Queries and changes the via label display. Feature is not available in products less than PCB XL.	prmed Display group	Call axlVisibleUpdate to update display.
viaLabelColor	1 to < <i>maxcolor</i> >	Yes	Queries and changes the via label color. Feature is not available in products less than PCB XL.	Color form, Display Group	Call axlVisibleUpdate to update display.
stackedViaLabelColor	1 to < <i>maxcolor</i> >	Yes	Queries and changes the stacked via label color. Feature is not available in products less than PCB XL.	Color form, Display Group	Call axlVisibleUpdate to update display.

Allegro SKILL Reference

Design Control Functions

Table 14-1 Supported Controls, *continued*

Name	Value	Set	Description	Equivalent	Side Effects
waiveDRCColor	1 to $<maxcolor>$	Yes	Queries and changes the waived DRC color.	Color form, Display Group, Waived DRC	Call axlVisibleUpdate to update display.
waiveDRCEnable	t/nil	Yes	Queries and changes the waived DRC display state	Color form, Display Group, Waived DRC	Call axlVisibleUpdate to update display.

Arguments

s_name symbol name of control. nil returns all possible names

s_value optional symbol value to set. Usually a t or a nil.

Value Returned

See above

ls_names: If name is nil then returns a list of all controls.

See Also

[axlDBControl](#), [axlColorGet](#), [axlColorShadowGet](#)

Examples

1. Find out grid color

```
color = axlDBDisplayControl('gridColor, nil)
```

2. Turn on grids

```
old = axlDBDisplayControl('gridEnable t)
```

3. Get all names supported by this interface

```
listOfNames = axlDBDisplayControl(nil)
```

Allegro SKILL Reference
Design Control Functions

Database Create Functions

Overview

This chapter describes the AXL functions that add objects to the Allegro PCB Editor database. Some functions require input that you set up using available auxiliary functions, which are also described in this chapter. For example, Allegro PCB Editor paths consist of any number of contiguous line and arc segments. To add this multi-structure to the Allegro PCB Editor database, first create a temporary path, adding each line or arc segment using separate function calls. Once the temporary path contains all required segments, create the Allegro PCB Editor line-object, shape or void by calling the appropriate database create function, giving the path structure as an argument. The chapter shows several examples of the process.

Database create (`DBCreate`) functions modify the active Allegro PCB Editor database in virtual memory and require a database save to make changes permanent in the file.

Supply all coordinates to these functions in user units, unless otherwise noted.

The functions described here do not display the objects immediately as they create them. To display all changes, call an interactive function, exit SKILL, or return control to the Allegro PCB Editor command interpreter.

- To immediately display an object you have just created, do one of the following:
 - Call the function `axlDisplayFlush`
 - or—
 - Call an interactive function

If you create an object and then delete it without calling `axlDisplayFlush` or calling an interactive function, the object never appears in the display.

The class of geometric objects that `DBCreate` functions create are called *figures*. `DBCreate` functions return, in a list, the *dbids* of any figures they create and a Boolean

Allegro SKILL Reference

Database Create Functions

value `t` if the creation caused any DRCs. The functions return `nil` if they could not create any figures. The exact structure of the data returned differs among the commands. See the individual commands for detailed descriptions.

You can set the active layer (Allegro PCB Editor class/subclass) by calling the `ax1SetCurrentLayer` function. This function returns a `nil` if you try to set an invalid layer or if you try to create a figure on a layer that does not allow that figure type.

AXL-SKILL creates a figure as a member of a net only if the figure is on an etch layer. Where a function has a netname as an argument, and the active layer is an etch layer, the function attaches the figure to the net specified by that netname. If the net does not exist, an error occurs. If you specify `nil` for the netname, the function determines the net for the figure by what other figure it touches. If the figure is free standing, that is, touches nothing, the figure becomes a member of the dummy net (no net).

The functions use defaults for all parameters you do not supply. If you do not supply a required parameter (one without a default, for example, `pointList`) the function considers the call an error and returns `nil`.

The database create functions do not add figures to the select set. They leave the select set unchanged.

Path Functions

An Allegro PCB Editor `line` is a figure consisting of end-to-end straight line and arc segments, each segment having a width you can define separately. Allegro PCB Editor `shapes` and `polygons` are figures that define an area. A shape owns a closed line figure that defines the perimeter of the shape. The shape has an associated fill pattern and can also own internal `voids`. Each void in turn owns a polygon that defines its boundary.


A `path` is a set of contiguous arc and single straight line segments. In AXL, you first create a path consisting of the line and arc segments by adding each segment with a separate AXL function, then creating the actual figure using the appropriate `ax1DBCreate` function, with the path as one of the arguments. With AXL convenience functions described later in this chapter, you can create rectangles, circles, and lines consisting only of straight segments.

All coordinate arguments to the path functions are in user units and are absolute to the layout origin.

Example

This general example shows how to create a path, then use it as an argument in an axlDBCreate function. The example creates a path consisting of a straight line segment, then adds an arc and another line segment, and uses it as an argument to create a path that is a member of net "net1" on etch subclass "top":

```
path = axlPathStart( (list 100:250))
  axlPathLine( path, 0.0, 200:250 )
  axlPathArcCenter( path, 0.0, 300:350, nil, 200:350 )
  axlPathLine( path, 0.0, 300:450 )
axlDBCreatePath( path, "etch/top", "net1")
```



axlPathStart

```
axlPathStart(  
    l_points  
    [f_width]  
)  
⇒ r_path/nil
```

Description

Creates a new path with a startpoint and one or more segments as specified by the list *l_points* and returns the path *dbid*. You can add more straight-line and arc segments to the returned *r_path* using the `axlPathArc` and `axlPathLine` functions described in this section. Once *r_path* has all the segments you require, create the actual database figure using the appropriate `axlDBCCreate` function, with *r_path* as one of the arguments.

Arguments

<i>l_points</i>	List of <i>n</i> vertices, where <i>n</i> > 1. If <i>n</i> = 1, <i>r_path</i> returns with that single vertex as its startpoint, but with no segments. You must subsequently add at least one segment before adding it to the database If <i>n</i> > 1, <i>r_path</i> returns with <i>n</i> -1 straight-line segments.
<i>f_width</i>	Width for all segments, if any created, between the <i>l_points</i> . <i>f_width</i> is the default width for all additional segments added to <i>r_path</i> using <code>axlPath</code> functions. You can override this default width each time you add a segment using an <code>axlPath</code> function by using a <i>f_width</i> argument when you invoke the function.

Value Returned

r_path/nil Returns the *r_path* handle.

Note: This is a handle object, but is *not* an Allegro PCB Editor *dbid*.

Example

See start of the [Path Functions](#) on page 826.

axlPathArcRadius

axlPathArcAngle

axlPathArcCenter

```
axlPathArcRadius(  
    r_path  
    f_width  
    l_end_point  
    g_clockwise  
    g_bigarc  
    f_radius  
)  
⇒ r_path/nil  
  
axlPathArcAngle(  
    r_path  
    f_width  
    l_end_point  
    g_clockwise  
    f_angle  
)  
⇒ r_path/nil  
  
axlPathArcCenter(  
    r_path  
    f_width  
    l_end_point  
    g_clockwise  
    l_center  
)  
⇒ r_path/nil
```

Description


Each of these functions provides a way to construct an arc segment from the current endpoint of *r_path* to the given *l_end_point* in the direction specified by the Boolean *g_clockwise*, as described below and shown in [Figure 15-1](#) on page 832.

Attempts to create small arcs using many decimal points of accuracy may fail due to rounding errors.

Arguments

<i>r_path</i>	Handle of an existing <i>r_path</i> to receive arc segment.
<i>f_width</i>	Width of an arc segment in user units. Overrides, for this segment only, any width originally given in <code>axlPathStart; nil</code> = use current width
<i>l_end_point</i>	End point to which an arc is to be constructed. Start point is the last point currently in <i>r_path</i> in absolute coordinates.
<i>g_clockwise</i>	Direction to create arc: <code>t</code> → create arc clockwise from start to endpoint <code>nil</code> → create counterclockwise. Default is counterclockwise (See Figure 15-1 on page 832).
<i>g_bigarc</i>	<code>axlPathArcRadius</code> : Create an arc greater than or equal 180 degrees (See Figure 15-1 on page 832).
<i>f_radius</i>	<code>axlPathArcRadius</code> : Arc radius in user units.
<i>f_angle</i>	<code>axlPathArcAngle</code> : Angle in degrees subtended by arc (See Figure 15-1 on page 832).
<i>l_center</i>	<code>axlPathArcCenter</code> : Arc center point in absolute coordinates.

Figure 15-1 Effects of *axlPathArc* Arguments



Value Returned

r_path Current path handle.


nil Arc path not created.

Example 1

```
mypath = axlPathStart( list( 8900:4400))
axlPathArcRadius( mypath, 12., 8700:5300, nil, nil, 500)
axlDBCreatePath( mypath, "etch/top")
```

Adds a smaller-than-180 degree counterclockwise arc by radius.


Creates the smaller possible arc:



Example 2

```
mypath = axlPathStart( list( 8900:4400))
axlPathArcAngle( mypath, 12., 8700:5300, nil, 330)
axlDBCreatePath( mypath, "etch/top")
```

Adds a counterclockwise arc subtending 330 degrees.



Example of axlPathArcCenter

See [Example](#) on page 827.

axlPathLine

```
axlPathLine(  
    r_path  
    f_width  
    l_end_point  
)  
⇒ r_path/nil
```

Description

Adds a single straight line segment to the end of an existing *r_path* structure as specified by the arguments. Start point of the line is the last point in *r_path*.

Arguments

<i>r_path</i>	Handle of an existing path.
<i>f_width</i>	Width of the segment. <i>nil</i> = segment takes the width given when <i>r_path</i> was created.
<i>l_end_point</i>	End point of the line segment in absolute coordinates.

Value Returned

<i>r_path</i>	Path structure following addition of single straight line segment to end of <i>r_rath</i> structure.
<i>nil</i>	No line segment added to <i>r_path</i> structure.

Example

See start of the [Path Functions](#) on page 826.

axlPathGetWidth

```
axlPathGetWidth(  
    r_path  
)  
⇒ f_width/nil
```

Description

Gets the default width of an existing path structure.

Arguments

r_path Handle of an existing path structure.

Value Returned

f_width Default width of the path structure.

nil *r_path* is not a path, or is empty.

Example

axlPathGetWidth returns the default path width of 173 mils.

```
path = axlPathStart( (list 1000:1250), 173)  
    axlPathLine( path, 29, 2000:1250)  
    axlPathLine( path, 33, 3000:3450)  
    axlDBCreatePath( path, "etch/top")  
  
    axlPathGetWidth( path)  
    ⇒ 173.0
```

- Creates a path with width 173 mils
- Adds line segments at widths 29 and 33 mils

axlPathSegGetWidth

```
axlPathSegGetWidth(  
    r_pathSeg  
)  
⇒ f_width/nil
```

Description

Gets the width of a single segment in a path structure.

Arguments

r_pathSeg Handle of a segment of a path structure.

Value Returned

f_width Returns the width of the segment.

nil *r_pathSeg* is not a segment.

Example

axlPathSegGetWidth returns the width of that segment only, 33 mils.

```
path = axlPathStart( (list 1000:1250), 173)  
    axlPathLine( path, 29, 2000:1250)  
    axlPathLine( path, 33, 3000:3450)  
  
lastSeg = axlPathGetLastPathSeg(path)  
axlPathSegGetWidth( lastSeg)  
⇒ 33.0
```

- Creates a path with default width 173 mils
- Adds line segments at widths 29 and 33 mils
- Gets the last segment added with axlPathGetLastPathSeg

axlPathGetPathSegs

```
axlPathGetPathSegs (
    r_path
)
⇒ r_pathList/nil
```

Description

Gets a list of the segments of a path structure, in the order they appear in the path.

Arguments

r_path Handle of an existing path structure.

Value Returned

r_pathList Returns a list of the segments of the path.

nil *r_path* is not a path.

Example

```
mypath = axlPathStart( (list 1000:1250), 173)
    axlPathLine( mypath, 29, 2000:1250)
    axlPathArcCenter( mypath, 12, 3000:2250, t, 3000:2250)
mysegs = axlPathGetPathSegs( mypath)
print mysegs
⇒array[6]:1057440 array[6]:1057416 array[6]:1057392)
```

- Creates a path
- Gets the segments of the path
- Prints the segments of the path

axlPathGetLastPathSeg

```
axlPathGetLastPathSeg(  
    r_path  
)  
⇒ r_pathList/nil
```

Description

Gets the last segment of a path structure.

Arguments

r_path Handle of an existing path structure.

Value Returned

r_pathList Returns the last segment of the path.

nil *r_path* is not a path.

Example

axlPathSegGetWidth returns the width of that segment only, 33 mils.

```
path = axlPathStart( (list 1000:1250), 173)  
    axlPathLine( path, 29, 2000:1250)  
    axlPathLine( path, 33, 3000:3450)  
  
lastSeg = axlPathGetLastPathSeg(path)  
axlPathSegGetWidth( lastSeg)  
⇒ 3.0
```

- Creates a path with the default width 173 mils
- Adds line segments at widths 29 and 33 mils
- Gets the last segment added using axlPathGetLastPathSeg

axlPathSegGetEndPoint

```
axlPathSegGetEndPoint(  
    r_pathSeg  
)  
⇒ l_endPoint/nil
```

Description

Gets the end point of an existing path structure.

Arguments

r_pathSeg Handle of a path segment.

Value Returned

l_endPoint List containing the end point of the path structure.

nil *r_pathSeg* is not the *dbid* of a path segment, or the structure is empty.

Example

```
path = axlPathStart( (list 1000:1250), 173)  
      axlPathLine( path, 29, 2000:1250)  
      axlPathLine( path, 33, 3000:3450)  
  
lastSeg = axlPathGetLastPathSeg(path)  
axlPathSegGetEndPoint( lastSeg)  
⇒(3000 3450)
```

- Creates a path with default width 173 mils
- Adds line segments at widths 29 and 33 mils
- Gets the last segment added with `axlPathGetLastPathSeg`

`axlPathSegGetWidth` returns the width of that segment only, 33 mils.

axlPathSegGetArcCenter

```
axlPathSegGetArcCenter(  
    r_pathSeg  
)  
⇒ l_point/nil
```

Description

Gets the center point of a path arc segment.

Arguments

r_pathSeg Handle of a path arc segment.

Value Returned

l_point List containing the center coordinate of the arc segment.

nil Segment is not an arc.

Example

`axlPathSegGetArcCenter` gets the center of the last arc segment.

```
path = axlPathStart( (list 1000:1250), 173)  
    axlPathLine( path, 29, 2000:1250)  
    axlPathArcCenter( path, 12., 3000:2250, nil, 2000:2250)  
  
lastSeg = axlPathGetLastPathSeg(path)  
axlPathSegGetArcCenter( lastSeg)  
⇒(2000 2250)
```

- Creates a path with a straight line segment and an arc segment
- Gets the last segment added with `axlPathGetLastPathSeg`

axlPathSegGetArcClockwise

```
axlPathSegGetArcClockwise(  
    r_pathSeg  
)  
⇒ t/nil
```

Description

Gets the clockwise flag (`t` or `nil`) of a path segment.

Arguments

`r_pathSeg` Handle of a path segment.

Value Returned

`t` Segment is clockwise.

`nil` Segment is counterclockwise.

Example

`axlPathSegGetArcCenter` returns `t`, meaning the arc segment is clockwise.

```
path = axlPathStart( (list 1000:1250), 173)  
    axlPathLine( path, 29, 2000:1250)  
    axlPathArcCenter( path, 12., 3000:2250, t, 2000:2250)  
lastSeg = axlPathGetLastPathSeg(path)  
axlPathSegGetArcClockwise( lastSeg)  
⇒ t
```

- Creates a path with a straight line segment and a clockwise arc segment
- Gets the last segment added using `axlPathGetLastPathSeg`

axlPathStartCircle

```
axlPathStartCircle(  
    l_location  
    f_width  
)  
⇒ r_path/nil
```

Description

Creates an axlPath structure (*r_path*) for a circle.

Arguments

l_location	Center and radius as ((X Y) R).
f_width	Edge width of the circle.

Value Returned

<i>r_path</i>	<i>r_path</i> with the circle as the only segment.
nil	axlPath structure not created.

Note: Width must be specified for this interface (it may be 0.0) and since it uses standard SKILL arg check, it must be a flonum.

Example

```
(axlPathStartCircle (list 100:200 20),0) ; no width specified.
```

axlPathOffset

```
axlDB2Path(  
    r_path  
    xy  
)  
==> r_path
```

Description

Adds an offset, *xy*, to all points within a *r_path*.

Arguments

<i>r_path</i>	
<i>offset</i>	<i>offset xy</i>

Value Returned

new r_path

See Also

[axlPathStart](#), [axlDB2Path](#)

Examples

Obtain shape outline as a *r_path* and then move it by 10:20.

```
p = ashOne("shapes")  
path = axlDB2Path(p)  
path1 = axlPathOffset(path 10:20)
```

axlDB2Path

```
axlDB2Path(  
    o_dbid  
)  
==> r_path
```

Description

This takes a database id (`o_dbId`) and converts it to an `r_path`. This function supports all dbids with a segment attribute. For example, shape, void, path, and line.

Note: In AXL-Skill terminology, path and line, refers to cline/line and segments, respectively.

Arguments

`o_dbId` The dbid for the line.

Value Returned

- `r_path` - if object can be converted
- `nil` - object cannot be converted.

See Also: [axlPathStart](#)

Examples

To obtain shape outline as a `r_path`, use following commands.

```
p = ashOne("shapes")  
path = axlDB2Path(p)
```

ax1DBCreatePath

```
ax1DBCreatePath(  
    r_path  
    [t_layer]  
    [t_netName] / [`line]  
    [o_parent]  
    [lo_props]  
)  
⇒ l_result/nil
```

Description

Creates a path figure (line or cline) as specified. Does not add a net name to etch when the etch is not connected to a pin, via, or shape. If etch is added, it ties to the first net it touches, otherwise it remains “not a net” as specified by the arguments described below.

Clines may merge with other clines so that the resulting coordinates may be a superset of the provided coordinates. This is not currently true for line types.

Normally, if you want to attach properties to a newly created object, call `ax1DBAddProp` after creating the object. CLINEs may merge with existing CLINEs, so the object you end up adding properties to may not match the one you created. The `lo_props` option deals with this issue. You can add properties when you create the CLINE and if the property list on your CLINE differs from any merged target CLINES, your CLINE will not merge.

LINES with the interface are supported even though lines do not merge.

Notes:

- `ax1DBCreatePath` does not add a net name to an etch when the etch is not connected to a pin, via, or shape.
- If an etch is added, it is tied to the first net it touches, otherwise it remains “not on a net”.

Arguments

<i>r_path</i>	Existing path consisting of the straight-line and arc segments previously created by <code>ax1Path</code> functions
<i>t_layer</i>	Layer on which to create a path figure. Default is the active layer.
<i>t_netName</i>	Name of the net to which the path figure is to belong. <code>ax1DBCreatePath</code> ignores <i>t_netName</i> if <i>t_netName</i> is non-nil and <i>t_layer</i> is not an etch layer.

Allegro SKILL Reference

Database Create Functions

If the net *t_netName* does not exist, `ax1DBCreatePath` does not create any path, and returns `nil`.

`'line` Changes default path created on an etch layer from a cline to a line.

`o_parent` *dbid* of object to be the parent of the path figure. Use the symbol instance or use `nil` to specify the design. If you attach etch figures to a symbol parent, the figures are not associated with the symbol, and do not move with it.

`[lo_props]` Optional list of property name/value pairs. (See `ax1DBAddProp` for format.)

Value Returned

`l_result` List:
(car) list of *dbids* of all path figures created or modified
(cadr) `t` if DRCs are created. `nil` if DRCs are not created.
`nil` Nothing was created.

See Also

[ax1DBAddProp](#)

Example

```
path = ax1PathStart( list 100:0 100:500)

; create path on current default layer
ax1DBCreatePath(path)

; create a cline path on top etch layer and assisgn to GND
ax1DBCreatePath(path "ETCH/TOP" "gnd")

;create a line path on top etch layer
ax1DBCreatePath(path "ETCH/TOP" 'line)
```

Allegro SKILL Reference

Database Create Functions

```
;have user create a two pick path on board geometry outline  
axlDBCreatePath( axlEnterPath() "BOARD GEOMETRY/OUTLINE")  
  
;create a cline path on top etch layer with properties  
proplist = list( '(FILLET t) '(TEARDROP "U1.C17"))  
axlDBCreatePath(path "ETCH/TOP" "gnd" nil proplist)
```

axIDBCreateLine

```
axIDBCreateLine(  
    l_points  
    [f_width]  
    [t_layer]  
    [t_netname]/['line]  
    [rd_parent]  
)  
⇒ l_result/nil
```

Description

Create a path of fixed width straight segments, a line with series of provided points. If line is on an ETCH layer a cline will be created unless overridden with 'line symbol.

All points are in absolute user units. For <n> points provided, the function creates <n-1> segments.

Arguments

<i>l_points</i>	List of the vertices (at least two) for this path.
<i>f_width</i>	Width for all segments in the path. Default is 0.
<i>t_layer</i>	Layer to which to add the path. Default is the current active layer.
<i>t_netname</i>	Name of the net.
<i>rd_parent</i>	<i>dbid</i> of the object to which the line is added. Use the symbol instance <i>dbid</i> or use <i>nil</i> to specify the design itself.

Value Returned

<i>l_result</i>	List: (car) list of <i>dbids</i> of all paths created or modified (cadr) t if DRCs are created. Otherwise the function returns <i>nil</i> .
<i>nil</i>	Nothing is created.

See Also

[axlDBCreatePath](#)

Example

```
axlDBCreateLine( (list 1000:1250 2000:2250), 15, "etch/top")
⇒ ((dbid:122784) t)
```

This example creates a line at width 15 mils from (1000, 1250) to (2000, 2250) on "etch/top". The command returns the *dbid* of the line and *t*, indicating that it created DRCs.

axIDBCreateCircle

```
axIDBCreateCircle(  
    l_location  
    [f_width]  
    [t_layer]  
    [rd_parent]  
)  
⇒ l_result/nil
```

Description

Create a circle at indicated location and with indicated diameter.

Arguments

<i>l_location</i>	Center and radius as (X:Y R).
<i>f_width</i>	Width of circle edge.
<i>t_layer</i>	Layer. Default is the current active layer.
<i>rd_parent</i>	<i>dbid</i> of object to add circle to (symbol instance or <i>nil</i> for design).

Value Returned

<i>l_result</i>	List containing: (car) list of circle <i>dbids</i> . There is always one <i>dbid</i> in the list. (cadr) <i>t</i> if any DRCs are created. <i>nil</i> if no DRCs are created.
<i>nil</i>	Nothing was created.

See Also

[axIDBCreatePath](#)

Create Shape Interface

You can create shapes using AXL functions as follows:

- To create a simple shape, filled or unfilled, without any voids, first create its boundary path using the `axlPath` functions described earlier. Next, call `axlDBCreateShape` using the path as an argument. `axlDBCreateShape` creates the shape in the database and returns, completing the process.
- To create a shape with voids, first create a shape in “open state” using `axlDBCreateOpenShape`. Next, add voids to the shape as needed using `axlDBCreateVoid` and `axlDBCreateVoidCircle`. Finally, put the shape permanently into the database with `axlDBCreateCloseShape`.

This final function changes the state of the shape from “open” to “closed,” making it a permanent part of the database. Only one shape can be in the “open” state at one time.

You specify both shape and void boundaries with the `r_path` argument, just as you do creating lines and connect lines. `axlDBCreateShape` and `axlDBCreateOpenShape` also check that the following are true:

- All boundary path arguments—shape or void—are closed (equal `startPoint` `endPoint`)
- No boundary path segments touch or cross (no “bow ties”).
- All void boundaries are completely within the boundary of their parent shape

If you fail to meet one or more of these conditions, the functions do not create the shape or void, and return `nil`.

Example

- Closes the shape so that it fills and the command does DRC


```
mypath = axlPathStart( list(1000:1250))
mypath = axlPathLine( mypath, 0.0, 2000:1250)
mypath = axlPathArcCenter(
    mypath, 0.0, 2000:3250, nil, 2000:2250)
mypath = axlPathLine( mypath, 0.0, 1500:3250)
mypath = axlPathLine( mypath, 0.0, 1000:1250)
myfill1 = make_axlFill( ?angle 45.0, ?origin 10:20,
    ?width 50, ?spacing 80)
myfill2 = make_axlFill( ?angle 135.0, ?origin 10:20,
    ?width 5, ?spacing 100)
myfill = list( myfill1 myfill2)
myshape = axlDBCreateOpenShape( mypath, myfill,
    "etch/top", "sclk1")
if( myshape == axlDBActiveShape()
    println( "myshape is the active shape"))
axlDBCreateVoidCircle( myshape, list(1600:1700 300))
```

Allegro SKILL Reference

Database Create Functions

```
myvoidpath = axlPathStart( list(1600:2300))
myvoidpath = axlPathLine( myvoidpath, 0.0, 2400:2100)
myvoidpath = axlPathLine( myvoidpath, 0.0, 2600:2700)
myvoidpath = axlPathLine( myvoidpath, 0.0, 2100:3000)
myvoidpath = axlPathLine( myvoidpath, 0.0, 1600:2300)
axlDBCreateVoid(myshape, myvoidpath)
axlDBCreateCloseShape( myshape)
```

- Creates a closed path
- Creates the fill structures specifying the crosshatch parameters
- Creates the open shape on "etch/top" associated with net "sclk1" with axlDBCreateOpenShape
- Checks that the shape created is the active shape using axlDBActiveShape which will print the message
- Creates a circular void and attach it to the shape
- Creates a void shape and attach it to the shape



axlDBCreateOpenShape

```
axlDBCreateOpenShape(  
    o_polygon/r_path  
    [l_r_fill]  
    [t_layer]  
    [t_netName/o_netdbid]  
    [o_parent]  
)  
⇒ o_shape/nil
```

Description

Creates a shape based on the characteristic of either *o_polygon* or *r_path*. With *r_path*, fills parameters, layer, netname, and parent you specify. Returns the *dbid* of the shape in open state. Open state means you can add and delete voids of the shape. With *o_polygon*, creates a shape with the boundary defined by the boundary of the polygon. The holes in the polygon are added as voids to the shape. (See axlPolyFromDB.)

The shape model uses the open/close model for performance reasons. While adding a shape without voids, you can use axlDBCreateShape, which hides the open and close. While adding voids you should do the following:

```
shape = axlDBCreateOpenShape(...)  
... add voids ...  
axlDBCreateCloseShape(shape).
```

You can modify an existing shape by using the axlDBOpenShape command, as follows:

```
axlDBOpenShape(shape <new boundary>)  
... add or delete voids ...  
axlDBCreateCloseShape(shape).
```

Will not allow hole polygons as input. When holes are passed as input, the following warning displays:

```
Invalid polygon id argument -<argument>
```

A static shape is created if you create shape on class ETCH; dynamic shapes are created if class is BOUNDARY. For example, to create a static shape on the TOP layer, make *t_layer=ETCH/TOP*. To make a dynamic shape, make *t_layer=BOUNDARY/TOP*. The same rule also applies to axlDBCreateShape.

fill structure for xhatch shapes is:

I_fill1	A fill_type.
---------	--------------

Allegro SKILL Reference

Database Create Functions

[l_fill2]	(optional) A fill_type. Supplied when more than second xhatch pattern is desired.
[f_outlineWidth]	(optional) Width of outline must be greater than or equal to fill width(s). Specified in design units. Default is current board xhatch width. Only supported for <i>o_polygon</i> since outline width for <i>r_path</i> should be supplied via the <i>r_path</i> defstruct.

where fill_type is a defstruct with members

f_spacing	spacing between xhatches (design units)
f_width	width of xhatch (design units)
l_origin	origin of xhatch (absolute to board)
f_angle	angle of xhatches

Arguments

<i>o_polygon/r_path</i>	The outline as an <i>r_path</i> from axlPathXXX data structure or an <i>o_polygon</i> from axlPolyXXX interfaces.
<i>l_r_fill</i>	List of fill structures (<i>r_fill</i>) for non solid fill shapes or: t →solid fill nil →unfilled
<i>t_layer</i>	Layer name. nil uses the default active layer.
<i>t_netname</i>	Name of net. Only allowed for shapes being added to etch layers.
<i>o_netdbid</i>	Can use <i>DBID</i> of net instead of the netname. Same restrictions apply as for <i>t_netname</i> .
<i>o_parent</i>	axl <i>DBID</i> of the object to add the shape to. Use the symbol instance, or use nil to specify the design itself.

Value Returned

<i>o_shape</i>	axl DBID of the shape. AXL-SKILL does not perform DRC on the shape until you close it using axlDBCreateCloseShape.
nil	No shape created.

Note

An open shape can have voids added to it. It is not DRC checked or filled, until axlDBCreateCloseShape is called.

A path starts at `startPoint` and a segment is created for each segment in the `pathList`. If the path does not end at the `startPoint`, it is considered an error.

A list of `o_polygons` is not considered valid input. Only a single `o_polygon` is correct input.

All path segment coordinates are absolute.

Allegro PCB Editor allows only one shape to be in open state at one time.

See Also

[axlDBActiveShape](#), [axlDBOpenShape](#), [axlDBCreateVoid](#), [axlShapeDeleteVoids](#), [axlDBCreateCloseShape](#), [axlDBCreateRectangle](#), [axlDBCreateShape](#), [axlDBCreateVoidCircle](#), and [axlShapeAutoVoid](#)

Example

■ Create a shape using rpath

```
path = axlPathStart( list( 0:0 400:000 600:400 400:600 0:0))

shp = axlDBCreateOpenShape(path); defaults to a solid filled shape
; unless layer allows unfilled only

; This is optional unless you are adding a shape to etch
; If you do axlDBCreateShape it automatically closes it for you
axlDBCreateCloseShape(car(shp))
```

■ Create a shape using a poly

```
p1 = axlPolyFromDB(inElem)
; add it as an unfilled shape on BOARD GEOMETRY/OUTLINE
```

Allegro SKILL Reference

Database Create Functions

```
res = axlDBCreateShape( car(p1) nil "BOARD GEOMETRY/OUTLINE")
```

- See examples `axldbctshp.il`.

axlDBCreateCloseShape

```
axlDBCreateCloseShape (
  o_shape
  [g_forceShape]
)
⇒ l_result/nil
```

Description

Closes the open shape and applies the fill pattern specified in `axlDBCreateOpenShape`. Then performs DRC. If the fill fails, returns `nil`.

Arguments

<i>o_shape</i>	<i>dbid</i> of the open shape created by <code>axlDBCreateOpenShape</code> .
<i>g_forceShape</i>	By default, Allegro creates a rectangle in its database when an outline is a rectangle. This is for performance and space reasons. To override this behavior, pass the argument value as <code>t</code> when closing a shape.
<i>r_fill</i>	Shape can be filled differently than voided. This should only be done with xhatch shapes and should use spacing/width in power of two multiples. We strongly discourage this option. Used in place of <code>g_forceShape</code> .

Value Returned

<i>l_result</i>	List:\n\n (car) <i>dbid</i> of the shape created.\n\n (cadr) <code>t</code> if DRCs are created. <code>nil</code> if DRCs are not created.
<code>nil</code>	Nothing was created.

Example

See [Create Shape Interface](#) on page 851 for an example.

axlDBActiveShape

```
axlDBActiveShape(  
    )  
⇒ o_shape/nil
```

Description

Returns the *dbid* of the open shape, if any.

Arguments

None.

Value Returned

<i>o_shape</i>	<i>dbid</i> of the active shape created by axlDBCreateOpenShape.
----------------	---

nil	There is no active shape.
-----	---------------------------

Example

See [Create Shape Interface](#) on page 851 for an example.

axIDBCreateVoidCircle

```
axIDBCreateVoidCircle(  
    o_shape  
    l_location  
    [f_width]  
)  
⇒ o_polygon/nil
```

Description

Creates a circular void in the open shape *o_shape*. Calling this function without an open shape causes an error.

Arguments

<i>o_shape</i>	<i>dbid</i> of the open shape created by axIDBCreateOpenShape.
<i>l_location</i>	Center and radius of the circular void to create. The structure of the argument is: (X:Y R).
<i>f_width</i>	Void edge width used by cross-hatch. Default is 0.

Value Returned

<i>o_polygon</i>	<i>dbid</i> of the circular void created.
<i>nil</i>	Error due to calling the function without an open shape. No void is created.

Example

See [Create Shape Interface](#) on page 851 for an example.

axIDBCreateVoid

```
axIDBCreateVoid(  
    o_shape/nil  
    r_path/o_polygon  
)  
⇒ o_polygon/nil
```

Description

Adds a void to a shape. To add multiple voids it is recommended that you either add the voids when creating the shape ([axIDBCreateShape](#)) or re-open the shape ([axIDBOpenShape](#)) before creating the voids.

Only certain layers, such as ETCH layer, allow voids in a shape. Use [axIOK2Void](#) to determine if shape supports voids. While adding multiple voids to an etch shape, first call [axIDBOpenShape](#), for best performance, add the voids then close the shape ([axIDBCreateCloseShape](#)).

Unless you want the void to be permanent, do not add voids to dynamic shapes. User added voids on dynamic shapes must be put on the dynamic shape, with class=BOUNDARY, not on the generated shape, class=ETCH.

Arguments

o_shape *dbid* of the open shape. If this value is *nil*, the command uses the open shape

r_path Existing path structure created by the [axIPath](#) functions.

Value Returned

o_polygon *dbid* of the void created.

nil Error due to calling the function with no open shape.

See Also

[axIDBCreateShape](#), [axIDBOpenShape](#), [axIOK2Void](#), [axIDBCreateVoidCircle](#)

Example

■ Create Shape Example

See [Create Shape Interface](#) on page 851 for an example.

2) Add to existing shape

See `dbc_shp_t10` function in `ax1dbctshp.il` example code.

axlDBCreateShape

```
axlDBCreateShape(  
    o_polygon/r_path  
    [l_r_fill]  
    [t_layer]  
    [t_netName]  
    [o_parent]  
)  
⇒ l_result/nil
```

Description

Takes the same arguments as `axlDBCreateOpenShape` and adds the `r_path` shape to the database. The difference is that this function creates the shape and puts it into the closed state immediately, rather than leaving it open for modification. Use `axlDBCreateShape` to add shapes without voids.

`axlDBCreateShape` has the same argument restrictions as `axlDBCreateOpenShape`.

Arguments

`o_polygon/r_path` Existing path structure created by `axlPath` functions.

`l_r_fill` One of three possible values:

`t` → create shape solid filled

`nil` → create shape unfilled

List of structures specifying crosshatch parameters for creating the shape:

```
(defstruct axlFill  ;(r_fill) - shape crosshatch data  
  origin          ;a point anywhere on any xhatch line  
  width           ;width in user units  
  spacing         ;spacing in user units  
  angle           ;angle of the parallel lines
```

Note: As with all SKILL defstructs, use the constructor function `make_axlFill` to create instances of `axlFill`. Use the copy function `copy_axlFill` to copy instances of `axlFill`.

`t_layer` Layer on which to create the shape.

`t_netName` Name of the net to which the shape is to belong.

Allegro SKILL Reference

Database Create Functions

o_parent *dbid* of the object to be the parent of the shape. The parent is a symbol instance or is *nil* if the design itself.

Value Returned

<i>l_result</i>	List: (car) <i>dbid</i> of the shape created (cadr) <i>t</i> if DRCs are created. <i>nil</i> if DRCs are not created.
<i>nil</i>	Nothing is created.

Example

See [Create Shape Interface](#) on page 851 for an example.

axIDBCreateRectangle

```
axIDBCreateRectangle(  
    l_bBox  
    [g_fill]  
    [t_layer]  
    [t_netname]  
    [o_parent]  
)  
⇒ l_result/nil
```

Description

Creates a rectangle with coordinates specified by *l_bBox*. If the rectangle is not created, the function returns *nil*.

If *t_netname* is non-null, the rectangle becomes a member of that net. Ignores *t_netname* if the rectangle is unfilled.

Does not create the rectangle and returns *nil* (error) in these instances:

- Net does not exist.
- Attempt to create a filled rectangle on an Allegro PCB Editor layer requiring an unfilled rectangle.
- Attempt to create an unfilled rectangle on an Allegro PCB Editor layer requiring a filled rectangle.

See [axIDBCreateSymbolSkeleton](#) for notes about restrictions on shapes that are part of symbol definitions.

Arguments

<i>l_bBox</i>	Bounding box of the rectangle: Lower left and upper right corners of rectangle
<i>g_fill</i>	If <i>t</i> then the fill is solid. If <i>nil</i> (default) then the rectangle is unfilled.
<i>t_layer</i>	Layer to which to add the rectangle. Default is the active layer.
<i>t_netname</i>	Name of net to which the rectangle is to belong. This argument is meaningful only if the rectangle is being added on an Etch layer.

Allegro SKILL Reference

Database Create Functions

o_parent *dbid* of object of which the rectangle is to be a part. Use either the *dbid* of a symbol instance or use *nil* to specify the design itself.

Value Returned

l_result List:

(car) rectangle *dbid*

(cadr) *t* if DRCs are created. *nil* if DRCs are not created.

nil Nothing is created.

Example

```
axlDBCreateRectangle(list(100:100 200:200))  
axlDBCreateRectangle(list(200:200 400:300) t)  
axlDBCreateRectangle( axlEnterBox() t "ETCH/TOP" 45.0 "net_1")
```

Creates an unfilled rectangle on the active layer with a bounding box of (100:100 200:200) and returns the rectangle's *dbid* in the return list.

Nonpath DBCreate Functions

This section describes the `DBCreate` functions that add nonpath figures to the Allegro PCB Editor database.

axlCreateBondFinger

```
axlCreateBondFinger(
    parentSymbol
    fingerName
    list(fingerLocation fingerRotation fingerPadstack)
    list(placementStyle ewlLength fingerSnap fingerAlign)
)
==> dbid/nil
```

Description

This function adds a valid, fully-instantiated bond finger to the database. Bond fingers created through this interface can be safely manipulated by the wirebond toolset and will also be properly recognized by all aspects of the database (DRC, signal integrity, 3D viewer, and so on).

Arguments

<code>parentSymbol</code>	dbid of the symbol (generally a die) with which this finger should be associated when performing operations like a move or delete.
<code>fingerName</code>	The optional parameter that specifies the name of the bond finger, as stored in the <code>BOND_PAD</code> property.
<code>fingerLocation</code>	The physical information about the bond finger being creation, the location is a database coordinate point, the rotation and angle in degrees, and the padstack the dbid of a padstack to use.
<code>Rotation</code>	
<code>Padstack</code>	
<code>placementStyle/ewlLength/fingerSnap/fingerAlign</code>	The placement data for the bond finger being created, as follows:

Allegro SKILL Reference

Database Create Functions

placementStyle	String value in the following list: <ul style="list-style-type: none">■ Orthogonal■ Equal Wire Length■ On Path■ Free Placement
ewlLength	Length value for Equal Wire Length style, which represents the desired length of the wire.
fingerSnap	String value in the following list: <ul style="list-style-type: none">■ Center of Finger■ Finger Origin■ Near End■ Far End■ Nearest Point■ Farthest Point
fingerAlign	String value in the following list: <ul style="list-style-type: none">■ Aligned with Wire■ Orthogonal to Die Side■ Orthogonal to Guide■ Pivoting Ortho to Guide■ Average Wire Angle■ Constant Angle■ Match CW Neighbor■ Match CCW Neighbor

Value Returned

- `dbid` of newly created bond finger if successful.
- `nil` if an error occurred (message printed to status window).

axlCreateBondWire

```
axlCreateBondWire(  
    parentSymbol  
    list(wireStartOwner wireStartLocation)  
    list(wireEndOwner wireEndLocation)  
    list(wireDiameter wireProfile)  
)  
==>dbidt/nil
```

Description

This function adds a valid, fully-instantiated bond wire to the database. Bond wires created through this interface can be safely manipulated by the wirebond toolset and will also be properly recognized by all aspects of the database (DRC, signal integrity, 3D viewer, etc).

Arguments

parentSymbol	dbid of the symbol (generally a die) with which this wire should be associated when performing operations like a move or delete.
wireStartOwner/Location	Optional. This is a list with the first item being, the dbid of the object to which the start of the wire attaches. If this object is a pin or finger, the location will be derived from the object's origin. If the object is a shape, you must pass the location for the connection as well.
wireEndOwner/Location	- This is a list with the first item being, the dbid of the object to which the end of the wire attaches. If this object is a pin or finger, the location will be derived from the object's origin. If the object is a shape, you must pass the location for the connection as well.
wireDiameter/Profile	- This list of two items describes the physical placement of the wire in terms of its 3D profile (a string) and the wire diameter (a number).

Value Returned


- dbid of newly created bond wire if successful.
- nil if an error occurred (message printed to status window).

axlDBCreateExternalDRC

```
axlDBCreateExternalDRC(
    t_constraint/lt_constraint
    l_anchor_point
    [t_layer]
    [lo_dbid]
    [l_secondPoint]
    [t_actualValue]
)
⇒ l_result/nil
```

Description

Creates an externally-defined (by user) DRC containing the values given in the arguments. An externally defined DRC marker always has the two characters “X D” in it.



You may pass the constraint as the traditional argument (*t_constraint*) where this contains both the constraint and expected value in a one string. The downside of this method is that the `show element` and `reports` commands report 0 for the `expectValue`. Alternatively, you can pass it as a list containing two strings: constraint name and expected value. This format reports properly in both the `show element` and `reports` commands. Note `constraint` and `expectValue` are implemented as properties on the external drc `dbid` whose names are `EXTERNAL_VIOLATION_DESCRIPTION` and `EXTERNAL_DRC_VALUE`.

The *t_actualValue* argument is optional and provides an externally-defined actual value for the DRC with units.

Note: Attempting to create a DRC object on a non-DRC class is an error. You can use this function in the layout editor, but not in the symbol editor.

Allegro SKILL Reference

Database Create Functions

Arguments

<i>t_constraint</i>	Name of the violated constraint. String contains the type of constraint and the required value and comparison.
<i>lt_constraint</i>	Alternative method it is a list of (<i>t_constraint t_expectValue</i>)
<i>l_anchor_point</i>	Coordinate of the DRC marker.
<i>t_layer</i>	Layer of the DRC marker.
<i>lo_dbid</i>	Optional list of the objects that caused the DRC (maximum of two).
<i>l_secondPoint</i>	Second reference point. This is a coordinate on the object of the DRC pair that does not have the DRC marker on it. Using this point, you can identify the second object involved in causing the DRC by reading the DRC data in later processes.
<i>t_actualValue</i>	Actual value that caused the DRC.

Value Returned

<i>l_result</i>	List: (car) <i>dbid</i> of the DRC created (always only one) (cadr) <i>t</i> (always)
<i>nil</i>	Nothing is created.

Example

Creates a user defined DRC marker at x1500, y1800 to mark a violation of user rule: "Line to Pin--MY SPACING RULE" with a required value of 12 and an actual value of 10.

Original method:

```
ax1DBCreateExternalDRC( "Line to Pin--MY SPACING RULE/
    req:12; actual:10", 1500:1800
    "drc error/all", nil, nil, "10 MILS")
```

New method for better show element and reports command behavior:

```
ax1DBCreateExternalDRC('("My Spacing Line to Pin" "12")
```

Allegro SKILL Reference

Database Create Functions

```
1500:1900 "top", nil nil "10 MILS")
```

The function adds an “X D” DRC marker at x1500, y1800.

Allegro SKILL Reference

Database Create Functions

The DRC marker displays the following information with the *Show – Element* command:

```
LISTING: 1 element(s)
< DRC ERROR >
Class: DRC ERROR CLASS
Subclass: ALL
Origin xy: (1500,1800)
CONSTRAINT: Externally Determined Violation
CONSTRAINT SET: NONE
CONSTRAINT TYPE: LAYOUT
Constraint value: 0 MIL
Actual value: 10 MILS
Properties attached to drc error
EXTERNAL_VIOLATION DESCRIPTION = Line to Pin--MY SPACING
RULE/req:12; actual:10
-----
```

axlDBCreatePadStack

```
axlDBCreatePadStack(  
    t_name  
    r_drill  
    l_pad  
    [g_nocheck]  
)  
⇒ l_result/nil
```

Description

Adds a padstack *t_name*, using drill hole *r_drill* and pad definition *l_pad*.

Defstructs used to create padstack

Drill (*r_drill*) use make_axlPadStackPad. Elements are:

fixed = (t/nil) internal fixed flag

uvia = (t/nil) if padstack is of type bbvia set as sub-type micro-via

keepout = (t/nil) if padstack is used for mechanical pins, its anti-pads have been set-up to act as route keepouts. If this pad is used for logical pins then this option is ignored.

drillDiameter = (float) drill hole size setting

figure = (symbol) the drill figure. Allowed symbols are NULL, CIRCLE, SQUARE, HEXAGON, HEXAGON_X, HEXAGON_Y, OCTAGON, CROSS, DIAMOND, TRIANGLE, OBLONG_X, OBLONG_Y, RECTANGLE. Note nil is treated as NULL.

figureSize = ((f_width f_height)) size of drill figure

offset = ((f_x f_y)) drill hole offset

plating = (symbol) plate status of drill hole
Symbols are: NON_PLATED, OPTIONAL, nil

drillChars = (string) drill characters identifier. Up to two characters are allowed.

multiDrillData = list for multiple drill data which is:
((x_num_rows nx_um_columns f_clearance_x

Allegro SKILL Reference

Database Create Functions

```
[f_clearance_y ["staggered"]]) )
data type is (int int float [float])

holeType = (symbol) the hole type. Allowed symbols are CIRCLE_DRILL,
OVAL_SLOT, RECTANGLE_SLOT.
nil is treated as CIRCLE_DRILL.

slotSize = ( (f_width f_height) ) size of slot hole

holeTolerance = (f_pos f_neg) ) +/- hole tolerance

drillNonStandard = (symbol) non-standard drill hole. Allowed symbols are
LASER_DRILL, PLASMA_DRILL, PUNCH_DRILL,
PHOTO_DRILL, COND_INK_DRILL, OTHER_DRILL.
```

Pad (*l_pad*) structure (up to 3 for each layer)

```
layer = (string) etch layer name (example: "TOP") or
"DEFAULT_INTERNAL" if you want one pad layer to map to all
internal layers between the top and bottom of the padstack.

type = (symbol) pad type
Allowed symbols: ANTIPAD, THERMAL or REGULAR. nil is
treated as REGULAR.

flash = (string) the pad aperture flash name. Reference a flash,
shape symbol name or nil for no flash.

figure = (symbol) the pad figure
Allowed symbols: NULL, CIRCLE, SQUARE, FLASH,
RECTANGLE, OBLONG_X, OBLONG_Y, OCTAGON. If NULL,
checks the figureSize and automatically assigns a figure type. If
you assign a type, the figureSize must match that type. For
example, a SQUARE must have both width and height of the
same value.
```

For shape symbol use the name of the *ssm* (minus extension and path) to figure. For example, if you have a shape symbol called *myshape* then it would be '?figure "myshape"'.

For an Anti-pad shape (fsm), assign the symbol 'FLASH and assign the fsm file (minus extension and path) to the flash name. For example, symbol "myflash" would be '?figure 'FLASH ?flash "myflash"'.

Allegro SKILL Reference

Database Create Functions

For either a shape or flash, the symbol must be located via PADPATH. Also, the ?figureSize attribute must be the extents of the symbol or larger.

`figureSize = ((f_width f_height))` height and width of the figure.
For a circle, you only need to assign diameter to either height/width, the other can be 0.

`offset = ((f_x f_y))` offset from the padstack origin

Arguments

`t_name` Padstack name.

`r_drill` Drill hole data for the padstack.

Note: As with all SKILL defstructs, use the constructor function `make_axlPadStackPad` to create instances of `axlPadStackPad`. See [Create Shape Interface](#) on page 851 for an example.

`l_pad` Pad definition data for the padstack.

Note: As with all SKILL defstructs, use the constructor function `make_axlPadStackPad` to create instances of `axlPadStackPad`. See [Create Shape Interface](#) on page 851 for an example.

`g_nocheck` Optional. `t` disables checks of the padstack definition. `nil` executes the following checks of the padstack definition:

- Contiguous pad definitions
- Anti-pad / thermal-relief pad definitions
- Existence of two pads with a drilled hole
- A drilled hole with the existence of two pads

Value Returned

`l_result` `dbid` of the padstack created.

`nil` Nothing is created.

See Also

[axlPadstackEdit](#), [axlLoadPadstack](#), [axlDBCopyPadstack](#)

Examples

Surface Mount Padstack Example

See <cdsroot>/share pcb/examples/skill/dbcreate/pad.il

The following example adds a surface mount padstack having a 25 by 60 rectangular pad on the top layer.

```
pad_list = cons(make_axlPadStackPad(
    ?layer "TOP", ?type 'REGULAR,
    ?figure 'RECTANGLE, ?figureSize 25:60) nil)
ps_id = axlDBCreatePadStack("smt_pad", nil, pad_list t)
```

The following example adds a padstack with an 80 diameter circle pad on the top layer, 75 diameter circle pad on internal layers, 80 square pad on the bottom layer and a 42 plated thru hole. The drill symbol will be a 60 square.

```
drill_data = make_axlPadStackDrill(?drillDiameter 42
    ?figure 'SQUARE, ?figureSize 60:60, ?plating 'PLATED)
pad_list = cons(make_axlPadStackPad(?layer "TOP",
    ?type 'REGULAR, ?figure 'CIRCLE,
    ?figureSize 80:80) pad_list)
pad_list = cons(make_axlPadStackPad(
    ?layer "DEFAULT INTERNAL", ?type 'REGULAR,
    ?figure 'CIRCLE, ?figureSize 75:75) pad_list)
pad_list = cons(make_axlPadStackPad(
    ?layer "BOTTOM", ?type 'REGULAR,
    ?figure 'SQUARE, ?figureSize 80:80) pad_list)
ps_id = axlDBCreatePadStack("thru_pad", drill_data, pad_list t)
```

To use a shape symbol “myshape”, do

```
pad = make_axlPadStackPad(?layer "TOP",
    ?type 'REGULAR, ?figure "myshape"
    ?figureSize 80:80) pad_list)
```

To use a flash symbol “myflash”, do

Allegro SKILL Reference

Database Create Functions

```
pad = make_ax1PadStackPad(?layer "TOP",
    ?type 'THERMAL,
    ?figure 'FLASH ?flash "myflash"
    ?figureSize 80:80 ) pad_list)
```

axlDBCreatePin

```
axlDBCreatePin(
    t_padstack/o_padstackDbid
    l_anchorPoint
    r_pinText/nil
    [f_rotation]
)
⇒ l_result/nil
```

Description

Adds a pin with padstack *t_padstack*, pin name *r_pinText* at location *l_anchorPoint*, and rotated by *f_rotation* degrees.

Notes:

- 1) This interface may only be used in the Symbol Editor.
- 2) Use axlDBCreatePin only in package and mechanical symbol drawings. Creating a pin in any other type of drawing causes errors.
- 3) Use *nil* for *r_pinText* to create a mechanical pin.

Arguments

t_padstack Padstack name for the via. If a padstack definition with this name is not already in the layout, the function searches in order the libraries specified by `PADPATH` and loads the definition into the database.

o_padstackDbid a padstack dbid

l_anchorPoint Layout coordinates of the location to add the pin.

r_pinText Pin number text structure:

```
(defstruct axlPinText ;(r_pinText) - pin number text data
  number      ;pin number as a text string
  offset      ;offset (X:Y) for pin number text
  text)       ;axlTextOrientation - ;for positioning text
```

This requires the `axlTextOrientation` structure:

```
defstruct axlTextOrientation
  ;;(r_textOrientation) - description of
  ;; the orientation of text
  textBlock    ;string - text block name
```

Allegro SKILL Reference

Database Create Functions

```
rotation      ; rotation in floatnum degrees
mirrored      ; t-->mirrored, nil --> not mirrored
               ; 'GEOMETRY --> only geometry is mirrored
justify       ; "left", "center", "right"
```

Note: As with all SKILL defstructs, use constructor functions `make_axlPinText` to create instances of `axlPinText` and `make_axlTextOrientation` for `axlTextOrientation`. See [Create Shape Interface](#) on page 851 for an example. Use `copy` functions `copy_axlPinText` to copy instances of `axlPinText` and `copy_axlTextOrientation` for `axlTextOrientation`.

f_rotation Rotation of pin in degrees.

Value Returned

l_result List:

 (car) *dbid* of the pin

 (cadr) *t* if DRCs are created. *nil* if DRCs are not created.

nil Nothing is created.

Example

- The following example adds pins "1", "2", "3", and a mechanical to a package symbol drawing. Pin "1" with a square pad is rotated 45 degrees, pins "2" and "3" with round pads, and pin "3" with its pin text mirrored.

```
mytext = make_axlTextOrientation(
           ?textBlock 6, ?rotation 60.0
           ?mirrored nil ?justify "center")

mypad = make_axlPinText(?number "1",
                        ?offset 0:75, ?text mytext)


axlDBCreatePin( "pad1" 0:0 mypad 45.0)
mytext->justify = "left"
mytext->rotation = 0.0
mypad->number = 2
mypad->offset = -125:0
axlDBCreatePin( "pad0" -100:-100 mypad)
mytext->rotation = -45.0
```

Allegro SKILL Reference

Database Create Functions

```
mytext->justify = "right"
mytext->mirror = t
mypin->number = 3
mypin->offset = 50:0
axlDBCreatePin( "pad0" 100:-100 mypin)
mypin->mytext = nil
axlDBCreatePin( "pad0" 100:100 mypin)
```

Adds the three pins in the positions shown:



■ 2) Create 8 pins using a loop

```
x=1000.0
y=1000.0

myText = make_axlTextOrientation(?textBlock 6
                                ?justify "center")
myPin= make_axlPinText(?offset 0:0 ?text myText)

for(i 1 8
    y=y-100
    sprintf(buf "a%d" i)
    myPin->number = buf
    axlDBCreatePin("VIA" x:y myPin)
)
)
```

axlDBCreateSymbol

```
axlDBCreateSymbol(
  t_refdes
  l_anchorPoint
  [g_mirror]
  [f_rotation]
  [t_embeddedLayer]
)
⇒ l_result/nil

axlDBCreateSymbol(
  l_symbolData
  l_anchorPoint
  [g_mirror]
  [f_rotation]
  [t_embeddedLayer]
)
⇒ l_result/nil
```

Description

Places a symbol instance in the design. Creates a symbol instance at location *l_anchor_point* with the given mirror and rotation. Examines its first argument to determine what symbol to add, as explained later. Next, searches for the symbol in the symbol definitions, first in the layout, then in the `PSMPATH`. Loads the definition if it is not already in the layout and creates the symbol instance. Returns `nil` a symbol definition is not found.

Note: Do not use this function in the symbol editor.

Arguments

The first argument can be either *t_refdes* or *l_symbolData*, as described here:

<i>t_refdes</i>	Reference designator of the component. If this is the first argument, the function looks for a component in the layout with that refdes, finds the package symbol required for its component device type, adds a package symbol with the symbol name prescribed by the component definition, and assigns that refdes to the symbol (example, refdes U1 requires a DIP14 package symbol). Returns <code>nil</code> if it cannot find the given refdes.
<i>l_symbolData</i>	If this is the first argument, the function looks for the symbol, symbol type, and refdes specified by this structure.

Allegro SKILL Reference

Database Create Functions

l_symbolData is a list (*t_symbolName* [[*t_symbolType* [*t_refdes*]])*,* where:

t_symbolName is the name of the symbol (example: DIP14)

t_symbolType is a symbol type: "PACKAGE" (default),
"MECHANICAL" or "FORMAT"

t_refdes is an optional refdes; if *t_refdes* is present,
t_symbolType must be "PACKAGE".

An example is the list: ("DIP16" "package" "U6")

To create a component with an alternate symbol, that is, a symbol different from the one specified in the component library, use the *l_symbolData* structure. For example, refdes C7 might be a capacitor requiring the top-mount package "CAP1206F". However, your design requires the alternative package "CAP1206B" on the bottom side of the layout.

To create the component mirrored, use ax1DBCreateSymbol with the *l_symbolData* argument:

"CAP1206B" "package" "C7")

t_refdes

Reference designator of the component associated with the symbol to be created.

l_symbolData

List (*t_symbolName* [[*t_symbolType* [*t_refdes*]])*.* (See example above.)

l_anchorPoint

Layout coordinates specifying where to create the symbol.

g_mirror

nil →create unmirrored. (default)
t →create symbol mirrored.
'GEOMETRY →geometry is mirrored.

f_rotation

Rotation of the symbol in degrees.(default is 0)

t_embeddedLayer

Place on embedded layer. Layer must be enabled for embedded. Mirror option is ignored. Layer may either be fully qualified ("ETCH/GND") or just the subclass ("GND"). May not use the top or bottom layer.

Allegro SKILL Reference

Database Create Functions

Value Returned


nil	Nothing is created.
l_result	a list containing: (car) axl DBID of the symbol created (cadr) t if DRCs are created. nil if DRCs are not created.

Note: The symbol definition in the drawing is used. If there is none in the drawing, then the symbol library is searched and the definition loaded.

Example

```
axlDBCreateSymbol("y29", 5600:4600)
=>(dbid:423143 nil)
```

Creates a symbol with the assigned refdes.




```
axlDBCreateSymbol( list( "dip14" "package"), 5600:4600)
=>(dbid:423144 nil)
```

Allegro SKILL Reference

Database Create Functions

Creates a symbol with the unassigned refdes, just the generic U*:



- Typical component driven symbol placement:

```
p = axlDBCreateSymbol("U1" 2175:1000)
```

- Place an embedded component. Assumes a layer, SIGNAL_2 is enabled for embedded.

```
p = axlDBCreateSymbol("R1" 2175:1000 nil nil "SIGNAL_2")
```

- Place non-logical package symbol with rotation of 90

```
p = axlDBCreateSymbol('("R_0402" "PACKAGE") 2000:800.1 nil 90.0)
```

axlDBCreateSymbolSkeleton

```
axlDBCreateSymbolSkeleton (
    t_refdes
    l_anchorPoint
    g_mirror
    f_rotation
    l_pinData
    [t_embeddedLayer]
)
⇒ l_result/nil
```

or

```
axlDBCreateSymbolSkeleton (
    l_symbolData
    l_anchorPoint
    g_mirror
    f_rotation
    l_pinData
    [t_embeddedLayer]
)
⇒ l_result/nil
```

Description

Places a skeleton or a minimal symbol instance at *l_anchorPoint* with mirror and rotation given but no data in the instance, except the pin data given by *l_pinData*. This is a list of *axlPinData* defstructures defining the data for all pins. The pin count and pin numbers must match that of the library symbol definition. The symbol definition must exist in the database or on LIBPATH.

Behaves like *axlDBCreateSymbol*, except that it adds no symbol data except the symbol pins in the instance. Use to create the “foundation” of a symbol. Then build, using *axlDBCreate* functions to add lines, shapes, polygons, and text as required.

Use, for example, to construct symbols when translated from other CAD systems that define symbol instances in different ways than Allegro PCB Editor.

AXL-SKILL applies each *axlPinData* instance in *l_pinData* only to the pin specified by its *number*. (See the description of the *l_pinData* argument below.) A *nil* value for *l_pinData* means *axlDBCreateSkeleton* adds the pins as they are in the library definition of the symbol. You can selectively customize none, one, or any number of the pins of the symbol instance you create.

Note: Do not use this function in the symbol editor.



This function is intended for programmers with a high level of knowledge of the Allegro PCB Editor database model. It provides a powerful method for creating symbols within Allegro PCB Editor. Although you can use this command to create non-conventional symbols, the rest of Allegro PCB Editor may not behave as you expect. To ensure a symbol behaves as a conventional symbol, you must ensure that what you create abides by symbol rules. For example, you can create a symbol with no attached graphics. Allegro PCB Editor's Find utility will not be able to find it. Another programmer may use this feature to create a temporary symbol instance as a placeholder.

Through interaction, the user changes this symbol into a conventional Allegro PCB Editor symbol.

Arguments

The first argument may be either `t_refdes` or `l_symbolData`, as described here:

`t_refdes` If this is the first argument, the function looks for a component in the layout with that refdes, finds the package symbol required for its component device type, adds a package symbol with the symbol name prescribed by the component definition, and assigns that refdes to the symbol (example, refdes U1 requires a DIP14 package symbol). Returns `nil` if it cannot find the given refdes.

`l_symbolData` If this is the first argument, the function looks for the symbol, symbol type, and refdes specified by this structure.

`l_symbolData` is a list

`(t_symbolName [[t_symbolType [t_refdes]]]), where:`

`t_symbolName` is the name of the symbol (example: DIP14)

`t_symbolType` is a symbol type: "PACKAGE" (default), "MECHANICAL" or "FORMAT"

`t_refdes` is a refdes; if `t_refdes` is present, `t_symbolType` must be "package"

Example of a list: ("DIP16" "package" "U6").

Allegro SKILL Reference

Database Create Functions

To create a component with an alternate symbol, a symbol different from the one specified in the component library, use the *l_symbolData* structure.

For example, refdes C7 is a capacitor requiring the top-mount package "CAP1206F". Your design requires the alternative package "CAP1206B" on the bottom side of the layout.

To create the component mirrored, use `axlDBCreateSymbol` with the *l_symbolData* argument:

```
"CAP1206B" "package" "C7")
```

l_anchorPoint

Layout coordinates of the location to create the symbol. This will be the origin of the symbol.

g_mirror

nil → create unmirrored (default).
t → create symbol mirrored.
'GEOMETRY → geometry is mirrored.

f_rotation

Rotation angle of the symbol in degrees.

nil → 0.0.

l_pinData

List of `axlPinData` defstructs for any pins you require to be different from their library definition, as shown below:

```
(defstruct axlPinData; (r_pinData) - pin data
  number      ;pin number as a text string
  padstack    ;padstack for the pin (text string)
  origin      ;relative location (X Y) of the pin
  rotation   ;relative rotation of pin in degrees)
```

Note: As with all SKILL defstructs, use the constructor function `make_axlPinData` to create instances of `axlPinData`. Use the copy function `copy_axlPinData` to copy instances of `axlPinData`.

t_embeddedLayer

Place on embedded layer. Layer must be enabled for embedded. Mirror option is ignored. Layer may either be fully qualified ("ETCH/GND") or just the subclass ("GND"). May not use the top or bottom layer.

Allegro SKILL Reference

Database Create Functions

Value Returned


l_result nil – Nothing is created.
List Containing the following:
 (car) axl DBID of the symbol created
 (cadr) t if DRCs are created. nil if DRCs are not created.

Example


```
mypins = list( make_axlPinData( ?number "2",
    ?padstack "pad1", ?origin -100:-100 ?rotation 45)
make_axlPinData( ?number "4", ?padstack "pad1",
    ?origin -100:-300 ?rotation 45)
make_axlPinData( ?number "6", ?padstack "pad1",
    ?origin -100:-500 ?rotation 45)
make_axlPinData( ?number "9", ?padstack "pad1",
    ?origin 200:-500 ?rotation 45)
make_axlPinData( ?number "11", ?padstack "pad1",
    ?origin 200:-300 ?rotation 45)
make_axlPinData( ?number "13", ?padstack "pad1",
    ?origin 200:-100 ?rotation 45))

axlDBCreateSymbolSkeleton( list("dip14"),
    5600:4600, nil, 0, mypins)
    fi (dbid:426743 nil)
```

Adds a DIP14 symbol with all even-numbered pins having the same padstack as pin 1, rotated 45 °, and offset -100 mils.



Library symbol



Skeleton symbol created
by code sample above

axlDBCreateText

```
axlDBCreateText(  
    t_text  
    l_anchorPoint  
    r_textOrientation  
    [t_layer]  
    [o_attach]  
)  
⇒ l_result/nil
```

Description

Creates a text string in the layout using the arguments described.

Arguments

t_text Text string to add. axlDBCreateText accepts newlines embedded in the text. Each newline causes the function to create a new text line as a separate database object. The function returns the *dbids* of all text lines it creates. The *textBlock* parameter block specified in the axlTextOrientation structure specifies spacing between multiple text lines.

l_anchorPoint Layout coordinates of the location to add the text.

r_textOrientation axlTextOrientation structure:

```
defstruct axlTextOrientation  
    ;;(r_textOrientation) - description of  
    ;; the orientation of text  
    textBlock  ;string - text block name  
    rotation   ;rotation in floatnum degrees  
    mirrored   ;t-->mirrored, nil --> not mirrored,  
                ;'GEOMETRY --> only geometry is mirrored  
    justify     ;;"left", "center", "right"
```

Note: As with all SKILL defstructs, use the constructor function make_axlTextOrientation to create instances of axlTextOrientation. Use the copy function copy_axlTextOrientation to copy instances of axlTextOrientation.

t_layer Name of the layer on which the text is to be added.

Allegro SKILL Reference

Database Create Functions

o_attach *DBID* of the object to which the text must be attached, or use *nil* for the design.

Value Returned

l_result Otherwise the function returns a list:
 (car) list of text *DBIDs* created, one for each line of text input
 (cadr) *t* if DRCs are created. Otherwise the function returns *nil*.

nil Nothing is created.

Notes

- If *o_attach* is a symbol instance, then the text is “stand alone”, but a child of the symbol instance.
- If the *t_text* string contains NEWLINEs, then multiple text records will be created (and multiple *DBIDs* returned).

See Also

[axlTextOrientationCopy](#), [axlDBChangeText](#)

Example

The following example adds the e text string “Chamfer both sides” center justified, mirrored and rotated 60 degrees.

```
myorient = make_axlTextOrientation(?textBlock "8", ?rotation 60.0,
                                    ?mirrored t, ?justify "center")
ret = axlDBCreateText( "Chamfer both sides", 7600:4600,
                      myorient, "board geometry/plating_bar", nil)
==> (dbid:526743 nil)
```

Allegro SKILL Reference

Database Create Functions

Adds the text string “Chamfer both sides” center justified, mirrored and rotated 60°.



axlDBCreateVia

```
axlDBCreateVia(  
    t_padstack/o_padstackDbid  
    l_anchorPoint  
    [t_netName]  
    [g_mirror]  
    [f_rotation]  
    [o_parent]  
)  
⇒ l_result/nil
```

Description

Creates a via in the layout as specified by the arguments described below.

Arguments

<i>t_padstack</i>	Padstack name. If a padstack definition with this name is not already in the layout, the function searches in order the libraries specified by <code>PADPATH</code> and loads the definition into the database.
<i>o_padstackDbid</i>	a padstack dbid
<i>l_anchorPoint</i>	Layout coordinates of the location to create the via.
<i>t_netName</i>	Name of the net to which the via is to belong; <code>nil</code> → via is stand-alone.
<i>g_mirror</i>	<code>t</code> → create via mirrored. <code>nil</code> → create via unmirrored. <code>'GEOMETRY</code> → only geometry is mirrored.
<i>f_rotation</i>	Rotation of via in degrees.
<i>o_parent</i>	<code>DBID</code> of the object to which to attach the via. Use a symbol instance or use <code>nil</code> to specify the design itself.

Value Returned

<i>l_result</i>	List: (car) <code>DBID</code> of the via created.
-----------------	--

Allegro SKILL Reference

Database Create Functions

(cadr) t if DRCs are created. nil if DRCs are not created.

nil Nothing is created.


Note

`axlDBCreateVia` cannot create a test point. You have to create testpoints by using the `axlTestPoint` function.

Example

```
myvia = axlDBCreateVia( "pad1", 5600:4200,  
                       "sclk1", t, 45., nil)  
                       ⇒ (dbid:526745 nil)
```

Adds a standalone via using padstack "pad1" at x5600 y4200 on net "sclk1", mirrored and rotated. Adds a via rotated at 45 degrees:



axlDBCreateSymbolAutosilk

```
axlDBCreateSymbolAutosilk(  
    o_symbol  
)  
⇒ t/nil
```

Description

Creates or updates the AUTOSILK information for the specified symbol, as required. Also updates, as required, any other AUTOSILK information near the symbol.

Arguments

o_symbol *dbid* of the symbol.

Value Returned

t A valid symbol *dbid* is provided.

nil The *dbid* provided is not for a valid symbol.

axlCreateWirebondGuide

```
axlCreateWirebondGuide(  
    r_path  
)  
==> dbid/nil
```

Description

This function adds a wirebond guide path into the design, which can then be used to snap fingers through the wirebond tools.

Arguments

r_path	Existing path consisting of the straight-line and arc segments previously created by axlPath functions
--------	--

Value Returned

- dbid of newly created guide path if successful.
- nil if an error occurred (message printed to status window).

Property Functions

This section describes the `DBCreate` functions you use to create your own (user-defined) property definitions, and add properties to database objects.

axlDBCreatePropDictEntry

```
axlDBCreatePropDictEntry(
    t_name
    t_type
    lt_objects/t
    [ln_range]
    [t_units]
    [g_hidden])
)
⇒ od_propDictEntry/nil

axlDBCreatePropDictEntry(
    nil
)
==> lt_availbeObject
```

Description

Creates an Allegro user-defined property dictionary entry with given attributes. Once a dictionary entry is created, the property can then be attached to objects.

STRING property values are limited to 1024. STRING_ID allows property values up to 4096. STRING_ID is not currently supported in "define property" dialog of Allegro PCB Editor.

If you need to store larger data within the database, use attachments ([axlCreateAttachment](#)).

Arguments

t_name Name of the property. Must be different from all other property names in the design, both Allegro PCB Editor pre-defined and user-defined property names.

t_type Data type of the property value.

Legal values are:

Typical: BOOLEAN, INTEGER, REAL, STRING, and DESIGN_UNITS.

Other supported types are:

Allegro SKILL Reference

Database Create Functions

ALTITUDE
CAPACITANCE
DISTANCE
ELEC_CONDUCTIVITY
FAILURE_RATE
IMPEDANCE
INDUCTANCE
LAYER_THICKNESS
NAME
NOISE_VOLTAGE
PERCENTAGE
PROP_DELAY
RESISTANCE
TEMPERATURE
THERM_CONDUCTANCE
THERM_CONDUCTIVITY
THERM_RESISTANCE
VOLTAGE
VELOCITY
STRING_ID

1t_objects

List of strings representing the object types to which this property can be added. (Use `ax1DBGetPropDictEntry (nil)` to get a list of valid objects). If only a single object type is allowed, then it

Allegro SKILL Reference

Database Create Functions

may be specified as a string, rather than a list containing one string.

If this value is t then all allowed properties are allowed.

ln_range

List of the lowest and highest legal values for the (numeric) property. If the first value is nil, it means negative infinitely. If the second value is nil, it means infinity.

t_units

A text string so be used with data types (*t_type*) without units, such as STRING, INTEGER, or REAL.

g_hidden

t property is hidden from the user. Hidden properties are not shown in any Allegro UI like Constraint Manager, Show Element or Property Edit. Hidden properties can be accessed via SKILL. Typically, properties are hidden if they are only meant to be changed outside of the SKILL program. Hidden properties are also visible via extracta.

Value Returned

o_propDictEntry DBID of the property dictionary entry created.

nil Property not created.

See Also

[axlDBAddProp](#), [axlCreateAttachment](#)

Example

- Add a new property of type string, supported on db objects

```
propDoct = axlDBCreatePropDictEntry("ACME" "STRING" t)
```

- Create MYPROP as a real number property with range -50 to 100 units of "level", attachable to pins, nets, and symbols.

```
axlDBCreatePropDictEntry( "myprop", "real", list( "pins" "nets" "symbols"),
list( -50. 100), "level")
propDict:2421543
```


Allegro SKILL Reference

Database Create Functions

To check

1. From Allegro PCB Editor, select *Setup – Property Definitions*.

The Define User Properties window appears.



2. Select *MYPROP* from the Available Properties list.

ax1DBAddProp

```
ax1DBAddProp(  
    lo_attach  
    ll_name_value  
)  
⇒ l_result/nil
```

Description

Adds all the property/value pairs listed in *ll_name_value* to all the object *dbids* listed in *lrd_attach*. If a particular object does not accept a particular property name in *ll_name_value*, ax1DBAddProp silently ignores that combination, and continues. If an object already has the specific property attached, ax1DBAddProp silently replaces its original value with the one specified in *ll_name_value*.

If any errors occur or if ax1DBAddProp has not added or changed any properties, the function returns nil.

Arguments

<i>lo_attach</i>	List of Allegro PCB Editor object dbids to which to add the property/value combinations listed in <i>ll_name_value</i> . A list of nil denotes attachment to the design (<i>list nil</i>). However, if <i>lo_attach</i> is nil, there are no objects for attachment, and ax1DBAddProp does nothing, returning nil.
<i>ll_name_value</i>	List of property-name/property-value pairs as lists. If the car of this list is not a list, then ax1DBAddProp treats <i>ll_name_value</i> as a single name-value list. The car of each name-value pair is the property name as a string. The cadr of the name-value list is the property value. It is either a string with or without units included, or a simple value (fixed or floating). If the value does not include units explicitly, then ax1DBAddProp uses the units specified in the system units.dat file. ax1DBAddProp ignores the property-value if the property data type is BOOLEAN.

Value Returned

l_result List:

Allegro SKILL Reference

Database Create Functions

(car) list of *dbids* of objects that had at least one property successfully added

(cadr) always nil.

nil No properties are added.

See Also

[axIDBDeleteProp](#), [axIDBCreatePropDictEntry](#) [axIDBGetPropDictEntry](#)
[axIDBGetProperties](#), [axIDBDeletePropAll](#), [axIDBDeletePropDictEntry](#), and
[axIDBGetPropDict](#)


Example

see [axIDBDeleteProp](#)

Allegro SKILL Reference

Database Create Functions

The Show Element window appears with the MYPROP value at 23.500000 level.



Load and Save Functions

This section describes the *Load* functions that add external objects to the Allegro PCB Editor database.

axlLoadPadstack

```
axlLoadPadstack (
  t_padname
)
⇒ o_dbid
```

Description

Loads a padstack by attempting to find the padstack by name in the existing database. Failing that, Allegro PCB Editor looks in the pad library on the disk.

Arguments

<i>t_padname</i>	Padstack name. If loaded from disk, Allegro PCB Editor uses the PADLIB path variable to find the pad. Pad name is limited to 20 characters.
------------------	---

Value Returned

<i>o_dbid</i>	<i>dbid</i> of padstack loaded.
---------------	---------------------------------

nil	Nothing is found.
-----	-------------------

Example

```
pad = axlLoadPadstack (VIA)
```

Loads the VIA padstack.

axlLoadSymbol

```
axlLoadSymbol(  
    t_symKind  
    t_symName  
) -> o_dbidSymDef/nil
```

Description

Searches for indicated symbol in database. If not present, searches PSMPATH and loads the symbol into the database. In the symbol editor, this can only be used for shape and mechanical symbols for use with padstacks.



If a symbol definition is not in use (dbid->instance is nil) then the definition is deleted. This deletion of unused symbols occurs during save drawing, refresh symbol, place manual among other place. This means the database is saved as part of axlRunBatchDBProgram then the unused symdefs will be deleted.

NOTES:

- axlDBCreateSymbol also loads the symbol definition if required. You do not need this API to place symbols.
- You can delete unused symdefs via axlDeleteObject.

Arguments

t_symkind "PACKAGE", "MECHANICAL", "FORMAT" (case insensitive)

t_symName Name of symbol (lower case). This is the root name of the symbol, do not include an extension (for example, .psm) or a directory path.

Value Returned

dbid Of symbol definition

nil Cannot find symbol, unknown symbol type, symbol type doesn't match symbol, can't find a padstack that is required for a sym pin, or symbol revision is too old.

Allegro SKILL Reference

Database Create Functions

See Also

[axlDBCreateSymbol](#)

EXAMPLE

```
symdef = axlLoadSymbol( "package" "dip14" )
```

axlPadstackToDisk

```
axlPadstackToDisk(  
    [t_padName]  
    [t_outPadName]  
)  
⇒ t/nil
```

Description

Saves a board padstack out to a library.

Arguments

<i>t_padName</i>	Name of the pad to be saved to a library.
<i>t_outPadName</i>	Name of the output pad.

Value Returned

<i>t</i>	Pad is created.
<i>nil</i>	Failed to create pad.

Example


- Dump all the padstacks in the layout.
`axlPadstackToDisk()`
- Dump padstack "pad60cir36d" from the layout as "pad60cir36d.pad".
`axlPadstackToDisk("pad60cir36d")`
- Dump padstack "pad60cir36d" from the layout as "mypadstack.pad".
`axlPadstackToDisk("pad60cir36d" "mypadstack")`

axlRefreshSymbol

```
axlRefreshSymbol(  
    t_symName/o_SymDef  
    [g_options]  
)  
==> t/nil
```

Description

Refreshes a symbol from file on disk which is located by current PSMPATH. Works the same as the refresh_symbol functionality except updates one symbol definition. Unlike refresh_symbol this does not support the reset custom drill option since this is done at the padstack level not the symbol level.



- Tip*
- 1) If updating multiple symbols use [axlDBCloak](#) for best performance and minimal memory use.
 - 2) To ignore the FIXED property see [axlDBIgnoreFixed](#).

Arguments

<i>t_symName</i>	existing symbol name
<i>o_SymDef</i>	symbol definition dbid
<i>g_options</i>	<p>The available options are:</p> <ul style="list-style-type: none">■ 'text - reset text locations■ 'fanout - reset fanouts (if design has fanouts delete them) <p>Default is to only delete fanouts if disk symbol has them.</p>

RETURNS

- *o_SymDef* – refreshed symdef
- *nil* – fails; typically if cannot find symbol on disk or if a FIXED property is present.

See Also

[axlDBCloak](#), [axlDBIgnoreFixed](#), [axlReplacePadstack](#)

Example

1. Update the DIP14 and reset text locations

```
axlRefreshSymbol("DIP14" 'text)
```

2. Update first symbol def off database root and set both the text and pin escape option

```
symdef = axlDBGetDesign()->symdefs  
axlRefreshSymbol(car(symdef) '(text fanout))
```

Allegro SKILL Reference
Database Create Functions

Database Group Functions

Overview

This chapter describes the AXL-SKILL Database Group functions.

ax1DBAddGroupObjects

```
ax1DBAddGroupObjects(  
    o_group  
    lo_members  
)  
⇒ t/nil
```

Description

Adds the database objects specified in the new members list to a group. All restrictions and disclaimers specified in [ax1DBCreateGroup](#) also apply for this procedure.

Arguments

<i>o_group</i>	<i>dbid</i> of the group to receive new members.
<i>lo_members</i>	List of <i>dbid</i> 's specifying the new group members. Database objects already in the group are silently ignored (giving a return value of t.) A single <i>dbid</i> can be substituted for a list.

Value Returned

t	Objects added to the group.
nil	Objects could not be added to the group because the resulting group does not meet the restrictions specified in ax1DBCreateGroup .

See Also

[ax1DBCreateGroup](#)

axlDBCreateGroup

```
axlDBCreateGroup(  
    t_name  
    t_type  
    lo_groupMembers  
)  
⇒ o_dbid/nil
```

Description

Creates a new group database object with members specified by *lo_groupMembers*.

Arguments

<i>t_name</i>	String providing the group name. If name is in use by an existing group, this function fails and returns <i>nil</i> .
<i>t_type</i>	String defining the group type. Legal values are: "generic" "net_group"
<i>lo_members</i>	List of AXL <i>dbids</i> defining the group members. Duplicate <i>dbid</i> entries are silently ignored. An object is added to a group only once. A single <i>dbid</i> can be substituted for a list.

If certain restrictions on the group members are violated, this function fails and returns `nil`.

- For each group type has only certain objects that are allowed. For example generic groups only permits:

- group
 - component
 - symbol
 - net
 - path
 - via
 - shape
 - polygon
 - pin
 - text

- A circular group relationship cannot be formed.

For example, group A cannot be added as a member of group B if group B is directly or indirectly a member of group A.

Value Returned

`o_dbid` *dbid* of the newly formed group.

`nil` If the group could not be created.

See Also

[axIDBAddGroupObjects](#), [axIDBDisbandGroup](#), [axIDBRemoveGroupObjects](#)

Example

■ Generic group

```
groupMembers = axlGetSelSet()  
group_dbid = axlDBCreateGroup("my_group" "generic" groupMembers)
```

■ Net group

```
groupMembers = axlSelectByName("NET" "NET*" t)  
group_dbid = axlDBCreateGroup("NG1" "net_group" groupMembers)
```

Note: The order of the group members provided when you access the *groupMembers* property may vary from the order provided in *lo_groupMembers*.

axlDBDisbandGroup

```
axlDBDisbandGroup(  
    o_group  
)  
⇒ t/nil
```

Description

Disbands the database group you specify with the *o_group* argument, thereby immediately removing the group. Members of the group are not deleted.

Arguments

o_group *dbid* of the group to be deleted.

Value Returned

t Group disbanded.

nil Group could not be disbanded due to an invalid argument, for example, the *dbid* not being for a valid group.

See Also

[axlDBCreateGroup](#)

axIDBGetGroupFromItem

```
axIDBGetGroupFromItem(
  o_dbid
  t_groupType
  [g_promoteToNet]
) -> lo_groupDbid/nil
```

Description

Filter object's group membership by a group type. You can normally fetch the list of groups that an object is a member of by using the groups attribute of its dbid (etc. o_dbid->groups). This function provides additional filtering where you can request if an belongs to a particular group type. Depending upon the group characteristics an object can either belong to single group of a type or can be a member multiple groups of a single type. For example, an object can belong to multiple generic groups can belong to only one diffpair group.

Arguments

<code>o_dbid</code>	dbid to be examined
<code>t_groupType</code>	group type name. This is the group type name NOT the name of the group. In dbid terms this is group->type.
<code>g_promoteToNet</code>	Promote object to its net/xnet and perform test on that object. Use this option for groups for which membership is limited to nets/xnets. It promotes the object provided to its owning xnet, and is targeted for use with diffpair and bus groups, where membership is limited to the net's xnet. It provides an easy way for those groups if given the dbid of a net to promote the id to its xnet.

Value Returned

`lo_groupDbid` Group dbids or nil if not a member of requested group type

See Also: [axIDBCreateGroup](#)

Examples

In both case ashOne is a shareware utility that allows user to select one object (see <CDSROOT>/share pcb/examples/skill/ash-fxf/ashone.il

Allegro SKILL Reference

Database Group Functions

- differential pair; set g_promoteToNet to t in case net is part of a xnet

```
p = ashOne()      ; select a net that is a diffpair member
```

```
l = axlDBGetGroupFromItem(p "DIFF_PAIR" t)
```

- generic group

```
p = ashOne()      ; create a group and select an object that is part of group
```

```
l = axlDBGetGroupFromItem(p "GENERIC" )
```

axIDBGroupRename

```
axIDBGroupRename (
    o_groupDbid
    t_newName
)
==> t/nil
```

Description

Renames a group. Groups supported are GENERIC, BUS, DIFF_PAIR, NETCLASS, NET_GROUP and MATCH_GROUP. Do not attempt to rename group types not listed.

Note: All restrictions and disclaimers specified in [axIDBCreateGroup](#) also apply for this API.

Arguments

<i>o_groupDbid</i>	The dbid of the group to be renamed
<i>t_newName</i>	New name of the group. Group name must be unique for the group type.

Value Returned

<i>t</i>	Successful in rename.
<i>nil</i>	Failed in rename; dbid not a group, group can't be renamed, new name is not legal for group type or name already exists in that group type.

See Also

[axIDBCreateGroup](#)

axlDBRemoveGroupObjects

```
axlDBRemoveGroupObjects(  
    o_group  
    lo_members  
)  
⇒ t/nil
```

Description

Removes the database objects from the specified group. Group members, though removed, are not deleted.

Arguments

<i>o_group</i>	Group <i>dbid</i> .
<i>lo_members</i>	List of database objects to be removed from the group. A single <i>dbid</i> can be substituted for a list.

Value Returned

t	One or more objects removed from the group.
nil	<i>lo_members</i> contained no <i>dbids</i> of objects that could be removed from the group.

Notes:

- If a group is left with no members, the group is tagged for deletion, but is not removed immediately.
- You do not need to explicitly remove objects from a group before deleting the object with `axlDeleteObject`. Deleting an object removes it from all groups to which it belongs.

See Also

[axlDBCreateGroup](#)

axlNetClassAdd


```
axlNetClassAdd(  
    o_netclassdbid/t_netclassName  
    o_dbid/lo_dbid  
)==> t/nil
```

Description

Adds members to a netclass group. Eligible members are:

- nets
- xnets
- differential pairs
- busses

See netclass discussion in [axlNetClassCreate](#). This will mark DRC out of date. It is up to the application to update the DRC system.



Tip
Using dbids is faster then using names.

Arguments

o_netclassdbid: dbid of a netclass group

t_netclassName: name of a netclass group

o_dbid: legal database dbid to add to netclass

lo_dbid: list of legal database dbids to add to netclass

Value Returned

t added elements

nil failed one or more element adds; object might already be a member of a netclass in that domain or not legal dbid to add to a netclass

Examples

To netclass group created in axlNetClassCreate add two nets

```
nc = car(axlSelectByName ("NETCLASS" "5_MIL"))
nets = axlSelectByName ("NET" '("NET8" "NET9"))
axlNetClassAdd(nc mg)
```

See Also

[axlNetClassCreate](#)

axlNetClassCreate

```
axlNetClassCreate(  
    t_name  
    g_domain/lg_domain  
) ==> o_dbid
```

Description

This creates a new netclass group. If a netclass exists with this name then `nil` is returned. Net Classes need to be populated via `axlNetClassAdd`. Empty net classes may be deleted on database save. A netclass must be part of one or more domains. These domains are shown below. The Same Net Constraint domain uses the netclass spacing domain. An object (bus, diffpair, xnet or net) may be a member of single netclass in a domain. For example, if net VCC exists in the POWER netclass in the physical domain then you cannot add it to another netclass in the physical domain. You can still add this net of a netclass in the spacing or electrical domain. You can obtain the current set of netclasses in the database via: `axlDBGetDesign() ->netclass`. `axlNetClassGet` reports if an object is a member of a netclass either directly or via the logic hierarchy.

To assign a cset to a netclass assign the `PHYSICAL_CONSTRAINT_SET`, `SPACING_CONSTRAINT_SET`, `SAME_NET_SPACING_CONSTRAINT_SET` or `ELECTRICAL_CONSTRAINT_SET` property to the netclass where the value of the property is the cset name.

Same Net constraints shares the same domain with the `SPACING_CONSTRAINT_SET`.

Arguments

<code>t_name</code>	name of netclass group (changed to upper case)
<code>g_domain</code>	netclass domain can be 'spacing', 'physical', 'electrical' or 'all'
<code>lg_domain</code>	list of netclass domains

Value Returns

<code>nil</code> :	error or netclass with that name exists
<code>o_dbid</code> :	dbid of group

See Also

[axlNetClassDelete](#), [axlNetClassAdd](#), [axlNetClassRemove](#), [axlNetClassGet](#), [axlDBAddProp](#),
[axlCNSCreate](#)

Examples

Create a netclass in physical domain called "5_MIL"

```
nc = axlNetClassCreate("5_mil" 'physical)
```

axlNetClassDelete

```
axlNetClassDelete(  
    o_netclassdbid/t_netclassName/lg_netclassdbid  
) -> t/nil
```

Description

This deletes a net class group. It does not delete the objects belonging to the group. It is up to the application code to update DRC.

Note: Using dbids is faster then using names.

Arguments

o_netclassdbid: dbid of a net class group
t_netclassName: name of a net class group
lg_netclassdbid: list of net class groups (dbids or names)

Value Returned

t: net class group deleted
nil: failed

See Also

[axlNetClassCreate](#)

Examples

Delete net class group created in axlNetClassCreate

```
nc = car(axlSelectByName ("NETCLASS" "5_MIL"))  
axlNetClassDelete(nc)
```

or

```
axlNetClassDelete ("5_MIL")
```

axlNetClassGet

```
axlNetClassGet(  
    o_dbid  
    s_domain  
    g_hierarchal  
)==> o_netclass
```

Description

Given a dbid (net, xnet, diffpair or bus) and a domain (spacing, physical or electrical) return its netclass. If g_hierarchical is nil, returns object's netclass if a direct member. If g_hierarchical=t returns first netclass encountered in logical hierarchy. For example, if a net is a member of a bus and the bus is assigned to netclass, BUSCLASS, and you pass a net of the bus to this API:

will return nil if g_hierarchy=nil

will return netclass dbid, BUSCLASS, if g_hierarchy=t

Arguments

o_dbid: dbid may be net, xnet, diffpair or bus

s_domain: netclass domain; spacing, physical or electrical

g_hierarchal

Value Returned

o_netclass dbid of netclass

nil object not part of a netclass in the domain or an invalid object

See Also

[axlNetClassCreate](#)

Examples

Use example in [axlNetClassAdd](#)

Allegro SKILL Reference

Database Group Functions

From example in (should return netclass in both cases)


```
net = car(axlSelectByName("NET" "NET8"))
axlNetClassGet(nets 'physical nil)
axlNetClassGet(nets 'physical t)
```

axlNetClassRemove

```
axlNetClassRemove(  
    o_netclassdbid/t_netclassName  
    o_dbid/lo_dbid  
)==> t/nil
```

Description

Removes elements from an existing net class group. Element must currently be a direct member of the group. This will mark DRC out of date. It is up to the application to update the DRC system.



Using dbids is faster then using names.

Arguments

o_netclassdbid: dbid of a netclass group

t_netclassName: name of a netclass group

o_dbid: legal database dbid to remove from group

lo_dbid: list of legal database dbids to remove from group

Value Returned

t removed elements

nil failed to remove one or more elements. Object may not be a cset member (member must be a direct member).

Examples

Using the example from axlNetClassAdd remove one of the nets:

```
axlNetClassRemove(nc_car(nets))
```

Allegro SKILL Reference

Database Group Functions

See Also

[axlNetClassCreate](#)

axlRegionAdd

```
axlRegionAdd(  
    o_regiondbid/t_regionName  
    o_dbid/lo_dbid  
) ==> t/nil
```

Description

Adds members to a region group. Eligible members are:

- shapes
- rectangles

Only objects on the CONS_REGION class may be added to a region. See region discussion in axlRegionCreate. This will mark DRC out of date. It is up to the application to update the DRC system

Note: Using dbids is faster then using names.

Arguments

<i>o_regiondbid</i> :	dbid of a region group
<i>t_regionName</i> :	name of a region group
<i>o_dbid</i> :	legal database dbid to add to region
<i>lo_dbid</i> :	list of legal database dbids to add to region

Value Returned

<i>t</i>	added elements
<i>nil</i>	failed one or more element adds; object might already be a member of a region or not legal dbid to add to a region

See Also

[axlRegionAdd](#)

Examples

To region group created in axlRegionCreate add a shape

```
nc = car(axlSelectByName ("REGION" "BGA"))
lyr = "CONSTRAINT REGION/OUTER_LAYERS"
shape = axlDBCreateRectangle( list(100:100 200:200) nil lyr)
shape = car(shape)
axlRegionAdd(nc shape)
```

axlRegionCreate

```
axlRegionCreate(  
    t_name  
) ==> o_dbid
```

Description

Creates a new region group. If a region exists with this name then *nil* is returned. Regions may contain shapes on CONS_REGION class. Shapes are added to the region group via the [axlRegionAdd](#). Empty regions may be deleted on database save. You can obtain the current set of regions in the database via: `axlDBGetDesign () ->region`. None of the region APIs are enabled in the PCB L product.

Note: For better performance, when modifying regions you may wish to wrap all the calls with the [axlDBCloak](#) command.

Arguments

t_name name of region group (changed to upper case)

Value Returned

nil : error or region with that name exists

o_dbid : dbid of group

If shapes are a member of a region then their dbid region attribute will refer to the region dbid

Examples

Create a region called "BGA"

```
nc = axlRegionCreate ("BGA")
```

See Also

[axlRegionDelete](#), [axlRegionAdd](#), [axlRegionRemove](#), [axlDBCreateShape](#),
[axlDBCreateRectangle](#)

axlRegionDelete

```
axlRegionDelete(  
    o_regiondbid/t_regionName/lg_regiondbid  
) -> t/nil
```

Description

This deletes a region group. It does not delete the objects belonging to the group.

Note: Using dbids is faster then using names.

Arguments

o_regiondbid: dbid of a region group
t_regionName: name of a region group
lg_regiondbid: list of region groups (dbids or names)

Value Returned

t: net class group deleted
nil: failed

See Also

[axlRegionCreate](#)

Examples

Delete region group created in axlRegionCreate

```
nc = car(axlSelectByName ("REGION" "BGA"))  
axlRegionDelete(nc)
```

or

```
axlRegionDelete("BGA")
```

axlRegionRemove

```
axlRegionRemove(  
    o_regiondbid/t_regionName  
    o_dbid/lo_dbid  
) ==> t/nil
```

Description

Removes shapes from an existing region group. Element must currently be a direct member of the group. This will mark DRC out of date. It is up to the application to update the DRC system.

Note: Using dbids is faster then using names.

Arguments

<i>o_regiondbid</i> :	dbid of a region group
<i>t_regionName</i> :	name of a region group
<i>o_dbid</i> :	legal database shapes to remove from group
<i>lo_dbid</i> :	list of legal database shapes to remove from group

Value Returned

<i>t</i>	removed elements
<i>nil</i>	failed to remove one or more elements. Object may not be a region member (member must be a direct member).

See Also

[axlRegionCreate](#)

Examples

Using the example from [axlRegionAdd](#) remove the shape:

```
axlRegionRemove(region  shape)
```

Allegro SKILL Reference
Database Group Functions

Allegro SKILL Reference
Database Group Functions

Database Attachment Functions

Overview

This chapter describes the AXL-SKILL Database Attachment functions.

axlCreateAttachment

```
axlCreateAttachment(  
    t_attachmentId  
    t_passwd  
    x_revision  
    s_dataFormat  
    t_data  
)  
⇒ o_attachment/nil
```

Description

Creates a new Allegro PCB Editor database attachment with the given attachment id. The attachment may optionally be given a password and a revision number. The attachment data may be specified as a string or as a file name.

axlDBControl ('maxAttachmentSize) returns the maximum size of data that can attach to the database.



Do NOT create or replace attachments you do not own. This includes any predefined Allegro attachments like DFA or quickviews.

Arguments

<i>t_attachmentId</i>	Id or name of the attachment to retrieve. Can be up to 31 characters in length.
<i>t_passwd</i>	Password for this attachment. Can be up to 31 characters in length. If no password is desired this may be <code>nil</code> .
<i>x_revision</i>	Revision number of the attachment. If <code>nil</code> , the revision number is set to zero.
<i>s_dataFormat</i>	Indicates the format of the <i>t_data</i> argument. If <i>s_dataFormat</i> is ' <code>string</code> ', the value of the <i>t_data</i> argument is used for the attachment data. If <i>s_dataFormat</i> is ' <code>file</code> ', then the <i>t_dataString</i> argument is interpreted as a file name from which the attachment data is read.

t_data String of ascii characters representing the attachment data. May represent the data itself or the name of the file from which to read the data, depending on the value of the *s_dataFormat* argument.

Value Returned

o_attachment AXL id for the new attachment, which can then be queried using the right arrow (->) operator.

nil Failed to create an attachment due to incorrect arguments.

Note: Once an attachment is password protected it needs to be deleted, then re-added to remove or change the password protection.

See Also

[axlGetAttachment](#)

EXAMPLE

This uses an attachment to store in the database a list of variables. For example, you design a form where the user enters in their preferences and you manage them in Skill via a disembodied property list. You would like to store the user's preferences with the design.

Create an attachment name, DO NOT USE "fxf". I would suggest using an underscore, company name and application to make it unique. For example, _acme_bom_rpt, would be a good attachment name.

```
attachName = "fxf"  
  
; A typical disembodied property list  
  
mylist = ncons(nil)  
mylist->ccw = t  
mylist->middle = nil  
mylist->cx = 0.12  
mylist->cy = 10.192  
mylist->layer = "TOP"
```

Note: Do NOT store dbid's in the disembodied list or make sure to remove them before storing as an attachment.

Allegro SKILL Reference

Database Attachment Functions

Store list in current design (assuming user saves design)

```
dataString = sprintf(nil " '%L" mylist)
axlCreateAttachment(attachName nil 0 'string dataString)
```

Next time user runs the Skill code, here is how to init the list:

```
attach = axlGetAttachment(attachName 'string)
if( attach)  then
    mylist = car(errsetstring(attach->data))
else      ; no list stored in design so init to default settings
    mylist = ncons(nil)
    mylist->ccw = t
)
```

axlDeleteAttachment

```
axlDeleteAttachment(  
    t_attachmentId  
    [t_passwd]  
)  
⇒ t/nil
```

Description

Deletes the given attachment. If the attachment is password protected, the correct password must be given.



Do NOT delete attachments you do not own. This includes any predefined Allegro attachments like DFA or quickviews.

Arguments

t_attachmentId Id or name of the attachment to delete.

t_passwd Password for this attachment.

Value Returned

t Attachment successfully deleted.

nil Attachment not deleted.

See Also

[axlGetAttachment](#)

axlGetAllAttachmentNames

```
axlGetAllAttachmentNames (
    )
⇒ l_attachment/nil
```

Description

Returns a list of the ids for all database attachments in the current Allegro PCB Editor database. If no attachments are present, then `nil` is returned. The attachments can retrieved using the [axlGetAttachment\(\)](#) function.

Arguments

none

Value Returned

l_attachment List of attachment ids.

`nil` No attachments exist in the database.

axlGetAttachment

```
axlGetAttachment(  
    t_attachmentId  
    [s_dataFormat]  
)  
⇒ o_attachment/nil
```

Description

Returns the database attachment with the given id. If the attachment exists, an *attachment record* is returned containing information about the attachment. The data is in the format specified by the *s_dataFormat* argument. If '*file*' format, then the *data* attribute contains a temporary file name to which the data was written. If '*string*', then the *data* attribute contains the attachment data itself. If the *s_dataFormat* argument is omitted or is *nil*, then the *data* attribute is *nil*.

The attachment record has the following attributes:

Name	Type	Set?	Description
<i>objType</i>	string	NO	Is always "attachment".
<i>id</i>	string	NO	Id (name) of the attachment.
<i>password</i>	boolean	NO	t/nil - Indicates if the attachment is password protected.
<i>timeStamp</i>	integer	NO	Indicates the time last modified in seconds.
<i>revision</i>	integer	YES	User defined revision number for the attachment data.
<i>dataFormat</i>	symbol	YES	Indicates the format of the data stored in the "data" attribute and is one of ' <i>file</i> ', ' <i>string</i> ', or <i>nil</i> (in which case the data is not displayed.)
<i>data</i>	string	YES	Attachment data. May be a file name, the data itself, or <i>nil</i> depending on the value of the <i>dataFormat</i> attribute.
<i>timeStamp</i>	integer	NO	Indicates the size of the attachment.



Access to attachments in the private database is allowed. Do not create, change, or delete these attachments. The rule for attachments access is: If your application did NOT create the attachment do NOT change it.

Arguments

<i>t_attachmentId</i>	Id or name of the attachment to retrieve. Can be up to 31 characters in length.
<i>s_dataFormat</i>	Format in which the attachment data is stored in the "data" attribute. Must be 'string', 'file', or nil.

Value Returned

<i>o_attachment</i>	AXL id for the attachment structure which can be queried using the right arrow (->) operator.
nil	Attachment does not exist.

Example

```
attachment = axlGetAttachment("attachmentOne" 'file)
⇒attachment:attachmentOne
```

See Also

[axlIsAttachment](#), [axlGetAllAttachmentNames](#), [axlCreateAttachment](#), [axlSetAttachment](#), [axlDeleteAttachment](#)

axlIsAttachment

```
axlIsAttachment(  
    o_attachment  
)  
⇒ t/nil
```

Description

Determines if the given object is an AXL attachment.

Arguments

o_attachment Object to check.

Value Returned

t Object is an attachment.

nil Object is not an attachment.

See Also

[axlGetAttachment](#)

axlSetAttachment

```
axlSetAttachment(  
    o_attachment  
    [t_password]  
)  
⇒ o_attachment/nil
```

Description

Modifies an existing Allegro PCB Editor database attachment with the data contained in the given AXL attachment id. Original attachment object must be obtained from the `axlCreateAttachment`, `axlGetAttachment`, or `axl GetAllAttachments` function. The attachment revision number and the attachment data may both be modified.

Format of the data is determined by the `dataFormat` attribute structure, which may be set by the user. If "`dataFormat`" is 'string', then the value of the `data` attribute is used for the new attachment data. If "`dataFormat`" is 'file', then the value of the `data` attribute is a file name from which the attachment data is read.

If the existing attachment is password protected, you must provide the correct password or the function fails.

Arguments

<code>o_attachment</code>	AXL id of the existing attachment to be modified. The <code>revision</code> , <code>dataFormat</code> , and <code>data</code> attributes may all be set to new values by the user.
<code>t_password</code>	Password for the given existing attachment. If this does not match the password of the existing attribute, the attachment update fails. If the existing attachment is not password protected, you may omit this.

Value Returned

`o_attachment` AXL id of the modified attachment.

`nil` Failed to modify the attachment.

Note: Once an attachment is password protected, to remove or change the password protection you must delete and then re-add the attachment.

Allegro SKILL Reference

Database Attachment Functions

See Also

[axlGetAttachment](#)

Allegro SKILL Reference
Database Attachment Functions

Database Transaction Functions

Overview

This chapter describes the AXL-SKILL Database Transaction functions.

ax1DBCloak

```
ax1DBCloak(  
    g_func  
    [g_mode] / [lg_mode]  
)  
⇒ g_return
```

Description

Improves performance and program memory use while modifying many items in the database. You use `ax1DBCloak` to update many etch or package symbols in batch mode. Works like SKILL's `eval` function. You pass it a function and its arguments using the following format:

```
ax1DBCloak ('MyFunc( myargs )' )
```

You can use `ax1DBCloak` to do the following:

- Batch any net based DRC updates.
- Batch connectivity update.
- Optionally, batch dynamic shape updates if `g_mode` is 'shape'.
- Optionally, ignores the FIXED property.
- Incorporate an errset around your function so any SKILL errors thrown are caught by `ax1DBCloak`.

This function must be used if you need to update many etch or package symbols in a batch fashion.

Do not use `ax1DBCloak` in these circumstances:

- If you are adding or deleting non-connectivity database items (for example, loading many lines to a manufacturing layer)
- If you need to interact with the user. Since connectivity is not updated, do not use the `ax1EnterXXX` functions. Instead, get the information from the user first, then do the cloak update.
- If you are reading the database, using cloak does not help and may actually slow performance.
- If making a single change, using Cloak slows performance.

Note: Using Cloak sets any database ids to nil.

gmode options (if multiple required pass a list of options)

' shape	Improves performance if changes being made effect any dynamic shapes on the design. Generally you should set this if effecting ETCH layers with your changes.
' ignoreFixed	Have the system ignore the FIXED property (see axIDBIgnoreFixed)



A frequent programming error is to leave off the tick (') mark which allows axIDBCloak to evaluate the function.


CORRECT MODEL:

```
axIDBCloak( 'MyFunc(myArgs) ' (shape ignoreFixed))
```

INCORRECT MODEL:

```
axIDBCloak( MyFunc(myArgs) '(shape ignoreFixed))
```

Both work but in the incorrect case now performance benefit offered by the cloaking function will be applied to MyFunc.



For effective debugging, first call your function directly from the top level function, then wrap in the cloak call.

Arguments

g_func Function with any of its arguments.

s_mode option

ls_mode list of options

Value Returned

Returns what *g_func* returns.

Example

```
procedure( DeleteSymbols())
let( (listOfSymbols)
```

Allegro SKILL Reference

Database Transaction Functions

```
listOfSymbols = axlDBGetDesign()->symbols
when( listOfSymbols
      axlDBCloak( 'DeleteDoit(listOfSymbols) 'shape' )
      axlShell("cputime stop"
    )))
procedure( DeleteDoit(listOfDatabaseObjects)

foreach(c_item listOfDatabaseObjects
      printf("REFDES %s\n", c_item->refdes)
      axlDeleteObject(c_item)
    )
nil
)
```

Deletes all placed symbols in the database.

axlDBTransactionCommit

```
axlDBTransactionCommit(  
    x_mark  
)  
⇒ t/nil
```

Description

Commits a database transaction from the last transaction mark.

Arguments

<i>x_mark</i>	Database transaction mark returned from axlDBTransactionStart.
---------------	---

Value Returned

t	Database transaction committed.
---	---------------------------------

nil	Database transaction not committed.
-----	-------------------------------------

Example

See axlDBTransactionStart() for an example.

ax1DBTransactionMark

```
ax1DBTransactionMark(  
    x_mark  
)  
⇒ t/nil
```

Description

Writes a mark in the database that you can use with [ax1DBTransactionOops](#) to rollback database changes to this mark.

When a transaction mark is committed or rolled back, all `ax1DBTransactionMarks` associated with that mark are discarded.

Arguments

<i>x_mark</i>	Database transaction mark returned from <code>ax1DBTransactionStart</code> .
---------------	---

Value Returned

t	Mark written in the database.
nil	No mark written in the database.

Example

See `ax1DBTransactionStart()` for an example.

axlDBTransactionOops

```
axlDBTransactionOops (
  x_mark
)
⇒ t/nil
```

Description

Undoes a transaction back to the last mark, or to start if there are no marks. Supports the Allegro *oops* model for database transactions.

When a transaction mark is committed or rolled back all, then that mark is no longer valid for *oopsing*.

Arguments

x_mark Database transaction mark returned from
axlDBTransactionStart.

Value Returned

t Transaction undo completed.

nil Transaction is already back to the starting mark and there is
nothing left to *oops*.

Example

See axlDBTransactionStart for an example.

ax1DBTransactionRollback

```
ax1DBTransactionRollback(  
    x_mark  
)  
⇒ t/nil
```

Description

Undo function for a database transaction.

Arguments

x_mark Database transaction mark returned from
ax1DBTransactionStart.

Value Returned

t Transaction undo completed.

nil Transaction undo not completed.

Example

See ax1DBTransactionStart for an example.

ax1DBTransactionStart

```
ax1DBTransactionStart(  
)  
⇒ x_mark/nil
```

Description

Marks the start of a transaction to the database. Returns a mark to the caller which is passed back to commit, mark, oops or rollback for nested transactions. Only the outermost caller of this function (the first caller) has control to commit or rollback the entire transaction.

You use this function with other `ax1DBTransaction` functions.

Allegro cancels any transactions left active when your SKILL code terminates. You cannot start a transaction and keep it active across Allegro commands as an attempt to support *undo*.

Saving or opening a database cancels transactions.

Arguments

none

Value Returned

<code>x_mark</code>	Integer mark indicating transaction start.
---------------------	--

<code>nil</code>	Failed to mark transaction start.
------------------	-----------------------------------

Allegro SKILL Reference

Database Transaction Functions

Example 1

```
mark = axlDBTransactionStart()
...#1 do stuff ...
axlDBTransactionMark(mark)
...#2 do stuff ...
axlDBTransactionMark(mark)
...#3 do stuff ...

;; do an oops of the last two changes
axlDBTransactionOops( mark ) ; oops out #3
axlDBTransactionOops( mark ) ; oops out #2
axlDBTransactionOops( topList); commit only #1
```

Emulates the Allegro *oops* model.

Example 2

```
i = axlDBTransactionStart()
... do stuff ...
j = axlDBTransactionStart()
... stuff ...
axlDBTransactionCommit(j) ;; this is not really committed

j = axlDBTransactionStart()
... do more stuff ...
axlDBTransactionRollback(j) ;; oops out "do more stuff"

axlDBTransactionCommit(i) ;; commit changes to database
```

Multiple Start marks.

Note: Database transaction functions do NOT mark select sets. The application handles select set management.

Constraint Management Functions

Overview

This chapter describes the AXL-SKILL functions related to constraint management.

For a list of constraints, see Appendix B in the *Allegro Constraint Manager User Guide*.

axlCnsAddVia

```
axlCnsAddVia(  
    t_csetName  
    t_padstackName  
)  
==> t/nil
```

Description

Adds padstack to the constraint via list of a physical cset. Via is added to end of list (see [axlCnsGetViaList](#) of via ordering functionality in etch editing).

Padstack does not need to exist to be added to a constraint via list.

If *t_csetName* is *nil*, add padstack to all physical csets.

Note: If a via already exists in the via list, a *t* is returned. Locked csets return a *nil*.

Arguments

t_csetName Name of physical cset or *nil* for all csets.

t_padstack Name of a via padstack.

Value Returned

t If added.

nil Error in arguments; cset does not exist or illegal padstack name.

Examples

Add ALLPAD to all csets

```
axlCnsAddVia(nil "ALLPAD")
```

Add ONEPAD to DEFAULT cset

```
axlCnsAddVia("DEFAULT" "ONEPAD")
```

axlCnsAssignPurge

```
axlCnsAssignPurge(  
    s_tableType  
) ==> x_delCount/ nil
```

Description

Obsolete. Kept for backward compatibility

Purges either the physical or spacing assignment table of unused entries. Allegro PCB Editor supports two assignment tables: physical and spacing. This functionality duplicates that found in the Constraint Assignment Tables forms.

Arguments

s_tableType: Spacing or Physical.

Value Returned

nil Error.

x_delCount Number of entries deleted.

Example

```
axlCnsAssignPurge('spacing)
```

See Also

[axlCnsList](#)

axlCnsClassTableChange

```
axlCnsClassTableChange (
    o_dbidClassTable
    s_csetType/ll_typeAndName
    [t_csetName]
) -> o_dbidClassTable/nil
```

Description

This command changes the Csets associated with an existing net class table entry.

Note: See [axlCnsClassTableCreate](#) for complete family of functions.

You cannot change any table entries containing a region entry in Allegro PCB Designer or lower tiers.

Arguments

<i>o_dbidClassTable</i>	dbid of an existing classTable entry.
<i>s_csetType</i>	symbol for cset type. spacing, 'physical or 'sameNet)
<i>ll_typeAndName</i>	lists <i>s_csetType</i> and <i>t_csetName</i>
<i>t_csetName</i>	cset name string

Value Returned

Updated classTable dbid or nil if failure

See Also

[axlCnsClassTableCreate](#)

Examples

Before running the sample skillcode for `axlCnsClassTableChange`, create a class table by running the example code in the [axlCnsClassTableCreate](#) command. Next, execute the following skill code and update the entry created in [axlCnsClassTableCreate](#) by adding it to the spacing.

Allegro SKILL Reference

Constraint Management Functions

```
cset named 1, physical cset named 2 and a same net cset named 3.  
prop = '((spacing "1") (physical "2") (sameNet "3"))  
tbl = axlCnsClassTableChange(tbl prop)
```

axlCnsClassTableCreate

```
axlCnsClassTableCreate(
    g_class1
    g_class2
    g_region
    s_csetType/11_typeAndName
    [t_csetName]
) -> o_dbidClassTable/nil
```

Description

This command creates a class table entry that consists of any of the following:

- class to class (spacing only)
- region to class (spacing, same net and physical)
- region to class to class (spacing only)

Optionally, the command also associates a spacing cset, a physical cset, and same net cset with the table entry. If a class table entry already exists, it is modified with the provided cssets.

Regions are not available in Allegro PCB Designer and lower products. Command will fail if you attempt to create a region-based table entry in these products. Class tables may not be created in symbol editor.

Points to remember:

1. The order of class1 and class2 does not matter.
2. If an entry already exists it will return the existing entry.
3. Netclasses can be classified by domain (spacing and/or physical). If a netclass is restricted to one domain, it is possible to create a netclass to any entry that crosses domains. This table entry will be ignored by DRC. For example, you have a netclass, ANY, in both physical and spacing domains; and another netclass PHYS that is restricted to the physical domain. It is possible to create a ANY to PHYS relationship which is only appropriate in the spacing domain but the PHYS netclass is not legal in that domain.

Note: This condition might be tested for and rejected in future releases.

4. DRC is set out-of-date, you must manually update the DRC.
5. Unlike Constraint Manager, you can add cset names that don't yet exist in the database. In these cases, we will automatically create a cset. Check via axlCnsList if your cset exists if you don't wish to create new csets.

6. Class table entries may also have constraint overrides attached via property overrides
(axlDBAddProp)

Arguments

<i>g_class1</i>	NETCLASS dbid or name of name class
<i>g_class2</i>	NETCLASS dbid, name of name class or nil
<i>g_region</i>	REGION dbid, name of region or nil
<i>s_csetType</i>	symbol cset type one of 'spacing, 'physical or 'samenet
<i>t_csetName</i>	string cset name for given type
<i>ll_typeAndName</i>	option list of values where you have ((<i>s_csetType</i> <i>t_csetName</i>) (<i>s_csetType</i> <i>t_csetName</i>) ...)

Value Returned

returns dbid of type classTable for new or existing cset or nil if error

See Also

[axlCnsClassTableFind](#), [axlCnsClassTableSeek](#), [axlCnsClassTableChange](#),
[axlCnsClassTableDelete](#), [axlCnsList](#),

Also see classTable dbid object description.

Examples

- Create appropriate entries in design

```
region = axlRegionCreate("ANALOG")
ncls = axlNetClassCreate("VOLTAGE" '(spacing physical))
```

1. Add new spacing region-class table entry and give it the spacing cset "25MILS"

```
tbl = axlCnsClassTableCreate("VOLTAGE" nil "ANALOG" 'spacing "25MILS")
```

2. Alternative method plus also add a physical voltage cset.

Allegro SKILL Reference

Constraint Management Functions

```
props = '((spacing "25MILS") (physical "VOLTAGE"))
tbl = axlCnsClassTableCreate(ncls nil region props)
```

axlCnsClassTableDelete

```
axlCnsClassTableDelete(  
    o_dbidClassTable/lo_dbidClassTable  
) -> t/nil
```

Description

Deletes one or more entries in the class table.

DRC is marked out of date.

Arguments

o_dbidClassTable dbid of an existing classTable entry.

lo_dbidClassTable deletes list of classTable entries.

Value Returned

t if successful, *nil* if an error

See Also

[axlCnsClassTableCreate](#), [axlCnsDeleteRegionClassClassObjects](#),
[axlCnsDeleteClassClassObjects](#)

Examples

Create a classTable entry by executing example code in [axlCnsClassTableCreate](#). Delete entry just created by running the following command.

```
axlCnsClassTableDelete(tbl)
```

axlCnsClassTableFind

```
axlCnsClassTableFind(  
    s_type  
    [o_dbid]  
) -> lo_dbidClassTable/nil
```

Description

This command searches the class table for class table entries matching the search criteria.

Arguments

s_type Specifies the type of search to perform. The options available are:

- `netclass – returns all class entries (all entries except for wire and component)
- `classClass – returns all class to class entries
- `classRegion – returns all class to region entries
- `classClassRegion – returns all class to class to region entries
- `wireProf – returns all wire profile entries (APD/SIP only)
- `component – returns all component entries (APD/SIP only)
- `match – returns all entries that contain provided region or class dbid (*o_dbid*)

o_dbid only applicable for the match option will return all class table entries containing the dbid.

Value Returned

List of class table dbids matching search criteria or `nil` if no match is found.

See Also

[axlCnsClassTableCreate](#), [axlCnsClassTableSeek](#), [axlSelectByName](#)

Examples

1. Return all class entries that effect physical, spacing or same net DRC

```
tbl = axlCnsClassTableFind('netclass)
```

2. Return all entries that contain Region “ANALOG” entry (assumes design has a region called “ANALOG”)


```
region = car (axlSelectByName("REGION" "ANALOG"))  
tbl = axlCnsClassTableFind('match region)
```

axlCnsClassTableSeek

```
axlCnsClassTableSeek(  
    g_class1  
    g_class2  
    g_region  
) -> o_dbidClassTable/nil
```

Description

This command seeks a specific class table entry matching exactly the provided dbids. Order of class1 and class2 does not matter since C1/C2 is the same as C2/C1 and only one entry exists in the table.



Tip
Constraint overrides may exist on a table entry via the `prop` attribute. While fetching multiple table entries, best performance is achieved by using dbids or using [axlCnsClassTableFind](#).

Arguments

<code>g_class1</code>	NETCLASS dbid, name of net class or nil
<code>g_class2</code>	NETCLASS dbid, name of net class or nil
<code>g_region</code>	REGION dbid, name of region or nil

Value Returned

Class table entry matching search criteria or `nil` if none found.

See Also

[axlCnsClassTableCreate](#)

Examples

Create a classTable entry by executing example code in [axlCnsClassTableCreate](#)

1. Return class table entry for a netclass called VOLTAGE and region called ANALOG.

Allegro SKILL Reference

Constraint Management Functions

```
tbl = axlCnsClassTableSeek("VOLTAGE" nil "ANALOG")
```

2. Alternative method using dbids

```
region = car( axlSelectByName("REGION" "ANALOG"))
netclass = car( axlSelectByName("NETCLASS" "VOLTAGE"))
tbl = axlCnsClassTableSeek(netclass nil region)
```

axlCNSCreate

```
axlCNSCreate(
  g_domain
  t_name
  t_copyName
)
==> t/nil
```

Description

Creates a new constraint set in the specified domain. For spacing and physical csets, you must supply an existing cset as the copy cset. If the *copyName* is nil, the DEFAULT cset is used. Electrical csets (ECsets) are created empty for a nil *copyName*. By default, the ECset created is empty. If you provide a second argument, the ECset contents are copied.

To assign a cset to a logical object such as a net, bus, or a netclass, assign a PHYSICAL_CONSTRAINT_SET, SPACING_CONSTRAINT_SET, SAME_NET_SPACING_CONSTRAINT_SET or ELECTRICAL_CONSTRAINT_SET property to the logical object where the value of the property is the cset name.

Note: Electrical csets cannot be created in Allegro PCB Designer.

Arguments

g_domain Specifies the domain of the Cset. Possible values are Physical, spacing, electrical, or 'sameNet'.

t_name Name of new cset.

t_copyName Name of cset to use as template. If this is nil, spacing and physical domains use DEFAULT as the template, while in case of electrical domain, an empty ECset is created.

Value Returned

t Cset created.

nil Failed for the following reasons: domain name is illegal; name of cset is illegal; cset already exists; or *copyName* cset does not exist.

See Also

[axlCNSEcsetCreate](#) , [axlCNSDelete](#) , [axlCnsList](#), [axlDBAddProp](#), [axlNetClassCreate](#)

Example

Create a new physical cset called `foo`.

```
axlCNSCreate('physical "foo" nil)
```

axlCNSCsetLock

```
axlCNSCsetLock(
    g_domain
    t_csetName
    g_mode
)
==> t/nil
```

Description

This locks or unlocks a constraint set in the given domain. See discussion in [axlCNSIsLockedDomain](#).

You should usually lock or unlock the entire domain since this matches the DRC user model. We provide this interface to temporary unlock a locked cset, make changes then reapply the lock.

Note: Changing the lock on a cset can take a considerable amount of time since DRC needs to be updated. In the spacing domain, dynamic shapes need to be updated. If doing other changes, consider cloaking axlDBCloak the entire process. This API already uses cloaking for the individual cset.

Arguments

<i>g_domain</i>	domain of cset; 'physical, 'spacing, 'sameNet, 'electrical
<i>t_csetName</i>	cset name
<i>g_mode</i>	may either be <i>t</i> (to lock) or <i>nil</i> to unlock

Value Returned

Returns *t* if updated lock status, *nil* an error.

Examples

Lock Spacing and Same net spacing domains

```
axlCNSIsLockedDomain('spacing t')
```

Allegro SKILL Reference

Constraint Management Functions

See Also

[axICNSIsLockedDomain](#)

axlCNSDelete

```
axlCNSDelete(  
    g_domain  
    t_name/o_dbidEcset  
)  
==> t/nil
```

Description

Deletes a cset and its references to any objects such as nets, net classes, etc. Locked cssets must first be unlocked before you delete them. If it is a spacing or physical domain, you cannot delete the DEFAULT cset. You cannot delete electrical cssets in Allegro PCB Design L.

Arguments

<i>g_domain</i>	Specifies the domain of cset. Valid values are: 'physical, 'spacing, 'sameNet, 'electrical
<i>t_name</i>	Name of cset.
<i>o_dbidEcset</i>	If an ECset, its <i>dbid</i> .

Value Returned

<i>t</i>	Cset deleted.
<i>nil</i>	Cset not deleted because cset does not exist or the cset is locked, or cset is <i>t</i> .

Example

Deletes electrical cset named UPREV_DEFAULT.

```
axlCNSDelete('electrical "UPREV_DEFAULT")
```

See Also

[axlCNSCreate](#)

axlCnsDeleteClassClassObjects

```
axlCnsDeleteClassClassObjects(  
    ) => x_delCount
```

Description

Delete all Class-Class entries.

Arguments

None

Value Returned

The count of the objects deleted.

See Also

[axlCnsPurgeCsets](#)

axlCnsDeleteRegionClassClassObjects

```
axlCnsDeleteRegionClassClassObjects(  
) => x_delCount
```

Description

Deletes all Region-Class-Class entries.

Arguments

None

Value Returned

The count of the objects deleted.

See Also

[axlCnsPurgeCsets](#)

axlCnsDeleteRegionClassObjects

```
axlCnsDeleteRegionClassObjects(  
    ) => x_delCount
```

Description

Delete all Region-Class entries.

Arguments

None

Value Returned

The count of the objects deleted.

See Also

[axlCnsPurgeCsets](#)

axlCnsDeleteVia

```
axlCnsDeleteVia(  
    t_csetName  
    t_padstackName  
)  
=> t/nil
```

Description

Deletes padstack from the physical via constraint list, *t_csetName*. If *t_csetName* is nil, delete provided padstack from all physical constraint sets.

Notes:

- Will return t if asked to delete a via that does not exist in the via list.
- Locked csets will return a nil.

Arguments

t_csetName Name of physical cset or nil for all csets.

t_padstack Name of a via padstack.

Value Returned

t If deleted.

nil Error in arguments; cset does not exist or illegal padstack name.

Example

Delete via to default cset

```
axlCnsDeleteVia("DEFAULT" "VIA")
```

Delete via to all csets

```
axlCnsDeleteVia(nil "VIA")
```

See Also

[axlCnsGetViaList](#) and [axlPurgePadstacks](#)

axlCNSDesignModeGet

```
axlCNSDesignModeGet(  
    nil  
)  
⇒ ls_constraints  
  
axlCNSDesignModeGet(  
    'all  
)  
⇒ lls_constraintNModes  
  
axlCNSDesignModeGet(  
    'editable  
)  
⇒ t/nil  
  
axlCNSDesignModeGet(  
    s_name/t_name  
)  
⇒ s_mode/nil
```

Description

Gets the current DRC modes for checks that fall into the set of design constraints. These constraints pertain to the entire board. To determine the design constraint checks currently supported, use the `axlCNSDesignModeGet()` command.

This has axlDebug support.

Note: Available constraint checks may change from release to release.

Arguments

<code>nil</code>	Returns all checks in design type DRC.
<code>'all</code>	Returns all checks and current mode.
<code>'editable</code>	Returns <code>t</code> if mode can be changed, <code>nil</code> mode is not changed and when in Allegro PCB Editor studio which does not offer this option.
<code>s_name</code>	Symbol name of check.
<code>t_name</code>	String name of check.

Value Returned

<code>ls_names</code>	List of checks (<i>s_name</i> ...)
<code>l ls_names</code>	List of checks and their mode ((<i>s_name s_mode</i>) ...)
<code>s_mode</code>	Mode 'on, 'off or 'batch

Example 1

```
axlCNSDesignModeGet(nil)
```

Gets a current list of design constraints.

Example 2

```
axlCNSDesignModeGet('all)
```

Gets a list of settings for all design constraints.

Example 3

```
axlCNSDesignModeGet('Package_to_Package_Spacing)
```

Gets current setting of package to package.

Example 4

```
axlCNSDesignModeGet("Negative_Plane_Islands")
```

Gets current setting of negative plane islands using a string.

axlCNSDesignModeSet

```
axlCNSDesignModeSet (
    t_name/s_name
    t_mode/s_mode
)
⇒ t/nil

axlCNSDesignModeSet (
    'all
    t_mode/smode
)
⇒ t/nil

axlCNSDesignModeSet (
    l_constraintNModes
    t_mode/smode
)
⇒ t/nil

axlCNSDesignModeSet (
    ll_constraintNModes
)
⇒ t/nil
```

Description

Sets the current DRC modes for design constraints. The modes control the DRC for that design constraint check on the entire board.

To determine the checks that are supported, use the following command:

```
axlCNSDesignModeGet()
```

You can set all checks using the argument '`'all`', set individual checks using `t_name`, or set a list of checks to the same mode as follows:

```
'(s_name...) t_mode/s_mode
'(t_name...) t_mode/smode
```

You can list sets of checks as follows:

```
'((s_name/t_name s_mode/t_mode) ...)
```

For performance reasons, changing modes or values does not invoke DRC. You must manually invoke DRC. You can mark changes in order to perform fewer DRC updates, depending on your changes (see [axlCNSMapUpdate](#) on page 1069.)

Note: Available constraint checks may change from release to release.

Arguments

<i>s_name</i>	Symbol name of check.
<i>t_name</i>	String name of check.
<i>s_mode</i>	Mode setting may be 'on, 'off, or 'batch.
<i>t_mode</i>	String mode setting may be "on", "off" or "batch"
'all	Returns all checks for a given tier of Allegro PCB Editor.

Value Returned

<i>t</i>	Success
nil	Failure.

Example 1

```
axlCNSDesignModeSet('Package_to_Place_Keepin_Spacing 'on)
```

Turns on package to package keepin check.

Example 2

```
axlCNSDesignModeSet('all 'batch)
```

Makes all design constraints batch only.

Example 3

```
axlCNSDesignModeSet(' (Negative_Plane_Islands Pad_Soldermask_Alignment)' off)
```

Turns two constraints off.

Example 4

```
axlCNSDesignModeSet('((Package_to_Place_Keepout_Spacing 'on)) )
```

Sets various constraints to different modes.

For a programming example, see `cns-design.il`, which you can find in the following location:

```
<cdsroot>/share pcb/examples/skillcmds
```

axlCNSDesignValueCheck

```
axlCNSDesignValueCheck(  
    s_name/t_name  
    g_value  
)  
⇒ (t_string/nil, nil/t_errorMsg/nil)
```

Description

Checks the syntax of the given value against the allowed syntax for the given constraint. You use the function `axlCNSDesignGetValue(nil)` to get the constraint names.

Note: Allowed syntax may change from release to release.

Arguments

<i>s_name</i>	Symbol name of the constraint.
<i>t_name</i>	String name of the constraint.
<i>g_value</i>	Value to verify

Value Returned

(<i>t_string/nil</i>)	Value correct. <i>t_string</i> shows current user unit preference. For example, if you supply "10", the return might be "10.0 MILS" if MILS is the current database unit.
(<i>nil/t_errorMsg</i>)	Value incorrect. <i>t_errorMsg</i> reflects the error.
<i>nil</i>	Arguments are incorrect.

Examples

```
axlCNSDesignValueCheck('Negative_Plane_Islands "10 mils")
```

Tests if allowed to set.

axlCNSDesignValueGet

```
axlCNSDesignValueGet(  
    nil  
    [g_returnNameString]  
)  
⇒ ls_constraints  
  
axlCNSDesignValueGet(  
    'all  
    [g_returnString]  
)  
⇒ l1s_constraintNValues  
  
axlCNSDesignValueGet(  
    s_name  
    [g_returnString]  
)  
⇒ f_value/t_value/nil
```

Description

Fetches the values from those design constraints that support values. Use `axlCNSDesignValueGet (nil)` to determine the set of these constraints.

Note: Constraint checks may change from release to release.

Arguments

<code>nil</code>	Returns all checks that support values.
<code>'all</code>	Returns all checks with values and current value.
<code><i>s_name</i></code>	Symbol name of value.
<code><i>t_name</i></code>	String name of value.
<code><i>g_returnNameString</i></code>	Returns constraint names as strings (default is symbol return.)
<code><i>g_returnString</i></code>	By default, this returns native type in user units (a float) for all checks supported. If <code>t</code> , return is a MKS string where <code>nil</code> returns native.

Allegro SKILL Reference

Constraint Management Functions

Value Returned

<code>ls_names</code>	List of all controls that support values (symbol.)
<code>lsls_constraintNValues</code>	List of all controls with their values <code>'((s_name f_value/t_value) ...)</code> <code>f_value</code> =user unit value, and <code>t_value</code> =MKS string value.

Example 1

```
axlCNSDesignValueGet(nil)
```

Gets a list of design constraints that support values.

Example 2

```
axlCNSDesignValueGet('all 't)
```

Gets a list of settings for all design constraints with values returned as MKS strings.

Example 3

```
axlCNSDesignValueGet('Negative_Plane_Islands)  
= 10.0
```

Gets the current setting of `Negative_Plane_Islands` in user units.

Example 4

```
axlCNSDesignValueGet("Pad_Soldermask_Alignment" t)  
= "10 mils"
```

Gets the current setting of `Pad_Soldermask_Alignment` as a MKS string (this passes in inquiry as a string).

axlCNSDesignValueSet

```
axlCNSDesignValueSet(  
    t_name/s_name  
    f_value/t_value  
)  
⇒ t/nil  
  
axlCNSDesignValueSet(  
    l1_constraintNValues  
)  
⇒ t/nil
```

Description

This sets the value of the design constraint.

To determine the list of supported values, use the following command:

```
axlCNSDesignValueGet(nil)
```

You may set single values or a list of values:

```
'((s_name/t_name f_value/t_value) ...)
```

For performance reasons, changing a value does not invoke DRC. You must manually invoke DRC. See [axlCNSMapUpdate](#) for a set of interfaces you can use to mark changes in order to perform fewer DRC updates.

Note: Constraint checks may change from release to release.

Arguments

<i>s_name</i>	Symbol name of check.
<i>t_name</i>	String name of check.
<i>f_value</i>	Floating point value provided is assumed to be in the default user unit for the constraint. Value may be rounded.
<i>t_value</i>	If given as a string with MKS type, the value is converted to current user units for the constraint. Rounding may result.

Value Returned

<i>t</i>	Design constraint value set.
----------	------------------------------

Allegro SKILL Reference

Constraint Management Functions

nil Failed to set design constraint value.

Example 1

```
axlCNSDesignValueSet('Negative_Plane_Islands 10.0) )
```

Sets a negative plan tolerance to 10 in current database units.

Example 2

```
axlCNSDesignValueSet('Negative_Plane_Islands "10.0 mils")
```

Sets a negative plan tolerance to 10 mils.

Example 3

```
axlCNSDesignValueSet('((Negative_Plane_Islands "20 inches")
  (Pad_Soldermask_to_Pad_Soldermask_Spacing 15.9)) )
```

Sets various constraints to different values.

For a programming example, see `cns-design.il` which you can find in the following location:

```
<cdsroot>/share pcb/examples/skill/cmds
```

axlCNSEcsetCreate

```
axlCNSEcsetCreate(  
    t_name  
    [t_copyName/o_dbidCopyEcset]  
)  
⇒ o_dbidEcset/nil
```

Description

Creates a new ECset. Electrical Constraint Set (ECset) is a mechanism for packaging up a set of electrical constraints into a group and applying them to a set of nets. The name must be legal and less than the maximum length allowed. Function fails if the ECset already exists.

By default, the ECset is created empty. You can provide a second argument to copy the contents of another ECset into the new ECset.

Arguments

t_name Name of new ECset.

t_copyName Optional name to copy from.

Value Returned

o_dbidEcset *dbid* of the new ECset

nil Failed due to one of the following: the name is illegal, or the ECset already exists.

See Also

[axlCNSDesignModeSet](#), [axlCNSCreate](#)

Example 1

```
axlCNSEcsetCreate("MyEmptyEcset")
```

Creates a new empty ECset.

Example 2

```
p = car(axlDBGetDesign() ->ecsets)  
axlCNSEcsetCreate("MyNewEcset" p)
```

Allegro SKILL Reference

Constraint Management Functions

Copies the contents of the first ECset in a list.

axlCNSEcsetDelete

```
axlCNSEcsetDelete(  
    t_name/o_dbidEcset  
)  
⇒ t/nil
```

Description

Deletes an ECset from the Allegro PCB Editor database and also deletes the *ELECTRICAL_CONSTRAINT_SET* property from any nets assigned this ECset value. Electrical Constraint Set (ECset) is a mechanism for packaging up a set of electrical constraints into a group and applying them to a set of nets.

If the ECset is locked, you must unlock it before you can delete it.

Arguments

<i>t_name</i>	ECset name
<i>o_dbidEcset</i>	ECset <i>dbid</i>

Value Returned

<i>t</i>	ECset successfully deleted.
<i>nil</i>	ECset is not deleted because of one of the following: the name is incorrect, or ECset is locked.

Example 1

```
axlCNSEcsetDelete("UPREV_DEFAULT")
```

Deletes an ECset by name.

Example 2

```
p = car(axlDBGetDesign()->ecsets)  
axlCNSEcsetDelete(p)
```

Deletes the first ECset in a list of ECsets.

axlCNSEcsetGet

```
axlCNSEcsetGet(  
    t_name  
)  
⇒ o_dbidEcset/nil
```

Description

Returns the *dbid* of the electrical cset when you request it by the ECset name. Electrical Constraint Set (ECset) is a mechanism for grouping a set of electrical constraints and applying them to a set of nets.

Arguments

t_name ECset name.

Values Returned

o_dbidEcset *dbid* of the ECset requested.

nil Function failed due to an illegal name.

See Also

[axlCNSEcsetValueGet](#) and [axlCnsList](#)

Example

```
axlCNSEcsetGet("foo")
```

Tests for the existence of an ECset named *foo*.

axlCNSEcsetModeGet

```
axlCNSEcsetModeGet (
    nil
)
⇒ ls_constraints

axlCNSEcsetModeGet (
    'all
)
⇒ lls_constraintNModes

axlCNSEcsetModeGet (
    s_name/t_name
)
⇒ s_mode/nil
```

Description

Returns the current DRC modes for checks that are members of electrical constraints. These modes pertain to the entire board. Electrical Constraint Set (ECset) is a mechanism for packaging up a set of electrical constraints into a group and applying them to a set of nets.

This has [axlDebug](#) support.

Note: Not all checks are available in all levels of Allegro PCB Editor. To determine the set of checks supported, use the command: `axlCNSEcsetModeGet()`. Constraint checks may change from release to release.

Arguments

<code>nil</code>	Returns all checks in design type DRC.
<code>'all</code>	Returns all checks and current mode.
<code>s_name</code>	Symbol name of the check.
<code>t_name</code>	String name of the check.

Value Returned

<code>ls_names</code>	List of checks ($s_name \dots$).
<code>lls_names</code>	List of checks and related modes (($s_name s_mode$) ...)
<code>s_mode</code>	Returns mode 'on, 'off, or 'batch

See Also

[axlCNSEcsetModeSet](#), [axlCNSEcsetValueGet](#)

Example 1

```
axlCNSEcsetModeGet(nil)
```

Lists currently available electrical constraints.

Example 2

```
axlCNSEcsetModeGet('all')
```

Lists settings for all electrical constraints.

Example 3

```
axlCNSEcsetModeGet('Maximum_Stub_Length')
```

Shows current setting of stub length.

Example 4

```
axlCNSEcsetModeGet("Maximum_Via_Count")
```

Shows current setting of via count.

axlCNSEcsetModeSet

```
axlCNSEcsetModeSet (
    t_name/s_name
    t_mode/s_mode
)
⇒ t/nil

axlCNSEcsetModeSet (
    'all
    t_mode/s_mode
)
⇒ t/nil

axlCNSEcsetModeSet (
    l_constraintNModes
    t_mode/s_mode
)
⇒ t/nil

axlCNSEcsetModeSet (
    ll_constraintNModes
)
⇒ t/nil
```

Description

Sets the DRC modes for checks that are members of the electrical constraints set. These modes control the entire board. Electrical Constraint Set (ECset) is a mechanism for packaging up a set of electrical constraints into a group and applying them to a set of nets.

Note: Not all checks are available in all levels of Allegro PCB Editor. To determine the set of checks supported, use the command: `axlCNSEcsetModeGet()`. Constraint checks may change from release to release.

You can set all checks using the argument '`'all`', set individual checks using `t_name`, or set a list of checks with the same mode as shown:

```
'(s_name ...) t_mode/s_mode
'(t_name ...) t_mode/s_mode
```

You can list sets of checks as shown:

```
'((t_name t_mode) ...)
'((s_name s_mode) ...)
```

For performance reasons, changing modes or values does not invoke DRC. You must manually invoke DRC. See [axlCNSMapUpdate](#) on page 1069 for a set of interfaces you can use to mark changes in order to perform fewer DRC updates.



Future releases may add or subtract constraint checks. The axl interface does guarantee the checks returned by this interface will remain constant from release to release.

Arguments

<i>s_name</i>	Symbol name of the check.
<i>t_name</i>	String name of the check.
<i>s_mode</i>	Mode setting; may be 'on', 'off', or 'batch'.
<i>t_mode</i>	String mode setting; may be "on", "off", or "batch".
'all	Set all checks for a given tier of Allegro PCB Editor.

Value Returned

<i>t</i>	DRC mode set.
nil	DRC mode not set.

Example 1

```
axlCNSEcsetModeSet('Maximum_Via_Count 'off)
```

Turns off max via check.

Example 2

```
axlCNSEcsetModeSet('all 'batch)
```

Makes all electrical constraints batch only.

Example 3

```
axlCNSEcsetModeSet(' (Maximum_Crosstalk Route_Delay) 'off)
```

Turns two constraints off.

Allegro SKILL Reference

Constraint Management Functions

Example 4

```
axlCNSEcsetModeSet( '((Maximum_Crosstalk off)
    (Propagation_Delay on) (Route_Delay 'on) (Impedance 'batch)) )
```

Sets various constraints to different modes.

axlCNSEcsetValueCheck

```
axlCNSEcsetValueCheck(  
    s_name/t_name  
    g_value  
)  
⇒ (t/t_errorMsg)/nil
```

Description

Checks the syntax of the given value against the allowed syntax for the given constraint. You use the function `axlCNSEcseValueGet (nil)` to get the constraint names. Electrical Constraint Set (ECSet) is a mechanism for packaging up a set of electrical constraints into a group and applying them to a set of nets.

Note: Allowed syntax may change from release to release.

Arguments

s_name Symbol name of constraint.

t_name String name of constraint.

g_value Value to verify.

Value Returned

t Syntax is correct.

t_errorMsg Syntax is incorrect. The message indicates the reason.

nil Constraint name is not supported.

Examples

```
axlCNSEcsetValueCheck('Net_Schedule_Topo "STAR")
```

Tests if allowed to set.

axlCNSEcsetValueGet

```
axlCNSEcsetValueGet(
    nil
    [g_returnNameString]
)
⇒ ls_constraints

axlCNSEcsetValueGet(
    'all
    [g_returnString]
)
⇒ lls_constraintNValues

axlCNSEcsetValueGet(
    o_ecsetDbid/t_ecsetName
    s_name
    [g_returnString]
)
⇒ f_value/t_value/nil
```

Description

Fetches the constraint values for a given ECset. Electrical Constraint Set (ECset) is a mechanism for packaging up a set of electrical constraints into a group and applying them to a set of nets.

Use `axlCNSEcsetValueGet(nil)` to determine the set of allowable constraints.

Each ECset may have all or none of the allowed constraints.

You can retrieve the ECset values by the ECset name or by its *dbid*. You can get the *dbid* of an ECset by using one of the following commands:

- `axlDBGetDesign() ->ecsets`
- `axlCNSEcsetCreate()`

Note: Constraint checks may change from release to release. Not all checks are available in all levels of Allegro PCB Editor.

Allegro SKILL Reference

Constraint Management Functions

Arguments

<i>o_ecsetDbid</i>	ECset <i>dbid</i> .
<i>t_ecsetName</i>	ECset name.
<i>nil</i>	Returns all checks that support values.
'all	Returns all checks with values and current value.
<i>s_name</i>	Symbol name of value.
<i>t_name</i>	String name of value.
<i>g_returnNameString</i>	Returns constraint names as strings (default is symbol return)
<i>g_returnString</i>	Default is to return native type for all checks supported, this is in user units (a float). If <i>t</i> , return is an MKS string where <i>nil</i> returns native.

Value Returned

<i>ls_names</i>	List of all controls that support values (symbol).
<i>lls_constraintNValues</i>	List of all controls with their values as shown: '((<i>s_name f_value/t_value</i>) ... <i>f_value</i> = user unit value and <i>t_value</i> = MKS string value.

Example 1

```
axlCNSEcsetValueGet(nil)
```

Gets a current list of design constraints that support values.

Example 2

```
ecsets = axlDBGetDesign()->ecsets
ecset = car(ecsets)
axlCNSEcsetValueGet(ecset 'all t)
```

Gets a list of settings for all design constraints with values returned as MKS strings.

Example 3

```
axlCNSEcsetValueGet("UPREVED_DEFAULT" 'Maximum_Via_Count)  
= 10.0
```

Gets the current setting of Maximum_Via_Count on ECset UPREVED_DEFAULT.

Example 4

```
axlCNSEcsetValueGet("UPREVED_DEFAULT" "Pad_Soldermask_Alignment" t)  
= "10 mils"
```

Gets the current setting of Pad_Soldermask_Alignment as a MKS string (this passes in inquiry as a string).

axlCNSGetDefaultMinLineWidth

```
axlCNSGetDefaultMinLineWidth(
    t_subclassName
)
=> f_minLineWidthValue
```

Description

Retrieves the minimum default line width value for the specific subclass.

Arguments

t_subclassname A subclass name of the ETCH or CONDUCTOR class.

Value Returned

f_minSpacingValue Minimum line width value (in design units) on the subclass.

Example

```
axlCNSGetDefaultMinLineWidth("TOP")
=> 0.004
```

Gets the minimum line width value for layer TOP.

axlCNSGetPhysical

```
axlCNSGetPhysical(
  t_cset
  t_layer
  s_constraint
  [g_string]
)
==> g_value/nil

axlCNSGetPhysical(
  t_cset
  t_layer
  nil
  [g_string]
)
==> ll_nameValue/nil

axlCNSGetPhysical(
  nil
  nil
  nil
)
==> ls_cnsTypes
```

Description

In its first operational mode, obtains the value of a physical constraint given a cset and layer. In the second mode of operation, it obtains all physical constraint as name/value pairs for a cset on a layer. This, in turn, may be passed to `axlCNSSetPhysical`.

In the final mode, a list of all supported physical constraints may be obtained by passing three `nil` values to the interface:

```
axlCNSGetPhysical(nil nil nil)
```

Data types

Unless otherwise specified, constraints are in current design units.

allow_etch	(boolean) <i>t/nil</i>
allow_ts	(symbol) NOT_ALLOWED, ANYWHERE, PINS_ONLY, PIN_VIAS_ONLY
allow_padconnect	(symbol) ALL_ALLOWED, VIAS_PINS_ONLY, VIAS_VIAS_ONLY, NOT_ALLOWED

Allegro SKILL Reference

Constraint Management Functions

vias	(string) colon separates the list of via names. Vias are not layer dependent, so are only returned for TOP. Order is important for etch editing working layer model. Use axlCnsGetViaList to get the via list as a list of strings. When <code>width_max</code> , <code>dp_neck_gap</code> , <code>dp_primary_gap</code> , and <code>necklength_max</code> are set to 0, it indicates that this value is not used.
------	---

Arguments

<code>t_cset</code>	Name of a physical cset. Can use "" for "DEFAULT".
<code>t_layer</code>	ETCH layer name (for example, "ETCH/TOP" or "TOP"). If <code>nil</code> , applies the change to all layers.
<code>s_constraint</code>	Name of constraint. If <code>nil</code> , returns a set of symbol/value pairs of all constraints.
<code>g_string</code>	By default, returns value in the native units of the constraint. If <code>g_string</code> is <code>t</code> , always returns data as a string.

Value Returned

<code>g_value</code>	Value of constraint in design units, except for <code>same_net</code> , which is returned as a <code>t nil</code> .
<code>ll_nameValue</code>	Name values of pairs of physical constraint symbol and constraint value for all physical (<code>s_constraint g_value</code>). <code>' ((necklength_min 10.0) (neckwidth_max 5.0) ...)</code>
<code>ls_cnsTypes</code>	List of supported physical constraint names.
<code>nil</code>	Returns <code>nil</code> on error (or <code>allow_etch</code>).

Example 1

```
axlCNSGetPhysical("") "TOP" 'width_min)
```

Gets the minimum line width in the default cset, TOP layer.

Example 2

```
axlCNSGetPhysical("VOLTAGE" "BOTTOM" nil)
```

Gets all physical constraints for the DEFAULT, BOTTOM layer

Example 3

```
axlCNSGetPhysical("") "TOP" 'vias)
```

Gets the via list for default cset.

Example 4

```
axlCNSGetPhysical(nil nil nil)
```

Gets supported physical constraint symbols.

Example 5

```
cset = ""          ;; DEFAULT cset
foreach(subclass axlSubclassRoute()
layer = axlCNSGetPhysical(cset subclass nil)
printf("\nLAYER=%s\n\tconstraints=%L\n" subclass, layer)
)
```

Fetches all layers and constraints of physical cset DEFAULT.

See Also

[axlCNSSetPhysical](#), [axlCnsList](#), [axlSubclassRoute](#), and [axlCnsGetViaList](#)

axlCNSGetPinDelayEnabled

```
axlCNSGetPinDelayEnabled()  
=> t/nil
```

Description

Returns if pin delay is enabled.

Arguments

None

Value Returned

t: Pin delay is enabled.

nil: Pin delay is not enabled.

axlCNSGetPinDelayPVF

```
axlCNSGetPinDelayPVF ()  
=> t_pinDelayPVF
```

Description

Returns the pin delay propagation velocity factor.

Arguments

None

Value Returned

t_pinDelayPVF: If the pin delay propagation velocity factor is defined, it is returned as a string. If not defined, a blank string is returned.

axlCNSGetSameNet

```
axlCNSGetSameNet(
  t_cset
  t_layer
  s_constraint
  [g_string]
)
==> g_value/nil

axlCNSGetSameNet(
  t_cset
  t_layer
  nil
  [g_string]
)
==> ll_nameValue/nil

axlCNSGetSameNet(
  nil
  nil
  nil
)
==> ls_cnsTypes
```

Description

Documentation same as [axlCNSGetSpacing](#).

Arguments

t_cset: name of a same net spacing cset. Can use "" for "DEFAULT".

t_layer: ETCH layer name ("ETCH/TOP" or "TOP"). If *nil* apply change to all layers.

s_constraint: name of constraint. If *nil* returns a set of symbol/value pairs of all constraints.

g_string: By default returns value in the native units of the constraint. If *g_string* is *t*, it will always return data as a string.

Value Returned

g_value: value of constraint in design units

Allegro SKILL Reference

Constraint Management Functions

<i>l_nameValue</i> -	name value pairs of spacing constraint symbol and constraint value for all spacing. (<i>s_constraintg_value</i>). ' ((shape_shape 10.0) (line_line 5.0) ...)
<i>ls_cnsTypes</i> -	list of supported same net spacing constraint names.
<i>nil</i> -	returns nil on error (or same_net).

See Also

[axICNSSetSameNet](#), [axICnsList](#), [axICNSGetSpacing](#)

Examples

Get shape to shape same net spacing in default cset, TOP layer

```
axICNSGetSameNet("") "TOP" 'shape_shape)
```

Get all same net constraints for 25_MIL_SPACE, bottom layer

```
axICNSGetSameNet("25_MIL_SPACE" "BOTTOM" nil)
```

Get all same net constraints for DEFAULT, bottom layer as strings

```
axICNSGetSameNet("") "BOTTOM" nil t)
```

Get supported same net constraint symbols

```
axICNSGetSameNet(nil nil nil)
```

Fetch all layers and constraints of same net cset DEFAULT

```
cset = ""      ;; DEFAULT cset
              foreach(subclass axISubclassRoute()
                  layer = axICNSGetSameNet(cset subclass nil)
                  printf("\nLAYER=%s\n\tconstraints=%L\n" subclass, layer)
              )
```

axlCNSGetSameNetXtalkEnabled

axlCNSGetSameNetXtalkEnabled() => *t/nil*

Description

Returns if Same Net Xtalk is enabled.

Arguments

None

Value Returned

t : same net Xtalk is enabled.

nil : same net Xtalk is not enabled.

axICNSGetSpacing

```
axlCNSGetSpacing(
    t_cset
    t_layer
    s_constraint
    [g_string]
)
==> g_value/nil

axlCNSGetSpacing(
    t_cset
    t_layer
    nil
    [g_string]
)
==> ll_nameValue/nil

axlCNSGetSpacing(
    nil
    nil
    nil
)
==> ls_cnsTypes
```

Description

In its first operational mode, obtains the value of a spacing constraint given a cset and layer. All values are returned in design units, except for `same_net`, which is a boolean (`t/nil`). In a second mode of operation, it obtains all spacing constraints as name/value pairs for a cset on a layer. This, in turn, may be passed to `axlCNSSetSpacing`. For the final mode, a list of supported spacing constraints may be obtained by passing three `nil` values to this interface:

```
axlCNSGetSpacing(nil nil nil)
```

Data types

- Unless otherwise specified, constraints are in current design units.

same_net (boolean) *t / nil*

- `bbvia_gap` is not layer dependent. You must use the TOP layer name as the `t_layer` value to get or set this value.

Arguments

<i>t_cset</i>	Name of a spacing cset. You can use "" for "DEFAULT".
<i>t_layer</i>	ETCH layer name (for example, "ETCH/TOP" or "TOP"). If <i>nil</i> , applies change to all layers.
<i>s_constraint</i>	Name of constraint. If <i>nil</i> , returns a set of symbol/value pairs of all constraints.
<i>g_string</i>	By default, returns value in the native units of the constraint. If <i>g_string</i> is <i>t</i> , always returns data as a string.

Value Returned

<i>g_value</i>	Value of constraint in design units, except for <i>same_net</i> , which is returned as <i>t/nil</i> .
<i>ll_nameValue</i>	Name value pairs of spacing constraint symbol and constraint value for all spacing (<i>s_constraint g_value</i>). <i>'((shape_shape 10.0) (line_line 5.0) ...)</i>
<i>ls_cnsTypes</i>	List of supported spacing constraint names.
<i>nil</i>	Returns <i>nil</i> on error (or <i>same_net</i>).

Example 1

```
axlCNSGetSpacing("") "TOP" 'shape_shape)
```

Gets shape to shape spacing in default cset, TOP layer.

Example 2

```
axlCNSGetSpacing("25_MIL_SPACE" "BOTTOM" nil)
```

Gets all spacing constraints for 25_MIL_SPACE, bottom layer.

Example 3

```
axlCNSGetSpacing("") "BOTTOM" nil t)
```

Gets all spacing constraints for DEFAULT, bottom layer as strings.

Example 4

```
axlCNSGetSpacing(nil nil nil)
```

Gets supported spacing constraint symbols.

Example 5

```
cset = ""          ;; DEFAULT cset
foreach(subclass axlSubclassRoute()
layer = axlCNSGetSpacing(cset subclass nil)
printf("\nLAYER=%s\n\tconstraints=%L\n" subclass, layer)
)
```

Fetches all layers and constraints of spacing cset DEFAULT.

See Also

[axlCNSSetSpacing](#), [axlCnsList](#), and [axlSubclassRoute](#)

axlCNSGetViaZEnabled

```
axlCNSGetViaZEnabled()  
=> t/nil
```

Description

Returns if Via Z is enabled.

Arguments

None

Value Returned

t : via Z is enabled

nil : via Z is not enabled

axlCNSGetViaZPVF

```
axlCNSGetViaZPVF()  
=> t_viaZPVF
```

Description

Returns the via Z propagation velocity factor

Argument

None

Value Returned

t_viaZPVF: If the via Z propagation velocity factor is defined, it is returned as a string. If not defined, a blank string is returned.

axlCNSPhysicalModeGet

```
axlCNSPhysicalModeGet(  
    nil  
) ==> ls_constraints  
  
axlCNSPhysicalModeGet(  
    'all  
) ==> lls_constraintNModes  
  
axlCNSPhysicalModeGet(  
    s_name/t_name  
) ==> s_mode/nil
```

Description

This fetches the current physical drc mode(s). Modes determine if a particular constraint is on or off. These modes apply to the entire board. To determine the set currently supported, physical modes do a `axlCNSPhysicalModeGet(nil)`. The physical mode set may be a subset of physical values since the implementation may associate certain values under a master mode. For example, `via_list` is not a constraint and the diff pair mode is under the `ecset` domain.

Note: Future releases may add or subtract constraint checks. The `axl` interface does guarantee the checks returned by this interface will remain constant from release to release.

Arguments

<i>nil</i> :	returns all modes that are in spacing domain
<i>all</i> :	returns all checks and current mode
<i>s_name</i> :	symbol name of check.
<i>t_name</i> :	string name of check

Value Returned

<i>ls_names</i> :	list of checks (<i>s_name</i> ...)
<i>lls_names</i> :	list of checks and their mode ((<i>s_name s_mode</i>) ...)
<i>s_mode</i> :	mode 'on, or 'off

Examples

Get current list of physical constraints

```
axlCNSPhysicalModeGet(nil)
```

Get list of settings for all physical constraints

```
axlCNSPhysicalModeGet('all')
```

Get current mode of max line width

```
axlCNSPhysicalModeGet('width_max')
```

Get current setting of allow Ts using a string

```
axlCNSPhysicalModeGet("allow_ts")
```

See Also

[axlCNSPhysicalModeSet](#), [axlCNSGetPhysical](#)

axlCNSIsCsetLocked

```
axlCNSIsCsetLocked( g_domain  
    t_csetName  
)  
==> t/nil
```

Description

This returns if a cset is locked. See discussion in [axlCNSIsLockedDomain](#).

A locked cset has the following characteristics:

- Cannot be edited
 - Has the effect of locking the entire domain

Argument

g_domain domain of cset; 'physical, 'spacing, 'sameNet,
'electrical

Value Returned

- t if cset is deleted
 - nil , if cset is not deleted due to being locked or not a cset

Examples

Command to check if the cset DEFAULT is locked

```
axlCNSIScSetLocked('electrical', "DEFAULT")
```

See Also

ax|CNSDesignModeSet

axlCNSIsLockedDomain

```
axlCNSIsLockedDomain(  
    g_domain  
)  
==> t/nil
```


Description

Used to check if the is constraint domain locked. A locked constraint domain has the following characteristics:

- csets cannot be edited, although new csets can be added
- any object (e.g. net) level property overrides are ignored

Notes:

- The spacing and sameNet domains are locked as a single domain.
- Locking is typically done via the techfile. In the techfile, you can lock individual csets. If one cset is locked, Allegro PCB Editor treats the entire domain as locked from the DRC perspective. When a domain is locked, any object level property constraint override is ignored.
- If a cset is locked it cannot be modified or deleted.



Use [axlCnsList\(nil\)](#) to get a list all domains.

Arguments

<i>g_domain</i>	domain of cset; 'physical, 'spacing, 'sameNet, 'electrical
-----------------	---

Value Returned

- t if a constraint domain is locked.
- nil - domain is not locked

Examples

- Command to check if the Electrical domain locked

```
axlCNSIsLockedDomain('electrical)
```

- To find a list of locked domains

```
lockedDomains = setof( x axlCnsList(nil) axlCNSIsLockedDomain(x))
```

See Also

[axlCNSCsetLock](#), [axlCNSIsCsetLocked](#), [axlCNSLockDomain](#), [axlCNSDesignModeSet](#),
[axlCnsList](#)

axlCNSLockDomain

```
axlCNSLockDomain(  
    g_domain  
    g_mode  
)  
==> t/nil
```

Description

This command locks or unlocks a constraint domain.

See discussion in [axlCNSIsLockedDomain](#).

Note: Changing the lock on a domain can take a considerable amount of time since DRC status for that domain needs to be updated. In the spacing domain dynamic shapes also need to be updated. If doing other changes, you should consider cloaking (axIDBCloak the entire process. This API already uses cloaking.

Arguments

<i>g_domain</i>	domain of cset; 'physical, 'spacing, 'sameNet, 'electrical
<i>g_mode</i>	may either be <code>t</code> (to lock) or <code>nil</code> to unlock

Value Returned

Returns `t` if lock status is updated, and `nil` in case of an error.

See Also

[axlCNSIsLockedDomain](#)

Examples

- Lock Spacing cset “DEFAULT” that has a side effect of locking spacing and same net domains

```
axlCNSCSetLock('spacing "DEFAULT" t)
```

axlCNSPhysicalModeSet

```
axlCNSPhysicalModeSet(  
    t_name/s_name  
    t_mode/s_mode  
)  
==> t/nil  
  
axlCNSPhysicalModeSet(  
    'all  
    t_mode/smode  
)  
==> t/nil  
  
axlCNSPhysicalModeSet(  
    l_constraintNModes  
    t_mode/smode  
)  
==> t/nil  
  
axlCNSPhysicalModeSet(  
    ll_constraintNModes  
)  
==> t/nil
```

Description

This sets the current drc modes (on/off) for checks in the area of physical constraints. These modes are global. To determine the constraints modes currently supported do a axlCNSPhysicalModeGet(nil). We support several interfaces. All checks may be set ('all), individual checks, (t_name), list of checks with a same mode' (s_name ...) t_mode/s_mode' (t_name ...) t_mode/s_mode and sets of checks via a list of: ' ((s_name/t_name s_mode/t_mode))

The constraints names may be passed as a symbol or a string. For performance reasons, you should either do all your updates in a single call or wrap individual changes in the map API (see axlCNSMapUpdate).

Note: Future releases may add or subtract constraint checks. The axl interface does guarantee the checks returned by this interface will remain constant from release to release.

Arguments

s_name: symbol name of check.

t_name: string name of check.

Allegro SKILL Reference

Constraint Management Functions

s_mode: mode setting; may be 'on or 'off.

t_mode: string mode setting "on or "off".

'all: set all checks for given tier of Allegro.

Value Returned

Returns t if succeeds or nil if failure.

See Also

[axlCNSPhysicalModeGet](#), [axlCNSGetPhysical](#), [axlCNSMapUpdate](#)

Examples

Turn all constraints off

```
axlCNSPhysicalModeSet('all 'off)
```

Turn on line width max

```
axlCNSPhysicalModeSet('width_max 'on)
```

Turn two constraint to on

```
axlCNSPhysicalModeSet('(bbvia_stagger_max bbvia_stagger_min) 'on)
```

Set various constraints to different modes

```
axlCNSPhysicalModeSet( '((width_max off) (allow_etch 'on)) )
```

axlCNSSameNetModeGet

```
axlCNSSameNetModeGet(  
    nil  
) ==> ls_constraints  
  
axlCNSSameNetModeGet(  
    'all  
) ==> lls_constraintNModes  
  
axlCNSSameNetModeGet(  
    s_name/t_name  
) ==> s_mode/nil
```

Description

Same as [axlCNSSpacingModeGet](#).

Arguments

nil : returns all modes that are in same net spacing domain
'all : returns all checks and current mode
s_name : symbol name of check.
t_name : string name of check

Value Returned

ls_names : list of checks (*s_name* ...)
lls_names : list of checks and their mode ((*s_name* *s_mode*) ...)
s_mode : mode 'on, or 'off

Examples

Get current list of same net spacing constraints

```
axlCNSSameNetModeGet(nil)
```

Get list of settings for all same net spacing constraints

```
axlCNSSameNetModeGet('all)
```

Allegro SKILL Reference

Constraint Management Functions

Get current setting of line to line

```
axlCNSSameNetModeGet('line_line')
```

Get current setting of line to shape using a string

```
axlCNSSameNetModeGet("line_shape")
```

See Also

[axlCNSSameNetModeSet](#), [axlCNSGetSameNet](#), [axlCNSSpacingModeGet](#)

axlCNSSameNetModeSet

```
axlCNSSameNetModeSet (
    t_name/s_name
    t_mode/s_mode
)
==> t/nil

axlCNSSameNetModeSet (
    'all
    t_mode/smode
)
==> t/nil

axlCNSSameNetModeSet (
    l_constraintNModes
    t_mode/smode
)
==> t/nil

axlCNSSameNetModeSet (
    ll_constraintNModes
)
==> t/nil
```

Description

Same as axlCNSSSpacingModeSet.

Arguments

<i>s_name</i> :	symbol name of check.
<i>t_name</i> :	string name of check.
<i>s_mode</i> :	mode setting; may be 'on or 'off.
<i>t_mode</i> :	string mode setting "on or "off".
<i>'all</i> :	set all checks for given tier of Allegro.

Value Returned

Returns *t* if succeeds or *nil* if failure.

See Also

[axlCNSSameNetModeGet](#), [axlCNSGetSameNet](#), [axlCNSSpacingModeSet](#)

Examples

Turn off all same net spacing constraints

```
axlCNSSameNetModeSet('all 'off)
```

Turn on line to line check

```
axlCNSSameNetModeSet('line_line 'on)
```

Turn two constraints to on

```
axlCNSSameNetModeSet('((line_shape thrupin_line) 'on)
```

Set several constraints to different modes

```
axlCNSSameNetModeSet( '((line_line off)
                           (thrupin_shape on)) )
```

axlCNSSetPhysical

```
axlCNSSetPhysical(  
    t_cset/nil  
    t_layer/nil  
    s_constraint  
    g_value  
)  
==> t/nil  
  
axlCNSSetPhysical(  
    t_cset/nil  
    t_layer/nil  
    ll_constraintValues  
    nil  
)  
==> t/nil
```

Description

Allows updating physical constraint values. By passing nil at the appropriate argument, values for all csets and all layers may be changed.

Data types


See axlCNSGetPhysical for the data type of each constraint.

Allowed Design Units:

- A number (integer or floating point) where units is current design units. Must not exceed accuracy of the design.
- Unitless string where accuracy cannot exceed database accuracy.
- String with units, data converted to current design units.

Allowed Data Values:

- Boolean: Use `t/nil` or `"true"/"false"`.
- Symbol: Use the symbol name or its string.



Tip

For best performance, when calling multiple axlCNS interfaces to update constraint values, wrap them in the `axlCnsMap` interfaces as shown below:

```
axlCNSMapClear()
```

Allegro SKILL Reference

Constraint Management Functions

```
axlCNSSetPhysical(nil nil 'width_min 5)
axlCNSSetPhysical("") nil 'allow_padconnect 'VIAS_PINS_ONLY)
...
axlCNSMapUpdate()
```

Single change calls do not require this.

For a list of physical constraints, see `axlCNSGetPhysical`. If adding/deleting individual vias, you may find it easier to use `axlCnsAddVia` and `axlCnsDeleteVia`.



Same_net behavior will change in 16.2. This does not change override values. For example, you can set width_min value in all csets, but if the you applied it to a net or constraint area as an override, it will still be used for those items.

Arguments

t_cset Cset name. You can use "" for the DEFAULT cset. Use *nil* to apply changes to all csets.

t_layer ETCH layer name (for example, "ETCH/TOP" or "TOP"). If *nil*, applies changes to all layers.

s_constraint Constraint symbol to change. Use `axlCNSGetPhysical(nil nil nil)` for list of permissible values.

g_value Value to update. For data types, see Data Types above.

ll_constraintValues Multiple values may be updated by passing a list of lists for the third argument.

```
'((s_constraint g_value) ... )
```

Value Returned

t Success.

nil An error occurs when the ECset name does not exist; the layer does not exist; the constraint does not exist; the value for the constraint is illegal; or the cset is locked.

Example 1

```
axlCNSSetPhysical(nil nil 'width_min 5)
```

Sets minimum line width on all constraints and layers

Example 2

```
axlCNSSetPhysical("") nil 'allow_etch t)
```

Sets allow_etch on all layers in default cset.

Example 3

```
axlCNSSetPhysical("VOLTAGE" "top" 'allow_ts "NOT_ALLOWED")
```

Doesn't allow Ts on top layer of VOLTAGE cset.

Example 4

```
axlCNSSetPhysical("VOLTAGE" "top" 'allow_ts 'NOT_ALLOWED)
```

Uses the same value.

See Also

[axlCNSGetPhysical](#), [axlCNSMapClear](#), [axlCNSMapUpdate](#) [axlCnsAddVia](#), and [axlCnsDeleteVia](#)

axlCNSSetSpacing

```
axlCNSSetSpacing(  
    t_cset/nil  
    t_layer/nil  
    s_constraint  
    g_value  
)  
==> t/nil  
  
axlCNSSetSpacing(  
    t_cset/nil  
    t_layer/nil  
    ll_constraintValues  
    nil  
)  
==> t/nil
```

Description

Allows updating spacing constraint values. By passing *nil* at the appropriate argument, values for all csets and all layers may be changed.

Data types


See [axlCNSGetSpacing](#) for the data type of each constraint.

Allowed Design Units:

- A number (integer or floating point) where units is current design units. Must not exceed accuracy of the design.
- Unitless string where accuracy cannot exceed database accuracy.
- String with units, data converted to current design units.

Allowed Data Values:

- Boolean: Use *t/nil* or "true"/"false".



Tip

- 1) For best performance, when calling multiple axlCNS interfaces to update constraint values, wrap them in the *axlCnsMap* interfaces as shown below:

```
axlCNSMapClear()  
axlCNSSetSpacing(nil nil 'line_shape 10.0)
```

Allegro SKILL Reference

Constraint Management Functions

```
axlCNSSetSpacing("") nil 'line_line 5)
...
axlCNSMapUpdate()
```

- 2) Single change calls do not require this. For a list of current spacing constraints, see [axlCNSGetSpacing](#).



Same net constraint has been moved to the same net spacing domain. An idiosyncrasy when values sent as strings requires the number of decimal points to be no more than the current database accuracy, or the change will be rejected. This does NOT change override values. For example, you can change the line to line value in all csets but if you have applied a net or constraint area override, it will still be used for those items.

Arguments

<i>t_cset</i>	The cset name. You can use "" for DEFAULT cset. Use <i>nil</i> to apply the changes to all csets.
<i>t_layer</i>	The ETCH layer name (e.g "ETCH/TOP" or "TOP"). If <i>nil</i> , applies the changes to all layers.
<i>s_constraint</i>	Constraint symbol to change. Use <code>axlCNSGetPhysical(nil nil nil)</code> for a list of permissible values.
<i>g_value</i>	Value to update. For data types, see Data types above.
<i>ll_constraintValues</i>	Multiple values may be updated by passing a list of lists for the third argument. <code>'((s_constraint g_value) ...)</code>

Value Returned

<i>t</i>	Success.
<i>nil</i>	Indicates an error. An error occurs when the ECset name does not exist; the layer does not exist; the constraint does not exist; the value for the constraint is illegal; or the cset is locked.

Examples

- Set line to shape spacing in all csets, all layers
`axlCNSSetSpacing(nil nil 'line_shape 5)`
- Set line to line spacing to 5 on DEFAULT cset, all layers
`axlCNSSetSpacing("") nil 'line_line 5)`
- Value of DEFAULT cset
`axlCNSSetSpacing("25_MIL_SPACE" "top" 'line_line 5)`

See Also

[axlCNSGetSpacing](#), [axlCNSMapClear](#), and [axlCNSMapUpdate](#)

axlCNSSetPinDelayEnabled

axlCNSSetPinDelayEnabled(*g_value*) => *t*

Description

Enables or disables Pin Delay.

Argument

g_value: *t* or *nil* to indicate if Pin Delay is turned on or off.

Value Returned

t

axlCNSSetPinDelayPVF

```
axlCNSSetPinDelayPVF(g_value)
=> t/nil
```

Description

Sets a value for pin delay propagation velocity.

Arguments

g_value : a string to define the new pin delay propagation velocity factor. A *nil* value indicates that the value is to be deleted.

Value Returned

t : no errors

nil : error detected

axlCNSSetSameNet

```
axlCNSSetSameNet(
  t_cset/nil
  t_layer/nil
  s_constraint
  g_value
)
==> t/nil

axlCNSSetSameNet(
  t_cset/nil
  t_layer/nil
  ll_constraintValues
  nil
)
==> t/nil
```

Description

Documentation same as [axlCNSSetSpacing](#).

Arguments

t_cset: cset name, can use "" for DEFAULT cset. Use `nil` to apply change to all cset.

t_layer: ETCH layer name ("ETCH/TOP" or "TOP"). If `nil` apply change to all layers.

s_constraint: Constraint symbol to change. Use `axlCNSGetSameNet(nil nil nil)` for list of permissible values.

g_value: Value to update. For data type, see above for "DATA TYPES".

ll_constraintValues: Multiple values may be updated by passing a list of lists for the third argument. `'((s_constraint g_value) ...)`

Value Returned

t if succeeds

nil an error
- ecset name does not exist

Allegro SKILL Reference

Constraint Management Functions

- layer does not exist
- constraint does not exist
- illegal value for constraint
- cset is locked

See Also

[axlCNSGetSameNet](#), [axlCNSSetSpacing](#)

Examples

Set line to same net spacing in all csets, all layers

```
axlCNSSetSameNet(nil nil 'line_shape 5)
```

Set line to line same net to 5 on DEFAULT cset, all layers

```
axlCNSSetSameNet("") nil 'line_line 5)
```

Value of DEFAULT cset

```
axlCNSSetSameNet("25_MIL_SPACE" "top" 'line_line 5)
```

axlCNSSetSameNetXtalkEnabled

```
axlCNSSetSameNetXtalkEnabled(g_value)
=> t
```

Description

Enables or disables Same Net Xtalk.

Arguments

g_value: t or nil to indicate if same net Xnet is turned on or off.

Value Returned

t

axlCNSSetViaZEnabled

axlCNSSetViaZEnabledenabled(g_value) => t

Description

Enables or disables Via Z.

Arguments

g_value: t or nil to indicate if Via Z is turned on or off.

Value Returned

t

axlCNSSetViaZPVF

```
axlCNSSetViaZPVF(g_value)
=> t/nil
```

Description

Sets a value for Via Z propagation velocity factor.

Arguments

g_value : a string to define the new via Z propagation velocity factor. A *nil* value indicates that the value is to be deleted.

Value Returned

t : no errors

nil : error detected

axlCNSSpacingModeGet

```
axlCNSSpacingModeGet(  
    nil  
) ==> ls_constraints  
  
axlCNSSpacingModeGet(  
    'all  
) ==> lls_constraintNModes  
  
axlCNSSpacingModeGet(  
    s_name/t_name  
) ==> s_mode/nil
```

Description

This fetches the current spacing drc mode(s). Modes determine if a particular constraint is on or off. These modes apply to the entire board. To determine the set currently supported spacing modes do a axlCNSSpacingModeGet(nil).

The spacing mode set may be a subset of spacing values since the implementation may associate certain values under a master mode.

Note: Future releases may add or subtract constraint checks. The axl interface does guarantee the checks returned by this interface will remain constant from release to release.

Arguments

nil : returns all modes that are in spacing domain
'all : returns all checks and current mode
s_name : symbol name of check.
t_name : string name of check

Value Returned

ls_names : list of checks (s_name ...)
lls_names : list of checks and their mode ((s_name s_mode) ...)
s_mode : mode 'on, or 'off

See Also

[axlCNSSpacingModeSet](#), [axlCNSGetSpacing](#)

Examples

Get current list of design constraints

```
axlCNSSpacingModeGet(nil)
```

Get list of settings for all design constraints

```
axlCNSSpacingModeGet('all')
```

Get current setting of line to line

```
axlCNSSpacingModeGet('line_line')
```

Get current setting of line to shape using a string

```
axlCNSSpacingModeGet("line_shape")
```

axlCNSSpacingModeSet

```
axlCNSSpacingModeSet (
    t_name/s_name
    t_mode/s_mode
)
==> t/nil

axlCNSSpacingModeSet (
    'all
    t_mode/smode
)
==> t/nil

axlCNSSpacingModeSet (
    l_constraintNModes
    t_mode/smode
)
==> t/nil

axlCNSSpacingModeSet (
    ll_constraintNModes
)
==> t/nil
```

Description

This sets the current drc modes (on/off) for checks in the area of spacing constraints. These modes are global. To determine the constraints modes currently supported do a axlCNSSpacingModeGet(nil). We support several interfaces. All checks may be set ('all), individual checks, (t_name), list of checks with a same mode '(s_name ...) t_mode/s_mode '(t_name ...) t_mode/s_mode and sets of checks via a list of: '((s_name/t_name s_mode/ t_mode)) The constraints names may be passed as a symbol or a string. For performance reasons, you should either do all your updates in a single call or wrap individual changes in the map API (see [axlCNSMapUpdate](#)).

Note: Future releases may add or subtract constraint checks. The axl interface does guarantee the checks returned by this interface will remain constant from release to release.

Arguments

s_name : symbol name of check.
t_name : string name of check.
s_mode : mode setting; may be 'on or 'off.

Allegro SKILL Reference

Constraint Management Functions

t_mode: string mode setting "on or "off"
'all': set all checks for given tier of Allegro.

Value Returned

Returns `t` if succeeds or `nil` if failure.

See Also

[axlCNSSpacingModeGet](#), [axlCNSMapUpdate](#)

Examples

Turn off all spacing constraints

```
axlCNSSpacingModeSet('all 'off)
```

Turn on line to line check

```
axlCNSSpacingModeSet('line_line 'on)
```

Turn two constraints to on

```
axlCNSSpacingModeSet('line_shape thrupin_line) 'on)
```

Set several constraints to different modes

```
axlCNSSpacingModeSet( '((line_line off)
                           (thrupin_shape on)) )
```

axlCnsPurgeAll()

```
axlCnsPurgeAll(  
    ) -> x_purgeCount
```

Description

Removes all unused constraint objects and constraint sets. Process all netclasses, regions, physical constraint sets and spacing constraint sets. Deletes all empty netclasses and regions.

Arguments

None

Value Returned

The count of the deleted items.

See Also

[axlCnsPurgeCsets](#)

Examples

```
axlCnsPurgeAll()
```

axlCnsPurgeCsets

```
axlCnsPurgeCsets(
    list l_type
) -> x_purgeCount
```

Description

Process all constraint sets of the specified domain and delete those without references.

This class of functions is design to help migrate designs to take advantage of the 16.0 constraint model. These functions do have to be used when migrating designs. Before using these functions you need to evaluate your constraint usage.

Arguments

Domain of interest 'physical or 'spacing

Value Returned

Count of the csets deleted.

Examples

```
axlCnsPurgeCsets('physical)
axlCnsPurgeCsets('spacing)
```

See Also

[axlCnsPurgeObjects](#), [axlCnsPurgeAll\(\)](#), [axlCnsDeleteClassClassObjects](#),
[axlCnsDeleteRegionClassClassObjects](#), [axlCnsDeleteRegionClassObjects](#)

axlCnsPurgeObjects

```
axlCnsPurgeObjects(  
    list l_type  
) -> x_purgeCount
```

Description

Process the database and delete all group_type objects that have no members; a netclass with no nets, or a region with no shapes.

Arguments

Domain of interest 'physical or 'spacing.

Value Returned

Count of the objects deleted.

Examples

```
axlCnsPurgeObjects('netclass)  
axlCnsPurgeObjects('region)
```

See Also

[axlCnsPurgeCsets](#)

axlViaZLength

```
axlViaZLength(  
    t_layer1  
    t_layer2  
) -> f_length
```

Description

Returns the via length from layer1 to layer2. The layer names can either be given as the ETCH subclass name (TOP) or given as the formal skill layer name ("ETCH/TOP").

This is the length used in the ViaZ option to several DRC checks.

This requires an XL or better product license.

Arguments

t_layer1 start layer name

t_layer2 end layer name

Value Returned

f_length via length in design units

Examples

Get length from top to bottom

```
axlViaZLength("TOP" "BOTTOM")
```

See Also


[axlCNSGetViaZPVE](#)

axlNetEcsetValueGet

```
axlNetEcsetValueGet(  
    o_itemDbid/t_netName  
    t_cnsName/s_name  
)  
==> t_cnsValue/nil
```

Description

Returns the value of a specific electrical constraint that has been assigned to a given net. Both fixed and user defined constraints may be accessed. This will not return a "flattened" net view of constraints applied to pinpairs. Use `axlCnsNetFlattened` to obtain this constraint view.



If requesting multiple constraints from the same net it is faster to get the `dbid` of the net and pass that as first argument instead of using the net name.

Arguments

<code>o_itemDbid</code>	<code>dbid</code> of any item that is assigned to a net or Xnet.
<code>t_cnsName</code>	Property name for the constraint to be fetched. This can be either a fixed constraint or a user-defined constraint.
<code>s_name</code>	Symbol name of DRC check (values returned by <code>axlCNSEcsetModeGet(nil)</code>). These names may not exactly match the property name. They do not exist for user-defined properties in the ECset.

Value Returned

<code>t_cnsValue</code>	Value returned as a string.
<code>nil</code>	No value defined for the net.

See Also

[axlCnsNetFlattened](#)

Allegro SKILL Reference

Constraint Management Functions

Examples:

Net is part of an ECset (electrical constraint set) which has a MAX_EXPOSED_LENGTH constraint:

```
net = car(axlSelectByName("NET" "NET2")
rule = axlNetEcsetValueGet(net "MAX_EXPOSED_LENGTH")
```

Net has an override constraint for MAX_VIA_COUNT:

```
rule = axlNetEcsetValueGet("NET2" "MAX_VIA_COUNT")
```

Same as above example but uses the DRC check name:

```
rule = axlNetEcsetValueGet("NET2" 'Maximum_Via_Count)
```

axlCNSEcsetValueSet

```
axlCNSEcsetValueSet(
  o_ecsetDbid/t_ecsetName
  t_name/s_name
  f_value
)⇒t/nil

axlCNSEcsetValueSet(
  o_ecsetDbid/t_ecsetName
  ll_constraintNValues
)
⇒t/nil
```

Description

Sets the value of the ECset DRC. Electrical Constraint Set (ECset) is a mechanism for packaging up a set of electrical constraints into a group and applying them to a set of nets.

To determine the list of supported values, use the following command:

```
axlCNSEcsetValueGet(nil)
```

You may set single values or a list of values. *ll_constraintNValues* represents a list of values as shown:

```
'((s_name/t_name f_value/t_value) ...)
```

Passing a `nil` or empty string " " as a value deletes the constraint from the ECset.

For performance reasons, changing a value does not invoke DRC. You must manually invoke DRC. See [axlCNSMapUpdate](#) on page 1069 for a set of interfaces that you use in order to mark changes to perform fewer DRC updates.

Note: Constraint checks may change from release to release.

Arguments

<i>o_ecsetDbid</i>	<i>dbid</i> of the ECset.
<i>t_ecsetName</i>	Name of the ECset.
<i>s_name</i>	Symbol name of constraint.
<i>t_name</i>	String name of constraint.

Allegro SKILL Reference

Constraint Management Functions

f_value Floating point value provided is assumed to be in the default user unit for the constraint. Value may be rounded.

t_value If given as a string with MKS type, the value is converted to current user units for the constraint. Rounding may result.

Value Returned

t Set value of ECset DRC.

nil Failed to set value of ECset DRC due to incorrect argument(s).

Examples

Sets impedance:

```
axlCNSEcsetValueSet("UPREVED_DEFAULT"  
    'Impedance ALL:ALL:100.0:2)
```

Sets multi-value:

```
axlCNSEcsetValueSet("UPREVED_DEFAULT"  
    '((Impedance "ALL:ALL:100.0:2") (Maximum_Via_Count 5)))
```

axlCnsGetViaList

```
axlCnsGetViaList(  
    t_csetName  
)  
==>lt_padstacks/nil
```

Description

Returns padstacks defined in a physical constraint set. If the cset name is provided then returns only vias assigned for that cset. Otherwise the function returns vias for all csets. The same vias may appear more than once when using the `nil` option.

If a cset name is given, order of vias in list effects the via selection behavior of the etch editing's working layer model (see this documentation for more information).

Note that padstacks in via list may not currently be loaded in database or may not exist on disk (via that cannot be found is shown by a " * " indicators in cns physical set dialog).

Arguments

`t_csetName` Name of physical cset.

`nil` Process all csets.

Value Returned

`lt_padstacks` List of padstacks defined in a cset or all csets.

`nil` If no padstacks found or cset not found.

See Also

[axlCnsAddVia](#), [axlCnsDeleteVia](#), and [axlCNSGetPhysical](#)

Examples

Report vias in default physical constraint set

```
axlCnsGetViaList ("DEFAULT")
```

Report vias in all physical constraint sets

Allegro SKILL Reference

Constraint Management Functions

`axlCnsGetViaList(nil)`

axlGetAllViaList

```
axlGetAllViaList(  
    [g_attrVias]  
)  
==> lo_padstack_dbid
```

Description

Returns a list of all padstacks included in via lists in the design. This is a compilation of all via lists from all constraint sets. Optionally it provides padstacks from net VIA_LIST properties.

The order of padstack dbids depends on the order of constraint sets, VIA_LIST properties and the associated via lists.



This interface will result in the via padstacks being loaded into the design if they are not already loaded.

Arguments

[g_attrVias]

Optional argument to add padstacks that are not included in constraint sets but are provided in some net VIA_LIST attributes.

Value Returned

lo_padstack_dbid List of padstack dbids.

nil The design has empty via lists.

axlDRCUpdate

```
axlDRCUpdate(  
    g_mode  
) -> x_cnt/nil
```

Description

Performs a DRC check on entire design.

Has two return options controled via `g_mode` option:

- `nil`: interactive (on) checks; similar to `drcupdate` command
- `t`: on and batch checks;similar to `dbdoctor drc` option

Will enable On-Line DRC if it is disabled. Obeys current DRC mode settings.



Caution

Batch mode is being phased out.

Arguments

`g_mode` `t` do all checks plus batch only checks, `nil` do only interactive checks

Value Returned

`x_cnt` Returns number of errors

See Also

[axlDRCGetCount](#), [axlDBControl](#), [axlDRCWaive](#), [axlDBCheck](#)

Example

Run a drc check on a net named "GND"

```
db = axlDBFindByName('net "GND")  
cnt = axlDRCItem(nil p)
```

axlDRCWaive

```
axlDRCWaive(  
    g_mode  
    o_DrcDbid/lo_DrcDbid  
    [t_comment]  
) ==> t/nil
```

Description

Manages waive DRC state and access to the waive DRC functionality. It supports both waiving and restoring (unwaive) DRC markers. The interface supports both a single and a list of DRC *dbids*. If restoring a DRC marker, it will reappear but it may no longer reflect an actual DRC error. This may be due to:

- Change in the constraint expected value
- Change in the object(s) causing DRC
- Different DRC mode settings

The only way of determining if a DRC still should exist is to perform an axlDRCItem on the first item in the DRC's *dbid* violation attribute. The exception to this rule is external DRCs where the tool that created the DRC must be re-run. Note: Comment can also be added by adding the comment property to the DRC by:

```
axlDBAddProp(drcDbid '("COMMENT" "This drc is OK"))
```

Arguments

<i>g_mode</i>	t: waive DRC. nil: unwaive DRC.
<i>o_DrcDbid</i>	A single DRC marker.
<i>lo_DrcDbid</i>	A list of DRC markers.
<i>t_comment</i>	Optional, add a comment to waived DRC. Only applies in waive mode.

Values Returned

t	Success.
---	----------

Allegro SKILL Reference

Constraint Management Functions

nil Failed due to incorrect arguments.

See Also

[axlDBControl](#), [axlDRCWaiveGetCount](#)

Example 1 Waive 1st DRC in drc list

```
p = axlDBGetDesign()->drcs  
axlDBGetDesign(t car(p) "This DRC is OK")
```

Example 2 Waive all drcs in design

```
p = axlDBGetDesign()->drcs  
axlDBGetDesign(t p)
```

Example 3 Restore all waived DRCs

```
p = axlDBGetDesign()->waived  
axlDBGetDesign(nil p)
```

axIDRCGetCount

```
axIDRCGetCount(  
    )⇒x_count
```

Description

Returns the total number of DRCs in the design. Note the design DRC may be out of date.

Arguments

None.

Value Returned

x_count DRC count.

axlDRCItem

```
axlDRCItem(  
    g_mode  
    o_dbid/lo_dbid  
)⇒x_cnt/lo_drcDbid/nil
```

Description

Performs a DRC check on the indicated item(s). The *dbid* may be any *dbid* type (except the design). If the same item appears multiple times in the list, then the same DRC error(s) are returned, and the count is the sum of errors created by each *dbid*. The *g_mode* option controls two return options:

nil Returns DRC error count.

t Returns list of DRC errors.

This obeys current DRC mode settings, which includes the master DRC on/off switch.

Due to waive and duplicate DRC suppression processing, the list of DRCs returned using *g_mode=t* may be less than the count returned by *g_mode=nil*.



This is not an efficient way to run batch DRC or "what if" checks.

Arguments

g_mode *nil*: Returns DRC error count.

t : Returns list of DRC errors.

o_dbid A single.

Value Returned

x_cnt Returns number of errors associated with list of items.

lo_drcDBid List of DRC *dbids*.

nil No *dbids* (if *g_mode = t*) or error in arguments.

See Also

[axlDRCGetCount](#), [axlDBControl](#), [axlDRCWaive](#), [axlDRCUpdate](#)

Examples

Run a DRC check on a net named "GND":

```
db = axlDBFindByName ('net "GND")  
cnt = axlDRCItem(nil p)
```

axlDRCWaiveGetCount

```
axlDRCWaiveGetCount()  
    => x_count
```

Description

Returns total number of waived DRCs in the design.

Arguments

None.

Value Returned

x_count Returns waived DRC count.

axlLayerSet

```
axlLayerSet(  
    o_dbid  
)  
==>o_dbid/nil
```

Description

Updates changes to layer parameters. You can only update the color and visibility attributes of a parameter. This is a wrapper for axlSetParam. After completing color or visibility changes, call axlVisibleUpdate to update the display.

Arguments

o_dbid Layer parameter dbid.

Value Returned

o_dbid Layer parameter dbid.

nil If error.

See Also

[axlSetParam](#) and [axlLayerGet](#)

Examples

1. Change color of top etch layer:

```
q = axlLayerGet("ETCH/TOP")
q->color = 7
q->pattern = 0                   ; solid pattern
q->visibility = nil
axlLayerSet(q)
; if setting multiple layer colors/visisibility only call
; visible update after last change
axlVisibleUpdate(t)
```

2. To set all items to the same color on a class do

```
q = axlGetParam("paramLayerGroup:ETCH")
q->color = 7
axlSetParam(q)
axlVisibleUpdate(t)
```

axlCnsList

```
axlCnsList(  
    s_csetDomain/nil  
)  
==> lt_csetNames/ls_csetsDomain
```

Description

Returns the list of cset names of the domain specified. See `axlDBGetDesign()` ->`ecsets` for a list of electrical csets.

See Also

[axlPurgePadstacks](#), [axlCnsDeleteVia](#), [axlCnsAddVia](#), and [axlCnsGetViaList](#)

Arguments

<i>s_csetDomain</i>	Domains supported: spacing, physical, sameNet, and electrical.
<i>nil</i>	Lists all supported domains.

Values Returned

<i>lt_csetNames</i>	Lists csets in specified domain.
<i>ls_csetDomains</i>	List of supported domains.

See Also

[axlCNSCreate](#)

Example 1

```
axlCnsList('spacing)
```

Returns all spacing cset names.

Example 2

```
axlCnsList(nil)
```

Allegro SKILL Reference

Constraint Management Functions

Returns supported domains.

axlCNSMapClear

```
axlCNSMapClear(  
)  
⇒ t
```

Description

See [axlCNSMapUpdate](#).

Arguments

none

Value Returned

t Always returns t.

Examples

See [axlCNSMapUpdate](#) on page 1069 for an example.

axlCNSMapUpdate

```
axlCNSMapUpdate(  
)  
⇒ x_drcCount/nil
```

Description

This function and `axlCNSMapClear`, which do not support nesting, batch and tune DRC updates from constraint changes made by `axlCNS<xxx>` functions. No `axlCNS<xxx>` functions perform a DRC update. Rather, they set the DRC system out-of-date.

You can run DRC system once on a *set* of constraint changes, which is more efficient than running it as part of each change. You may notice the increased efficiency on large boards.

Arguments

none

Value Returned

<code>nil</code>	There is no matching <code>axlCNSMapClear</code> .
<code>x_drcCount</code>	Number of DRCs caused by batch changes.

Allegro SKILL Reference

Constraint Management Functions

Example 1

```
axlCNSMapClear()  
axlCNSEcsetModeSet('Maximum_Via_Count 'off)  
axlCNSDesignModeSet('all 'on)  
axlCNSDesignValueSet('Negative_Plane_Islands 10.0)  
axlCNSMapUpdate()
```

Turns off electrical max via check by turning all design checks on and setting the island tolerance to 10.

Example 2

```
axlCNSMapClear()  
axlCNSEcsetModeSet('Maximum_Via_Count 'on)  
x1CNSMapUpdate()
```

Does one change.

axlCnsNetFlattened

```
axlCnsNetFlattened(  
    o_netDbid/t_netName  
    t_cnsName/s_name  
)  
==> t_cnsValue/nil
```

Description

Permits a view of constraints where explicit pinpair rules are promoted to the net. The information reported by the function is the same as in `show element` under the Properties attached to net heading. It is also in a format used by the third party netlist (`netin`) and in the `pstxnet.dat` file used by `netrev`.

If pinpairs are constrained by an electrical rule (for example, `PROPAGATION_DELAY`), Allegro PCB Editor stores the constraints on the pinpair, not on the net. The electrical constraints stored on the net are those applied to dynamic pinpairs (the use of the `AD:AR`, `L:S`, syntax) or where the rule applies to the net (for example, `MAX_VIAS`).

This does not return all constraint values applied to the net, if the constraint is obtained via the electrical constraint set (ECset) or overrides exist at the bus or diffpair level. This information is reported in `show element` under the heading, Electrical constraints assigned to net. Allegro PCB Editor maps electrical constraints from xnets, matched groups, and pin pairs to nets by promoting or flattening the electrical property to present a traditional net view of the constraints and to provide compatibility with schematic netlisters. Additional constraints may effect the net because of the ECset assigned to the net, xnet, differential pair or bus level. Additional override properties may exist at the differential pair or bus level. You can use `axlNetECsetValueGet`, but it will not flatten constraints.



Tip
When requesting multiple constraints from the same net, use the `dbid` of the net as first argument instead of the net name.

Arguments

o_netDbid/t_netName dbid or name (string) of the net.

t_cnsName Property name for the constraint.

Allegro SKILL Reference

Constraint Management Functions

<i>s_name</i>	Symbol name of DRC check (values returned by axlCNSECsetModeGet(nil) . These names may not exactly match the property name.
---------------	---

Value Returned

t_cnsValue Value returned as a string exactall.

nil No value defined for the net.

Examples

Get impedance rule by name on net1:

```
rule = axlCnsNetFlattened("NET1" "IMPEDANCE_RULE")
```

Get impedance rule by DRC check name on net1:

```
rule = axlCnsNetFlattened("NET1" 'Impedance)
```

Get PROPAGATION_DELAY on MEM_DATA8 using the dbid of net:

```
net = car(axlSelectByName ("NET" "MEM_DATA8"))
rule = axlCnsNetFlattened(net "PROPAGATION_DELAY")
```

Command Control Functions

Overview

The chapter describes the AXL-SKILL functions that register and unregister AXL-SKILL functions with Allegro PCB Editor and set various modes in the user interface.

AXL-SKILL Command Control Functions

This section lists the command control functions.

axlCmdRegister


```
axlCmdRegister(  
    t_allegroCmd  
    ts_callback  
    ?cmdType t_cmdType  
    ?doneCmd ts_doneCmd  
    ?cancelCmd ts_cancelCmd  
)  
⇒ t/nil
```

Description

Registers a command named *t_allegroCmd* with the Allegro PCB Editor shell system. If the command already exists, either because it is a base Allegro PCB Editor command or because it has been registered by this function at an earlier time, it will be hidden.

Once you register a command, Allegro PCB Editor passes its arguments to SKILL-AXL without parsing them.

You can call the `axlCmdRegister` command any time. Once a command is registered, you can type it at the Allegro PCB Editor command line and also incorporate it into menus and pop-ups.



Tip

Interactive mode should be used if you are changing the database. It will "done" an active interactive command before starting your command. General mode should be used to view the database or to provide some non-database capabilities. It is allowed to co-exist with other general and interactive commands. If changing the database using a form only command, for example, not requesting user picks from the canvas, then you should provide a dummy event handler to prevent your skill code from returning to Allegro.

See example in `<cdsroot>/share/pcb/examples/skill/cns-design.il` function `_AcDesignEvent()`.

You can pass arguments from the Allegro command line to your registered Skill function. See `<cdsroot>/share/pcb/examples/skill/examples/axlcore/arg.il`



Caution

You cannot access interactive Allegro PCB Editor commands via axlShell if you register your skill code as interactive, because nesting interactive commands are not supported. This includes using axlShell

to spawn Allegro PCB Editor scripts that contain interactive commands, which are those that display in the lower right side of the Allegro PCB Editor window (where the Idle string appears).

Arguments

t_allegroCmd Name of the command to register. Use lowercase letters for the command name.

ts_callback Name of SKILL callback routine called when the command is activated from the Allegro PCB Editor window.

t_cmdType String denoting the type of this command:

"interactive"

Allegro PCB Editor interactive command which is the default.

"general"

Immediate command that executes as soon as the command is called, even during another command. Use for display refresh commands, for example.

"sub_cmd"

Must be called inside an interactive command. Use for pop-ups.

ts_doneCmd Done callback function that Allegro PCB Editor calls when the user types *done* or selects *Done* from the pop-up. Can be either a symbol or string. If *nil*, Allegro PCB Editor calls *axlFinishEnterFun* by default.

ts_cancelCmd Cancel callback function that Allegro PCB Editor calls when the user types *cancel* or selects *Cancel* from the pop-up. This argument can be either a symbol or a string. If it is *nil*, Allegro PCB Editor calls *axlCancelEnterFun* by default.

Value Returned

t Command registered successfully.

nil Command not registered.

See Also

[axlCmdUnregister](#), [axlCmdList](#), [axlUIWHelpRegister](#)

Example 1

```
axlCmdRegister( "my swap gates" 'axlMySwapGates  
?cmdType "interactive" ?doneCmd 'axlMySwapDone  
?cancelCmd 'axlMySwapCancel)  
⇒ t
```

Registers the command `my swap gates` as calling the function `axlMySwapGates`.

Example 2 SKILL Function Example

For commands (`s_allegroCmd value`) that accept parameters as strings, the SKILL function converts the parameters to symbols.

```
axlCmdRegister( "do it" 'do_print)  
do it myFile Text AshFindAllText
```

Sample `axlCmdRegister` with a registered function that takes arguments where `myFile` is an output port.

```
(defun do_print (arg1 description find_func) ;; Added to deal with strings  
    myport = evalstring(arg1) ;; Added to deal with strings  
    do_print2( myport description find_func) ;; Added to deal with strings  
    ) ; do_print ;; Added to deal with strings  
# Here is the real function  
(defun do_print2 (p description find_func)  
    (let (list)  
        (fprintf p "Properties on %s:\n" description)  
        (setq list (apply find_func nil))  
        (print_list_props list p)  
        (fprintf p "\n\n")  
        ) ; let  
    ) ; do_print2
```

Parse and process the `do it` arguments.

axlCmdUnregister

```
axlCmdUnregister(  
    t_allegroCmd  
)  
⇒ t/nil
```

Description

Unregisters or removes from the Allegro PCB Editor shell system, a previously registered command named `t_allegroCmd`. If the command already exists because it is a base Allegro PCB Editor command, the original command is available again.

Arguments

<code>t_allegroCmd</code>	Name of command to be unregistered.
---------------------------	-------------------------------------

Value Returned

<code>t</code>	Command unregistered successfully.
----------------	------------------------------------

<code>nil</code>	Failed to unregister the specified command.
------------------	---

Example

```
axlCmdUnregister( "my swap gates")  
⇒ t
```

Unregisters the command `my swap gates`.

axlEndSkillMode

```
axlEndSkillMode()  
    )  
    => t
```

Description

Returns from the SKILL command mode to the program's command line. The SKILL exit function is mapped to this function. In a SKILL program this command has no effect.

Arguments

None

Value Returned

t	Always returns t.
---	-------------------

Example

```
axlEndSkillMode()  
=> t
```

Exits AXL-SKILL.

axlFlushDisplay

```
axlFlushDisplay(  
    )  
    => t
```

Description

Flushes all data from the display buffer to the display screen itself. Displays items intended to be displayed, but not yet displayed because no event has triggered a flush of the display buffer.

You can display the following items:

- Visible objects added to the database
- Messages
- Highlighting and dehighlighting of selected objects
- Pending display repairs

Generally, AXL delays screen updates until a prompt for user input occurs or an AXL program completes, such as axlEnterPoint. Certain programs, such as those that spend long times doing calculations between screen updates, might want to call axlFlushDisplay after each batch of screen updates to indicate the progress of the command. Overuse of this call may hurt performance.

Arguments

None


Value Returned

t	Always returns t.
---	-------------------

Example

```
mypath = axlPathStart( list(8900:4400))
axlPathArcRadius(mypath, 12., 8700:5300, nil, nil, 500)
myline = axlDBCreatePath( mypath, "etch/top" nil)
; Arc is not yet visible
axlFlushDisplay()
; Now arc is visible
```

Creates a path and displays it immediately regardless of whether the user has caused a display event such as moving the cursor into the Allegro PCB Editor window.



axlOKToProceed

```
axlOKToProceed(  
    )  
    => t
```

Description

Checks whether Allegro PCB Editor is processing another interactive command or engaged in some process that might interfere with a SKILL command. Use this to check before starting functions such as `dbcreate`, user interactions, and select set operations. Returns `t` if Allegro PCB Editor is ready to properly execute a SKILL command, and returns `nil` if it is not.

Arguments

`t` Suppresses the error message produced when it is not OK to proceed.

Value Returned

`t` Allegro PCB Editor can allow AXL-SKILL database, selection, and interactive functions to execute.

`nil` Allegro PCB Editor cannot allow AXL-SKILL database, selection, and interactive functions to execute.

Example

```
(when axlOKToProceed  
    ;; do AXL interactive command  
)
```

axlSetLineLock

```
axlSetLineLock(
    ?arcEnableg_arcEnable
    ?lockAnglef_lockAngle
    ?minRadiusf_minRadius
    ?length45f_length45
    ?fixed45g_fixed45
    ?lengthRadiusf_lengthRadius
    ?fixedRadiusg_fixedRadius
    ?lockTangentg_lockTangent
)
⇒ t/nil
```

Description

Sets one or more of the line lock parameters. The parameters are the same as those accessible in the *Line Lock* section of the Allegro PCB Editor Status form.

All parameters not explicitly set in a call to `axlSetLineLock` keep their current settings.

Arguments

`g_arcEnable` If t, sets Lock Mode to Arc. Otherwise Lock Mode is Line.
Default is Line.

`f_lockAngle` Sets Lock Direction. Allowed values are: 45 (degrees), 90 (degrees), or 0 (off, or no lock).

`f_minRadius` Sets Minimum Radius, a value in user units.

`f_length45` Sets the Fixed 45 Length value in user units.

`g_fixed45` If t, sets the Fixed 45 Length mode. You cannot set this parameter unless `f_lockAngle` is 45, and `g_arcEnable` is nil.

`f_lengthRadius` Sets Fixed Radius value in user units.

`g_fixedRadius` If t, sets the Fixed Radius mode. You cannot set this parameter unless `f_lockAngle` is 45 or 90, and `g_arcEnable` is t.

`g_lockTangent` If t, sets the Tangent mode to on.

Value Returned

- | | |
|-----|--|
| t | Set the given line lock parameters successfully. |
| nil | Failed to set the given line lock parameters. |

Example

```
axlSetLineLock( ?arcEnable t ?lockAngle 90 ?fixedRadius t  
?lengthRadius 50)
```

Sets the Line Lock parameters to Lock Direction: 90, Lock Mode: Arc, Fixed Radius: on at 30 mils.

axlSetRotateIncrement

```
axlSetRotateIncrement(  
    ?angular f_angular  
    ?radial f_radial  
)  
⇒ t/nil
```

Description

Sets the dynamic rotate angle increment in degrees (*f_angular*) or radians (*f_radial*). Sets the rotate increment for rotation of objects in the dynamic buffer.

Arguments

f_angular Sets angle lock increment in degrees.

f_radial Sets radial lock increment in radians.

Value Returned

t Set the given rotate increment parameters successfully.

Example

```
(axlSetRotateIncrement ?angular 15)  
⇒ t
```

Sets the dynamic rotate angle to 15 degrees.

axlUIGetUserData

```
axlUIGetUserData()  
⇒ r(userData/nil)
```

Description

Gets the current user data structure from Allegro PCB Editor. The user data structure stores basic information about the state of the user interface. By default it contains the properties:

<i>doneState</i>	How the user returned control to the application. Possible values are either: <code>done</code> or <code>cancel</code> .
<i>popupId</i>	List of the current pop-up values. A list of string pairs, as shown: <code>(("Done" "axlFinishEnterFun") ("Cancel" "axlCancelEnterFun"))</code>
<i>ministatForm</i>	Always <code>nil</code> . (Reserved for future releases.)

You can set your own attributes in the user data structure to communicate with callbacks, as shown in the example. You cannot overwrite the three basic attributes: `doneState`, `popupId`, or `ministatForm`.

Arguments

None

Value Returned

<i>r(userData)</i>	User data structure from Allegro PCB Editor.
<i>nil</i>	Failed to get user data structure from Allegro PCB Editor.

Example

```
userdata = axlUIGetUserData()  
userdata->??  
⇒ (doneState cancel  
popupId (("Cancel" "axlCancelEnterFun"))  
ministatForm nil  
)
```

axlUIPopupDefine

```
axlUIPopupDefine(  
    r_popup  
    ts_pairs)  
⇒ r_popup/nil
```

Description

Creates a pop-up from the name value pair list *ts_pairs*. If *r_popup* already exists, it appends the name value pairs at the end of the existing pairs in *r_popup*. Use the returned *r_popup* id as the argument to `axlUIPopupSet` to make it the active pop-up.

Arguments

r_popup Predefined pop-up handle to which to append new entries. Can be `nil` to create a new pop-up.

ts_pairs List containing the pairs $((t_display\ t_callback))$ defining each pop-up entry display name and its AXL function callback.

Value Returned

r_popup Id of the pop-up created or updated.

`nil` No pop-up created or updated.

Example

```
popid = axlUIPopupDefine( nil
    (list (list "Complete" 'axlMyComplete)
        (list "Rotate" 'axlMyRotate)
        (list "Something" 'axlMySomething)
        (list "Cancel" 'axlCancelEnterFun) )

⇒ ( ("Complete" 'axlMyComplete)
    ("Rotate" 'axlMyRotate)
    ("Something" 'axlMySomething)
    ("Cancel" 'axlCancelEnterFun) )
```

Creates a pop-up with the following selections:

- *Complete*, associated with your function `axlMyComplete`
- *Rotate*, associated with `axlMyRotate`
- *Something*, associated with `axlMySomething`
- *Cancel*, associated with `axlCancelEnterFun`

axlUIPopupSet

```
axlUIPopupSet(  
    r_popup  
)  
⇒ t/nil
```

Description

Sets the active pop-up in Allegro PCB Editor. If *r_popup* is `nil`, unsets the currently active pop-up.

If this call is preceded by a call to `axlUICmdPopupSet` with a non-`nil` *r_popup*, the contents of this popup are used to control graying of the popup items defined in the call to `axlUICmdPopupSet`. Otherwise *r_popup* is used to replace the popup entries. In both cases, the popup callbacks will be replaced.

Note: The popup is invoked by pressing mouse popup button, this is normally the right mouse button.

You can clear the active pop-up by calling outside of the form callback, as follows:

```
axlUIPopup (nil)
```

Arguments

r_popup Predefined pop-up handle created by `axlUIPopupDefine`.

Value Returned

`t` Set *r_popup* as the active pop-up.

`nil` Failed to set *r_popup* as the active pop-up.

Example

```
popid = axlUIPopupDefine( nil
    (list (list "Complete" 'axlMyComplete)
        (list "Rotate" 'axlMyRotate)
        (list "Something" 'axlMySomething)
        (list "Cancel" 'axlCancelEnterFun) )

⇒ ( ("Complete" 'axlMyComplete)
    ("Rotate" 'axlMyRotate)
    ("Something" 'axlMySomething)
    ("Cancel" 'axlCancelEnterFun) )
```

Creates a pop-up with the following selections:

- *Complete*, associated with your function `axlMyComplete`
- *Rotate*, associated with `axlMyRotate`
- *Something*, associated with `axlMySomething`
- *Cancel*, associated with `axlCancelEnterFun`

```
axlUIPopupSet( popid)
⇒ t
```

Sets up the pop-up.

axlBuildClassPopup

```
axlBuildClassPopup(  
    r_form  
    t_field  
)  
⇒ t/nil
```

Description

Supports building a form pop-up with a list of classes.

Arguments

<i>r_form</i>	Form handle.
<i>t_field</i>	Field name in form or pop-up name of form.

Value Returned

<i>t</i>	Pop-up built.
<i>nil</i>	Failed to build pop-up due to incorrect arguments.

Examples

```
axlBuildClassPopup(fw, "CLASS")  
axlFormSetField(fw, "CLASS" axlMapClassName ("ETCH"))
```

axlBuildSubclassPopup

```
axlBuildSubclassPopup (
  r_form
  t_field
  t_class
)
⇒ t/nil
```

Description

Supports building a form pop-up with a list of subclasses from the indicated class.

Arguments

<i>r_form</i>	Form handle
<i>t_field</i>	Field name
<i>t_class</i>	Class name

Value Returned

<i>t</i>	Built form subclass pop-up.
<i>nil</i>	Failed to build form subclass pop-up due to incorrect arguments.

Example

```
# place holder since popup will be overridden by the code
POPUP <subclass>"subclass" "subclass".
...
# field name should match t_field
FIELD subclass
FLOC 9 3
ENUMSET 19
OPTIONS prettyprint ownerdrawn
POP "subclass"
ENDFIELD
axlBuildSubclassPopup(fw, "subclass" axlMapClassName("ETCH"))
axlFormSetField(fw, "subclass" "GND")
```

Form file entry provides a subclass pop-up with color swatch support.

Note: axlMapClassName supports Allegro Package Designer L and Allegro Package SI XL, which rename certain classes.

axlSubclassFormPopup

```
axlSubclassFormPopup (
  r_form
  t_field
  t_class
  nil/lt_subclass
)
⇒ t/nil
```

Description

Builds a form pop-up for a given Allegro PCB Editor class for a given field of *r_form* using the axlSubclassFormPopup function. This function is a combination of axlGetParam and axlFormBuildPopup with color swatching.


If the fourth argument is *nil*, the pop-up is based on all subclasses of the given class.

You can easily build a subclass pop-up containing current colors as swatches. To do this, add the following in the form file for that field:

```
OPTIONS ownerdrawn
```

Pop-ups built this way are dispatched back to the application as strings.

Note: if list of subclasses are passed, illegal subclass names are silently ignored.



To take advantage of color swatches in your subclass pulldown (ENUMSET) use this interface and the owner drawn option in the form file. The form file entry for your control should look like:

```
FIELD <field name>
FLOC <x y location>
ENUMSET <width of field>
OPTIONS prettyprint ownerdrawn
POP <popup name>
ENDFIELD
```

Note *prettyprint* option upper/lower cases the popup name the user sees.

Arguments

<i>r_form</i>	Standard form handle (see axlFormCreate on page 629)
<i>t_field</i>	Field name in form or pop-up name of form.
<i>t_class</i>	Class name.
<i>nil/lt_subclass</i>	Use <code>nil</code> for all members of the class, otherwise specify a list.

Value Returned

- | | |
|-----|------------------------------|
| t | Form pop-up built. |
| nil | Failed to build form pop-up. |

Example

```
axlSubclassFormPopup( form "subclass_name" "ETCH" nil)
```

axlVisibleUpdate

```
axlVisibleUpdate(  
    t_now)  
⇒ t
```

Description

The axlVisible family and its base building block permit changing layer color and visibility.

```
    axlSetParam("paramLayerGroup:...")
```

You can also use these functions in conjunction with Find Filter interaction to permit filtering objects by layer via changing visibility.

The SKILL application must indicate display update via `axlVisibleUpdate` when changing visibility on the user.

Updates any forms that display color or visibility to the user.

For most situations, pass `nil` to this function. This defers updating the main graphics canvas until control is returned to the user, allowing a combination of several canvas updates into one update.

Arguments

<code>t</code>	Update now.
<code>nil</code>	Update when control is returned to the user.

Value Returned

<code>t</code>	Returns <code>t</code> always.
----------------	--------------------------------

Example 1

```
;; You should not interact with the user when you have
;; visibility modified
;; get current visibility
p = axlVisibleGet()
axlVisibleDesign(nil) ; turn off all layers
;;... change visibility of selected layers ...
;;... Selection of objects without user interaction
; restore visibility
axlVisibleSet(p)
```

Selects items using visibility without updating the display.

Example 2

```
;; only leave top etch layer on
axlVisibleLayer("etch" nil)
axlVisibleLayer("etch/top" t)
; update display when control is returned to the user
axlVisibleUpdate(nil)
```

Updates the display after changing visibility.

Example 3

```
p = axlLayerGet("etch/top")
; legal numbers are 1 to 24
p->color = 10
axlSetParam(p)

;make this call after you change all colors and visibility
axlVisibleUpdate(t)
```

Changes color on top etch layer.

axlWindowFit

```
axlWindowFit(  
    )  
    => l_bBox
```

Description

Zooms in to (or out of) a design fitting it fully on the window. For the Allegro PCB Editor in layout mode, performs a fit on the outline. For the Allegro PCB Editor symbol mode, performs a fit such that all visible objects occupy maximum window area. Returns the bounding box of the window after the fit has been performed.

Arguments

none

Value Returned

l_bBox The bounding box of the window after zooming (in user units).

Note: This is available as the Allegro PCB Editor command *window fit*.

Polygon Operation Functions

Overview


This chapter describes the AXL/SKILL Polygon Operation functions and includes the following sections:

- About Polygon Operations
- AXL-SKILL Polygon Operation Attributes
- AXL-SKILL Polygon Operation Functions
- Use Models

About Polygon Operations

A *poly* is a set of points linked so that the start and end point are the same. A poly is always non-intersecting and may contain *holes*. A hole is a non-intersecting closed loop enclosed within a poly.

Figure 21-1 Poly with Holes



Note: These polys refer to the *o_polygon* object in AXL-SKILL. Polys are different from the AXL Skill Database *polygon* object which represents an Allegro PCB Editor unfilled shape.

Allegro SKILL Reference


Polygon Operation Functions

These functions, which perform geometric operations on polys, are called logical operations and do the following:

- Create route keepouts based on the board outline, offset by a pre-determined distance.
- Create split planes from route-keepin and Anti-etch.
- Automatically generate a package keepout surrounding a package and its pins, contoured around the package.

Logical operations in AXL-SKILL enable SKILL programmers to do the following:


- Create logical operation objects (*lo_polygon*) from these Allegro PCB Editor database objects:
 - pins
 - lines
 - clines
 - vias
 - shapes
 - rectangles
 - frectangles (filled rectangles)
 - voids
- Create *o_polygon* from holes in a poly (*o_polygon*)
- Create an Allegro PCB Editor database shape from an *o_polygon*
- Perform geometric operations on *lo_polygons*, resulting in the creation of other *lo_polygons*.
 - Logical AND - The intersection of two polys.




Allegro SKILL Reference

Polygon Operation Functions


- ❑ Logical OR - The union of two polys.



- ❑ Logical ANDNOT - Subtracting one poly from another.



- ❑ Logical EXPAND (CONTRACT is expand in the opposite direction.)



- Perform query operations on a *o_polygon*, including the following:
 - ❑ The area of the poly
 - ❑ The bounding box around the poly
 - ❑ The holes and vertices of a poly
 - ❑ If the *o_polygon* is a hole
- Access path data and holes from an *o_polygon*
- Locate a point respective to the poly

Error Handling

Return values for each function are specified along with the description of the function, in case of error.

AXL-SKILL Polygon Operation Attributes


The following are the attributes of the *o_polygon* type:

Attribute Name	Type	Description
<i>area</i>	float	Area of the poly in the same units as the drawing.
<i>bBox</i>	bBox	Poly's bounding box.
<i>vertices</i>	list	Path-like data of the outer boundary of the poly available as a list of lists where each of the sublists will contain a point representing a vertex of the poly and a floating point number representing radius of the edge from the previous vertex to the present vertex.
		No arcs spanning across quadrants or greater than 90 degrees.
		Radius of 0.0 indicates a straight line edge between the two vertices.
		Positive radius value indicates that the arc lines to the left of the center and negative radius imply that the arc lies to the right of the center of the arc.
<i>holes</i>	list	<i>lo_polygon</i>
<i>isHole</i>	boolean	<i>t = hole, nil = poly</i>

Allegro SKILL Reference

Polygon Operation Functions

The following figures illustrate the attributes described.



■ Attributes

```
vertices(((9775.0 775.0)0.0)
        ((9100.0 1075.0)0.0)
        ((8350.0 950.0)0.0))
holes(poly:20199696 poly:20199896
      poly:22204476)
isHole nil
```

Note: All the 3 polys representing holes of the above poly have their isHole attribute set to t.



■ Attributes

```
vertices(((5975.0 976.0) 0.0)
        ((5787.0 788.0) 188.0)
        ((7225.0 599.0) 0.0)
        ((7413.0 787.0)-188.0)
        ((7225.0 975.0-188.0))

holes nil
isHole nil
```

AXL-SKILL Polygon Operation Functions

This section lists the polygon operation functions.

axlPolyFromDB

```
axlPolyFromDB (
    o_dbid/r_path
    ?endCapTypes_endCapType
    ?layer/_layer
    ?padType s_padType
    ?holes      t/nil
    ?line2poly  t/nil)
⇒ lo_polygon/nil
```

Description

Creates a list of *o_polygon* objects from the *dbid* or an *r_path*. Use the *lo_polygon* list to get the poly attributes or to perform logical operations on these polys. In the case of *r_path* option, we expect a path that reflects a closed shape with no intersections. It is important that the first and last point be the same. The width option of *r_path* is ignored as well as the '?' arguments to axlPolyFromDB .

Polygon Attributes

area	(float) Area of polygon in design units. If a hole this is negative. If a polygon is not a hole then the area is the sum of the base poly area minus any of its holes.
bBox	(bBox) bounding box of polygon
holes	(list of o_polys/nil) list of any holes in poly
isHole	(t/nil) is this a hole (void) or a shape
objType	(t_string) "polygon"
vertices	(list of coords). This always describes a closed shape. Format for each coord is: (xy f_radius)

Where

`xy` - vertex point in design units

`f_radius` - 0 if previous point and this point forms a segment else points form a arc with radius. The sign of the radius indicates for positive the arc is to the left of the y-axis and a negative indicates arc is the right.

If arcs are present a polygon typically may contain more segments than the underlying shape dbid. This is due to the polygon arcs cannot cross a quadrant so are broken along quadrant boundaries.

NOTES

- A polygon is NOT a dbid.
- Comparing two polys using Skill functions:
 - equal function: geometrically compares that two polys are the same thus slightly slower than the eq function.
 - eq function compares that the poly ids are the same.

This is different from the dbid comparison where both the `equal` and `eq` return the same results.

What this means from a programming standpoint, is that if you have two identical shapes in Allegro PCB Editor, the 'equal' comparison on the shape dbids returns that they are NOT equal but converting these shapes to polys via `axlPolyFromDB` and doing a 'equal' of the resulting polygons will return 't' while the 'eq' comparison will return 'nil'.

Arguments

`o_dbid` `axl dbid` for one of the following: path (line and cline), shape, rect, frect, pin, via, void, arc and line from which to construct the poly.

Note: Arc and line are segments reported by `show element`.

`r_path` Path construct from the `axlPath` API family. This is not an Allegro PCB Editor database object and is a much more efficient method for creating an Allegro PCB Editor shape, than converting it to a Poly.

Note `axlDBCreateOpenShape` also supports an `r_path`. For

more details, see **Description**.

See `line2poly`. `r_path` must describe a closed non-intersecting shape unless the `line2poly` is `t` (see below).

`s_endCapType`

Keyword string specifying the end cap type to use for the polygon, one of '`SQUARE`', '`OCTAGON`', or '`ROUND`'. Used in case of line or cline only, otherwise ignored. Default is '`SQUARE`'.

`t_layer`

Keyword string specifying the layer of the pad to retrieve, for example, "`ETCH/TOP`". Used in the case of pin or via only, otherwise ignored. Default is "`ETCH/TOP`".

`s_padType`

Keyword string specifying the type of the pad to be retrieved, one of '`REGULAR`', '`ANTI`', or '`THERMAL`'. Used for pins, vias, or if `r_path` is based with the `line2poly` option, otherwise ignored. Default is '`REGULAR`'.

`holes`

Default value is `t`. By default, for shapes with voids returns any voids as holes. If the value is set to `nil`, does not return the holes.

`line2poly`

Applicable only if first argument is an `r_path`. By default, an `r_path` describes a closed path. When this option is `t`, the `r_path` itself is converted to a poly in a manner similar to `line dbids`. It is strongly recommended that the `r_path` has width otherwise the artwork undefined line width is used.

Typically one poly is returned for each segment in the `r_path`.

Value Returned

`lo_polygon`

Object representing the resulting geometry.

`nil`

Cannot get polys.

See Also

Other APIs that support or generate polygons:

- [axlPolyOperation](#) – performs various logical operations on 2 lists of polygon
- [axlPolyExpand](#) – expands or contracts polygon

Allegro SKILL Reference

Polygon Operation Functions

- axlIsPolyType – is object a polygon object
- axlPolyErrorGet – return last error from axlPolyOperation
- axlPolyFromDB – convert an allegro dbid to a polygon
- axlPolyMemUse – debug function to return memory use of polygon sub-system
- axlPolyOffset – move a polygon
- axlPolyFromHole – converts a hole polygon to a positive polygon
- axlDBCCreateShape – create a shape

See documentation for individual use.

Examples

- Create a poly from a via

```
polyList = axlPolyFromDB(via_dbid, ?layer "ETCH/BOTTOM" ?padType 'ANTI)
```
- Create a rectangle poly (one corner at 0,0 with a width 1000 and height of 500) using *r_path* method

```
; note first and last points are the same
myPath = axlPathStart( list(0:0 1000:0 1000:500 0:500 0:0) 0)
pathPoly = axlPolyFromDB(myPath )
poly = car(pathPoly)
poly->??
```

axlPolyMemUse

```
axlPolyMemUse (
    ) -> lx_polyCounts
```

Description

This returns a list of integers reflecting the internal memory use of the `axlPoly` interfaces. If you assign Poly objects to global handles (instead of assigning to locals, e.g `let` or `prog` statements) then you need to insure all of global data is `nil`-ed at the end of your program. The example below shows how to check that you have written your program correctly.

Description of 5 integers. Integers 2 through 5 are for Cadence use.

- 1 - Most important and shows number of Skill Polys still in use.
- 2 - Number of Allegro Polys in use. This is always \geq to Skill Polys. The additional polys are voids (holes) in the Skill polys.
- 3 - Number of edges in all Allegro polys.
- 4 - Number of Allegro Floating Point Polys (should be 0).
- 5 - Number of edges in all Allegro Floating Point Polys (should be 0).

Arguments

None

Value Returned

`lx_polyCounts` A list of 5 integers reflecting Poly memory usage.

See Also

[axlPolyOperation](#)

Example

Verify at end of your program you have no hanging Poly memory in use.

```
gc() ; requires Skill development licenses
```

Allegro SKILL Reference

Polygon Operation Functions

```
axlPolyMemUse()  
;; should return all 0's
```

axlPolyOffset

```
axlPolyOffset (
    o_polygon/lo_polygon
    l_xy
    [g_copy]
)
=> o_polygon
```

Description

This offsets the entire poly by the provided xy coordinate. Optionally if g_copy is t it will copy the poly, default is to offset the provided poly.

Note: The offseted polygon must be entirely within the extents of the drawing.

Arguments

o_polygon *o_polygon* on which the operation is to be done.

lo_polygon Optionally pass a list of polys.

l_xy Coordinates in user units for offset.

g_copy Optional, if t does the offset on a copy.

Value Returned

lo_polygon/

o_polygon In place offset (*g_copy nil*) or offseted copy of polygon (*g_copy* is t). If passed a list of polys returns a list otherwise return a poly.

See Also

[axlPolyFromDB](#)

Example

See the following.

Allegro SKILL Reference

Polygon Operation Functions

<cdsroot>/share pcb/examples/skill/axlcore/ashpoly.il

axlPolyOperation

```
axlPolyOperation
  o_polygon1 / lo_polygon1
  o_polygon2 / lo_polygon2
  s_operation
)
⇒ lo_polygon/nil
```

Description

Performs the logical operation specified on the two sets of polygons. Does not allow hole polygons as input. When holes are passed as input, the following warning is displayed:

Invalid polygon id argument -<argument>



Caution

-- This function is provided "as-is". Result, in certain cases, may fail or deliver incorrect results. No commitment can be made to address issues uncovered when using this API.

-- Underlying polygon operation function fails and returns nil in rare dense geometrical situations.

Arguments

o_polygon1 / lo_polygon1 *o_polygon* or list of *o_polygons* on which the operation is to be done.

o_polygon2 / lo_polygon2 *o_polygon* or the list of *o_polygons* on which the operation is to be done.

s_operation String specifying the type of logical operation, one of 'AND, 'OR, or 'ANDNOT.

Value Returned

lo_polygon List of *o_polygons* which represent the resulting geometry from performing the operation on the arguments.

nil Error due to incorrect arguments.

For example:

(*o_polygon_out1 o_polygon_out2 ...*) is returned if the result after performing the operation is a list of polygons.

`nil` is returned if the result after performing the operation is a `nil` polygon. For example, consider performing the `AND` operation on two non-overlapping sets of polys.

`nil` is returned if the operation fails. You can obtain a descriptive error message by calling [`axlPolyErrorGet`](#).

Example

```
poly1_list = (axlPolyFromDB cline dbid)
poly2_list = (axlPolyFromDB shape_dbid)
res_list = (axlPolyOperation poly1_list poly2_list 'OR)
```

axlPolyExpand

```
axlPolyExpand(  
    o_polygon1 / lo_polygon1  
    f_expandValue  
    s_expandType  
)  
⇒ lo_polygon/nil
```

Description

This function yields a list of polys after expanding them by a specified distance. Use of a negative number causes contraction. Distance is specified in user units. This function does not allow hole polys as input. When holes are passed as input, the following warning is displayed:

Invalid polygon id argument -<argument>



Underlying logical operation function fails and returns nil in rare dense geometrical situations. 'ALL_ARC mode may have round-off issues when shape has very small arc segments.

Trimming options are (s_expandType):

'NONE	no corner modifications
'ACU_ARC	Trim inside acute (less than 90 degrees) line/line corners with arcs and always chamfer spikes. No obtuse or right angle trimming is done.
'ACU_BLUNT	Trim acute inside corners and spikes with line segments.
'ALL_ARC	Trim inside and outside line/line, line/arc and arc/arc corners with respect to these angle rules: <ul style="list-style-type: none">■ All acute angles are trimmed.■ Most obtuse angles (more than 135 degrees) are trimmed.■ 90 degree corners are trimmed. Finally always chamfer spikes.

Note: Poly expansion with 0 and no trim is returns the input poly NOT a list
`axlPolyExpand(poly 0.0 'NONE) -> o_polygon.`

Arguments

o_polygon1 /lo_polygon1

o_polygon / list of o_polygons on which the operation is to be done.

f_expandValue Amount of expansion in user units.

s_expandType Symbol specifying the exterior corners of the geometry during expansion, (see above)

Value Returned

lo_polygon List of *o_polygons* which represent the resulting geometry after performing the expansion on the polys passed as arguments.

nil Failed to expand polys due to incorrect arguments.

To be more specific:


- (*o_polygon_out1 o_polygon_out2 ...*) is returned if the result after performing the operation is a list of polys.
- *nil* is returned if the result after performing the operation is a *nil* poly, for example, consider contracting a 20x30 rectangle by 40 units.
- *nil* is returned if the operation fails. You can get a descriptive error message by calling `axlPolyErrorGet()`.

Example

```
poly_list = (axlPolyFromDB shape_dbid)
exp_poly = (axlPolyExpand poly_list 10.0 'ALL_ARC)
```

The following sequence of diagrams illustrates the behavior of each of the options.

Figure 21-2 Original Poly



ALL_ARC


During expansion of the poly boundary, an arc is inserted for the edges in the offset shape that satisfy the following criteria:

- Edges form an *outside* (or convex) point of the poly boundary.
The reverse is true for the voids.

Allegro SKILL Reference

Polygon Operation Functions

Figure 21-3 Expanded Using ALL_ARC




ACU_ARC

During expansion of the poly boundary, an arc is inserted for the edges in the offset shape that satisfy the following criteria:

- Edges form an *outside* (or convex) point of the poly boundary.
- Edges form an angle sharper than 90 degree.
The reverse is true for the voids.

Figure 21-4 Expanded Using ACU_ARC



Legend:


- Original Polygon
- Expanded Polygon

ACU_BLUNT

During expansion of the poly boundary, a blunt edge is inserted for the edges in the offset shape that satisfy the following criteria:

- Edges form an *outside* (or convex) point of the poly boundary.
- Edges form an angle sharper than 90 degree.
The reverse is true for the voids.

Figure 21-5 Expanded Using ACU_BLUNT



Legend:

- Original Polygon
- Expanded Polygon

axlIsPolyType

```
axlIsPolyType (
    g_polygon
)
⇒ t/nil
```

Description

Tests if argument *g_polygon* is a polygon user type.

Arguments

g_polygon Object to test, any skill variable

Value Returned

t *g_polygon* is a polygon user type.

nil *g_polygon* is not a polygon user type.

See Also

[axlPolyFromDB](#)

Example

```
poly = axlPolyFromDB(cline_dbid)
axlIsPolyType(poly) returns t.
axlIsPolyType(cline_dbid) returns nil.
```

axlPolyFromHole

```
axlPolyFromHole (
  o_polygon
)
⇒ lo_polygon/nil
```

Description

Creates a new poly from the vertices of the hole, and sets the *isHole* attribute of the resulting poly to `nil`. Function returns `nil` in case of error.

Arguments

o_polygon *o_polygon* on which the operation is to be done. Must have *isHole* attribute set to `t` (that is, the argument must be a hole).

Value Returned

lo_polygon List of *o_polygons* which represent the resulting geometry after creating poly from the hole argument.

`nil` Error due to incorrect argument.

Example

```
poly = axlPolyFromDB(shape_dbid)
hole = car(poly->holes)
polyList = axlPolyFromHole(hole)
```

axIPolyErrorGet

```
axIPolyErrorGet (  
    )  
⇒ t_error/nil
```

Description

Retrieves the error from the logop core. See the following list of error strings returned by the logical operation core:

Error type	String returned
problem with arcs	“Bad arc data in polygon operations.”
bad data	“Data problem inside polygon operations.”
internal error in logical op data handling	“Polygon operation failed because of internal error.”
numerical problem in logical op	“Computational problem while doing polygon operations.”
memory problem	“Out of memory.”
no error	NIL

Arguments

None.

Allegro SKILL Reference

Polygon Operation Functions

Value Returned

t_error Error from the logical operation core.

nil No logical operation error.

Example

```
l_poly1 = axlPolyFromDB(shape_dbid)
l_poly2 = axlPolyFromDB(cline_dbid ?endCapType 'SQUARE)
l_polyresult = axlPolyOperation(l_poly1 l_poly2 'ANDNOT)
if (null l_polyresult) axlMsgPut(list axlPolyErrorGet())
```


Use Models

Example 1


The existing Split Plane functionality can use the AXL version of the logical operation.

The objective is to split the route-keepin shape on the basis of the anti-etch information and add the resulting split-shapes to the database.


Split Plane Usage



1. startShape - route keepin rectangle



2. antiEtchGeom - anti-etch line on layer "ANTI ETCH/XYZ"



3. The above two shapes are created after doing the operation ANDNOT and then creating the shape for the resultant polys.

```
; retrieve the route keepin rectangle
startShape = (myGetRouteKeepin)
; retrieve the shapes and lines on the anti-etch subclass
antiEtchGeom = (myGetAntiEtchGeom (axlGetActiveLayer))

; create the polygon for the route-keepin rectangle
startPoly = (axlPolyFromDB startShape)
; create the polygon for all the anti-etch elements
antiEtchPoly = nil
(foreach antiElem antiEtchGeom
    antiElmPoly = (axlPolyFromDB antiElem ?endCapType 'ALL_ARC)
    antiEtchPoly = (append antiElmPoly antiEtchPoly)
)
; do the LogicalOp operation
splitPolyList = (axlPolyOperation startPoly antiEtchPoly 'ANDNOT)

;check for any error in logop
(if splitPolyList then
```

Allegro SKILL Reference

Polygon Operation Functions

```
(; add the resultant polygons as a set of filled shapes on the
; active class/subclass with no net name.
(foreach resPoly splitPolyList
    (axlDBCreateShape resPoly t)
))
else
    (axlMsgPut(list axlPolyErrorGet()))
)
```

Example 2

```
; retrieve the polygon corresponding to clock gen
clockPoly = (axlPolyFromDB rect_id)
; get polygon associated with the ground shape
gndPoly = (axlPolyFromDB shp_dbid)
; get the intersection of the two polygons
shieldedPoly = (axlPolyOperation clockPoly gndPoly 'AND)

; check for any error in logop
(if shieldedPoly then
    (; get the area of the intersection polygon
    shieldedArea = shieldedPoly->area
    ; get the area associated with clock gen
    clockArea = clockPoly->area

    ;get the ratio of the two areas
    ratioArea = shieldedArea / clockArea)
else
    (axlMsgPut(list axlPolyErrorGet()))
)
```

Gets the shielded area of a clock generator by a ground shape using the rule stating that the ratio of the shielded area to the actual area should be less than a particular threshold.

Allegro SKILL Reference
Polygon Operation Functions

Allegro PCB Editor File Access Functions

AXL-SKILL File Access Functions

This chapter describes the AXL-SKILL functions that open and close Allegro PCB Editor files.



Use these functions, instead of SKILL's infile and outfile, to access files using Allegro PCB Editor standards, not via the SKILL path.

axlDMFileError

```
axlDMFileError(  
    ) -> nil/t_errorMessage
```

Description

This returns the error from the last `axlDMXXX` call. Subsequent calls reset the error message so you should retrieve the error as soon as a call fails.

Arguments

none

Value Returned

<code>nil</code>	No error message available.
<code>t_errorMessage</code>	Message indicating why last operation failed.

See Also

[axlDMOpenFile](#)

Example

```
q = axlDMOpenFile("TEMP" "foo.bar" "r")  
unless(q  
printf("ERROR is %L\n" axlDMFileError()))
```

axlDMFindFile

```
axlDMFindFile (
  t_id
  t_name
  t_mode
  [t_prop]
)
⇒ t_name/nil
```

Description

Opens a file using Allegro PCB Editor conventions. Adds an extension and optionally looks it up in an Allegro PCB Editor search path.

Note: Must have an entry in `fileops.txt` file.

Arguments

<i>t_id</i>	Id describing file attributes from <code>fileops.txt</code>
<i>t_name</i>	Name of file to find.
<i>t_mode</i>	Open mode. One of the following: r: read-only w: write wf: write line-buffered
<i>t_prop</i>	Property string.

Value Returned

<i>t_name</i>	Name of file opened.
nil	Failed to open file.

See Also

[axlDMOpenFile](#)

Allegro SKILL Reference

Allegro PCB Editor File Access Functions

Example

```
(setq aPort(ax1DMFindFile "ALLEGRO_TEXT","clip","w",":HELP=clipboard"))
```

Finds the fully qualified name `clip.txt` for writing.

axlDMGetFile

```
axlDMGetFile(  
    t_id  
    t_name  
    t_mode  
    [t_prop]  
)  
⇒ t_name/nil
```

Description

Gets the file name *t_name* using Allegro PCB Editor conventions as described in the arguments. Returns the full path name of the file. Displays an error message if the file cannot be opened.

Arguments

<i>t_id</i>	File attribute id. This string must be one of the types in the Allegro PCB Editor system file <code>fileops.txt</code> . Examples are <code>ALLEGRO_LAYOUT_DB</code> for Allegro PCB Editor layouts with extension <code>brd</code> , <code>ALLEGRO_REPORT</code> for Allegro PCB Editor report files with extension <code>rpt</code> .
<i>t_name</i>	String giving name of the file to open.
<i>t_mode</i>	Open mode. One of the following: <code>r</code> : read-only <code>w</code> : write <code>wf</code> : write line-buffered
<i>t_prop</i>	Property string.

Value Returned

<i>t_name</i>	Name of the file. In the case of <i>t_mode</i> = "r", the file must exist for successful completion.
nil	File not found. Displays a confirmmer giving the name of the file it could not find.

See Also

[axlDMOpenFile](#)

Example

```
myfile = axlDMGetFile( "ALLEGRO_TEXT" "clip" "r")
⇒ "/usr/home/fred/myproj/clip.txt"
```

Finds the file `clip.txt`, available for reading.

ax1DMOpenFile

```
ax1DMOpenFile(  
    t_id  
    t_name  
    t_mode  
)  
⇒ p_port/nil
```

Description


Opens a file in conventional Allegro manner; adds an extension and optionally looks it up in an Allegro search path. Must have an entry in `fileops.txt` file.

Allegro currently does not support directory or file names containing spaces.

Use this in place of Skill's `infile/outfile`. The Skill interfaces resolve the file location using `SKILLPATH` which may mean that files may not open in the local directory if the `SKILLPATH` does not have `".` as its first component. `ax1DMOpenFile` uses the Allegro convention to open file.

Note: If you use `ax1DMOpenFile` to open a file, use `ax1DMClose` to close it. All other Skill file APIs work on the port returned by this interface.

If you want to use Allegro's standard file extension support (the extension is appended if not present), then see `<cdsroot>/share/pcb/text/fileops.txt` for a list of `t_ids`. Otherwise, if you always provide an extension, use the `TEMP` id.



Use `get_filename(p_port)` to obtain the name of the file.

Arguments

<code>t_id</code>	File attribute id. This string must be one of the types in the Allegro PCB Editor system file <code>fileops.txt</code> . Examples are <code>ALLEGRO_LAYOUT_DB</code> for Allegro PCB Editor layouts with extension <code>brd</code> , <code>ALLEGRO_REPORT</code> for Allegro PCB Editor report files with extension <code>rpt</code> .
<code>t_name</code>	String giving the name of the file to open.
<code>t_mode</code>	Open mode. One of the following:

r: read-only

w: write, create if doesn't exist, truncate to zero length if exists

a: open for writing, create if doesn't exist, go to end of file for appending if exists

In addition, the following modifiers are supported

f : Flush file after each write. This can be slow on Windows if writing across the network. This is typically used if a process will take a long time and you would like to look at the file to see the progress. Example "wf"

b : Open in binary mode. This only has effect on Windows. If file is ASCII, this has the effect for reading of not eliminating the carriage-returns (\r) that are in DOS ASCII files. For writing, it does not add the carriage-returns when it sees a linefeed (writes it like a UNIX ASCII file). Example "rb"

s : Allow spaces in the file or directory name. Currently, Allegro does not support this behavior. Setting this option is unsupported. Example "rbs"

Value Returned

p_port Port of the opened file. In the case of *t_mode* = "r", the file must exist for successful completion.

nil File not found. Displays a confirmmer giving the name of the file it could not find.

See Also

[ax1DMFileError](#), [ax1DMFindFile](#), [ax1DMGetFile](#), [ax1DMOpenLog](#),
[ax1DMClose](#), [ax1DMFileParts](#)

Example

Opens a file `clip.txt` for writing.

```
aPort = ax1DMOpenFile("ALLEGRO_TEXT" "clip" "w")
```

Allegro SKILL Reference

Allegro PCB Editor File Access Functions

Opens a file b.bar.

```
aPort = axlDMOpenFile("TEMP" "foo.bar" "r")
```

axIDMOpenLog

```
ax1DMOpenLog(  
    t_program  
)  
⇒ p_port/nil
```

Description

Opens a file for writing log messages. Uses the name of your program or application without an extension. Opens a file with that name and the extension `.log`. Returns the port of the file if it succeeds.

Arguments

t_program Your program name - no extension.

Value Returned

p_port Port of the opened file. In the case of *t_mode* = "r", the file must exist for successful completion.

nil File not found. Displays a confirmmer giving the name of the file it could not find.

See Also

ax1DMOpenFile

Example

```
logport = ax1DMOpenLog("clipboard"))
```

Opens the file clipboard.log for writing.

axlDMClose

```
axlDMClose(  
    p_port  
)  
⇒ t/nil
```

Description

Closes a file currently open in Allegro PCB Editor. Instead of using Skill's infile/outfile commands, this command must be used to close the files opened using `axlDMOpenFile` or `axlDMOpenLog` commands.



While the core SKILL function, `close` can be used to close a file, it is recommended that any file opened using an `axlDM` function, must be closed using this function. Programs that adhere to this standard, will be compatible with future Allegro Data Management enhancements.

Arguments

p_port Id of the open port to be closed.

Value Returned

t Closed the file.

nil File not found.

Example

```
mylog = axlDMOpenLog("myapplic")  
      ⇒ port: "/usr/home/fred/myproj/myapplic.log"  
axlDMClose(mylog)  
      ⇒ t
```

Opens and closes the file `myapplic.log`.

axlDMBrowsePath

```
axlDMBrowsePath(  
    t_adsFileType  
    [t_title]  
    [t_helpTag]  
)  
⇒ t_filename/nil
```

Description

Invokes a standard Allegro PCB Editor file browser supporting paths, for example, SCRIPTPATH. To use, pass one of the file types supported by fileops.txt. Browses file types that include the fileops PATH attribute. axlDMFileBrowse should be used to browse other file types. This works on non-PATH file types since this browses in the current working directory. The user is not able to change the directory with this browser.

Arguments

<i>t_adsFileType</i>	First entry in fileops.txt.
<i>t_title</i>	Title for the dialog
<i>t_helpTag</i>	Tag for the help file (used only by Cadence)

Value Returned

<i>t_filename</i>	Full path to the filename.
nil	Error due to incorrect arguments.

Example

```
ret = axlDMBrowsePath("ALLEGRO_SCRIPT")  
ret = axlDMBrowsePath("ALLEGRO_CLIPBOARD" "Select Clipboard")
```

axlDMDirectoryBrowse

```
axlDMDirectoryBrowse(  
    t_startingDirectory  
    g_writeFlag  
    [?helpTag t_helpTag]  
    [?title t_title]  
)  
⇒ t_dirName/nil
```

Description

Opens a directory browser. Unlike file browsers, this only allows a user to select a directory. This function call blocks until the user selects or cancels.

Arguments

<i>t_startingDirectory</i>	Name of the starting directory.
<i>g_writeFlag</i>	A boolean - if the file is to be opened for write (<i>t</i>), or for read (<i>nil</i>).
<i>t_helpTag</i>	Defines the help message to display if the <i>Help</i> button is selected in the browser. Default help is provided if this option is not set.
<i>g_title</i>	Override default title bar of the browser. Normally, this is the name of the command that invoked the browser.

Value Returned

<i>t_dirName</i>	Name of directory selected.
<i>nil</i>	No directory selected.

Example

```
axlDMDirectoryBrowse("." t ?title "Pick a directory")
```

Browses the current directory.

axlDMFileBrowse

```
axlDMFileBrowse(
  t_fileType
  g_writeFlag
  [?defaultName t_defaultName]
  [?helpTag t_helpTag]
  [?directorySet g_directorySet]
  [?noDirectoryButton g_noDirectoryButton]
  [?mainFile g_mainFile]
  [?noSticky g_noSticky]
  [?title t_title]
  [?optFilters t_filters]
)
⇒ t_fileName/nil
```

Description

Opens a standard file browser. Unlike the other `axlDM` functions, this always presents the user with a file browser. This function call blocks until the user selects a file or cancels.

Note: The name of the file is selected and returned to the caller. Does not open the selected file.

The final filter is 'All files (*. *)'.

Arguments

<code>t_id</code>	Id describing the file attributes from <code>fileops.txt</code> , or list of ids for different types, or <code>nil</code> if you use <code>optFilters</code> to describe files.
<code>g_writeFlag</code>	If the file is to be opened for write (<code>t</code>), for read (<code>nil</code>).
<code>t_defaultName</code>	Name of file to select by default.
<code>t_helpTag</code>	Tag that defines the help message to display if the Help button is selected in the browser. Default help provided if option not set.
<code>g_directorySet</code>	Sets the directory change button which, by default, is not set.
<code>g_noDirectoryButton</code>	Hiding of the directory change button in the browser. By default, the button is present.

Allegro SKILL Reference

Allegro PCB Editor File Access Functions

<i>g_noSticky</i>	File browser normally remembers the directory from the previous invocation. This helps the user who browses in the same location that is different from the current working directory. If t, then it starts the browser in the current working directory. Normally, you should set this option if <i>g_directorySet</i> is t.
<i>g_mainFile</i>	Matches options Allegro PCB Editor uses to open files from the File menu. This is <i>g_noSticky=t</i> & <i>g_directorySet=t</i> . For non-main files, use no options.
<i>g_title</i>	Overrides default title bar of the browser. Normally this is the name of the command that invoked the browser.
<i>g_filters</i>	Filters added to default <i>t_id</i> filter. The format is: <i><msg> <filter> <msg> <filter>...</i>

Value Returned

<i>t_fileName</i>	Name of the file selected.
<i>nil</i>	No file selected.

Examples

- Browses Allegro PCB Editor text files.

```
axlDMFileBrowse("ALLEGRO_TEXT" nil)
```
- Browses Allegro PCB Editor text files and allows secondary filter of *.log.

```
axlDMFileBrowse("ALLEGRO_TEXT" nil ?optFilters "All log files|*.log|")
```
- Browse Skill files (both il and ils extensions).

```
axlDMFileBrowse(nil nil ?optFilters "Skill files(*.il)|*.il|Skill  
Oops(*.ils)|*.ils|")
```

axlDMFileParts

```
axlDMFileParts(  
    t_filespec  
)  
⇒ (directory file fileWext ext)
```

Description

Breaks a filename into it's component parts.

Arguments

t_filespec Filename or full path spec.

Value Returned

list (directory file fileWext ext)

See Also

[axlDMOpenFile](#)

Example

```
fileparts = axlDMFileParts("/usr1/xxx/stuff.txt")  
--> ("/usr1/xxx/" "stuff" "stuff.txt" "txt")  
fileparts = axlDMFileParts("stuff.txt")  
--> ("/usr1/xxx/" "stuff" "stuff.txt" "txt")  
  
**where /usr1/xxx is the cwd
```

axlOSFileCopy

```
axlOSFileCopy(  
    t_src  
    t_dest  
    g_append  
)  
⇒ t/nil
```

Description

Copies a given source file to a given destination with optional append.

Arguments

<i>t_src</i>	Full path of the source file.
<i>t_dest</i>	Full path of the destination file.
<i>g_append</i>	Flag for the append function (t/nil)

Value Returned

<i>t</i>	Copied file.
<i>nil</i>	Failed to copy file due to incorrect arguments.

Example

```
unless(axlOSFileCopy("~/myfile" "~/newfile" nil)  
    axlUIConfirm("file copy FAILED") )
```

axIOSFileMove

```
axIOSFileMove (
    t_src
    t_dest
)
⇒ t/nil
```

Description

Moves the given source file to the given destination.

Arguments

t_src Full path of the source file.

t_dest Full path of the destination file.

Value Returned

t Moved file.

nil Failed to move file.

Example

```
unless (axIOSFileMove("/mydir/myfile" "/newdir/newfile")
      axlUIConfirm("file move FAILED") )
```

axlOSSlash

```
axlOSSlash(  
    t_directory  
)  
⇒ t_directory/nil
```

Description

Changes DOS style backslashes to UNIX style slashes which are more amenable to SKILL.
On UNIX, returns the incoming string.

Arguments

t_directory Given directory path.

Value Returned

t_directory Directory path using UNIX style slashes (/).

nil Failed due to incorrect argument.

See Also

[axlOSBackSlash](#)

Example

```
p = axlOSSlash("\tmp\mydir")  
-> "/tmp/mydir"
```

axlRecursiveDelete

```
axlRecursiveDelete(  
    t_directory  
)  
⇒ t/nil
```

Description

Recursively removes directories and subdirectories in the argument list. Directory is emptied of files and removed. If the removal of a non-empty, write-protected directory is attempted, the utility fails. If it encounters protected files or sub-directories, it does not remove them or the parent directories, but removes all other objects.



Caution

This can be dangerous since it can severely damage your system or data if not used with care. For example, axlRecursiveDelete("/") could delete your OS and all of your data.

Arguments

t_directory The given directory or filename.

Value Returned

t Directory is successfully removed.

nil Failed for one of the following reasons:
- doesn't exist
- read protected
- sub-file or directory does not allow remove (*partial success*)
- sub-file or directory is in use (NT only) (*partial success*)
A partial success means that some of the files and directories were deleted.

Allegro SKILL Reference

Allegro PCB Editor File Access Functions

Example

```
parent = "./tmp"
child = (strcat parent "/child")
(createDir parent)
(createDir child)
(axlOSFileCopy"~/.cshrc" (strcat parent"/csh") nil)
(axlOSFileCopy"~/.cshrc" (strcat child"/csh") nil)
(axlRecursiveDelete parent)
```

axlTempDirectory

```
axlTempDirectory(  
    )  
⇒ t_directoryName/nil
```

Description

Returns the temporary directory for the current platform.

Arguments

none

Value Returned

<i>t_directory</i>	Temporary directory for the current platform.
nil	Failed to identify temporary directory for the current platform.

axlTempFile

```
axlTempFile(  
    [g_local]  
)  
⇒ t_tempFileName/nil
```

Description

Returns a unique temp file name. The temp file should be removed, even if not used, by axlTempFileRemove.

By default, the files are written to /tmp, but you can modify this with the environment variable TEMPDIR.

Arguments

<i>g_local</i>	Flag, which if true, creates a temp file in the current directory. Most applications should use the default /tmp directory. The local directory should only be used if the file will be more than 2 megabytes.
----------------	--

Value Returned

<i>t_tempFileName</i>	Name of the unique temp file.
nil	Failed to create temp file.

axlTempFileRemove

```
axlTempFileRemove (  
    t_filename  
)  
⇒ t
```

Description

Deletes the temporary file and removes the temporary name from the pool. It is important to call this function once you are finished with a temporary filename.

This can also be used to delete files whose names are not obtained from `axlTempFile`.

Arguments

t_filename Name of the file to delete.

Value Returned

t Deleted temporary file specified.

nil Failed to delete temporary file specified due to incorrect argument.

Reports and Extract Functions

AXL-SKILL Data Extract Functions

The chapter describes the AXL-SKILL functions that extract data from an Allegro layout and write it to an ASCII file for external processing.

axlExtractToFile

```
axlExtractToFile(  
    t_viewFile  
    lt_resultFiles  
    [lt_options]  
)  
⇒ t/nil
```

Description

Extracts data from the current design into an ASCII file. Performs the same process as the Allegro batch command `a_extract`.

Arguments

<i>t_viewFile</i>	Name of the extract command file (view file).
<i>lt_resultFiles</i>	String or list of strings giving the names of the files to which to write the extracted ASCII data. If you designate only one output file, this is a string.
<i>lt_options</i>	List of keyword strings for various options:
"crosshatch"	Generate crosshatch lines when extracting crosshatched shapes.
"ok"	Unknown field names are OK. Useful when the extract command file has property names not defined for the design being extracted.
"short"	Extract data in the short format
"quiet"	Do not print progress messages on stdout.
"mcm"	Output MCM terminology.

Value Returned

<i>t</i>	Extract complete.
<i>nil</i>	Failed to complete the extract. See the file <code>extract.log</code> for explanatory error messages.

Example

```
axlExtractToFile( "cmp_rep_view" "my_comp_data")
⇒ t
```

Extracts the component data from the current layout. Writes the data to the file `my_comp_data.txt`.

axlExtractMap

```
axlExtractMap(  
    t_viewFile  
    [s_applyFunc]  
    [g(userData)]  
)  
⇒ t/l_dbid/nil
```

Description

Takes a set of Allegro database objects you select using the Allegro extract command file and applies to each object a SKILL function you have chosen. The extract command file (the *view*) selects the objects and also sets any filters. Ignores the output data fields listed in the extract command file, since it does not create an output file.

Applies to each object that passes the selection and filter criteria in *s_applyFunc*, the SKILL function you supplied. SKILL calls *s_applyFunc* with two arguments—the *dbid* of the object and the variable *g.userData* that you supply as an argument. *g.userData* may be *nil*. If not, it normally is a *defstruct* or disembodied property list so that the called routine can update it destructively.

If *s_applyFunc* returns *nil*, then *axlExtractMap* stops execution, writes the message, **User CANCEL received** to the extract log file, and returns *nil*. If the callback function returns non *nil* then execution continues.

If *s_applyFunc* is *nil*, then *axlExtractMap* simply returns *l_dbid*, a list of *dbids* of the objects that pass the filter criteria. Use *l_dbid* to perform a *foreach* to operate on each object. (See examples below.)

Behaves slightly differently from a standard extract to a file. Provides *s_applyFunc* with the *dbid* of the parent (rotated) rectangle or shape, and not individual line/arc segments. Returns the attached text in the FULL GEOMETRY view.

Allegro “pseudoviews” (DRC, ECL, ECS, ECL_NETWORK, PAD_DEF, and so on) may not be used with *axlExtractMap*. The callback function is never called.

Note: *axlExtractMap* extracts only objects AXL-SKILL can model. For example, it does not extract function instances and unplaced components.

Arguments

<i>t_viewFile</i>	Name of the extract command file (view file).
<i>s_applyFunc</i>	SKILL function to call for each selected object.
<i>g(userData)</i>	Data to pass to <i>s_applyFunc</i> . May be nil. Ignores <i>g(userData)</i> if <i>s_applyFunc</i> is nil.

Value Returned

<i>t</i>	<i>s_applyFunc</i> is non nil. Applied SKILL functions to specified objects.
<i>l_dbid</i>	List of <i>dbids</i> of the specified objects.
nil	Failed to apply SKILL functions to specified objects. See the file <i>extract.log</i> for explanatory error messages.

Example

```
; user callback provided - function declared
; with the (lambda) function
; returns a list of the names of all nets
(defun get_netnames ()
  ; byReference is disembodied prop list
  ; with property 'nets to be used to store
  ; the net names
  (let ((byReference (list nil 'nets nil)))
    (axlExtractMap "net_baseview"
      ; function created right here
      (lambda (dbid netRef)
        ; add the name of this net to
        ; the list of names
        (putprop netRef
          (cons (get dbid 'name)
            (get netRef 'nets)) 'nets)
        t) ; success return
      byReference)
    (get byReference 'nets))) ; return list of names
```

axlReportList

```
axlReportRegister(  
    ) -> ll_reportList/nil
```

Description

Lists all the SKILL reports registered to the Allegro PCB Editor report interface. Even if you do not register any reports, Allegro PCB Editor registers default reports written in SKILL.

Arguments

None.

Value Returned

ll_reportList List of lists of reports register.

Each sub-list has the following format:

(g_reportCallback t_description t_title)

nil No reports registered.

See Also

[axlReportRegister](#)

axlReportRegister

```
axlReportRegister(  
    g_reportCallback  
    t_description  
    t_title  
) ==> t
```

Description

Allows registration of user reports using the Allegro PCB Editor report dialog box. You provide a report name, title, and a report-generating callback function. Callback function format is: `g_reportCallback(t_outfile)`.

If you generate the report, returns a `t` from the function, or `nil`, if you do not generate a report. If you provide a `nil` `t_description` then the current report is unregistered. You can disregard the `t_title` in the unregister mode. You can register only one report per callback function (`g_reportCallback`). To delete an existing report, pass the callback function assigned to the report, a `nil` for the `t_description`, and an empty string for the `_title`.

Note: Only applicable if you enable the *HTML-style reports*.

You can generate the report file in two formats: text or HTML.

Text:

- File is text based.
- Conversions include inserting links when following keywords are encountered:
`(http://)` - add an HTML link
`(num <,> num)` - XY coordinate; add a cross-probe link to zoom center on that coordinate

HTML:

- File starts with an `<HTML>`
- To enable xy zoom center, decorate all xy coordinates as follows:
`<a href="xprobe:xy:<x>,<y>">(x y)`
Example: xy coordinate is (310 140)
`(310.0 140.0)`

Suggestions and restrictions:

- Your report description string should start with your company name or some other standard to keep all your reports together in the report dialog. Keep the description short to fit within the space provided in the dialog box.
- The report dialog is blocking. Do not use the following:
APIs:
 - any user pick or selection API, `axlSelect`, `axlEnter`.
 - `axlShell`
 - save or open a drawing.
- You can invoke your own form within the report callback but make sure it is blocking (use `axlUIWBlock(<formhandle>)`)
- Return `t` if you want to the report to display. A `nil` will not display the report
- If building a context where your report function is stored, you cannot make the `axlReportRegister` inside the context. The `axlReportRegister` must be placed in `allegro.ilinit` or the `.ini` file (if building autoload contexts). This is the same rule that applies to `axlCmdRegister`.

Arguments

`g_reportCallback` Symbol or string of a SKILL function.

`t_name` Name of report (shown in reports dialog box); if `nil` will delete the report associated with `g_reportCallback`.

`t_title` Name in title bar when displaying report.

Value Returned

`t` Arguments correct.

`nil` Illegal argument.

Examples

The following registers the report My Hello. The optional keyword `in MyReport` lets a direct call to `MyReport` generate a report to a fixed name file, `helloWorld.rpt`. otherwise it takes the name from the report dialog box.

Allegro SKILL Reference

Reports and Extract Functions

```
axlReportRegister('MyReport, "XYZ Inc. Hello" "Hello World")  
  
; optional keyword allows a you to call MyReport with a nil where  
; the report file generated will be helloWorld.rpt. Otherwise if  
; called from report dialog, it will be passed a temporary filename  
procedure( MyReport(@optional (reportName "helloWorld"))  
  
    let( (fp)  
        fp = axlDMOpenFile("ALLEGRO_REPORT" reportName "w")  
        axlLogHeader(fp "This is my report")  
        fprintf(fp, "\nHello World\n")  
        close(fp)  
        t  
    ))
```

Unregister above report:

```
axlReportRegister('MyReport, nil nil)
```

See Also

[axlReportList](#) [axlLogHeader](#)

Utility Functions

The chapter describes the AXL-SKILL utility functions. These include functions to derive arc center angle and radius, and to convert numeric values to different units.

axlCheckString

```
axlCheckString(  
    t_type  
    t_string  
) -> t_modString/nil  
  
axlCheckString(  
    nil  
    nil  
) -> lt_types  
  
axlCheckString(  
    'error  
    nil  
) -> t_errorMsg/nil
```

Description

Checks the provided string for legal characters and length. You must also provide the data type. Give this API two nils if you want to see the list of supported data types.

It performs the following checks for the data type provided:

- length check
- legal characters

For all data types except PROPVALUE, it may also modify the provided string and return the updated string to meet Allegro database rules.

- stripping leading and trailing white space
- upper case

Unique considerations by data type:

- PROPVALUE checks for common property value restrictions. Typically, a property may have more severe restrictions.
- GROUP checks for common group naming restrictions. A particular group may enforce additional restrictions.

You should use the return string since it may have been modified.

Errors messages may evolve over time. Last error is only maintained until next call to axlCheckString.

Arguments

<i>t_type</i>	data type (nil to return all supported data types)
<i>t_string</i>	input string
'error	fetch last error message

Value Returned

<i>t_modString</i>	Modified output string if check is successful
<i>l t_types</i>	List of data types supported
<i>nil</i>	Failed check

See Also

[axlDBControl](#) - max name length

Examples

- return all supported types

```
axlCheckString(nil nil)
```

- typical check

```
axlCheckString("REFDES" "u1") -> "U1"
```

- error

```
axlCheckString("NET" "!GND") -> nil
axlCheckString('error nil)
-> "ERROR(SPMHUT-1): Illegal character(s) present in the name or value."
```

axlCmdList

```
axlCmdList(  
)  
⇒ ll_strings/nil
```

Description

Lists commands registered by `axlCmdRegister`. The list consists of paired strings.

((*<allegro command> <skill function>*)...)

Arguments

None.

Value Returned

<i>ll_strings</i>	List of registered Allegro PCB Editor commands paired with the related SKILL functions.
<i>nil</i>	No commands registered.

Examples

```
axlCmdRegister("interboxcmd" 'axlEnterBox)  
axlCmdList()  
will return the following:  
(  
  ("interboxcmd" "axlEnterBox")  
)
```

axlDebug

```
axlDebug(  
    t/nil  
) t/nil
```

Description

This enables/disables AXL debug mode. See [axlIsDebug](#) for description of what this entails.

Enable debug also enables error messages for invalid attributes of Allegro *dbids*. This enables detecting typos when fetching data from *dbids*. This entails a slight performance hit. For example, if you have a pin *dbid* and you do a pin->bbox (instead of pin->bBox), then an error will be issued.

Arguments

t	To enable AXL Skill debug mode.
nil	To disable.

Values Returned

Returns last setting

See Also

[axlIsDebug](#)

axlDetailLoad

```
axlDetailLoad(  
    t_filename  
    point  
    f_scale  
    x_rotation  
    g_mirror)  
==> t/nil
```

Description

This loads a the designated `ipf` file (`t_filename`) into the current design at location (`point`), with scaling (`f_scale`), rotation (`x_rotation`) and mirror (`g_mirror`). Items are clipped to rectangle provided a save file time. It will load the detail to the active layer.

Note: scale values much less then 1.0 may have unpredictable results.

Arguments

<code>t_filename</code>	the name of the plot file which contains the detail.
<code>point</code>	the location to place the detail.
<code>f_scale</code>	the scaling factor of the details as a floating point number (1.0 is no scaling). Must be greater then 0.1
<code>x_rotation</code>	the rotating angle in degrees. Rotation is restricted to integers.
<code>g_mirror</code>	whether the detail should be mirrored (t/nil).

Value Returned

<code>t</code>	was able to load
<code>nil</code>	otherwise

Examples

Select a group of objects and load at 0,0 with double scaling.

- use `ashSelect` function in Skill examples area

Allegro SKILL Reference

Utility Functions

```
file = "myplt.plt"
objs = ashSelect(nil)
lyr = "MANUFACTURING/DETAIL"
win = axlDBGetDesign ()->bBox
when(objs
    axlDetailSave(file win objs)
    axlLayerCreateNonConductor(layer)
    axlVisibleLayer(layer t)
    axlSetActiveLayer(layer)
    axlDetailLoad(file 0:0 2.0 0 nil)
)
```

See Also

[axlDetailSave](#), [axlSetActiveLayer](#)

axlDetailSave

```
axlDetailSave(  
    t_filename  
    l_bBox  
    o_dbid/lo_dbid  
    [g_filledPads]  
)  
==> t/nil
```

Description

This saves a clipping box (*l_bBox*) and the passed set of geometries (*lo_dbid*) to a Allegro ipf file (*t_filename*).

Notes:

- Any attached text to the dbids is saved.
- Ignores logical dbids such as nets, components, etc.

Arguments

<i>t_filename</i>	the name of the file into which the detail is saved
<i>l_bBox</i>	list of two xy coordinates defining selection box
<i>lo_dbid</i>	list of AXL DBID's or single DBID
<i>g_filledPads</i>	output filled pads as filled (t) or unfilled (nil). Default is filled. Certain other filled figures may be effected by this option

Value Returned

<i>t</i>	was able to save into the file
<i>nil</i>	otherwise

See Also

[axlDetailLoad](#)

axlEmail

```
axlEmail(  
    t_to  
    t_cc/nil  
    t_subject  
    t_body  
)  
==> t/nil
```

Description

Sends an e-mail. If multiple *To* or *Cc* addresses are required; separate their names with a semicolon (;). On Windows, a warning confirmmer may generate. To disable the warning, add the following to the registry:

```
HKEY_CURRENT_USER/Identities/[ident code]/Software/  
Microsoft/Outlook Express/5.0/Mail/Warn on Mapi Send
```

Set the data value to 0.



On UNIX, it is not possible for the interface to return an e-mail delivery failure.

Arguments

<i>t_to</i>	E-mail address.
<i>t_cc</i>	Any carbon copy persons to send; <code>nil</code> if none.
<i>t_subject</i>	What to put on the subject line.
<i>t_body</i>	Body of message.

Value Returned

<code>t</code>	If successful.
<code>nil</code>	Failure.

Allegro SKILL Reference

Utility Functions

Example

```
axlEmail("aperson" nil "A test message" "anybody home?")
```

axlHistory

- Report history buffer (first to last)

```
axlHistory(  
    [x_num]  
) -> t
```

- Read or write history to a file

```
axlHistory(  
    s_operation  
    t_filename  
) -> t/nil
```

Description



This is a developers aid only. Do NOT use it in a Skill program.

Provides command recall capability to the Skill development window.

Functionality also applies to the Allegro PCB Editor command line except the command is: "history <n>" where n is the print the last N commands.

The command line has no ability to read or write history files. They are automatically read on program startup and saved on exit.

History environment variables:

- allegro_history = <n> (default is 200 commands)

Command recall buffer length.

- allegro_savehist = <n> (default off)

Save history file to be saved on program exit. Will be read next time on startup. File is saved at <HOME>/pcbenv/history_<name>.txt

where <name>

- is skill for the skill command area
- program name for Allegro command area

History support:

- !! – last command (same as !-1)

Allegro SKILL Reference

Utility Functions

- !<num> – redo command number (ex !5)
- !-<num> – redo relative to last cmd (ex !-2)
- !<str> – redo cmd starting with string last to first search (ex !echo)
- !?<str> – redo cmd matching with string last to first search. For example, !?unnamed

Arguments

<i>x_num</i>	print last <num> commands, 0 or no argument prints entire recall buffer
<i>s_operation</i>	'read – read history buffer from provided file and append to history 'write – write history buffer to provided file
<i>t_filename</i>	A history file (default extension is .txt)

Value Returned

<i>t</i>	Operation succeeded
<i>nil</i>	Failed

Also prints history buffer if running with option 1.

Example

- Report history buffer

```
a = 1
b = 2
axlHistory()
```

- Save history

```
axlHistory('write "skillhist")
```

- Read history

```
axlHistory()
axlHistory('read "skillhist")
axlHistory()
```

axlHttp

```
axlHttp(  
    t_url  
)  
⇒ t
```

Description

Displays a URL from Allegro PCB Editor in an external web browser. First attempts to use the last active window of a running web browser, raising the browser window to the top if required. If no browser is running, tries to start one.

On UNIX, supports only the browser, Netscape. If Netscape is not running, tries to start it. May not detect failure if the web page fails to load.

Note: Netscape must be in your search path.

You can override the program name using the environment variable:

```
set http_netscape = <program name>
```

For example:

```
set http_netscape = netscape405
```

Note: On UNIX, this function has been tested with Netscape only and may not function properly with another web browser.

On Windows, this function uses the default web browser listed in the Windows registry. If no browser is registered, this function fails. Both Netscape and Windows Explorer work with this function. You can open any file type with a Windows registry entry.

Arguments

t_url URL to display.

Value Returned

t	URL displayed in web browser.
nil	Failure due to web browser not being found (on UNIX), not being registered (on Windows), or being unable to load the URL.

Note: The function may not detect when a URL has not loaded on UNIX.

Examples

```
axlHttp("http://www.cadence.com")
```

axlIsDebug

```
axlIsDebug(  
) ==> t/nil
```

Description

This checks if AXL debug mode is enabled. This is associated with the `axldebug` Allegro environment variable.

When this mode is set, AXL may print additional AXL API argument warnings when arguments to AXL functions are incorrect. Many warnings do not obey this variable because they are considered serious or edge conditions. Warnings supported are less serious and are known from user feedback to be troublesome to program around.

Typically, when an AXL API function encounters an argument error, it will print a warning and return `nil`.

When unset, the code runs in development mode and eliminates many of these warnings. You should have this mode enabled when developing Skill code.

This functionality was introduced in 15.2. Currently, few AXL functions take advantage of this option.

Arguments

None

Value Returned

`t` if mode is enabled, `nil` otherwise.

See Also

[axlDebug](#)

Example

```
when( axlIsDebug() printf("Error\n") )
```

axlIsProductLineActive

`axlIsProductLineActive(t_productLine) -> t/nil`

Description

This routine determines if a product in a given product line has been started.

Arguments

`productLine` The product line that you want to check.
The legal values are:

- SI
- PCB
- CONCEPT
- ORCAD
- APD
- SIP
- PACKAGING

Note: PACKAGING" is equivalent to "APD" + "SIP"

Value Returned

- `t`: There is a license checked out for the given product line.
- `nil`: There is no license checked out for the given product line.

axILicDefaultVersion

```
axILicDefaultVersion(  
    ) -> f_version
```

Description

This returns the default version number used in licensing. Most applications in a release will use this version number when checking out licenses.

Arguments

None

Value Returned

f_version - floating point number (e.g. 16.6)

axILicFeatureExists

```
axILicFeatureExists(  
    t_license  
    [f_version]  
) -> t/nil
```

Description

Checks if license feature exists. Does not verify that the license is available. If no version is provided, the tool default version (see [axILicDefaultVersion](#)) is used.

Argument

<i>t_license</i>	license name
<i>f_version</i>	floating point number (e.g. 16.3)

Value Returned

t if checkout, *nil* in case of failure

See Also

[axILicIsProductEnabled](#)

axILicIsProductEnabled

```
axILicIsProductEnabled(  
    t_license  
) -> t/nil  
  
axILicIsProductEnabled(  
    `all  
) -> lt_licenses
```

Description

Checks if license is checked-out by tool.

In first form, if given a license string returns `t` when license is checked-out and `nil` if it isn't. The test is based on the result obtained by running tool. There is no Skill method to determine licenses.

In the second form, if called with the symbol `all` returns a list of licenses currently checked out by the tool.

Arguments

<code>t_license</code>	Name of license (case sensitive)
<code>'all</code>	Get all licenses currently checked-out by the program.

Value Returned

- `t` - license checked out
- `nil` - license not checked out
- `lt_licenses` - list of licenses checked-out by program (all mode)

See Also

[axILicFeatureExists](#), [axILicDefaultVersion](#)

Examples

See if skill developer license (product 900) is checked out:

```
axILicIsProductEnabled("skillDev")
```

axlLogHeader

```
axlLogHeader(  
    p_port  
    t_titleString  
    [t_prefix]  
)  
⇒ t/nil
```

Description

Writes the standard Allegro PCB Editor log file header to the passed open file. The header record includes:

- Title String
- Drawing Name
- Software Release
- Date and Time

Arguments

<i>p_port</i>	SKILL port for the open file.
<i>t_titleString</i>	Title string in the log file header.
<i>t_prefix</i>	Optional prefix string to header for easier parsing (recommend "#")

Value Returned

<i>t</i>	Wrote log file header to open file.
<i>nil</i>	Failed to write log file header to open file due to incorrect arguments.

axIMKS2UU

```
axIMKS2UU (
    t_mksString
)
⇒ f_value/nil
```

Description

Converts between an MKS string to the current database user units. String can be any length name plus many common abbreviations (see `units.dat` file in the Allegro PCB Editor share/text hierarchy for supported names.)

Conversion can fail for the following reasons:

- Input string not a legal MKS format.
- Conversion will overflow the maximum allowed database size.

Notes:

- Conversion between metric and english units may result in rounding.
- Return number is rounded to the database precision.

Arguments

t_mksString Input unit's string with MKS units.

Value Returned

f_value Floating point number.

nil Conversion failed. See previous description for possible reasons.

Allegro SKILL Reference

Utility Functions

Example 1

```
ax1MKS2UU("100.1") -> 100.0
```

Default conversion with database in mils.

Example 2

```
ax1MKS2UU("100 mils") -> 100.0
```

Database is in mils.

Example 3

```
ax1MKS2UU("100 inches") -> 100000.0
```

Database is in mils.

Example 4

```
ax1MKS2UU("100 METER") -> 3937008.0
```

Database is in mils.

ax1MKSAlias

```
ax1MKSAlias(  
    t_MKS Alias  
)  
⇒ t_alias/nil
```

Description

Searches the MKS unit database for the current definition associated with *unitName*. Unlike ax1MKSConvert, this function does not convert.

You load the MKS database from the following file:

```
<cds_root>/share/pcb/text/units.dat
```

Argument

t_mksAlias Name of the alias string.

Value Returned

t_def Definition name as a string.

nil Definition name could not be found.

Examples

```
ax1MKSAlias("VOLTAGE") -> "V" (Intended usage)  
ax1MKSAliaas("M") -> "METER"  
ax1MKSAlias("KG") -> NIL (The function supports only the use of basic units.)
```

axlMKSCConvert

Operates in several ways, depending on the arguments passed.

1. To convert a number from an input units type to an output unit type, general case:

```
axlMKSCConvert (
  n_input
  t_inUnits
  [t_outUnits]
)
=> f_output/nil
```

2. To convert a number from an input units type to MKS units:

```
axlMKSCConvert (
  n_input
  t_inUnits
  nil
)
=> f_output/nil
```

3. To convert a number from MKS units to an output unit type:

```
axlMKSCConvert (
  n_input
  nil
  t_outUnits
)
=> f_output/nil
```

4. To convert an MKS string to an output units, i.e. ".5 MILS" to "INCHES":

```
axlMKSCConvert (
  t_input
  [t_outUnits]
)
=> f_output/nil
```

5. To pre-register an input units, so that subsequent calls need not specify units:

```
axlMKSCConvert (
  nil
  t_inUnits
)
=> t/nil
```

6. To convert a unit from a pre-registered input units:

```
axlMKSCConvert (
  n_input
)
=> f_output/nil
```

Description

Converts any allowable unit to any other allowable unit. It operates in several ways, depending on the arguments.

Allegro SKILL Reference

Utility Functions

In all instances with `t_outUnits` as an argument, if that argument is omitted, the function converts to active design units.

1. If the first argument is a number and the second argument is evaluated as the units of that number, the number is converted to the units specified by the third argument.
A special case is if first argument is a number, the second is "design" and the third is a length unit then the input number is converted from current design units to specified length units.
2. In the case where the first argument is a string, that string must be a fully instantiated units string, i.e. "15 MILS". In this case the second string is interpreted as the output units, and the value of the first string is converted to these units.
3. If the first argument is nil, then the input units specified by the second argument is remembered for the future calls. The output units will default to the active design, and the function will fail as above if no design is active. Note that pre-registration will not work if there is no active design.
4. When only a number is specified, the function will confirm that an input unit has been pre-registered, and will convert that number, in the pre- registered units, to the design units. Function will issue a warning and return nil if no pre-registered input units, or no active design
5. When the second and third arguments are present but one is nil, it represents MKS standard units for the input or output units, respectively.

Arguments

<code>n_input</code>	Number to convert
<code>t_inUnits</code>	String giving the units of the input number If first argument is not specified, this string should specify the input number to convert and its units.
<code>t_outUnits</code>	String giving the new units for <code>f_output</code> . If <code>t_outUnits</code> is nil, converts the number to the current units of the layout.

Value Returned

<code>f_output</code>	Converted value of <code>n_input</code> .
nil	Failed to convert value due to incorrect arguments.

Examples

- Typical use, convert from design units to another type (design is in mils)

```
axlMKSCConvert(.5 "design" "INCHES") => 0.0005  
axlMKSCConvert(".5 MILS" "INCHES") => 0.0005
```

- Pre-register a unit type then use it on future conversions

```
axlMKSCConvert(nil "MILS") => t  
axlMKSCConvert(.5) => 0.0005
```

- Go to default output conversion (METERS)

```
axlMKSCConvert(.5 "MILS" nil) => 2.54e-05
```

- Not just length is supported (go to farads)

```
axlMKSCConvert(1e-09 nil "pF") => 1000.0
```

axIMKSStr2UU

```
axIMKSStr2UU(  
    t_String  
)  
⇒ t_mksString/nil
```

Description

Converts an input string to a MKS string in current database units. If the input string is in MKS units, that is used as the basis for the conversion. If the string has no units, the function uses the default database units for the string.

Conversion may fail for the following reasons:

- Input string is not a legal MKS format.
- Conversion overflows the maximum database size allowed.

Notes:

- Conversion between metric and english units may result in rounding.
- Number returned is rounded to the database precision.

Argument

t_String Input string.

Value Returned

t_mksString MKS string in current database units.

nil Failed to convert input string. See earlier Description for possible reasons.

Example

```
axIMKSStr2UU("100.1") -> "100.0 MILS"
```

Default conversion with the database in mils.

Allegro SKILL Reference

Utility Functions

axlMapClassName

```

axlMapClassName (
    t_oldName / lt_oldName
    [g_mapToPCB]
)
⇒ t_newName / lt_newName

```

Description

Use this function to write a SKILL program that runs in Allegro PCB Editor and APD. You can map from class names to the name appropriate to the program running your SKILL program. For example, you can write a program using Allegro PCB Editor class names and have the program run in APD.

The table shows the name mapping between Allegro PCB Editor and APD.

Table 24-1 Class Name Mapping

Allegro PCB Editor Class Name	APD Class Name
BOARD GEOMETRY	SUBSTRATE GEOMETRY
ETCH	CONDUCTOR
ANTI ETCH	ANTI CONDUCTOR
PACKAGE GEOMETRY	COMPONENT GEOMETRY
PACKAGE KEEPIN	COMPONENT KEEPIN
PACKAGE KEEPOUT	COMPONENT KEEPOUT
BOARD	SUBSTRATE

When using the list of names mode, names that are not recognized are returned "as is".

Argument

t_oldName Allegro PCB Editor class name.

lt_oldName List of Allegro PCB Editor class name.

g_mapToPCB Optional. *t* maps from the APD name to the PCB names. Default is *nil* (PCB to APD conversion).

Allegro SKILL Reference

Utility Functions

Value Returned

<i>t_newName</i>	Appropriate class name based on product type.
<i>l t_newName</i>	List of class names renamed.

Examples

1. Get APD class name when in APD.

```
axlMapClassName ("ETCH") -> "CONDUCTOR"
```

2. Gets Allegro PCB Editor class name when in Allegro PCB Editor.

```
axlMapClassName ("ETCH") -> "ETCH"
```

3. List in APD

```
axlMapClassName (' ("ETCH" "ANALYSIS")) -> ("CONDUCTOR" "ANALYSIS")
```

axlMemSize

```
axlMemSize(  
    )  
⇒ x_size
```

Description

Returns an estimate of memory use. Returns not what the program is *using*, rather what it is *requesting* from the operating system.

Argument

nothing

Value Returned

<i>x_size</i>	Estimate of memory use in bytes.
---------------	----------------------------------

axIOSBackSlash

```
axIOSBackSlash(  
    t_directory  
)  
==> t_directory/nil
```

Description

This changes UNIX style forward slashes to DOS style backslashes. While most applications support either style, certain older Windows applications only support DOS style path.

The UNIX style is more amenable to Skill programming.

On UNIX this just returns the incoming string.

Arguments

t_directory String containing directory path with forward slashes

Value Returned

t_directory/nil

See Also

[axIOSSlash](#)

Example

```
p = axIOSBackSlash("/tmp/foo")  
-> "\\tmp\\foo"
```

axIOSControl

```
axIOSControl(
  s_name
  [g_value]
)
==> g_currentValue/ls_names
```

Description

Inquires and/or sets the value dealing with the graphics. If setting a value, the return is the old value of the control.

A side effect of most of these controls is if a form is active that is displaying the current setting it may not be updated. Additional side effects of individual controls, currently supported, are listed in the following table.

Name	Value	Set?	Description	Equivalent	Side Effects
cpu	x_number	No	Returns number of available CPUs. Included in the number are multi-cpu multi-core, and hyper threading.	none	none
is64exe	t/nil	No	Returns t if this executable is 64bit	none	none
is64os	t/nil	No	Returns t if this is a 64bit based OS.	none	none
isWindows	t/nil	No	Returns t if a Windows OS and nil if UNIX or Linux.	none	none
hostname	string	No	Returns hostname of computer this programming is running on.	none	none
physicalMemory	x_number	No	Returns in units of 1Mbyte the amount of physical memory. This is not to be confused with virtual memory.	none	none
			Note: 32bit OS can at most address 4GB (4000MB) of memory. 32bit Windows is restricted to 3GB. So even if you have more installed on your PC this will still report 3GB.		

Arguments

s_name Symbol name of control. If this value is `nil`, all possible names are returned.

g_value Optional symbol value to set. Usually a `t` or a `nil`.

Value Returned

See above

ls_names If name is `nil` then returns a list of all controls.

See Also

`axlUIControl`, [axlMemSize](#)

Example

1. Get CPUs

```
size = axlOSControl('cpu)
-> 2
```

2. Get if 64bit program

```
axlOSControl('is64exe)
-> nil
```

axlPPrint

```
axlPPrint(  
    t_name  
)  
⇒ t_pname
```

Description

Converts a string with Allegro PCB Editor's pretty print text function as follows:

- Ensures that the first character after a white space, _ (underscore) or / (forward slash) is capitalized.
- Ensures the rest of the text in the given string is lower case.

Argument

t_name A string.

Value Returned

t_pname The converted string.

Example

```
axlPPrint("ETCH/TOP") -> "Etch/Top"
```

axlPdfView

```
axlPdfView(  
    t_pdfFile  
)  
⇒ t
```

Description

Displays a PDF file from Allegro PCB Editor. If just the filename is given, attempts to find the PDF file using Allegro PCB Editor's PDFPATH variable. Displays the PDF file in an external PDF viewer.

On UNIX, the only supported PDF viewer is Acroread. The program, Acroread, must be in your PATH.

On Windows, uses the default PDF viewer registered with the Windows registry. If there is no registered PDF viewer, the call fails.

Argument

t_pdfFile Name of PDF file to display.

Value Returned

t PDF file displayed.

nil Failed to display PDF file due one of the following:

 - No Acroread PDF viewer found on UNIX.

 - No PDF viewer registered on Windows.

Example

```
axlPdf("allegro.pdf")
```

axlPrintDbid

```
axlDumpDbid(  
    o_dbid/lo_dbid  
    [o_port]  
) -> t
```

Description

This is a debug function to print one or a list of dbids. Output format is terse and parsable. This will not print all attribute data in a dbid but is customized to aid in understanding the dbid data.

Format: <key> <attribute> <value>

where key can be

- c common value of attribute (objType, name, xy)
- a other attributes
- l printable detail on list of dbids associated with element Not all list of dbids are reported.
- g what groups have the object.

Format:

```
g group <type> name= <name>
```

Output is either directed to the Skill window or if port is provided written to a file.

Note using the environment variable, `pv_showelem` you can get the same data in the *show element* command.

Arguments

o_dbid/lo_dbid dbid or a list of dbids

o_port option port object (from outfile)

Value Returned

t

Allegro SKILL Reference

Utility Functions

See Also

[axlShowObject](#)

Example

```
l = axlGetDesign()  
axlPrintDbid(l)
```

axlRegexpList

```
axlRegexpIs(  
    t_exp  
)  
⇒ t/nil
```

Description

Determines whether an environment variable expression contains Allegro PCB Editor compatible wildcard characters. Certain select-by-name functions support wildcard characters. You can test for the presence of wildcards before calling the select-by-name type of functions.

Regular expressions used by Allegro PCB Editor are more compatible with the character set allowed in the Allegro PCB Editor object names than SKILL regular expressions. Do not use to test patterns being sent to the SKILL `regexp` family of functions.

Argument

t_exp SKILL symbol for the environment variable name.

Value Returned

t Expression contains Allegro PCB Editor compatible wildcards.

nil Expression does not contain Allegro PCB Editor compatible wildcards.

axlRunBatchDBProgram

```
axlRunBatchDBProgram(  
    t_prog  
    t_cmdFmt  
    [?logfile logfile]  
    [?startMsgt startMsg]  
    [?reloadDBt/nil]  
    [?noUnloadt/nil]  
    [?silentt/nil]  
    [?noProgress t/nil]  
    [?warnProgram t/nil]  
)  
⇒ t/x_error
```

Description

Spawns batch jobs that require an open database via an abstract model. When the job completes, it prints a message and optionally reloads (?reloadDB) the database if successful. If the database is saved from the current active database, it uses a temporary name to avoid overwriting the database on disk.

The following options are always required (UIBatchSpawn):

t_prog Name of the program to run.

t_cmdFmt Command string.

The following options are optional.

t_logFile Name of log file that the program creates. Registers this with the log file viewlog facility if the program ends in an error. If no log file is required, do not set this option. If no extension is given, adds .log as the extension.

startMsg Enables a start message to display when the program starts. Defaults to the program name. If you override by providing this string, the message begins with "Starting..."

reloadDB If you set this to *t*, the database reloads after a successful run of the program. If the batch program does not save the database, you need not reload the database.


Allegro SKILL Reference

Utility Functions

<i>noUnload</i>	If you set this to <code>t</code> , you don't save the database to disk. You use this for a program that creates a new database or doesn't require an Allegro PCB Editor database. Default is <code>nil</code> .
<i>silent</i>	If you set this to <code>t</code> , no messages are displayed. Use when the user does not need to know that a program is spawned. Default is <code>nil</code> .
<i>noProgress</i>	If <code>t</code> , the progress meter does not display. Default is <code>nil</code> .
<i>noLogview</i>	When set, it prevents display if log file on program exit.
<i>noWarnOnExit</i>	When set, suppresses some exit warning messages.
<i>warnProgram</i>	Program supports warning status (returns 0, if success; 1, if warnings; and 2, if errors).
<i>noExitMsgs</i>	When set, suppresses messages about program success or failure.

Note: For `t_cmdFmt`, the formatting should include everything except the design filename. Place a `%s` where the design should appear. To get a `%s` while doing a `sprintf`, use a “`%%s`” as shown in following examples:

```
cmdFmt = "netrev -$ -q -r %s"
sprintf(cmdFmt, "%s -$ %s %s %%s", prog, argq argr)
```



- a.** For debug, set the env variable, `wait_debug`, on the Allegro command line:

```
set wait_debug
```

or in Skill

```
axlSetVariable("wait_debug" nil)
```

This echos the spawning arguments of your program. You can also use this variable to see how Allegro spawns programs from its dialogs. The "#T<num>.tmp" name seen in this output is the temporary save of the current design to disk and the use of the "%s" argument in your `t_cmdFmt` statement.

- b.** For a list of Allegro programs and their command line arguments see the directory:

```
<cdsroot>/share/pcb/batchhelp
```

or run the batch program with the "-help" argument.

Allegro SKILL Reference

Utility Functions

Example: `idf_in -help`

- c. Many Allegro batch programs support '`-$`' as a standard argument. This prevents prompting for missing input arguments.

Argument

<code>t_prog</code>	string containing program name
<code>t_cmdFmt</code>	string containing starting arguments (including program)
<code>t_logfile</code>	optional string showing logfile
<code>t_startMsg</code>	optional string having start message
<code>?reloadDB</code>	Optional t/nil having database be reloaded after job completes
<code>?noUnload</code>	Optional t/nil stating database shouldn't be saved
<code>?silent</code>	Optional t/nil controlling info messages
<code>?noProgress</code>	Optional t/nil controlling progress meter

Value Returned

<code>t</code>	Batch job ran.
<code>x_error</code>	Error number that is program dependent on failure.

Examples

- Spawn genfeedformat which requires design to be saved to a temp file

Program Args:

- `-$` - silent
- `-b` - name of design (required)
- `%%s` - because we `sprintf` the format before calling batch we need to escape the `%s` by prepending an extra %

Skill:

Allegro SKILL Reference

Utility Functions

```
sprintf(format "genfeedformat -$ %s %%s", "-b")
;format= "genfeedformat -$ -b %s"
axlRunBatchDBProgram("genfeedformat" format
?logfile "genfeed")
```

Without sprintf

```
axlRunBatchDBProgram("genfeedformat" "genfeedformat -$ -b %s" ?logfile
"genfeed")
```

- Spawn 3rd party program, notepad, on an existing file "allegro.jrl". In this case we do not want to save design (?noUnload t) and no progress meter is required (?noProgress t)

```
axlRunBatchDBProgram("notepad" "notepad allegro.jrl"
?noUnload t ?noProgress t)
```

- Spawn 3rd party import login, a program that requires read/write database wrapping. Read existing 3rd party netlist file called "netlist.txt". Since design needs to be reloaded if import is successful use the "?reloadDB t" option.

Program Args:

- \$ - silent
- g - run gate assign
- y 1 - Always Place changed component
- netlist - name of netlist file (e.g. netlist.txt)
- %s - use current design

Skill:

```
axlRunBatchDBProgram("netin"
"netin -$ -g -y 1 netlist %s"
?startMsg "Logic Import"
?logfile "netin"
?reloadDB t)
```

- Export IDF

Program Args:

- d IDF - File name type
- V 3.0 - IDF version
- h 2000 - default package height
- s ... - Source id (note \"...\" allows spaces in name)
- o myidf - output idf files (with bdf and ldf extensions)

Allegro SKILL Reference

Utility Functions

- %s - axl will enter name of temp database saved to disk

Skill:

```
axlRunBatchDBProgram("idf_out"
    "idf_out %s -d IDF -o myidf -s \"allegro_16.3\" -b 1 -h 2000 -V 3.0")
```

- Import IDF, assumes an existing bdf file, unnamed.bdf. If successful load updated design back into memory via the reload option (?reloadDB t).

Program Args:

- -o %s - name of current design (%s - substitute in current design)
- unnamed - name of bdf file on disk

Skill:

```
axlRunBatchDBProgram("idf_in" "idf_in -o %s unnamed" ?reloadDB t)
```

axlShowObject

```
axlShowObject(  
    lud_dbid  
)  
⇒ t/nil
```

Description

Displays the object data for each *dbid* in *lud_dbid* in a *Show Element* window. Does the same function as the interactive command `list element`. *lud_dbid* can be either a single *dbid* or a list of *dbids*.

Arguments

lud_dbid *dbid*, or list of *dbids*.

Value Returned

t Displayed the **Show Element** window for any objects.

nil Failed to display the Show Element window for any objects.

Example

```
axlDBCreatePropDictEntry(  
    "myprop", "real", list( "pins" "nets" "symbols"),  
    list( -50. 100), "level")  
axlClearSelSet()  
axlSetFindFilter(  
    ?enabled '("NOALL" "ALLTYPES" "NAMEFORM")  
    ?onButtons "ALLTYPES")  
axlSingleSelectName( "NET" "ENA2")  
axlDBAddProp(axlGetSelSet(), list("MYPROP" 23.5))  
axlShowObject(axlGetSelSet())  
⇒ t
```

1. Defines the string-valued property MYPROP.
2. Adds it to the net ENA2.
3. Displays the result to the user with `axlShowObject`.

axlSleep

```
axlSleep(  
    x_time  
)  
==> t/nil
```

Description

Sleeps specified time.

This is a replacement for Skill's sleep which is actually provided by the IPC Skill package. On Windows the IPC sleep crashes if you call `axlEnterEvent`.

If you are using the IPC interfaces then you should call `axlSleep` instead of using `sleep`.

Arguments

<i>x_time</i>	Time in seconds.
---------------	------------------

Value Returned

<i>t</i>	All of the time.
----------	------------------

axlSort

```
axlSort(  
    t_infile  
    t_outfile  
    [t_sortfields]  
    [t_sort_options]  
)  
⇒ t/nil
```

Description

Sorts contents of a given input file and places results in the output file. No warning is given if the output file overwrites an existing file - any checking must be done by the caller of this function.

Default sort is a left to right, ASCII ascending sort of the input file, with duplicate lines left in. You can control the sort behavior using the optional parameters.

Allegro SKILL Reference

Utility Functions

Argument

<i>t_infile</i>	Name of the input file to sort.
<i>t_outfile</i>	Name of the file containing results of the sort.
<i>t_sortfields</i>	String specifying which fields to use as sort keys, the sort order of those fields, and how to interpret the data type of the field for sorting. String contains a series of triplets: <code>field_number sortOrder fieldType</code> String can contain multiple triplets separated by commas. Triplets can contain valid elements as shown:

Triplet Element	Description
<i>field_number</i>	Number representing the position of the field on the line, from left to right. Numbering starts at 1.
<i>sortOrder</i>	A - Ascending sort order D - Descending sort order
<i>fieldType</i>	A - Alpha I - Integer F - Float

An example of a *t_sortfields* triplet:

"3 A A, 5 D I, 1 A F"

This triplet sorts based on the following:

1. The third field, ascending, field type ASCII.
2. The fifth field, descending, field type Integer.
3. The first field, ascending, field type Float.

Allegro SKILL Reference

Utility Functions

t_sort_options String containing directives controlling the global sort parameters. Sort options can appear in any order, and must be separated by commas. These options are available:

Option	Description
Field Delimiter	Supported delimiters include any character in punctuation character class except comma.
U	Remove duplicate lines. Default is keep duplicate lines.
D	Descending order. Default is ascending order.

An example of the *t_sort_options* string:

"!,U"

This means to use the ‘!’ character as the field delimiter and to remove any duplicate lines.

Value Returned

- | | |
|-----|---|
| t | Sort successful. |
| nil | Sort unsuccessful due to incorrect arguments. |

Examples

Input file

```
2!3!4!5!6  
2!3!4!5!6  
5!6!7!8!9  
5!1!7!8!9  
2!2!3!4!5  
1!2!3!4!5  
3!4!5!6!7  
4!5!6!7!8
```

Example 1

```
(axlSort "input.txt" "output.txt" nil "!,U")
```

Results 1

```
1!2!3!4!5  
2!2!3!4!5  
2!3!4!5!6  
3!4!5!6!7  
4!5!6!7!8  
5!1!7!8!9  
5!6!7!8!9
```

Example 2

```
(axlSort "input.txt" "output.txt" "2 A I, 1 D I" "!"")
```

Results 2

```
5!1!7!8!9  
2!2!3!4!5  
1!2!3!4!5  
2!3!4!5!6  
2!3!4!5!6  
3!4!5!6!7  
4!5!6!7!8  
5!6!7!8!9
```

axlstrcmpAlpNum

```
axlstrcmpAlpNum(  
    t_str1  
    t_str2  
)  
⇒ t/nil
```

Description

Provides an alpha-numeric sort similar to `alphlessp` with one important distinction. If both strings end in the number, the number portion is separated and the two stripped strings are first compared. If they are equal, then the number sections are compared as numbers, rather than strings.

<code>alphlessp sort</code>	<code>U1 U10 U2</code>
<code>axlstrcmpAlpNum sort</code>	<code>U1 U2 U10</code>

Arguments

<code>t_str1</code>	A string
<code>t_str2</code>	A string

Value Returned

<code>0</code>	The two strings are equal.
<code>+num</code>	If <code>t_str1</code> is greater than <code>t_str2</code> (1 goes after 2)
<code>nil</code>	If <code>t_str1</code> is less than <code>t_str2</code> (1 goes before 2)

Example

```
l = '("U5" "U10" "U1" "U5" "U2")  
sort(l 'axlstrcmpAlpNum)  
====> ("U1" "U2" "U5" "U5" "U10")
```

axlStringCSVParse

```
axlStringCSVParse(  
    t_string  
    [g_stripWhite]  
) -> lt_string/nil
```

Description

Parses a comma delimited line (typical from Excel). This differs from the Skill prehistorian function in several areas which make it compatible with Excel csv file format:

- `parseString` ignores two adjacent commas.
- if a comma is contained within a cell, Excel quotes the cell. `parseString` treats this as two cells.
- Correctly processes double quotes in a cell.

Arguments

t_string A csv string

g_stripWhite Option to strip leading and trailing white space from each output string. Default is to leave whitespace.

Value Returned

lt_string list of strings parsed based on comma separator.

nil error (unlikely to happen)

See Also

`parseString` in *Cadence SKILL Language Reference*

Example

- white space strip example

```
ret = axlStringCSVParse(" a ,b" t)  
-> ( "a" "b")
```

Allegro SKILL Reference

Utility Functions

■ properly parse a csv file

```
ret = axlStringCSVParse("a,,c,\\"d,e\\\"")  
-> ("a" "" "c" "d,e")
```

axlStringRemoveSpaces

```
axlStringRemoveSpaces(  
    t_string  
) -> t_modString/nil  
  
axlStringRemoveSpaces(  
    lt_string  
) -> lt_modString/nil
```

Description

This will strip leading or trailing whitespace from a string (standard C `isspace()` macro). Has two modes:

- one string
- list of strings

In list of strings, items in list that are not a string are filtered out of the return.

Argument

t_string A string.

lt_string list of strings

Value Returned

t_modString Modified string

lt_modString Modified strings

nil Not a string

See Also

[axlCheckString](#)

Example

```
ret = axlStringRemoveSpaces(" a ")  
ret = axlStringRemoveSpaces(' (" a " " b ")')
```

axlVersion

```
axlVersion(  
    s_option  
)  
⇒ g_value/nil
```

Description

Returns Allegro PCB Editor or OS dependent data.

Argument

s_option SKILL symbol for the environment variable name.

Value Returned

Return depends upon option given.

Option	Value	Returns
none	<i>ls_values</i>	List of available options.
version	<i>f_value</i>	Allegro PCB Editor program version, for example, 15.7.
tVersion	<i>t_value</i>	Allegro PCB Editor program version as a string, for example, 16.3.
fullVersion	<i>t_value</i>	Allegro PCB Editor program version and patch as a string (for example, 15.7 s01).
buildDate	<i>t_value</i>	Date program was built at Cadence (month/day/year),for example, 7/19/2006.

Allegro SKILL Reference

Utility Functions

Option	Value	Returns
release	<i>t_value</i>	Allegro PCB Editor release value. Consists of a prefix and a number (< <i>p</i> >< <i>nn</i> >), where prefixes are as shown: A - Alpha B - Beta P - Production S - Patch For example, S23 indicates the 23 rd patch release.
internalVersion	<i>t_value</i>	Internal program version, for example, v15-1-25A.
programName	<i>t_value</i>	Executable being run, for example, allegro.
displayName	<i>t_value</i>	Short display name of program (may contain spaces.) Certain programs may change this during run-time depending on the license level. This may be the same or shorter than the formal name. It may change from release to release. <i>Example:</i> "Allegro PCB Design XL"
formalName	<i>t_value</i>	Long Display name of program (may contain spaces). This is the full formal name of program and may change during run-time since it depends upon the license level. The name can be the same or longer than <i>displayName</i> , and may change from release to release.
isWindows	<i>g_value</i>	<i>t</i> if Windows operating system. <i>nil</i> if UNIX operating system.
isSQ	<i>g_value</i>	<i>t</i> if Allegro PCB SI (SpecctraQuest base product), <i>nil</i> otherwise.

Allegro SKILL Reference

Utility Functions

Option	Value	Returns
isPI	<i>g_value</i>	t if Allegro PCB PI Option XL (SpecctraQuest Power Integrity option), nil otherwise.
isPDN	<i>g_value</i>	t if PDN analysis option, nil otherwise
isAPDSi	<i>g_value</i>	t if Allegro Package Designer SI L, nil otherwise
isAPDSiL	<i>g_value</i>	t if Allegro Package Designer SI L, nil otherwise
isAllegroExpert	<i>g_value</i>	t if Allegro PCB Design XL, nil otherwise.
isAllegroDesigner	<i>g_value</i>	t if Allegro PCB Performance L or Allegro PCB Design L product, nil otherwise.
isAllegroOrcad	<i>g_value</i>	t if Allegro OrCAD product, nil otherwise.
isAllegroPCB	<i>g_value</i>	t if Allegro PCB product, nil otherwise.
isAPD	<i>g_value</i>	t if Allegro Package Designer product, nil otherwise.
isAPDL	<i>g_value</i>	t if Allegro Package Designer L, nil otherwise
isAPDXL	<i>g_value</i>	t if Allegro Package Designer XL, nil otherwise
isAPDLegacy	<i>g_value</i>	t if Allegro Package Designer VT2300, nil otherwise
isChipIOPlanner	<i>g_value</i>	t if any ChipIOPlanner product, nil otherwise
isICP	<i>g_value</i>	t if any ICP based product, nil otherwise
isSIP	<i>g_value</i>	t if any SIP product, nil otherwise
isSIPDigital	<i>g_value</i>	t if any SIP Digital product, nil otherwise
isSIPDigArch_L	<i>g_value</i>	t if running the SIP Digital Architect L product, nil otherwise
isSIPDigArch_GXL	<i>g_value</i>	t if running the SIP Digital Architect GXL product , nil otherwise

Allegro SKILL Reference

Utility Functions

Option	Value	Returns
isSIPDigSI_XL	<i>g_value</i>	t if running the SIP Digital SI XL product, nil otherwise
isSIPDigLay_GXL	<i>g_value</i>	t if running the SIP Digital Layout GXL product, nil otherwise
isSIPRF	<i>g_value</i>	t if running any SIP RF product, nil otherwise
isSIPRFArch_L	<i>g_value</i>	t if running the SIP RF Architect L product, nil otherwise
isSIPRFLay_GXL	<i>g_value</i>	t if running the SIP RF Layout GXL product, nil otherwise
isSigxp	<i>g_value</i>	t if any version of SigXP, nil otherwise.
isSxExpert	<i>g_value</i>	t if SigXP Expert product, nil otherwise.
isSxExplorer	<i>g_value</i>	t if SigXP Explorer product, nil otherwise.
isEmbedded	<i>g_value</i>	t if Embedded placement allowed.
isBackDrill	<i>g_value</i>	t if Backdrill functionality allowed.

Examples

```
axlVersion()
```

axlVersionIdGet

```
axlVersionIdGet(  
    )  
    ⇒ x_time
```

Description

Returns an id stamp based upon computer time.

Argument

none

Value Returned

<i>x_time</i>	Returns an id stamp based on computer time.
---------------	---

axlVersionIdPrint

```
axlVersionIdPrintd(  
    x_time/t_time  
)  
⇒ t_printTime/nil
```

Description

Prints version_id.

VERSION_ID is stored as a property on the database root and on the symbol definitions as shown:

```
axlDBGetDesign () ->prop->VERSION_ID
```

Use to determine if a symbol should be refreshed. VERSION_ID is updated every time the database is saved, except if done as part of an uprev.

Argument

<i>x_time/t_time</i>	VERSION_ID obtained from the database property or returned from axlVersionIdGet ().
----------------------	---

Value Returned

<i>t_printTime</i>	Printable string in standard Allegro PCB Editor date/time format.
nil	Failed to print VERSION_ID due to incorrect argument.

Example

```
axlVersionIdPrint(axlDBGetDesign () ->prop->VERSION_ID  
-> "Mon Dec 16 12:45:16 2004"
```

Allegro SKILL Reference

Utility Functions

Math Utility Functions

Overview

This chapter describes the AXL-SKILL Math Utility functions.

axlDegToRad

```
axlDegToRad(  
    n_angle  
) => f_angle
```

Description

Converts an angle in degrees to radians.

Arguments

n_angle Angle in degrees

Value Returned

f_angle Angle in radians

See Also

[axlRadToDeg](#), [axlMathConstants](#)

Example

```
axlDegToRad(45.0)  
=> 0.7853982
```

axlDistance

```
axlDistance(  
    l_point1  
    l_point2  
)  
⇒ f_distance
```

Description

Returns the distance between two points. You may use floating point.

Arguments

l_point A point.

ll_line Two points at the ends of a line.

Value Returned

f_distance Distance between two points in floating point form.

Example

```
axlDistance(10:20 5:20) = 5.0
```

axlGeo2Str

```
axlGeo2Str(  
    f_dbrep/point  
) -> t_result/nil
```

Description

When converting floating point numbers to strings you may find the number printed is slightly differently than the value Allegro reports. This difference is due to how floating point numbers are represented in the computer. The following article is an excellent paper on the subject: *What Every Computer Scientist Should Know About Floating-Point Arithmetic* by David Goldberg.

http://docs.sun.com/source/806-3568/ncg_goldberg.html

This article also explains why sometimes the comparison of two floating numbers that appear the same results in a non-equal result. The results only differ from printf when a "5" exists at the location one place more than the database accuracy. The behavior is as follows for rounding:

- if digit at db accuracy is odd and then 5 round up
- if digit at db accuracy is even and then 5 round down

See examples below. This supports two modes, a single floating point number and a point (a list of two floating point numbers).

Arguments

dbrep a floating point number

point a xy point

Value Returned

Returns a string with Allegro rounding. If a point is passed then the return format is: "<x><xy>"

nil : not a legal argument

See Also

[axlGeoEqual](#)

Examples

Assume database is two decimal places

```
procedure( testit( f )
          printf("printf=%.2f\taxlGeo2Str=%s \toriginal value %.3f\n"
                 f axlGeo2Str(f) f)
        )
        testit(1.115)
        testit(1.125)
        testit(-1.115)
        testit(-1.125)

Results:
printf=1.11      axlGeo2Str=1.12          original value 1.115
printf=1.12      axlGeo2Str=1.12          original value 1.125
printf=-1.11     axlGeo2Str=-1.12         original value -1.115
printf=-1.12     axlGeo2Str=-1.12         original value -1.125
```

Using a point

axlGeo2Str(100.124:123.345)



axlGeoArcCenterAngle

```
axlGeoArcCenterAngle(  
    l_startPoint  
    l_endPoint  
    f_angle  
    [g_clockwise]  
)  
⇒ l_center/nil
```

Description

Calculates the center of an arc given the angle between its endpoints. Uses the arguments depending on *g_clockwise* as shown in Figure 25-1 on page 1223.

Figure 25-1 Center of Arc Calculation



Arguments

<i>l_startPoint</i>	Start point of the arc
<i>l_endPoint</i>	End point of the arc
<i>f_angle</i>	Included angle of the arc
<i>g_clockwise</i>	Rotational sense of the arc: <i>t</i> is clockwise. <i>nil</i> is counterclockwise (the default).

Value Returned


<i>l_center</i>	Center of the arc as a list: (<i>X Y</i>).
<i>nil</i>	Cannot calculate the center from the given arguments.

Example

```
print axlGeoArcCenterAngle( 7500:5600 8000:4700 68.5 t)
mypath = axlPathStart(list( 7500:5600))
    axlPathArcAngle(mypath, 0., 8000:4700, t, 68.5)
    axlDBCreatePath( mypath, "etch/bottom")
⇒ (7089.086 4782.826)
```

Prints the center for the clockwise arc going through the points (7500:5600) and (8000:4700) using `axlGetArcCenterAngle`, then adds the arc through those points using `axlPathArcAngle`, and compares their centers.

The arc is shown in the following figure.



Allegro SKILL Reference

Math Utility Functions


Do *Show Element* on the arc to show its center coordinate. The arc lists: "center-xy (7089, 4783)" which agrees with the (7089.086 4782.826) printed by ax1GeoArcCenterRadius.

axlGeoArcCenterRadius

```
axlGeoArcCenterRadius(
    l_startPoint
    l_endPoint
    f_radius
    [g_clockwise]
    [g_bigArc]
)
⇒ l_center/nil
```

Description

Calculates center of an arc given its radius. Calculates *l_center* either for one arc or another depending on the arguments, as shown.



Arguments

<i>l_startPoint</i>	Start point of the arc
<i>l_endPoint</i>	End point of the arc
<i>f_radius</i>	Radius of the arc
<i>g_clockwise</i>	Rotational sense of the arc: <i>t</i> is clockwise. <i>nil</i> (default) is counterclockwise.

Allegro SKILL Reference

Math Utility Functions

g_bigArc Flag telling whether the arc extends as the larger or the smaller of the two arcs possible between the start and endpoints.

Value Returned

l_center Center of the arc as a list: (*X Y*).

nil Cannot calculate the center from the given arguments.

Example

```
print axlGeoArcCenterRadius( 7500:5600 8000:4700 1000)
⇒ (8499.434 5566.352)

mypath = axlPathStart(list( 7500:5600))
axlPathArcRadius(mypath, 0., 8000:4700, t, nil, 1000)
axlDBCreatePath( mypath, "etch/bottom")

print axlGeoArcCenterRadius( 7500:5600 8000:4700 1000 t)
⇒ (7000.566 4733.648)


mypath = axlPathStart(list( 7500:5600))
axlPathArcRadius(mypath, 0., 8000:4700, nil, nil, 1000)
axlDBCreatePath( mypath, "etch/top")
```

Prints the two possible centers for the arcs going through the points (7500:5600) and (8000:4700), then adds arcs through those points using `axlPathArcRadius`, and compares the centers.

Allegro SKILL Reference

Math Utility Functions

The arcs are shown in the following figure.



Do *Show Element* on each arc to show its center coordinate. The solid arc on the left lists: "center-xy (8499, 5566)" which agrees with the (8499.434 5566.352) printed by axlGeoArcCenterRadius. The dotted arc on the right lists: "center-xy (7001, 4734)", which agrees within rounding with (7000.566 4733.648) printed for the other arc.

Arguments 3

```
ax1MKSConvert(  
    nil  
    [t_outUnits]  
)  
⇒ t/nil
```

Pre-registers *t_outUnits*, the input units string, so that subsequent calls to ax1MKSConvert need not specify units.

t_outUnits String giving the units to convert to for subsequent calls to ax1MKSConvert. If there is no active drawing, function fails with this combination of arguments.

Value Returned 3

t	Conversion string acceptable.
nil	Conversion string not acceptable.

Example 3

See Example 4 below.

Arguments 4

```
ax1MKSConvert(  
    n_input  
)  
⇒ f_output/nil
```

Use this combination of arguments only after a call to ax1MKSConvert as in Arguments 3. Converts the number *n_input* specifying a value using the *t_outUnits* supplied by a previous call to ax1MKSConvert, and returns as *f_output*.

n_input Number giving the input value to convert

Value Returned 4

f_output Converted value of *n_input*.


Allegro SKILL Reference

Math Utility Functions

Example 4

```
(axlMKSCConvert .5) -> nil ;;error,if no preregistered units  
(axlMKSCConvert nil "MILS") -> t  
(axlMKSCConvert .5) -> 0.0005 ; remembers MILS
```

The following **Show Element** form shows the net with MYPROP attached:



axlGeoEqual

```
axlGeoEqual (
  f_one
  f_two
)
⇒ t/nil
```

Description

Performs an equal comparison between two floating point numbers and determines if they are equal within plus or minus the current database accuracy.

Useful for comparing floating point numbers converted from strings (example - using `atof` function) with those obtained from an AXL database id. Since the conversion of these numbers takes different paths (string to float versus integer to float, in the case of the database) you can have different numbers.

Note: To understand the basis of why a simple equal (`==`) comparison cannot always be used with floating point numbers see David Goldberg's paper on "[What Every Computer Scientist Should Know About Floating-Point Arithmetic](#)."

Arguments

Two floating point numbers.

Value Returned

t	Given numbers are equal within the current database accuracy.
nil	Given numbers are not equal within the current database accuracy.

Example

```
axlGeoEqual (2.0 2.0)
```

See Also

[axlGeo2Str](#), [axlGeoPointsEqual](#)

axlGeoRotatePt

```
axlGeoRotatePt(  
    f_angle  
    l_xy  
    l_origin/nil  
    [mirror]  
) -> l_xyResult/nil
```

Description

Rotates *xy* about an origin by angle. Optionally applies mirror on the *x* axis.

Arguments

<i>f_angle</i>	Angle 0 to 360 degrees (support for 1/1000 of a degree); rotation is counter-clockwise for positive numbers.
<i>l_xy</i>	<i>xy</i> point to rotate in user units.
<i>l_origin</i>	Origin to rotate about; if <i>nil</i> uses (0, 0) mirror: optional mirror flag (<i>t</i> perform mirror).

Value Returned

<i>l_xyResult</i>	Rotated result.
<i>nil</i>	Error in arguments or rotation results in return being outside of the database extents.

Examples

Rotate:

```
axlGeoRotatePt(45.0 10:200 5:2) -> (-131.4716 145.5427)
```

Rotate and mirror:

```
axlGeoRotatePt(45.0 10:200 5:2 t) -> (-138.5427 138.4716)
```

Rotate about 0,0:

```
axlGeoRotatePt(90.0, 100:0 nil) -> (0.0 100.0)
```

axlGeoPointsEqual

```
axlGeoPointsEqual(  
    l_point1  
    l_point2  
) -> t/nil
```

Description

This performs an equal comparison between two xy points and determines if they are equal within db accuracy.

Arguments

two xy points

Value Returned

- `t` if they are equal within current database accuracy.
- `nil` not equal

See Also

[axlGeoEqual](#)

Examples

```
pt1 = '(2.0 1.1)  
pt2 = '(2.0 1.1)  
axlGeoPointsEqual(pt1 pt2)
```

axllsBetween

```
axllsPointInsideBox (
  l_testPoint
  l_pt1, l_pt2
) -> t/nil
```

Description

Used to check if a given point lies between two specified points. Returns *t* if the point is in between the two points or on one of the points.

Arguments

<i>l_testPoint</i>	test point
<i>l_pt1, l_pt2</i>	two test points

Value Returned

t if between or on, else *nil*

See Also

[axllsPointInsideBox](#)

axlIsPointInsideBox

```
axlIsPointInsideBox(  
    l_point  
    l_box  
)  
⇒ t/nil
```

Description

Returns *t* if a point is inside or on the edge of a box. Also see [axlGeoPointInShape](#) on page 1272 for *dbid*-based tests. You may use floating point.

Arguments

l_point A point.

l_box A bounding box.

Value Returned

t Point is inside or on edge of box

nil Point is outside of box.

Example

```
axlIsPointInsideBox(10:20 list(5:20 15:30)) = t  
axlIsPointInsideBox(0:20 list(5:20 15:30)) = nil  
axlIsPointInsideBox(15:20 list(5:20 15:30)) = t
```

axlIsPointOnLine

```
axlIsPointOnLine(  
    l_point  
    ll_line  
)  
⇒ t/nil
```

Description

Returns `t` if point is on a given line or `nil` if not on the line.

Arguments

`l_point` A point.

`ll_line` Two end points.

Value Returned

`t` Point is on the specified line.

`nil` Point is not on the specified line.

Example

```
axlIsPointOnLine(10:20 list(5:20 15:30)) = nil  
axlIsPointOnLine(10:30 list(5:20 15:30)) = t
```

See Also

[axlIsBetween](#)

axlLineSlope

```
axlLineSlope(  
    ll_line  
)  
⇒ f_slope
```

Description

Returns the slope of a line. You may use floating point.

Arguments

ll_line Two end points.

Value Returned

f_slope Slope of the line.

nil Line is vertical.

Example

```
axlLineSlope(list(5.0:20.10 15.4:30.2)) = 0.9711538  
axlLineSlope(list(5:20 5:40)) = nil
```

axlLineXLine

```
axlLineXLine (
    l_seg1
    l_seg2
)
⇒ t
```

Description

This function is no longer required, but is kept for backward compatibility.

Arguments

None.

Value Returned

t	Returns t always.
---	-------------------

axlMathConstants

Provides predefined set of high accuracy math constants. They are:

- axlPI – PI
- axlPI_2 – PI/2.0
- axlPI_4 – PI/4.0
- axlSQRT2 – sqrt(2)
- axlSQRT1_2 – 1/sqrt(2)
- axlEpsilonFloat – epsilon for floating point numbers (32 bit)
- axlEpsilonDouble – epsilon for doubles (64 bit)
- axlDegPerRad – Degrees per radian
- axlRadPerDeg – Radians per degree

axlRad0, axlRad45, axlRad90, axlRad135, axlRad180, axlRad225, axlRad270, axlRad315, axlRad360 – radians values for popular degrees values

Note: Skill, by default, limits the number of decimal places printed but these constants are still stored and used at the full precision. To see the full precision of the constant you can do:

```
sstatus(fullPrecision t)
```

or

```
printf("%5.18\n" axlPI)
```

axlMidPointArc

```
axlMidPointArc(  
    ll_endPoints  
    l_center  
    f_radius  
    g_clockwise  
) -> l_midPoint
```

Description

Returns mid-point on a arc. Note mid-point may not be on a database coordinate. All parameters may be obtained from a arc dbid.

Arguments

<i>ll_line</i>	arc end points
<i>l_center</i>	center of arc
<i>f_radius</i>	arc radius
<i>g_clockwise</i>	Is arc in clockwise (<i>t</i>) or counter clockwise direction (<i>nil</i>)

Value Returned

<i>l_midPoint</i>	mid-point of line
<i>nil</i>	error in arguments

See Also

[axlMidPointLine](#)

Example

■ try clockwise

```
axlMidPointArc(list(20:0 0:20) 0:0 20 t) = (-14.14214 -14.14214)
```

■ try counter-clockwise

```
axlMidPointArc(list(20:0 0:20) 0:0 20 nil) = (14.14214 14.14214)
```

axlMidPointLine

```
axlMidPointLine(  
    ll_line  
) -> l_midPoint
```

Description

Returns mid-point of line. Note mid-point might not be a database coordinate.

Arguments

<i>ll_line</i>	Two end points
----------------	----------------

Value Returned

<i>l_midPoint</i>	mid-point of line
-------------------	-------------------

<i>nil</i>	error in arguments
------------	--------------------

See Also

[axlMidPointArc](#)

Example

```
axlMidPointLine(list(5:20 15:30)) = (10.0 25.0)
```

axlMPythag

```
axlMPythag(  
    l_pt1  
    l_pt2  
) -> f_distance/nil
```

Description

Calculates distance between two points using pythagoras. This is faster then building this code in Skill.

The l_ptN is an x:y coordinate.

Arguments

l_pt1, l_pt2 Two xy points.

Value Returned

f_distance Distance between points.

nil Arguments were not xy points.

See Also

[axlMXYAdd](#)

Example

```
axlMPythag(1263.0:1062.0 1338.0:1137.0) -> 106.066
```

axlMUniVector

```
axlMUniVector(  
    l_pt1  
    l_pt2  
    [f_length]  
) -> l_uniPt1
```

Description

This calculates a unit-vector. A unit vector allows one to calculate points additional points along that line.

It has two modes of operation:

- Without a length returns a unit vector to use in other operations like `axlMXYMult`. Use this mode if you need to calculate several points from the same unit vector.
- With a length, calculates a new `xy` location `f_length` from `l_pt1` along the vector specified by `pt1` and `pt2`.

This provides optimized solution over the traditional trigonometric approach.

Arguments

`l_pt1, l_pt2:` 2 `xy` points

`f_length:` optional length to project

Value Returned

Returns a unit-vector, `xy` point

`nil`: arguments were not `xy` points

Examples

Found a point 5 units along a line from 1263.0:1062.0 to 1338.0:1137.0

```
origin = 1263.0:1062.0  
uniVec = axlMUniVector(origin 1338.0:1137.0)  
res = axlMXYMult(uniVec, 5.0 origin)
```

Allegro SKILL Reference

Math Utility Functions

Same as example 1 except have `uni_vec` do all the work

```
res = axlMUniVector(origin 1338.0:1137.0 5.0)
```

axlMXYAdd

```
axlMXYAdd(  
    l_pt1  
    l_pt2  
) -> l_pt/nil
```

Description

This does a `l_pt1 + l_pt2` and returns the result.

The `l_ptN` is an x:y coordinate.

Arguments

`l_pt1, l_pt2` Two xy points.

Value Returned

`l_pt` Returns coordinate that is result of addition.

`nil` Arguments are not coordinates.

See Also

[axlMXYSub](#)

Example

```
axlMXYAdd(1263.0:1063.0 1338.0:1137.0) -> (2601.0 2200.0)
```

axIMXYMult

```
axIMXYMult(  
    l_uniVec  
    f_factor  
    [l_origin]  
) -> l_pt/nil
```

Description

This is a convenience function that does a `l_pt.x * f_factor` and `lpt.y * factor` and returns the result. If provided an origin, it adds the origin.

```
(l_uniVec * f_factor) + l_origin
```

It is normally used in conjunction with `axIMUniVector` to project a point along a vector.

Arguments

<code>l_uniVec</code> :	xy point
<code>f_factor</code> :	multiplication factor
<code>l_origin</code> :	additive point

Value Returned

<code>l_pt</code> :	Returns resultant coordinate
<code>nil</code> :	Arguments are not coordinates

Examples

```
axIMXYMult(1263.0:1063.0 2.0) -> (2526.0 2126.0)
```

See Also

[axIMUniVector](#)

axlMXYSub

```
axlMXYSub (
  l_pt1
  l_pt2
) -> l_pt/nil
```

Description

This does a `l_pt1 - l_pt2` and returns the result.

The `l_ptN` is an x:y coordinate.

Arguments

`l_pt1, l_pt2` Two xy points.

Value Returned

`l_pt` Returns coordinate that is result of subtraction.

`nil` Arguments are not coordinates.

See Also

[axlMXYAdd](#)

Example

```
axlMXYSub ('(1263.0 1063.0) '(1338.0 1137.0)) -> (-75.0 -74.0)
```

axlRadToDeg

```
axlRadToDeg(  
    n_angle  
) => f_angle
```

Description

Converts an angle in radians to degrees.

Arguments

n_angle The angle in radians

Value Returned

f_angle The angle in degrees

See Also

[axlDegToRad](#), [axlMathConstants](#)

Example

```
axlRadToDeg(0.7853982)  
=> 45.0
```

axl.ol.ol2

```
axl.ol.ol2(  
    l_seg1  
    l_seg2  
)  
⇒ l_result
```

Description

Finds the intersection point of two lines. If the lines intersect, returns the intersection point with a distance of 0. If the lines do not intersect, the distance is not zero and the function returns t.

Arguments

<i>l_seg1</i>	1st line segment (list <i>x1:y1 x2:y2</i>)
<i>l_seg2</i>	2nd line segment (list <i>x1:y1 x2:y2</i>)

Value Returned

<i>nil</i>	Error due to incorrect argument.
(<i>car l_result</i>)	Intersect or nearest point on seg1
(<i>cadr l_result</i>)	Intersect or nearest point on seg2
(<i>caddr l_result</i>)	Distance between the two intersect points.

Examples

Data for examples

```
a=list(1:5 5:5)
b=list(2:5 4:2)
c=list(0:0 5:0)
d=list(4:5 7:5)
```

Example 1

```
axl.ol.ol2(a b)
⇒((2.0 5.0) (2.0 5.0) 0.0)
```

Intersects line, returns intersection point, note distance of 0.

Example 2

```
axl.ol.ol2(a c)
⇒((3.0 5.0) (3.0 0.0) 5.0)
```

Lines don't intersect, returns closest point on each line and distance.

Example 3

```
axl.ol.ol2(a d)
⇒((4.5 5.0) (4.5 5.0) 0.0)
```

Lines overlap, distance of 0 and selects mid-point of the overlap.

bBoxAdd

```
bBoxAdd(  
    l_bBox1  
    l_bBox2  
) -> l_bBox_result
```

Description

Adds two bounding boxes together and returns the result.

Arguments

2 bBox values

Value Returned

Resulting bounding box.

Example

Expand bounding box by 100.

```
orig = '((200 100) (400 500))  
res = bBoxAdd(orig '((-100 -100) (100 100)))  
-> ((100 0) (500 600))
```

Example 2

```
res = bBoxAdd('((200 100) (400 500)) '((0 0) (200 100)))  
-> ((200 100) (600 600))
```

Allegro SKILL Reference

Math Utility Functions

Database Miscellaneous Functions

Overview

This chapter describes the AXL-SKILL functions that do not fit into other sections.

axlAirGap

```
axlAirGap(  
    o_item1DBID  
    o_item2DBID  
    [t_layer]/nil  
    [s_mode]  
)  
==> l_airGapData/nil/(s_error l_airGapData/l_errorData)
```

Description

Finds the air gap and location between two given items. Gap is the same as reported by the `show measure` command. Any geometric objects; logical, group or symbols not supported (same as `show measure`). Unfilled shapes are currently treated as filled but this may change in the future.

You only need to provide a layer option when measuring between to pin or vias (also called pad comparison). When doing pad comparison without the layer, we use the current active layer. The layer syntax should either be "ETCH/<subclass>" or "<subclass>".

For spacing to the special via or pin subclasses below, either provide "PIN" or "VIA CLASS" as the class name.

- SOLDERMASK_TOP
- SOLDERMASK_BOTTOM
- PASTEMASK_TOP
- PASTEMASK_BOTTOM
- FILMMASKTOP
- FILMMASKBOTTOM

Both of these class names work equally well with pins and vias. If you want the soldermask top spacing between a pin and via, then use "PIN/SOLDERMASK_TOP".

Output data appears in one of the following formats depending on the `s_mode` option:

- Default is `s_mode` (`s_mode==nil`) returns the `l_airGapData` or a `nil` if there is an error. If `s_mode` is `t` then data is returned as `(s_error l_airGapData)` where `s_error` is one of the following:

`t` Success (`t (l_airGapData)`)


Allegro SKILL Reference

Database Miscellaneous Functions

'NOMATCH	No subclass matches between pin or via and object. Returns object's layer. (<code>(NOMATCH (t_layer))</code>)
'RANGE	No subclass match between two etch elements (one or both must be a pad element (pin or via). If common layers exist, Allegro PCB Editor returns the top and bottom layer where matches exist otherwise returns nil: (<code>(ETCH (t_topMatch t_bottomMatch))</code>)
'INVALID	One or both elements are invalid. Data return format: (<code>(INVALID nil)</code>). For legacy purposes, this interface does not return an air gap if the two objects do not share the same layer. If you want the air gap in any layer, use <code>s_mode = 'anyLayer'</code> .
	Enhanced out, <code>s_mode = 'enhanced'</code> offers anyLayer air gap and returns a disembodied property list of:
	airGap = <spacing between objects> (floating point)
	location1 = xy location first item where air gap measured
	location2 = xy location of second item where air gap measured
	layer1 = layer (class subclass) of where first object measured (string)
	layer2 = layer (class subclass) of where second object measured (string)
	isEtch = both objects of type ETCH (boolean)
	For distance between two pads, return gap based upon the active etch subclass, if <code>t_layer</code> is nil. Otherwise use <code>t_layer</code> to determine gap. If one or both pads do not exist on that layer:
	<ul style="list-style-type: none">■ in anyLayer mode we will return the distance between the closest pad layers.■ it is an error in <code>s_mode=nil</code> or <code>s_mode=t</code>
	For distance between a pad and non-pad element; use the layer of the pad that you want the measurement if layer is not provided we use the active layer or the top layer of the padstack.

If performance is a concern, use `anyLayer` mode over enhanced output.

The distance if objects do not share the same layer do NOT take into account board thickness.



PROGRAMMING TIP: For legacy purposes, this interface does not return an air gap if the two objects do not share the same layer. If you want the air gap any layer use `s_mode = 'anyLayer` or `s_mode = 'enhanced`.

Arguments

<code>o_item1DBID</code>	dbid of the first item.
<code>o_item2DBID</code>	dbid of the second item.
<code>t_layer</code>	Optional layer used to resolve gap comparison between two pin or via elements. If in 'anyLayer or 'enhanced mode this targets a particular layer for comparison. It is most useful in measuring mask layer gaps.
<code>s_mode</code>	Return additional info to clarify error. This may be: <ul style="list-style-type: none">■ <code>nil</code>: Default mode (objects must be on same layer)■ <code>t: ("full mode")</code> return <code>l_airGapData</code> or if not share see above (objects must be on same layer)■ <code>anyLayer</code>: support any layer measure return just gap■ <code>enhanced</code>: return disembodied property list of additional air gap criteria (see above)

Value Returned

<code>l_airGapData</code>	List containing the following items: <code>(l_airGapPt1 l_airGapPt2 f_airGapDistance)</code>
---------------------------	---

where:

Allegro SKILL Reference

Database Miscellaneous Functions

<i>l_airGapPt1</i>	(X,Y) point on the first item where the air gap is measured.
<i>l_airGapPt2</i>	(X,Y) point on the second item where the air gap is measured.
<i>f_airGapDistance</i>	Distance between the two points.
<i>nil</i>	Input data error; element 1 and 2 are the same or no air gap can be computed between the two items. If <i>t_layer</i> is used but does not specify an etch layer.
<i>s_error</i>	See error symbols listed above.

Examples

Basic input:

```
axlAirGap(e11 e12)
-> ((1337.5 1100.0) (1362.5 1100.0) 25.0)
```

Basic input layer:

```
axlAirGap(e11 e12 "TOP")
-> ((1337.5 1100.0) (1362.5 1100.0) 25.0)
```

Full output success:

```
axlAirGap(e11 e12 nil t)
-> (t ((1337.5 1100.0) (1362.5 1100.0) 25.0))
```

Any layer airgap:

```
q = axlAirGap(e11 e12 nil 'anyLayer)
```

Enhanced output:

```
q = axlAirGap(e11 e12 nil 'enhanced)
```

Obtain soldermask spacing

```
axlAirGap(vial pin2 ""PIN/SOLDERMASK_TOP" )
-> (((1337.5 1100.0) (1362.5 1100.0) 40.0))
```

Full output failure:

```
axlAirGap(e13 e12 nil t)
-> (RANGE ("TOP" "GND"))
```

axlBackDrill

```
axlBackDrill(  
    o_dbid  
    s_layer  
) -> l_result/nil
```

Description

pin/via backdrill analysis

Does a backdrill analysis on a given pin or a via (*o_dbid*) where the backdrill should start on top or bottom (*s_layer*).

Note: This is a tier limited feature and is therefore, not available with all versions of the tool.

This analysis is based upon the current backdrill parameter settings.

(see backdrill setup command).

Result of analysis is a disembodied property list containing:

Symbol	Type	Data
status	symbol	result of analysis (see below)
toLayer	number	xsection layer number for end drill
remainStub	float	lengthStub - depthDrill
lengthStub	float	depth (user units) of desired drill
depthDrill	float	depth (user units) of actual drill
maxStub	float	max stub from net's BACKDRILL_MAX_PTH_STUB property or 0 if no prop
minPth	float	pin/via or symbol's BACKDRILL_MIN_PIN_PTH property value or 0 if no prop

Allegro SKILL Reference

Database Miscellaneous Functions

Status results

Skip Drill Items due to:

net	net does not have the BACKDRILL_MAX_PTH_STUB property or item not on a net
stubOk	stub is ok to skip (drill_depth < maxStub)
noStub	no stub on item
skipThisSide	drilling not permitted on this side of design
pad	skip because this object type (pin or via) should not be drilled
holeType	padstack has no hole, non-plated or a slot

Exclude Drill Items

via	via has BACKDRILL_EXCLUDE property
pin	pin has BACKDRILL_EXCLUDE property
symbol	symbol has BACKDRILL_EXCLUDE property
unconnected	pin/via has no connections
testVia	via is a test via
testPin	pin is a test pin
excludePinSide	exclude pin side due to BACKDRILL_PRESSFIT_CONNECTOR on symbol

Errors

Argument	Valid Values
errorStubLen	Drill depth exceeds BACKDRILL_MAX_PTH_STUB value
errorPinPth	(boardThickness - drillDepth) of pin is less than the property value BACKDRILL_MIN_PIN_PTH for pressfit connectors.
unknown	unknown problem (atypical)

Arguments

Argument	Valid Values
----------	--------------

o_dbid	■ pin ■ via
s_layer	■ top ■ bottom

Value Returned

nil	Indicates an error, generated due to one of the following reasons
	■ This feature is not available in this editor
	■ argument specified is not a pin or a via
l_result	a disembody property list see above for description

Example

```
result = axlBackDrill(pin, 'bottom)
```

axlDBGetLength

```
axlDBGetLength(  
    o_dbid  
)  
==> f_etchlength/nil
```

Description

Calculates the length of the given object which may be a NET, CLINE, SEGMENT, or RATSNEST. If RATSNEST returns the Manhattan length. If a net is partially routed, includes sum of all ratsnest Manhattan lengths.

Currently does not include VIA-Z or PIN_DELAY in its calculation.

Arguments

o_dbid *dbid*

Value Returned

nil Not a legal object

f_etchLength Length of object

See Also

[axlDBGetManhattan](#), [axlDBPinPairLength](#)

Example

```
Skill> p = ashOne()  
Skill> axlDBGetLength(p)  
-> 2676.777
```

ax1DBGetManhattan

```
ax1DBGetManhattan(  
    o_dbid_net  
)  
⇒ l_result/nil
```

Description

Given a net, calculates an etch, path, and Manhattan length. The result is the same as that used by list element.

- Etch - The current length of etch. The length is 0 when there is no etch.
- Path - The etch plus remaining length. When the net is fully connected, there is no remaining, and path is equal to etch.
- Manhattan - The estimated routing length.

Note: Path is equal to Manhattan when the net has no etch.

Arguments

o_dbid Net *dbid*.

Value Returned

l_result (*etchLength path manhattan*)

nil Not a net *dbid*.
 Net is out of date.
 No ratsnest.

See Also

[ax1DBGetLength](#)

Example

```
p = ashOne()  
ax1DBGetManhattan(p)  
(2676.777 3300.0)
```

axIDBGetSymbolBodyExtent

```
axlDBGetSymbolBodyExtent( o_dbid ) -> bBox/nil
```

Description

This returns the body extent of a symbol. Unlike the bBox associated with a dbid, a body extent is either one of the following.

1. the extent box created by the union of all shapes on layers PACKAGE_GEOMETRY (PLACE_BOUND_TOP, PLACE_BOUND_BOTTOM, DFA_BOUND_TOP, DFA_BOUND_BOTTOM) and EMBEDDED_GEOMETRY (PLACE_BOUND and DFA_BOUND)
 2. the symbol bbox, a union of all items in symbol

The symbol instance extent box is based upon the design origin while the symdef box is based upon the symbol origin.

Arguments

o dbid A symbol instance or definition

Value Returned

bBox body box of symbol (minX:minY maxx:maxY)

dbid is not a symbol instance (symbol) or definition (symdef)

See Also

axIDBAltOrigin

axlDBPinPairLength

```
axlDBPinPairLength(  
    o_pin1  
    o_pin2  
)  
==> f_etchlength/nil
```

Description

Calculate the shortest length between 2 pins. Pins must be on the same xnet. The pin can also be a VIA or RAT_T. If the distance is not fully routed, it includes a Manhattan estimate of the unrouted portion.

Includes VIA-Z or PIN_DELAY in its calculation if these options are enabled and if your license permits this capability.

Arguments

<i>o_pin1</i>	A pin, via or rat_t
<i>o_pin2</i>	A pin, via or rat_t on same xnet as <i>o_pin1</i>

Value Returned

nil – Not a legal object; unsupported dbid or items not on same xnet
f_etchLength – length of object

See Also

[axlDBGetLength](#)

Example

```
Skill> pin1 = ashOne()  
Skill> pin2 = ashOne()  
Skill> axlDBPinPairLength(pin1 pin2)  
-> 2676.777
```

axlDeleteByLayer

```
axlDeleteByLayer(  
    t_layerName/lt_layerName  
    [nil/'fixed']  
)  
==> x_cnt/nil
```

Description

Deletes all data on one or more provided layers. The following should be noted:

- Does not delete pins or vias.
- Deletes pins escapes and other symbol data associated with symbols.
- Does not delete objects on a symbol definition. If you are using this interface as a prerequisite to deleting a layer, objects on a symbol definition may prevent you from deleting the layer.
- To delete dynamic shapes, you also need to delete data on the equivalent BOUNDARY class.
- Certain classes, such as, DRC_ERROR_CLASS, PIN, VIA_CLASS, ROUTER_PLAN and CAVITY, are ignored.

Arguments

t_layerName layer name <class>/<subclass>

lt_layerName list of layer names

'fixed Optional, ignore FIXED property

Value Returned

x_cnt number of items deleted

nil any error

Example

- Delete all data on ETCH/TOP except for fixed data

```
axlDeleteByLayer("ETCH/TOP")
```

- Delete all data on ETCH/BOTTOM plus OUTLINE layers including fixed

```
axlDeleteByLayer(list("ETCH/TOP" "BOARD GEOMETRY/OUTLINE") 'fixed)
```

axlExtentDB

`axlExtentDB()`
⇒ *l_bBox/nil*

Description

Determines a design type and returns the *bBox* extent. See [axlExtentLayout](#) and [axlExtentSymbol](#) for what Allegro PCB Editor considers an extent.

Arguments

None

Values Returned

<i>l_bBox</i>	Returns <i>bBox</i> extent.
<i>nil</i>	Unknown drawing type.

axlExtentLayout

```
axlExtentLayout(  
    )  
⇒ l_bBox/nil
```

Description

Obsolete. Use `axlExtentDB`. Kept for backward compatibility.

Computes the layout extents and returns the smallest bounding box to be used for window-fit. Only `lines`, `linesegs`, and `shapes` are searched on selected layers in the following order:

- 1.** BOARD GEOMETRY/OUTLINE
- 2.** PACKAGE KEEPIN/ALL
- 3.** ROUTE KEEPIN/ALL

The first layer with any elements is used to determine the layout extents. If no elements are found on these layers, the design extents are returned.

Arguments

None

Value Returned

l_bBox Returns *bBox* of the layout. (See `axlExtentDB`.)

nil Error such as the failure of `axlVisibleGet`.

See Also

[axlExtentDB](#)

axlExtentSymbol

```
axlExtentSymbol(  
    )  
    ⇒ l_bBox
```

Description

Obsolete. Use [axlExtentDB](#). Kept for backward compatibility.

Computes the bounding box enclosing all objects visible for a drawing (a `.dra` file).

Arguments

None

Value Returned

<i>l_bBox</i>	Smallest bounding box enclosing all visible objects. If no objects are visible, set to the design extents. (See <u>axlExtentDB</u> .)
---------------	---

See Also

[axlExtentDB](#)

axlFindPath

```
axlFindPath(  
    o_oneDbid  
    o_twoDbid  
    [g_altPath]  
)  
==> lo_dbid/llo_dbid/nil
```

Description

Finds an etch path from one object to another. Items must be on the same net and must be connect type, such as, pins, vias, clines or shapes, and tee.

Restrictions:

- A partial connection between the 2 objects (ratsnest still exists) results in a nil return.
- Segments are promoted to their owning cline (path)

Return list is ordered by:

```
o_oneDbid, ... <connected items>, o_twoDbid
```

To use this for finding loops on a net, you must compare every node to every other node. This can be very time consuming for large pin count nets.



– If multiple paths exist between the two objects, returns will follow a single path but the one it uses is not defined (by this it may decide on the shortest or longest).

– Because of the high number of interconnects, VOLTAGE nets may not return correct results since the algorithm is recursive and terminates if it nests too deeply.

Arguments

<code>o_oneDbid</code>	first net item
<code>o_twoDbid</code>	second net item
<code>[g_altPath]</code>	enable alternate path

Value Returned

<i>nil</i>	no path exists between objects or an error
<i>lo_dbid</i>	path list if g_altPath is nil
<i>llo_dbid</i>	path list if g_altPath is t. First item is one path and second item is nil or the alternative path. (lo_1dbid l01dbid)

Example

1. Find a path between two items

```
; ashOne is a selection utility found at <cdsroot>/pcb/examples/skill/ash-fxf/  
ashone.il  
one = ashOne()  
two = ashOne()  
; pick a line, cline or segment (set find filter)  
path = axlFindPath(one two)  
axlShowObject(path)
```

2. See if the two objects is a start/end point of a loop

```
path = axlFindPath(one two t)
```

axlGeoPointInShape

```
axlGeoPointInShape(  
    l_point  
    o_dbid/o_polygon  
    [g_include_voids]  
    [t/nil]  
)  
⇒ t/nil
```

Description

Given a point and a shape *dbid*, determines whether that point is inside or outside the shape or a polygon. For a shape with voids, a point is considered *outside* the given shape if inside a void. If shape has voids and *g_include_voids* is *t* then point is outside if inside a void.

The command does not allow hole polygons as input. When polygon holes is passed the following warning is displayed:

```
Invalid polygon id argument -<argument>
```

Arguments

<i>l_point</i>	Point to check.
<i>o_dbid/o_polygon</i>	dbid of the shape / <i>o_polygon</i>
<i>[g_include_voids]</i>	Applicable only in case the second parameter is a shape otherwise it's ignored. In case of shapes, if the parameter value is nil, voids are excluded. The default value is <i>t</i> .
<i>[t/nil]</i>	<i>t</i> means include voids, <i>nil</i> means use the shape outline only. Default is <i>t</i> .

Value Returned

<i>t</i>	Point is inside the shape.
<i>nil</i>	Point is outside the shape, or incorrect arguments were given.

See Also: [axlGeoPointShapeInfo](#)

axlGeoPointShapeInfo

```
axlGeoPointShapeInfo(  
    l_point  
    o_dbid  
) ==> (g_state o_dbid)/nil
```

Description

Given a point and a shape dbid returns relation of point to shape. State may be outside, inside or on. Additional dbid is returned in the second argument to indicate if void or shape is involved.

Return matrix:

G_STATE	O_DBID
outside	nil if outside shape, void dbid if inside void
inside	nil
on	shape dbid if on shape else void dbid



- ❑ Assumes that cross-hatch shapes are solid filled.
- ❑ Rounds point to database units. If database accuracy is 2 and you pass a 3 decimal place point, we will round it to 2 places before doing the test.

Arguments

l_point	the point
o_dbid	dbid of the shape

Value Returned

nil - if an error since as an invalid argument

g_state/o_dbid - see *Description*

axlGetImpedance

```
axlGetImpedance(  
    o_dbid  
) => (f_min f_max)/nil
```

Description

Returns minimum and maximum impedance for given item. Item can be either cline, cline segment, net or xnet. Impedance is in ohms by default.

Arguments

o_dbid Segment cline

Value Returned

f_min f_max Impedance in current MKS units.

nil Segment is not a cline segment.

See Also

[axlSegDelayAndZ0](#)

axlImpdedanceGetLayerBroadsideDPImp

```
axlImpdedanceGetLayerBroadsideDPImp (
    t_layer1/x_layerNum1
    t_layer2/x_layerNum2
    f_width
) ==> f_diffImpedance/nil
```

Description

Computes the differential impedance of a broadside-coupled diffpair with the given line width and two specified layers on which the signal lines will be routed. A warning message may be given if the parameters are inappropriate for the calculation.

Arguments

t_layer1	Layer name (example "ETCH/TOP" or "TOP")
x_layerNum1	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
t_layer2	Layer name (example "ETCH/TOP" or "TOP")
x_layerNum2	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
f_width:	The line width in user units.

Value Returned

The line differential impedance in ohms (float) or `nil` on error.

See Also

[axlImpedance2Width](#)

axlImpdedanceGetLayerBroadsideDPWidth

```
axlImpdedanceGetLayerBroadsideDPWidth(
    t_layer1/x_layerNum1
    t_layer2/x_layerNum2
    f_diffImpedance
)
==> f_lineWidth/nil
```

Description

Computes the differential impedance of a broadside-coupled diffpair with the given line width and two specified layers on which the signal lines will be routed. A warning message may be given if the parameters are inappropriate for the calculation.

Arguments

t_layer1	Layer name (example "ETCH/TOP" or "TOP")
x_layerNum1	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
t_layer2	Layer name (example "ETCH/TOP" or "TOP")
x_layerNum2	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
diffImp:	The target differential impedance in ohms.

Values Returned

The line width in user units or nil on error.

See Also

[axlImpedance2Width](#)

axlImpdedanceGetLayerEdgeDPImp

```
axlImpdedanceGetLayerEdgeDPImp (
    t_layer/x_layerNum
    f_spacing
    f_width
) ==> f_diffImpedance/nil
```

Description

Computes the differential impedance of a edge-coupled diffpair with the given line width and spacing on a specified layer. A warning message may be given if the parameters are inappropriate for the calculation.

Arguments

t_layer	Layer name (example "ETCH/TOP" or "TOP").
x_layerNum	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
f_spacing:	Spacing between the two signal lines in use units.
f_width:	The line width in user units.

Value Returned

The differential impedance value in ohms (float) or `nil` on error.

See Also

[axlImpedance2Width](#)

axlImpdedanceGetLayerEdgeDPSpacing

```
axlImpdedanceGetLayerEdgeDPSpacing (
    t_layer/x_layerNum
    f_width
    f_diffImp
)
==> f_spacing/nil
```

Description

Given the line width of the two signal lines of an edge-coupled diffpair on the specified layer, finds the spacing such that the differential impedance is closest to the target value. A warning message may be given if the parameters are inappropriate for the calculation.

Arguments

t_layer	Layer name (example "ETCH/TOP" or "TOP").
x_layerNum	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
f_width:	The given line width, in user units.
f_diffImp:	The target differential impedance in ohms.

Value Returned

The target spacing in user units or `nil` on error.

See Also

[axlImpedance2Width](#)

axlImpdedanceGetLayerEdgeDPWidth

```
axlImpdedanceGetLayerEdgeDPWidth (
    t_layer/x_layerNum
    f_spacing
    f_diffImp
) ==> f_width/nil
```

Description

Given the spacing of the two signal lines of an edge-coupled diffpair on the specified layer, finds the line width such that the differential impedance is closest to the target value. A warning message may be given if the parameters are inappropriate for the calculation.

Arguments

t_layer	Layer name (example "ETCH/TOP" or "TOP").
x_layerNum	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
f_spacing:	The spacing between the two signal lines in user units.
f_diffImp:	The target differential impedance in ohms.

Value Returned

The line width in database units (float) or `nil` on error.

See Also

[axlImpedance2Width](#)

axlImpedance2Width

```
axlImpedance2Width(  
    t_layer/x_layerNum  
    f_impedance  
) ==> f_lineWidth/nil
```

Description

Converts the given impedance on a specified layer to a line width.

Note: None of the axlImpedance APIs are available in Allegro PCB L.

Arguments

t_layer	Layer name (example "ETCH/TOP" or "TOP").
x_layerNum	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
f_impedance	The impedance value, in ohms, that is to be converted to a line width.

Value Returned

f_lineWidth	The converted line width in drawing units.
nil	Conversion was not successful.

See Also

[axlImpedance2Width](#)
[axlImpedanceGetLayerEdgeDPImp](#)
[axlImpedanceGetLayerEdgeDPWidth](#)
[axlImpedanceGetLayerEdgeDPSpacing](#)
[axlImpedanceGetLayerBroadsideDPImp](#)
[axlImpedanceGetLayerBroadsideDPWidth](#)

axlPadOnLayer

```
axlPadOnLayer(  
    o_dbid  
    t_layer/x_layerNumber  
    [g_noPadSuppress]  
)  
==> t/nil
```

Description

Tests if a pad is present on an etch layer. A pad is present on the layer if the padstack has a regular, anti or thermal pad and it is not suppressed by the rules of Pad Suppression.

While this does support a padstack dbid, for best operation, pass the VIA or PIN object.

Arguments

<i>o_dbid</i>	A via, pin or padstack
<i>t_layer</i>	Name of layer (e.g. "TOP")
<i>x_layerNumber</i>	layer number (starts at 0)
<i>g_noPadSuppress</i>	t if ignore pad suppression, nil (default) use pad suppression

Value Returned

t if a pad is on layer; *nil* no pad on layer

See Also

[axlPadSuppressGet](#)

Example

- Using ashOne shareware in <cdsroot>/share pcb/examples/skill/ash-fxf/ashone.il

Assuming a design where pad suppression is enabled on etch layer GND

```
pad = ashOne(list("vias" "pins"))
```

Allegro SKILL Reference

Database Miscellaneous Functions

```
res1 = axlPadOnLayer(pad "GND")
res2 = axlPadOnLayer(pad "GND" t)
```

axlPadstackSetType

```
axlPadstackSetType(  
    o_padstack/t_padstack  
    g_uvviaBbvia  
) -> t/nil
```

```
axlPadstackSetType(  
    o_padstack/t_padstack  
    g_type  
    g_value  
) -> t/nil
```

Description

Changes a padstack type. In its 2 argument mode is the same as:

```
axlPadstackSetType(padstack 'type g_uvviaBbvia)
```

Permits changing the type or antipads as Route Keepouts (ARK) via the g_type options.

'type

Changes a bbvia padstack to a micro via and vice versa. Uvia types can be managed separately in the constraints system. This has no effect if the padstack is used with Pins. Values are 'bbvia or 'uvia.

'keepout

Enables (or disables) the antipads as Route Keepouts. This indicates the padstack has been built to allow use of the antipad to generate the equivalent of a rko for mechanical pins. It has no effect if these padstacks are used for logical connections. Values are t or nil.

Marks DRC out-of-date if successful.

Arguments

o_padstack padstack dbid

t_padstack padstack name

g_type mode (either 'type or 'keepout)

g_value appropriate setting (see above)

Value Returned

<i>t</i>	change successful
<i>nil</i>	failed. Not a padstack, padstack not in database, type not recognized or padstack not a bbvia or uvia.

Examples

Change padstack named VIA to a micro via

```
axlPadstackSetType("VIA" 'type 'uvia)
```

Change to support antipads as Route Keepouts (ARK)

```
axlPadstackSetType("VIA" 'keepout t)
```

See Also

[axlDBCreatePadStack](#), [axlPadstackEdit](#)

axlPinExport

```
axlPinExport(  
    g_includeTextLocation  
    [t_csvfile]  
)  
--> t/nil
```

Description

This exports all pins in the symbol editor in csv format. The format of the csv file is described in [axlPinImport](#).

Note: Function is only enabled in symbol editor.

Arguments

g_includeTextLocation if *t*, include pin text location (offset, rotation and mirror);
nil omits data which means pin text when loaded into a symbol will be located at pin origin.

t_csvfile Name of csv file; default is symbol name. Assumes a csv extension.

Value Returned

t csv file created

nil failed to create csv file

See Also

[axlPinImport](#)

Example

See example in [axlPinImport](#).

axlPinImport

```
axlPinImport(  
    t_csvFile  
)  
--> l_cnt/nil
```

Description

This imports pin csv (comma separated values) file into the symbol editor. With this file you can describe the location and other characteristics of a set of pins (including mechanical) that comprise a symbol.

Note: This function is only enabled in symbol editor.

To best understand the format of this file, you should export one via axlPinExport.

Two formats are supported:

- pin only, pin text is located at pin origin
- pin with text

File format:

- A '#' indicates a comment
- (Optional) Units,<*units strings*>
- table describing pins

Pin Table (column number indicated)

1. PinNumber - Pin number, if blank then a mechanical pin.
2. Padstack - name of padstack
3. x - x location of pin (no units)
4. y - y location of pin (no units)
5. rotation - pin rotations, if blank has no rotations

If the pin text option is used then the following columns should be present.

1. x offset location from pin origin
2. y offset location from pin origin

3. rotation of text (absolute), if blank no rotation
4. textMirror; blank no mirror, "m" text should be mirrored

Text block used for pin text is the design active text block.

Note: Setting axlDebug() may give additional info on why pins fail to load.

Arguments

t_csvFile csv file, assumes a .csv extension.

Value Returned

nil Unable to open file or no pins loaded

l_cnt A list of (x_pinsLoaded x_pinFailed)

See Also

[axlPinExport](#)

Example

- In the symbol editor with a dra file loaded. Export pins with text location, date, delete all pins and then import them:

```
axlPinExport(nil "foo")
axlDeleteObject(axlDBGetDesign()->pins nil
axlPinImport(foo")
```

axlReratNet

```
axlReratNet(  
    t_netName/o_dbid  
)  
==> t/nil
```

Description

Rerats a net. Normally this is not required since Allegro PCB Editor automatically updates ratsnesting as required.

Arguments

<i>t_old_name</i>	the existing net name.
<i>o_dbid</i>	Alternative is a dbid that is on a net

Value Returned

<i>t</i>	the net is successfully renamed.
<i>nil</i>	fails.

Example

```
axlReratNet("NET1")
```

axlText2Lines

```
axlText2Lines(
  o_textDbid
)
==> llr_path/nil
```

Description

This vectorizes a text dbid into a list of lists of `r_path` objects.

The return is a list of list `r_paths` for each character:

```
llr_path = (l_rpathChar1, l_rpathChar2 ... l_lrpath_CharLast)
```

Each character can have one or more line draws and each line draw can have one or more segments. For example, an 'A' has 2 line draws; one have 2 segments and the second 1 segment.

```
l_rpathChar1 = (l_rpathLine1, ... lrpathLineN)
```


where:

```
l_rpathLineX->_width -> thickness of line
l_rpathLineX->_pathList -> list of segments making up a line
```

Things of note:

- Vectorization returns line segments (no arcs) although this may change in the future.
- A single character may return multiple `r_paths` and one `r_path` may have multiple segments.
- The width is the same for all lines making up a single `textDbid`. This means that the width for all segments undefined since the `r_path` has the width.
- Characters are returned left to right.
- Whitespace is skipped.

Allegro draws all text as stroke text. This converts a text dbid into a series of line draws using `r_path` structures.



Tip
You can convert a `r_path` to an `o_polygon` by using `axlPolyFromDB` using its "`?line2poly t`" option.

Arguments

o_textDbid A text dbid

Value Returned

llr_path A list of list of *r_paths* (see above)

nil An error (not a text dbid) or text dbid is an empty string (shown in Allegro with a small triangle).

See Also

[axlPolyFromDB, Path Functions](#)

Example

Function *ashOne* is a shareware utility that allows user to select one object (see <cdsroot>/share pcb/examples/skill/ash-fxf/ashone.il).

- Pick a text and add converted lines on BOARD GEOMETRY/OUTLINE layer

```
text = ashOne("TEXT")
lines = axlText2Lines(text)
layer = "BOARD GEOMETRY/OUTLINE"
; flatten list
flattened = foreach( mapcan x lines x)
; create objects in database
foreach(path flattened i = axlDBCreatePath(path layer nil nil nil))
```

- Pick a text and add converted to shapes on "BOARD GEOMETRY/ASSEMBLY_DETAIL"

```
text = ashOne("TEXT")
lines = axlText2Lines(text)
layer = "BOARD GEOMETRY/ASSEMBLY_DETAIL"
; flatten list
flattened = foreach( mapcan x lines x)
foreach(path flattened
; may return multiple polys
polys = axlPolyFromDB(path ?endCapType 'ROUND ?line2poly t)
; create shapes in database
foreach(poly polys i = axlDBCreateShape(poly t layer nil nil)))
)
```

axlUnfixAll

```
axlUnfixAll(  
    )  
==> x_count
```

Description

This is a convenience API.

If removes the FIXED property from all elements in the design.

Arguments

none

Value Returned

<i>x_count</i>	Number of fixed properties removed.
----------------	-------------------------------------

Example

```
axlUnfixAll()
```

axlWidth2Impedance

```
axlWidth2Impedance(  
    t_layer/x_layerNum  
    f_lineWidth  
) ==> f_impedance/nil
```

Description

Converts the given line width on a specified layer to an impedance. This uses the field solver to compute the impedance

Arguments

t_layer	Layer name (example "ETCH/TOP" or "TOP").
x_layerNum	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
f_lineWidth	The line width to be converted to an impedance.

Value Returned

f_impedance	The converted impedance value.
nil	Conversion was not successful.

See Also

[axlImpedance2Width](#)

axlIsHighlighted

```
axlIsHighlighted(  
    o_dbid  
)  
==> x_highlightColor/nil
```

Description

If the object is permanently highlighted returns the highlight color; otherwise `nil`.

Note: Pins can be highlighted.

Only symbols, nets, pins and DRC errors can be highlighted. Cadence suggests that you do not highlight drc objects unless they are external DRCs, since Allegro PCB Editor DRCs are frequently recreated.

Arguments

`o_dbid` A `dbid` for which highlighting information is desired.

Value Returned

`x_highlightColor` Highlight color; `nil` if not highlighted, or object does not support highlighting.

See Also

[axlHighlightObject](#)

Examples

See [axlHighlightObject](#)

axlTestPoint

```
axlTestPoint
  o_dbid
  top|bottom|nil
)
⇒ t/nil/s_error
```

Description

Sets or clears a pin and/or via's test point status. Abides by the rules of the testprep parameter form in its ability to add a test point (see possible errors, below). If testprep rules prevent adding a test point, an error symbol is returned. If the command fails for other reasons, nil is returned. On success, a t is returned.

If you add a test point to a pin/via that already has a test point, the existing test point is replaced.

Uses current testprep parameter settings except (these may be relaxed in future releases):

- set to flood
- set allow SMT/Blind or Thru pad stack type

Not enabled in a symbol editor.

Adds test point text using same rules as the testpoint manual command.

Note: Does not delete associated test point text. This may be a future enhancement. For the present, use axlDeleteObject and axlDBGetAttachedText.

Supports axlDebug API to print failure to place error.

Arguments

<i>o_dbid</i>	Pin or via dbid
<i>g_mode</i>	Add test point to top or bottom, or clear one.

Value Returned

t	Object changed.
nil	Error other than test point checks.

Allegro SKILL Reference

Database Miscellaneous Functions

s_error Symbol indicating an error from testprep parameter check.

Errors

PAD_TOO_SMALL	Size does not meet parameter minimums
PAD_UNDER_COMP	Padstack under component
PIN_OFF_GRID	Pin off grid
PAD_UNDEFINED	Layer of padstack not defined on required layer
PAD_NOT_SMD	Padstack must be a SMD
PAD_NOT_THRU	Padstack must be a thru pad
PAD_IN_NO_PROBE_AREA	Testpoint pad in NO_PROBE area
PIN_IS_VIA	Pin type requires a via or any point
PIN_NOT_VIA	Pin type requires a via
PIN_NOT_OUTPUT	Pin type requires an output pin for test point
PIN_NOT_IO	Pin type requires an IOpin for test point
PIN_TOO_CLOSE	Pin too close to another test point
PAD_UNDER_PIN	Test point under another pin
PIN_NOT_NODE	Test point requires a node for testbench
FIXED_TEST_POINTS	Testpoints are fixed and cannot be removed
OTHER	Unclassified error

Examples

The following examples use the `ashone.il` file in `<cdsroot>/share pcb/skill/examples` to allow you to select objects:

- 1) Add testpoint to top

Allegro SKILL Reference

Database Miscellaneous Functions

```
axlUIWPrint(nil 'info1 "Select pin or via to add testpoint")
dbid = ashOne(' (VIAS PINS))
ret = axlTestPoint(dbid 'top)
```

2) Clear a testpoint

```
axlUIWPrint(nil 'info1 "Select pin or via to clear testpoint")
dbid = ashOne(' (VIAS PINS))
ret = axlTestPoint(dbid nil)
```

axlChangeNet

```
axlChangeNet (
  o_dbid
  t_netName/o_netdbid
)
⇒ t/nil
```

Description

Changes the net an object is currently on. Restricted to shapes, filled rectangles (rectangles), pins and vias. Returns *t* when successful. Will not rip up clines or vias.

Failure can occur for the following reasons:

- Object is not supported.
- netName does not exist.

The following restrictions apply to this function:

- Pins must be assigned. Pins must have an associated component. Mechanical pins are un-assigned.
- Via net assignment is advised. The via must be able to connect to something on the provided net to remain on that net. Otherwise, it will fall back to the original net or possibly another net.
- If a via is in open space, it will be on a dummy net. This API cannot be used to force it onto a net.
- This API is useful for a via, if it touches multiple shapes but it is assigned to the wrong shape's net.

Potential side effects of this function:

- It may not properly reconnect two touching cline segments that were previously connected by the shape.
- Clines only attached to the shape will inherit the new net of the shape.
- Vias attached to the shape will not inherit the new net. This is different from the Allegro change net command.

Arguments

o_dbid

Shape *dbid*

Allegro SKILL Reference

Database Miscellaneous Functions

t_netName/o_netdbid Name of a net or a netdbid (for dummy nets)

Value Returned

t Object changed.

nil No object changed.

axlSegDelayAndZ0

```
axlSegDelayAndZ0 (
  o_clineSegDbid
)
⇒ (f_delay f_z0)/nil
```

Description

Returns the delay and impedance of a cline segment. Returns `nil` if a segment isn't a cline segment. Normally, delay is in nanoseconds and impedance is in ohms.

This function is noisy if you pass in non-cline segments.

Arguments

`o_clineSegDbid` Segment cline

Value Returned

`f_delay f_z0` Delay and impedance in current MKS units.

`nil` Segment is not a cline segment.

See Also

[axlGetImpedance](#)

axlSetDefaultDieInformation

```
axlSetDefaultDieInformation(comp)
==> t/nil
```

Description

Sets the default die information for a component.

This function will configure a newly-placed IC-class component as a die in a MCM or SIP design. Based on the placed component's information the die will be flagged as either wire bond or flip-chip.

Arguments

comp	dbid of the component / symbol to set default information for.
------	--

Value Returned

t if successful, nil otherwise.

Microsoft Excel Integration Functions

axlSpreadsheetClose

```
axlSpreadsheetClose()  
  ==> t
```

Description

Releases the spreadsheet document in memory. All information is freed. This function should be called whenever you have completed working with the active spreadsheet document.

Once the spreadsheet information is released, you cannot access any data about it. This includes retrieving style information, cell contents, lists of worksheets, etc. Any such information that you need to reference after the spreadsheet is freed should be retrieved prior to this call.

If there is no active spreadsheet, this function does nothing.

Arguments

Nothing

Values Returned

t	Spreadsheet information successfully freed.
---	---

See Also

[axlSpreadsheetInit](#), [axlSpreadsheetRead](#), [axlSpreadsheetWrite](#)

axISpreadsheetDefineCell

```
axISpreadsheetDefineCell(row, col, style, type, value)
  ==> t / nil
```

Description

Completely define a single cell in the active worksheet. This function is more efficient than calling [axISpreadsheetSetCell](#) with multiple [axISpreadsheetSetCellProp](#) calls afterwards.

Arguments

<i>row</i>	Row index (1-based) for the desired cell.
<i>col</i>	Column index (1-based) for the desired cell.
<i>style</i>	Style name to apply to this cell / nil for default.
<i>type</i>	Type definition for this cell / nil for default (string).
<i>value</i>	Value for cell / nil for empty.

Value Returned

<i>t</i>	Cell successfully defined.
<i>nil</i>	Cell not defined. See console for reason.

See Also

[axISpreadsheetGetCell](#), [axISpreadsheetSetCell](#), [axISpreadsheetSetCellProp](#)

axISpreadsheetDoc

Description

The axISpreadsheet family of functions allow you to read and write Microsoft's open XML-based spreadsheet format from within skill. You can create a spreadsheet from data within your active Allegro tool, or you can read a spreadsheet and extract information from it to update your database.

Documentation for individual functions is separately available. This entry provides an overview, as well as a small example of how to use the API routines together.

Example

The following is a simple example which creates a small, two-worksheet spreadsheet with a few formatting style definitions and cells which use those styles to format their contents when the spreadsheet is viewed with a tool such as Microsoft's Excel.

```
procedure( spreadsheetExample() ; Initialize an empty spreadsheet.  
          ; Note that you do not need to provide a name until you  
          ; wish to write the spreadsheet to disk.  
          axISpreadsheetInit()  
  
          ; Define initial, default style.  
          ; Styles may be defined at any point during the spreadsheet's  
          ; construction, but must be defined before they are referenced  
          ; by any row, column, or cell.  
          axISpreadsheetSetStyle("Default" nil)  
          axISpreadsheetSetStyleProp("Alignment" "Vertical" "Top")  
          axISpreadsheetSetStyleProp("Alignment" "Horizontal" "Left")  
          axISpreadsheetSetStyleProp("Alignment" "WrapText" "1")  
  
          ; Define a second style, derived from the Default style, which  
          ; will include a thin border outline and specifies a red  
          ; background fill.
```

Allegro SKILL Reference

Microsoft Excel Integration Functions

```
axlSpreadsheetSetStyle("Red" "Red Cell")
axlSpreadsheetSetStyleParent("Default")
axlSpreadsheetSetStyleBorder("Left" nil "Continuous" "2")
axlSpreadsheetSetStyleBorder("Right" nil "Continuous" "2")
axlSpreadsheetSetStyleBorder("Top" nil "Continuous" "2")
axlSpreadsheetSetStyleBorder("Bottom" nil "Continuous" "2")
axlSpreadsheetSetStyleProp("Fill" "Color"
axlSpreadsheetGetRGBColorString(255 0 0))
axlSpreadsheetSetStyleProp("Fill" "Pattern" "Solid")

; Define the first worksheet in the spreadsheet.
axlSpreadsheetSetWorksheet("First")
; With a wider first column
axlSpreadsheetSetColumnProp(1 "Width" "500")
axlSpreadsheetDefineCell(1 1 "Default" "String" "Default formatted cell")
axlSpreadsheetDefineCell(1 2 "Red" "String" "Red background cell")

; Write the compiled spreadsheet to XML file on disk.
axlSpreadsheetWrite("spreadsheet.xml")

; Close and release the compiled spreadsheet's data.
axlSpreadsheetClose()
)
```

axISpreadsheetGetCell

```
axlSpreadsheetGetCell(row, col)  
  ==> t / nil
```

Description

Retrieves the data from the specified cell.

Arguments

`row` Row index (1-based) of cell to look up.

`col` Column index (1-based) of cell to look up.

Value Returned

Structure describing cell, or nil if cell not defined.

Structure includes information such as row/col, style, data type, and data itself.

See Also

`axlSpreadsheetSetCell`, `axlSpreadsheetSetCellProp`, `axlSpreadsheetDefineCell`

axlSpreadsheetGetRGBColorString

```
axlSpreadsheetGetRGBColorString(n_red, n_green, n_blue)
==> RGB string
```

Description

Given red, green, and blue color values, return an RGB string for use in spreadsheet style definitions in format required for Microsoft open spreadsheet format.

Arguments

n_red	Integer red value (0-255)
n_green	Integer green value (0-255)
n_blue	Integer blue value (0-255)

Value Returned

RGB string	Denotes color value for the RGB value passed in.
------------	--

See Also

[axlSpreadsheetGetRGBColorString](#)

axlSpreadsheetGetRGBForNamedColor

```
axlSpreadsheetGetRGBForNamedColor(t_name)
==> RGB string / nil
```

Description

Spreadsheets have a small set of known, pre-defined color values. To retrieve the RGB value for a specific named color, pass that color name to this function.

Arguments

t_name	Name of color to retrieve RGB value for.
--------	--

Value Returned

RGB string	Denotes color value for the named color, as listed in Microsoft standards.
------------	--

nil	Color name was not found in list of standard colors.
-----	--

See Also

[axlSpreadsheetGetRGBColorString](#)

axlSpreadsheetGetStyles

```
axlSpreadsheetGetStyles()  
  ==> list of style names + IDs / nil.
```

Description

Retrieve a list of all the styles defined for the active spreadsheet. If no worksheets currently exist, nil will be returned.

Arguments

Nothing.

Value Returned

list	List of style names and IDs as pairs (ID, name)).
nil	No worksheets current defined / no spreadsheet active.

See Also

[axlSpreadsheetSetWorksheet](#)

axlSpreadsheetGetWorksheets

```
axlSpreadsheetGetWorksheets()  
  ==> list of worksheet names / nil.
```

Description

Retrieve a list of all the worksheets defined in the active spreadsheet. If no worksheets currently exist, nil will be returned.

Arguments

Nothing.

Value Returned

list	List of worksheet names (as ordered in the spreadsheet).
nil	No worksheets current defined / no spreadsheet active.

See Also

[axlSpreadsheetSetWorksheet](#)

axlSpreadsheetGetWorksheetSize

```
axlSpreadsheetGetWorksheetSize()  
  ==> list(rows, columns).
```

Description

Return the "size" of the current worksheet, in terms of the highest row and column which have data.

Arguments

Nothing.

Value Returned

list	(maxRow, maxColumn).
nil	No worksheets current defined / no spreadsheet active.

See Also

[axlSpreadsheetSetWorksheet](#)

axlSpreadsheetInit

```
axlSpreadsheetInit()  
==> t / nil
```

Description

Initializes an empty spreadsheet document to begin filling it with worksheets, styles, and cell data. A new spreadsheet, when first initialized, does not include any of this information. It is completely empty.

If there is a spreadsheet already active in memory, it will be closed. Only one spreadsheet may be active at a time.

Arguments

Nothing.

Value Returned

t	Spreadsheet successfully initialized.
nil	Unable to initialize empty spreadsheet. Reason printed to console.

See Also

[axlSpreadsheetClose](#), [axlSpreadsheetRead](#), [axlSpreadsheetWrite](#)

axISpreadsheetRead

```
axISpreadsheetRead(t_fileName)
==> t / nil
```

Description

Read a spreadsheet file on disk into memory for data access and manipulation. File is expected to be in Microsoft XML open spreadsheet format. For text-delimited files, use [axISpreadsheetReadDelimited](#).

Arguments

t_fileName	Name of spreadsheet file on disk to be read.
------------	--

Value Returned

t	Spreadsheet successfully read; ready for querying.
---	--

nil	Unable to read spreadsheet file.
-----	----------------------------------

See Also

[axISpreadsheetClose](#), [axISpreadsheetInit](#), [axISpreadsheetWrite](#),
[axISpreadsheetReadDelimited](#)

axlSpreadsheetReadDelimited

```
axlSpreadsheetReadDelimited(t_fileName, t_delimiter)
==> t / nil
```

Description

Read a text file on disk into memory for data access and manipulation as a spreadsheet. File is expected to be a delimited text file, with cell delimiters as specified in the *t_delimiter* argument. For XML spreadsheets, use [axlSpreadsheetRead](#).

Arguments

<i>t_fileName</i>	Name of text file on disk to be read.
<i>t_delimited</i>	Delimiter character used to separate "cells" in text file.

Value Returned

<i>t</i>	File successfully read; ready for querying.
<i>nil</i>	Unable to read spreadsheet file.

See Also

[axlSpreadsheetRead](#)

axlSpreadsheetSetCell

```
axlSpreadsheetSetCell(row, col)
  ==> t / nil
```

Description

Make the active row/column of the current worksheet active.

Arguments

row Row index (1-based) of cell to activate.

col Column index (1-based) of cell to activate.

Value Returned

t Cell successfully activated.

nil Cell not activated. See console for reason.

See Also

[axlSpreadsheetGetCell](#), [axlSpreadsheetSetCellProp](#), [axlSpreadsheetDefineCell](#)

axISpreadsheetSetCellProp

```
axISpreadsheetSetCellProp(propName, propVal)
  ==> t / nil
```

Description

Sets a property on the active cell in the spreadsheet.

Arguments

propName	Property to set. Allowable values are: STYLE, TYPE, or VALUE
propVal	Value to set this property to.

Value Returned

t	Cell property successfully set.
nil	Property not set (no active cell or invalid property). See console for further details.

See Also

[axISpreadsheetSetCell](#), [axISpreadsheetGetCell](#), [axISpreadsheetDefineCell](#)

axlSpreadsheetSetColumnProp

```
axlSpreadsheetSetColumnProp(column propName propVal)
  ==> t / nil
```

Description

Sets a property for the given column of the active worksheet.

Arguments

column	Column index to set property for.
propName	Property to set. Allowable values are: AUTO_FIT_WIDTH, WIDTH, STYLE.
propVal	Value to set this property to.

Value Returned

t	Property set on column.
nil	Property not set. Reason printed to console.

See Also

[axlSpreadsheetSetRowProp](#)

axlSpreadsheetSetDocProp

```
axlSpreadsheetSetDocProp(propName, propVal)
==> t / nil
```

Description

Sets a property on the document (spreadsheet) itself.

Arguments

propName Property to set. Allowable values are: AUTHOR, LAST_AUTHOR, DATE, COMPANY, or VERSION.

propVal Value to set this property to.

Value Returned

t Document property successfully set.

nil Property not set (no active spreadsheet or invalid property). See console for further details.

axlSpreadsheetSetRowProp

```
axlSpreadsheetSetRowProp(row propName propVal)
  ==> t / nil
```

Description

Sets a property for the given row of the active worksheet.

Arguments

row	Row index to set property for.
propName	Property to set. Allowable values are: AUTO_FIT_HEIGHT, HEIGHT, STYLE.
propVal	Value to set this property to.

Value Returned

t	Property set on row.
nil	Property not set. Reason printed to console.

See Also

[axlSpreadsheetSetColumnProp](#)

axISpreadsheetSetStyle

```
axISpreadsheetSetStyle(id, name)
  ==> t / nil
```

Description

Defines or activates the specified style in the active spreadsheet. Styles may be referenced in any worksheet of the spreadsheet. You do not need to redefine the style for each new worksheet you create.

Arguments

id	The spreadsheet ID for this style.
name	The user "name" for this style / nil. This is the name that is displayed for this style in the Excel style editor and selection pull-down.

Value Returned

t	Style successfully activated / defined.
nil	Style not activated. Reason written to console.

See Also

[axISpreadsheetSetCell](#), [axISpreadsheetSetWorksheet](#)

axISpreadsheetSetStyleBorder

```
axISpreadsheetSetStyleBorder(l_position, l_color, l_lineStyle, l_weight)  
==> t / nil
```

Description

Sets the cell border properties for a active style definition.

Arguments

position	Position must be one of the accepted Microsoft positions (Left, Right, Top, Bottom, etc).
color	Microsoft color name or RGB value (e.g. "BLACK" or #FF00AA).
lineStyle	Line style to use (normally "Continuous" for a solid line).
weight	The thickness of the line, in pixels. Must be positive integer.

Value Returned

t	Border style successfully set.
nil	Border style not set (no active style or invalid parameters). See console for further details.

See Also

[axISpreadsheetSetStyle](#), [axISpreadsheetSetStyleProp](#), [axISpreadsheetSetStyleParent](#)

axISpreadsheetSetStyleParent

```
axISpreadsheetSetStyleParent(parent)
==> t / nil
```

Description

Sets the active style's parent. Style will inherit default properties from its parent style, therefore only changes need to be specified in the child style. Parent must already be defined for spreadsheet.

Arguments

parent	Style ID of parent to link to. Note that the parent must already be defined before it can be referenced by children.
--------	--

Value Returned

t	Style parent successfully set.
nil	Parent not set (no active style or parent style doesn't exist). See console for further details.

See Also

[axISpreadsheetSetStyle](#), [axISpreadsheetSetStyleBorder](#), [axISpreadsheetSetStyleProp](#)

axISpreadsheetSetStyleProp

```
axISpreadsheetSetStyleProp(type, propName, propVal)
  ==> t / nil
```

Description

Sets a specific style property in the active style definition.

Arguments

type	Type of property being set. Must be one of: ALIGNMENT, FONT, FILL, NUMBER_FORMAT, PROTECTION.
propName	Name of the property being set (varies by type).
propVal	Value to set the property to.

Value Returned

t	Style attribute successfully set.
nil	Attribute not set (no active style or invalid parameters). See console for further details.

See Also

[axISpreadsheetSetStyle](#), [axISpreadsheetSetStyleBorder](#), [axISpreadsheetSetStyleParent](#)

axlSpreadsheetSetWorksheet

```
axlSpreadsheetSetWorksheet (name)
  ==> t / nil
```

Description

Makes the specified worksheet the active one for future cell references. If the worksheet does not exist, it will be created as the new last worksheet in the document.

Arguments

name The name of the worksheet to activate.

Value Returned

t Worksheet successfully activated / defined.

nil Worksheet not activated. Reason written to console.

See Also

[axlSpreadsheetSetCell](#), [axlSpreadsheetSetStyle](#)

axlSpreadsheetWrite

```
axlSpreadsheetWrite(t_fileName)
==> t / nil
```

Description

Write the spreadsheet in memory to file on disk. File will be written compliant with Microsoft's open spreadsheet XML format.

Arguments

t_fileName	Name of file to be written to, including path if not to be written to current working directory.
------------	--

Value Returned

t	File successfully written.
---	----------------------------

See Also

[axlSpreadsheetClose](#), [axlSpreadsheetInit](#), [axlSpreadsheetRead](#)

Plugin Functions

Overview

This chapter describes the AXL-SKILL functions related to plugin APIs.

The axIDll family of APIs provides the ability to bind compiled Dll (shared library) packages into programs supporting the Skill axl APIs. Any publically exported functions from a Dll can be imported. The only restriction is that exported Dll functions must support the API specified below.

Any reference to 'DLL' is the equivalent to a shared library for UNIX and Linux programmers. All UNIX references apply to Linux.

Creating a plugin requires two components:

- Skill code to import and wrap the functionality provided by the dll.
- The dll/shared library implementing the plugin functionality.

SKILL Programming

The Skill progamming model for plugins is:

- Locate and open a plugin via `ax1D1lOpen`. We suggest assigning a handle to a global Skill symbol. On subsequent calls into your Skill application, the symbol will be non-nil, so the call to `ax1D1lOpen` can be skipped. (See `ax1D1lOpen`.)
- Import the required symbols from the plugin via `ax1DLLSym`. Like the handle returned by `ax1D1lOpen`, these handles should be assigned to global symbols.
- Use either `ax1D1lCall` or `ax1D1lCallList` to access the capability from the plugin.
- The I/O data types that are supported are documented in `ax1D1lCall`.

DLL Programming

DLL programming allows the use of external developers to utilize existing C/C++ code or develop new capabilities in C/C++ to plugin as extensions to SPB software. SPB software supporting this capability are those that incorporate the "axl" extension package to Skill.

Implementation of a plugin dll:

- Obtain the compiler environment required by Cadence. (See the Allegro platform documentation.)
- Use the existing Cadence Makefile (UNIX) or Project file (Microsoft) which contains the required compile/link options. You can use these files to build your plugin to adapt your own software configuration environment. (See <cdsroot>/share pcb/examples/skill/plugin.)
- Ensure that the exported Dll functions meet the API requirements. (See API plugin functions below). The include file, <cdsroot>/share pcb/include/axlplugin.h, has the required structure definitions and defines.
- Build your plugin.
- Test it.

Required Cadence files for plugin programming:

<cdsroot>/share pcb/include/axlplugin.h

API Plugin Functions

The C API for any plugin function is as follows:

```
long <function>(AXLPluginArgs *output, AXLPluginArgs *input)
```

The API takes identical structures for both its input and output arguments. The calling Cadence software updates the input structure with the data passed by the calling Skill code. It also initializes the output structure.

The Plugin function must return a value and optionally update the output structure with return data (argv and count). The plugin return value is passed back to the calling Skill code as follows:

return == 0	Returns a list of from output data structure up to the count value. If count in output structure is 0, returns an empty list.
-------------	---

return != 0	Return value is returned to Skill as an integer.
-------------	--

Allegro SKILL Reference

Plugin Functions

AXLPluginArgs Input/Output Structure Members

version = AXLPLUGIN_VERS_IN	Version of input structure. If additional capability is added in the future, this version number will be bumped. It informs the plugin of the capability supported in the structure.
flag = 0	Future use
maxEntries = AXLPLUGIN_MAX	Can be ignored on input. On output, you cannot exceed this value for return arguments.
count = <number of argv entries>	Number of entries in argv. Basically, the number of arguments provided to the axlDLLCall APIs. Will never be more than maxEntries.
argv[]	Array of AXLPluginEntry arguments

AXLPluginEntry (argv) Structure Members

(See Input/Output Data Primitives.)

type	Indicates type of data
data	Union of primitive types supported

For the called Dll function to return data to calling Skill code, both count and argv entries should be set in the output data structure. For each argv entry return, you should also set the data type to one of the primitives shown below. Under no situation should you attempt to return more than maxEntries.

If your exported dll functions will be used outside your programming environment, then you should valid check the input arguments either in the Skill wrapper or in your Dll function. For example, if you expect a string argument and the calling Skill code passes an integer, a program exception will occur if the data is not checked.

Input/Output Data Primitives

A set of I/O data primitives is supported. The argv entry of AXLPluginArgs is an array of these structures. Each array member has its data type indicated and the data itself. Both the input and output data use the AXLPluginArgs structure.

Allegro SKILL Reference

Plugin Functions

The data primitives that are supported are:

Type	Skill type	C type	C struct member
AP_BOOL	t/nil	int	b_value
AP_LONG	x_value	long	l_value
AP_DOUBLE	f_value	double	d_value
AP_CONST_STRING	t_value/s_value	char *	cs_value
AP_STRING	t_value	char *	s_value (output only)
AP_XY	f_value:f_value	AXLXY	xy_value

AP_STRING types will not be seen on input. All strings passed from Allegro to the plugin are AP_CONST_STRING. To return a string, the plugin may use either AP_CONST_STRING or AP_STRING. If AP_STRING is used, then Allegro will free the memory associated with the string using the standard C "free" API, which means you must allocate it via malloc.

Other data type restrictions are:

- The plugin must not modify in place any input AP_CONST_STRING; corruption of Skill will occur.
- To maintain AP_CONST_STRING input data across function calls, you should make a copy of them. Skill may garbage collect the memory after your Dll function returns.
- If you use your own memory manager, do not use AP_STRING types for return. These require the use the standard `malloc` memory manager.
- Input arguments can be Skill symbols ('<symbol>') but these are converted to AP_CONST_STRING types.
- The STRING types do not support wide character sets; use only characters in the ASCII character set.
- AP_XY represents a (x y) location and is implemented as a structure of two doubles.
- If AP_BOOL type is used, two defines are provided in `axlplugin.h`:
 - AXLPLUGIN_TRUE = 1
 - AXLPLUGIN_FALSE = 0

Return value from plugin exported back to Skill:

- If `output->count` is 0, then we look at the return value from the plugin function and return x_value to symbol.

- Else (non-zero count), we return this value to Skill as a Skill integer type.

Programming Restrictions, Cautions and Hints

- Cadence only supports the compiler listed in the SPB Platform documentation. Also required are any compiler and DLL linker options listed.
- If your DLL has dependancies upon other DLLs, make sure those do not conflict with DLLs used by Cadence. Typically, they need to be the same version and not built with debug options.

To determine the DLLs used by Cadence use:

- Window: depends or procexp (www.sysinternals.com)
- Solaris, Linux: ldd <program name>
- AIX: dump -H <program name>
- On Windows, you can include UI components in your plugin. This capability is not supported on Unix.
- Wide character types are not supported in the plugin to the Allegro interface.
- On Unix, if threading is used, then you should POSIX threads (pthreads).
- STL programming should use the default STL provided by the Cadence required compiler. Do not use a third party STL.
- On Windows, if DLL is MFC based, then do not compile it debug. MFC Classes change in size if code is built debug and are not compatible with non-debug MFC code. There are methods described on the Web on how to build MFC debuggable without requiring the MFC debug shared library. Typically on Windows, Debug DLLs are not compatible with non-Debug DLLs. Also many different versions of MFC exist which are incompatible with one another. Use one of the binary query tools (see above) to determine the version of MFC currently required by Cadence.
- There are currently no methods to make function calls back to Allegro from the plugin.
- Your DLL can be used across multiple Cadence releases without recompiling your plugin. Re-compiling is only required if Cadence changes the compiler in the release.
- Programming errors in your plugin can crash the host program. In rare cases, these bugs can corrupt an Allegro database. (See customer support below.)
- On Windows, to access stdout/stderr, set the TELCONSOLE=1 as the OS level. This variable cannot be set via Allegro's env file. This is also considered a debug environment so it should not be used during board design.

Performance Considerations

The following issues should be considered if high performance is required:

- Locating and loading a plugin. This should be done once per activation. Assign the handle return by `ax1DllOpen` to a global symbol to prevent Skill garbage collection. Do not close the plugin.
- Import symbols of a plugin once. The `ax1Dll` interface internally caches symbol import so subsequent lookups will be faster than the initial call.
- A plugin function should do meaningful work since there is some overhead converting input data from Skill to native C types and doing the opposite for return data.

Cadence Customer Support

Cadence does not support debugging customer developed plugins.

An environment variable, `allegro_noextension_plugin`, is available to disable plugin capability. If Allegro starts crashing or databases become corrupt, you should set this variable to determine if a plugin is the cause.

Examples

An example containing Skill, the plugin C code, Gnu Makefile (UNIX) and project file (Visual.NET) is contained at `<cdsroot>/share/pcb/examples/plugin`. In addition, a prebuilt plugin module is contained in the Cadence install hierarchy so you do not need to compile and link the plugin source code to run the Skill code.

The example plugin provided has three exported symbols:

- An echo API which returns as output any input given.
- A `x_value` API which returns the number of input arguments.
- A distance implementation to calculate the distance between two points.

axIDllCall

```
axIDllCall(  
    o_pluginFunc  
    [g_arg1]  
    ...  
    [g_arg10]  
) -> nil/x_value/lg_data
```

Description

Calls a symbol that has been imported from a plugin. As the first argument, it requires `o_pluginFunc` which was returned via a call to `axIDllSym`. The rest of the arguments are what the implement plugin API has defined.

The return from the call is one of the following:

- `nil`: error processing data
- `x_value`: plugin function returned a non-zero result
- `lg_data`: plugin function returned a zero and it calls the import function from the plugin

Arguments

`o_pluginFunc` plugin symbol handle

`[g_arg1..10]` up to 10 arguments

Value Returned

`nil` Error in processing arguments or funding functions.

`x_value` If plugin function returns a non-zero, then this is what is returned.

`lg_data` If plugin function returns zero, then its output arguments are processed and returned as a list. If the output argument list from the plugin has 0 entries, then an empty list is returned.

See Also

[axlDllOpen](#)

Example

Example carried from axlDllSym

```
axlDllCall(_ashDistance 10:0 25.1:0) -> 15.1
```

axIDllCallList

```
axIDllCall(
    o_pluginFunc
    l_args/nil
) -> nil/x_value/lg_data
```

Description

This function is identical to `axIDllCall` except it takes a list of arguments to pass to the plugin function. Unlike `axIDllCall`, which is limited to 10 arguments, this interface can take up to 512 arguments.

See `axIDllCall` for a further explanation.

Arguments

`o_pluginFunc` Plugin symbol handle

`l_args` A list of up to 512 arguments

Value Returned

`nil` Error in processing arguments or funding functions.

`x_value` If plugin function returns a non-zero, then this is what is returned.

`lg_data` If plugin function returns zero, then its output arguments are processed and returned as a list. If the output argument list from the plugin has 0 entries, then an empty list is returned.

See Also

[axIDllCall](#), [axIDllOpen](#)

Example

From `axIDllOpen` example

```
_ashEcho = axIDllSym(_ashTestDll "ashEcho")
axIDllCallList(_ashEcho list(-1 -2.0 nil "another string"
                           -10.1:-2 0.2))
```

ax1DllClose

```
ax1DllClose(  
    o_plugin  
)  
==> t/nil
```

Description

This closes an open plugin handle. Once a handle is closed, you can no longer call functions obtained from the plugin. Also, a plugin is automatically closed when there are no active references to it via Skill's garbage collection.

It is not advisable to close a plugin due to performance considerations.

Arguments

`o_plugin` Plugin handle obtained from `ax1DllOpen`.

Value Returned

`t` if successful to close, `nil` if handle is not a legal handle

See Also

[ax1DllOpen](#)

Example

See example referenced by `ax1DllOpen`.

ax1DllDump

```
ax1DllDump(  
)  
==> l_dllLoad/nil
```

Description

This is a debug function that reports all plugins loaded by Skill.

Arguments

None

Value Returned

List of plugin handles or `nil` if no loaded plugins.

See Also

[ax1DllOpen](#)

Example

```
ax1DllDump()
```

axlDllOpen

```
axlDllOpen(  
    t_dllname  
)  
==> o_plugin/nil
```

Description

This binds a dll/shared library to the current program. While this can load any dll, only those built to be compatible with the axl Plugin model can be utilized via Skill (see [DLL Programming](#) on page 1326 for information on building compatible dlls).

If the dll name does not have a directory path component, then `AXLPLUGINPATH` environment variable is used to search for the dll.

After a dll is successfully loaded, you need to import one or more symbols (`axlDllSym`).

Plugin Attributes

Name	Type	Description
name	string	Name of plugin file (dll name)
functions	l_dbid	Disembodied property list name/value pairs of imported symbols (t_name o_pluginFunc)
objType	string	"plugin"

Note: To access imported plugin function types do a

```
<o_plugin>->functions-><pluginFuncName>
```

Arguments

`t_dllname` Name of dll. For platform indendence, it is strongly suggested that you do not include the file extension or a directory path component.

Value Returned

`o_plugin`

`nil` Can't locate library or not a dll.

See Also

[DLL Programming](#) on page 1326, [axlDllSym](#), [axlDllCall](#), [axlDllCallList](#)
[axlDllClose](#), [axlDllDump](#)

Example

Open Cadence test dll

```
_ashTestDll = axlDllOpen("axlecho_plugin")
```

axlDllSym

```
axlDllSym(  
    o_plugin  
    t_symbolName  
)  
==> o_pluginFunc/nil
```

Description

This imports a symbol from a loaded dll. A dll can have one or more exported symbols. The symbol must have been exported from the dll when the dll was compiled and linked (See axlDllDoc).

PluginFunc Attributes

Name	Type	Description
name	string	Name of imported symbol file
functions	nil	Always nil
objType	string	"pluginFunc"

Arguments

o_plugin dll handle from axlDllOpen
t_symbolName Name of an exported function within the dll

Value Returned

o_pluginFunc Symbol handle
nil Error; symbol not present in dll.

See Also

[axlDllOpen](#)

Example

Load the distance symbol from the axl plugin test dll

Allegro SKILL Reference

Plugin Functions

```
_ashDistance = axlDllSym(_ashTestDll "ashDistance")
```

Allegro SKILL Reference

Plugin Functions

Skill Language Extensions

axldo

```
axldo(
  g_initList
  g_terminateList
  [g_body]
) -> g_result

axldoStar(
  g_initList
  g_terminateList
  [g_body]
) -> g_result
```

Description

A do function, modeled after the CL (Common Lisp) do.

Public:

```
(defmacro do ((var [init [step]]) ...) (end-test result result ...) @body)
(defmacro doStar ((var [init [step]]) ...) (end-test result result ...))
```

The do macro provides a generalized iteration facility, with an arbitrary number of *index variables*. These variables are bound within the iteration and stepped in specified ways. They may be used both to generate successive values of interest or to accumulate results. When an end condition is met (as specified by end-test), the iteration terminates, the result sexps are successive evaluated, and the value of the last result sexp is returned.

The first item in the form is a list of 0 or more index-variable specifiers. Each index-variable specifier is a list of the name of the variable, var; an initial value, init; and a stepping form, step.

If init is omitted, it defaults to nil. If step is omitted, the var is not changed by the do construct between repetitions (though code within the do is free to alter the value of the variable by using setq).

An index-variable specified can also be just the name of a variable. In this case, the variable has an initial value of nil and is not changed between repetitions. This would be used much as a locally scoped variable in a let statement would be.

Before the first iteration, all the init forms are evaluated, and each var is bound to the value of its respective init. Because this is a binding, and not an assignment, when the loop terminates the old values of the variables is restored. All of the init forms are evaluated before any var is bound; hence all the init forms may refer to the old bindings of all the variables (that is, to the values visible BEFORE beginning execution of the do).

Note: All init bindings are done in parallel for `axlDo`, and serially for `axlDoStar`.

The second element of the loop is a list of an end-testing predicate form `end-test`, and zero or more result forms. This resembles a conditional clause. At the beginning of each iteration, after processing the variables, the `end-test` is evaluated. If the result is nil, execution proceeds with the body of the form. If the result is non-nil, the result forms are evaluated in order as an implicit `progn`, and then the do returns the value of the last evaluated result.

At the beginning of each iteration, the index variables are updated as follows.

- All the step forms are evaluated, from left to right, and the resulting values are assigned to the respective index variables. Any variable that has no step value is not assigned.

Arguments

<code>g_initList</code>	0 or more index variable specifiers
<code>g_terminateList</code>	end test predicate
<code>g_body</code>	body of procedure

Value Returned

Value resulting from evaluating last result `sexp`.

See Also

[letStar](#)

copyDeep

```
copyDeep (
    l_object
) -> l_newObject
```

Description

This function recursively copy a list.

The copy function makes a new list containing copies of all top level elements in the source list. But each new element contains references to the same sublist elements as the source list. Thus, if sublist items are modified in the source list they are also modified in the copy, and vice-versa. The copyDeep function makes a complete copy of the list, top to bottom. So changes in one list do not affect the other. This allocates more memory, of course.

Arguments

l_object The list to be copied

Value Returned

A new list identical to the orginal but sharing no memory.

isBoxp

```
isBoxp (  
        g_bBox  
    )  
==> t/nil
```

Description

Checks argument to see if it is a valid bounding box. A valid bounding box should be of the form of ((a b) (c d)) where a, b, c, and d are all numbers and a!=c and b!=d, to ensure that the bounding box encloses some area.

Arguments

g_bBox	input argument to be tested.
--------	------------------------------

Value Returned

t: If g_bBox is a valid bounding box.

nil: If g_bBox is not a valid bounding box.

lastelem

```
lastelem(  
    l_list  
) -> g_elem
```

Description

The `last()` function returns the last LIST object in a list, but `lastelem()` takes the car of that to get the last ATOM.

Arguments

`l_list` a list

Value Returned

The last atom element of a list.

Example

```
l = list(1 2 3)  
last(l) -> (3)  
lastelem(l) -> 3
```

letStar

```
letStar(  
    l_bindings  
    [@body]  
) -> g_lastValue
```

Description

This is a let* implementation of CL (Common Lisp). This is a mprocedure function.

Arguments

l_bindings	list of l_varbind where:
l_varbind	is (<name> <value>) where
name	interned as lexically-scoped symbol
value	evaluated to arrive at value
@body	one or more expressions to be evaluated.

Value Returned

last value of @body

See Also

[axldo](#)

listnindex

```
listnindex(  
    l_theList  
    g_item  
) -> x_found/nil
```

Description

Finds the position of an item in a list. Works just like `nindex`, but finds the position of an element in a list instead of a character in a string. An integer denoting the sequence number of the first matching element is determined.

Arguments

`l_theList` A list containing the element to be found

`g_item` The element to be found

Value Returned

The position in the list where the element was first found, or `nil` if it is not found.

Example

```
(listnindex "dog" '("three" "dog" 'night)) -> 2
```

movedown

movedown - move an element one item farther from the head of a list

```
movedown (  
    g_elem  
    l_list  
) --> l_newlist
```

Description

Find all occurrences of element within list *l* and move them one item closer to the list tail. No action for other items and the last element of the list.

This destructively modifies the list.

Arguments

g_elem	The element to be moved, matched using (equal)
l_list	The list containing the element to be moved.

Value Returned

The modified list.

moveup

```
moveup (
    g_elem
    l_list
) --> l_newlist
```

Description

Moves an element one item closer to the head of a list. Finds all occurrences of the element within list *l* and moves them one item closer to the list head. No action for other items and the car.

This destructively modifies the list.

Arguments

<i>g_elem</i>	The element to be moved, matched using (equal)
<i>l_list</i>	The list containing the element to be moved.

Value Returned

The modified list.

parseFile

```
parseFile (
    t_fileName
    s_handler
    [t_breakChars]
)
==> g_result
```

Description

Parse all lines of a file. Opens input file and reads it line by line. Each line is parsed using parseQuotedString. The result of parseQuotedString is passed to the application defined handler `s_handler`. The handler defines the return value.

Arguments

<code>t_fileName</code>	Name of file to be read.
<code>s_handler</code>	application callback function to process parsed arguments

```
s_handler (
    l_curLineInfo
    l_lineArgs
    g_result
)
==> g_result
```

Where:

<code>l_curLineInfo</code>	List of info which describes the current line being processed.
----------------------------	--

Defined as:

`(t_fileName g_lineNo t_curString)`

`t_fileName` Name of file being read

`g_lineNo` Current line number

`t_curString` Unparsed file line

Allegro SKILL Reference

Skill Language Extensions

<code>l_lineArgs</code>	List of strings that result from parsing the line.
<code>g_result</code>	The application callback result. This is continually passed to <code>s_handler</code> so that a result can be built up from the processing of all file lines. This will be nil the first time and will be whatever <code>s_handler</code> last returned for subsequent calls.
<code>t_breakChars</code>	Optional string containing characters that are used as break characters. The default is "' \\ \" " (quote chars and space char).

Value Returned

`g_result` The application callback result from the last call to `s_handler`.

parseQuotedString

```
parseQuotedString(  
    t_string  
    [t_breakCharacters]  
)  
--> l_strings
```

Description

Breaks a string into a list of words. Multiple words enclosed within quotation marks are treated as single words.

Arguments

t_string	String to be parsed.
t_breakCharacters	Optional string containing characters to be used as break characters. The default is "' \\ \" " (quote chars and space char).

Value Returned

l_strings	A list of strings parsed from the t_string argument.
-----------	--

Note: A word break is not created at the start of a quote unless the quote character is a break character.

Examples

- parseQuotedString("111 222'333 444'" " ") => ("111" "222333 444")
- parseQuotedString("111 222'333 444'" " ' ") => ("111" "222" "333 444")

pprintln

```
pprint(  
    g_item  
    [p_port]  
) -> t/nil
```

Description

Prints a newline character at the end of the line.

Arguments

g_item The item to be printed.

p_port The optional parameter that specifies the port to write to. Default value is stdout.

Value Returned

Returns item pretty printed plus a newline character.

propNames

```
propNames (
    g_propList
) -> ls_names/nil
```

Description

Use this command to get the names of properties in a disembodied property list. Walk each property in disembodied property list, building a list of the names of each property.

Note: Order of returned property names is unspecified.

Arguments

g_propList A disembodied property list.

Value Returned

ls_names A list of symbols corresponding to the names of each property found in the list.

Example

```
n = ncons(nil)
n->one = 1
n->two = 2
propNames(n) -> (one two)
```

Logic Access Functions

Overview

This chapter describes the AXL-SKILL functions related to schematic capture or the logical definition of the design.

axlDBAssignNet

```
axlDBAssignNet(  
    o_object/lo_object  
    o_net/t_net  
    [g_riput]  
)  
⇒ t/nil
```

Description

Assigns an object or a list of objects to a new net. Supports pins, vias, and shapes. Vias may not stay on net assigned if they do not connect to an object on the new net. This is not applicable if the new net has RETAIN_NET_ON_VIAS property.

Arguments

<i>o_object</i>	<i>dbid</i> , or list of <i>dbids</i> of objects to change net.
<i>o_net</i>	<i>dbid</i> of destination net, or <i>nil</i> if assigning to a dummy net.
<i>t_net</i>	Net name can be used as an alternative to a dbid net.
<i>g_riput</i>	An optional flag to ripup clines connected to modified objects. possible values are: <i>t</i> = ripup clines connected to modified objects. <i>nil</i> = do not ripup clines connected to modified objects. The default is <i>nil</i> .
<i>g_ignoreFixed</i>	By default, won't allow net assignment if FIXED property is present on the object(s) in question. Setting this argument to <i>t</i> ignores the FIXED property. If <i>g_riput</i> is <i>t</i> , and connected clines have the FIXED property then the clines will remain and an error message thrown.

Value Returned

<i>t</i>	At least one object changed net.
<i>nil</i>	No object changed net.

See Also

[axlDBCreateNet](#), [axlDBIgnoreFixed](#)

Example:

- Simple re-assignment

```
pin_id->net->name => ""
net_id->name => "GND"

axlDBAssignNet(pin_id net_id t)=> t
pin_id->net->name => "GND"
```

- Interactive exploration; use the ashOne shareware provided in examples area of cdsroot.

```
;select an object
item = ashOne()
new net
net = "net1"

axlDBAssignNet(item net t t)
```

axlDBCreateConceptComponent

```
axlDBCreateConceptComponent (
    s_refdes
    s_partPath
    s_logName
    s_primName
    [s_pptRowName]

)
⇒ r_dbid/nil
```

Description

Given the Concept information needed to describe an Allegro PCB Editor device, create the Allegro PCB Editor component and return its *dbid*. If the component definition already exists, use the existing definition to create the new component. If the component definition does not exist, create a new definition and then create the component instance. Concept information comes from a `chips_ptr` file and from a physical parts table (PPT). Determine the location of this information using the `cptListXXX` family of routines, which allow browsing through a Concept library.

Arguments

<code>s_refDes</code>	Reference designator for the new component.
<code>s_partPath</code>	Full path to the <code>chips_ptr</code> file containing the description of the desired logical part. Determine using the <code>cptListComponentLibraries</code> function.
<code>s_logName</code>	Name of the desired logical part. You can determine this using the <code>cptListComponentPrimitives</code> function.
<code>s_primName</code>	Name of the desired primitive. You can determine this using the <code>cptListComponentPrimitives</code> function.
<code>s_pptRowName</code>	Name of the desired PPT part. Concept data may not include specific device information which would be contained in a PPT. Indicates a specific row in a PPT from which to create the component. You can determine this using the <code>cptListComponentDevices()</code> function.

Value Returned

r_dbid *dbid* of the new Allegro PCB Editor component instance.

nil Unable to create component instance.

Note: The actual name of the resulting Allegro PCB Editor device is generated automatically. If using the `cptListComponentDevices()` function, then the name should have been created already and is included in the return values of that function. Name is determined by the Concept library data you use to create the part.

This function is meant to be called from SKILL.

axIDBCreateComponent

```
axIDBCreateComponent(  
    s_refDes  
    s_deviceName  
    [s_package]  
    [s_value]  
    [s_tolerance]  
)  
==> r_dbid/nil
```

Description

Given the information needed to describe a Allegro PCB Editor device, create the Allegro PCB Editor component and return its `dbid`. If the component definition already exists, use the existing definition to create the new component. If the component definition does not exist, create a new definition using the device file and create the new component.

Arguments

<code>s_refDes</code>	The reference designator for the new component.
<code>s_deviceName</code>	Name of Allegro PCB Editor device file.
<code>s_package</code>	Package name to be used for the component. This overrides the value found in the device file (can be nil).
<code>s_value</code>	"Value" attribute value. This will override the value found in the device file (can be nil).
<code>s_tolerance</code>	"Tolerance" attribute value. This will override the value found in the device file (can be nil).

Value Returned

<code>r_dbid</code>	<code>dbid</code> of new Allegro PCB Editor component.
<code>nil</code>	If unable to create component.

Note: If you change an existing component definition by specifying a new value for package, value, or tolerance, you need a device file.

Example

Create a new empty comp from an existing one, ashOne can be found at:

```
<cdsroot>/share/pcb/examples/skill/examples/ash-fxf/ashone.il
syminst = ashOne()
ci = syminst->component
nci = axlDBCreateComponent("C1_NEW" ci->deviceType ci->package
ci->compdef->prop->VALUE ci->compdef->prop->TOL)
```

If your component is not a discrete component, you do not need the fourth and fifth arguments, but the above example will work for all components.

axIDBCreateManyModuleInstances

```
axIDBCreateManyModuleInstances (
    t_name
    t_moddefName
    x_tileStartNum
    l_origin
    l_offset
    x_num_tiles
    f_rotation
    x_logicMethod
    [l_netExcept]
    [g_mirror]
)
==> o_result/nil
```

Description

Creates multiple module instances in the design. By reducing the number of times the module definition file opens, this function optimizes performance when creating several instances of the same module.

Arguments

<i>t_name</i>	Prefix of the names of the module instances.
<i>t_moddefName</i>	Name of the module definition/
<i>x_tileStartNum</i>	Tile numbering start number and increment by 1 for each tile.
<i>l_origin</i>	First location of first module.
<i>l_offset</i>	List containing the offset wanted between module origins.
<i>x_numTiles</i>	The number of module instances to be place.
<i>f_rotation</i>	Angle of rotation for the module instance.
<i>x_logicMethod</i>	Flag to indicate where the logic for the module comes from.

Allegro SKILL Reference

Logic Access Functions

0	No logic.
1	Logic from schematic.
2	Logic from module definition.
<i>l_netExcept</i>	Optional list of net names to add to the net exception list.
<i>g_mirror</i>	Optional if modules should be mirrored

Value Returned

<i>lo_result</i>	If successful, returns the list of database objects that belong to the module instances created.
<i>nil</i>	Creation of module instance could not be completed.

See Also

[ax1DBCreateModuleDef](#), [ax1DBCreateModuleInstance](#)

Example

Add five module instances based on the module definition file `mod.mdd`, starting at point `(10,10)` and offsetting by `(5,0)` every time:

```
modinsts = ax1DBCreateManyModuleInstances(  
    "Num" "mod" 2 10:10 '(5 0) 5 0 2 '("GND" "+5"))
```

Creates five module instances named `Num2`, `Num3`, `Num4`, `Num5`, `Num6`.

axlDBCreateModuleDef

```
axlDBCreateModuleDef (
  t_name
  l_origin
  l_objects
)
⇒ t/nil
```

Description

Creates a module based on existing database objects.

Arguments

<i>t_name</i>	String providing the name of the module definition. File name is the module definition name appended with .mdd.
<i>l_origin</i>	Coordinate serving as the origin of the module definition.
<i>l_objects</i>	List of objects to add to the module.

Value Returned

t	Module definition successfully created.
nil	No module definition created.

Example

```
axlSetFindFilter(?enabled '("noall" "components") ?onButtons '("noall"
  "components"))
axlSingleSelectName ("COMPONENT" "U1")
compl = car(axlGetSelSet())
axlSingleSelectName ("COMPONENT" "U2")
comp2 = car(axlGetSelSet())
axlDBCreateModuleDef("comps" '(0 0) '(compl comp2))
⇒ A module definition file named comps.mdd is created.
```

Creates a module definition file containing two components.

axIDBCreateModuleInstance

```
axIDBCreateModuleInstance (
    t_name
    t_moddef_name
    l_origin
    r_rotation
    i_logic_method
    l_net_except
)
⇒ o_result/nil
```

Description

Allows you to use or place a previously defined module.

Arguments

<i>t_name</i>	String providing name of the module instance.
<i>t_moddef_name</i>	String providing name of the module definition to base the instance on.
<i>l_origin</i>	Coordinate location to place the origin of the module definition.
<i>r_rotation</i>	Angle of rotation for the module instance.
<i>i_logic_method</i>	Flag indicating where the logic for the module comes from: 0 - no logic 1 - logic from schematic 2 - logic from module definition.
<i>l_net_except</i>	Optional list of net names to add to net exception list.

Value Returned

<i>o_result</i>	Database object that is the group used to represent the module instance.
nil	Module instance not created.

Example

```
modinst = axlDBCreateModuleInstance("inst" "mod" '(500 1500) 2 '("GND" "+5"))
```

Adds a module instance based on the module definition file mod.mdd.

axlDBCreateNet

```
axlDBCreateNet(  
    t_netName  
)  
==> o_dbid/nil
```

Description

Creates a net in database if does not exist or returns `dbid` of net if it exists.

Arguments

`t_netName` Net name to create, or find.

Value Returned

`nil` if not created, or a `axl dbid` of net

See Also

[axlDBAssignNet](#)

Example

```
net = axlDBNetCreate("gnd")  
=> dbid:123456  
net->name  
=> "GND"
```

axlDBCreateSymDefSkeleton

```
axlDBCreateSymDefSkeleton (
    l_symbolData
    l_extents
    [l_pinData]
)
==> axlDBID/nil
```

Description

Creates a “minimal” symbol definition. While the symbol name and type must be provided, the instance is created only with pins. Once this “skeleton” definition has been created, you add the rest of the symbol geometry with additional axlDBCreate calls. This provides the ability to create symbols that do not exist in the library.

Shape symbol:

- You may only attach a single shape to a shape symbol, no voids.
- Layer required is “ETCH/TOP”.
- Extents should be larger than the shape but there is no adverse impact if they are significantly larger.

Flash symbol:

- You may attach multiple shapes, but none may contain voids.
- Layer required is “ETCH/TOP”.
- Extents should be larger than the shape but there is no adverse impact if they are significantly larger.

Arguments

l_symbolData A list of (*t_symbolName* [*t_symbolType*]).

t_symbolName Name of the symbol.

t_symbolType Package (default), mechanical, or format.

l_extents The lower left and upper right corners of the symbol def extents.

l_pinData List of *axlPinData* defstructs for the pins.

Value Returned

`axlDBCreateSymDefSkeleton nil` if not created, or `axlDBID` of the symbol definition.

Examples

```
symdef = axlDBCreateSymDefSkeleton('("shape_pad" "shape") list(-100:-100 100:100))
p = axlPathStart( list(-4:10 4:10 8:0 4:-10 -4:-10 -4:10))
s = axlDBCreateShape(p t "ETCH/TOP" nil symdef)
```

Creates a shape symbol.

```
symdef = axlDBCreateSymDefSkeleton('("flash_pad" "flash") list(-100:-100 100:100))
p = axlPathStart( list(-4:10 4:10 8:0 4:-10 -4:-10 -4:10))
ps = axlPathStart( list(-4:10 4:10 4:-10 -4:-10 -4:10))
s = axlDBCreateShape(p t "ETCH/TOP" nil symdef)
s = axlDBCreateShape(ps t "ETCH/TOP" nil symdef)
```

Creates a flash symbol.

ax1DBDummyNet

```
ax1DBDummyNet (
    g_mode)
-> lo_dbid/nil
```

Description

This command returns all dummy nets in design. Two courtesy options provided are:

- ❑ 'pin for any dummy net that has a pin return the first pin of the dummy net
- ❑ 'shape for any dummy net that has a shape return the first shape of the dummy net

Typically each dummy net in design will only have a single pin or shape but this may not always be the case. Clines or vias cannot, by themselves exist on a dummy. Symbols (`dra`) do not have dummy nets

Arguments

g_mode

Can have following two values:

- 'pin – returns a list of first pins on dummy nets
- 'shape – returns list of first shapes on dummy nets

Value Returned

- `t` - indicates success
- `nil` - failed due to incorrect arguments

See Also

[axllsDummyNet](#), [axlDbidName](#)

Examples

1. Print all 1st pins on dummy nets

```
foreach( mapc x ax1DBDummyNet('pin) printf("%s\n" axlDbidName(x)) )
```

2. Get all dummy nets on design

```
p = ax1DBDummyNet(nil)
```

axIDbidName

```
ax1DbidName (
```

Description

Provides the standard Allegro PCB Editor name of a database object. Many of the named Allegro PCB Editor objects (for example, nets) have names defined in the name attribute (for example, `dbid->name`) but other objects (for example, clines and pins) either do not have the desired reporting name or are unnamed.

Arguments

o_dbid A Allegro PCB Editor database id.

Note: Some Allegro PCB Editor database ids are pseudo ids (for example, ax1DBGetDesign and pads) and generate a nil return.

Value Returned

Allegro PCB Editor name of object, or `nil` if not a `dbid` or true Allegro PCB Editor database object.

Examples

This uses the `ashOne` selection function found in:

```
<cdsroot>/share/pcb/examples/skill/examples/ash-fxf/ashone.il
```

Pin name:

```
pin = ashOne()  
ax1DbidName(pin)  
-> "U1.1"
```

Cline name:

```
cline = ashOne()  
ax1DbidName(cline)  
-> "Net3, Etch/Top"
```

axlDiffPair

■ Add DiffPair

```
axlDiffPair(  
    t_diffpair  
    o_net1/t_net1  
    o_net2/t_net2  
)  
⇒ o_diffpair/nil
```

■ Modify DiffPair

```
axlDiffPair(  
    o_diffpair/t_diffpair  
    o_net1/t_net1  
    o_net2/t_net2  
)  
⇒ o_diffpair/nil
```

■ Delete DiffPair

```
axlDiffPair(  
    o_diffpair/t_diffpair  
)  
⇒ t/nil
```

Description

Creates, modifies, or deletes a differential pair. In all cases you can pass names or a *dbid*.

Note: If the differential pair was created due to Signoise models, you cannot modify or delete it. Consequently, you cannot modify or delete the differential pair if the following is true:

```
diffpair_dbid->prop->DIFFP_ELECTRICAL ==t.
```

Arguments

o_diffpair Diffpair *dbid*

t_diffpair Diffpair name.

o_net Net *dbid*.

t_net Net name.

Value Returned

Values returned depend on whether adding, modifying, or deleting.

o_diffpair *dbid* of new or modified diffpair

t Diffpair deleted.

nil Error due to incorrect arguments.

Example 1

```
DPdbid = axlDiffPair("DP" "NET1+" "NET2-")
```

Creates a differential pair and names it DP1.

Example 2

```
DPdbid = axlDiffPair(DPdbid "NET1+" "NET1-")
```

Modifies a differential pair.

Example 3

```
axlDiffPair(DPdbid)
```

Deletes a differential pair.

Example 4

```
axlDiffPair(axlDBGetDesign() ->diffpair)
```

Delete all differential pairs in design.

axlDiffPairAuto

```
axlDiffPairAuto(  
    t_diffPairPrefix  
    t_posNetPostfix  
    t_negNetPostfix  
    [g_returnDiffPairList]  
)  
⇒ x_cnt / (xcnt lo_diffpair) / nil
```

Description

Allows automatic generation of the diffpair. Generates the set of diffpairs based on the provided positive (*t_posNetPostfix*) and negative (*t_negNetPostfix*) postfixes used in your net naming.

You may provide a prefix (*t_diffPairPrefix*) used in generating the diffpair names of the form: <*t_diffPairPrefix*> + *netname* - *postfix*.

If nets are part of busses and end the bitfield syntax (<1>), the syntax portion is ignored when performing suffix matching. If a diffpair is created the bit number is added to the base net name used in forming a diffpair. For example, given two nets; DATA_P<1> and DATA_N<1> will result in a diffpair called DP_DATA1 with this call:

```
axlDiffPairAuto("DP_" "_P" "_N")
```

Arguments

<i>t_diffPairPrefix</i>	String to prefix diffpair names. Use " " if no prefix is desired.
<i>t_posNetPostfix</i>	Postfixes used to identify + diffpair members.
<i>t_negNetPostfix</i>	Postfixes used to identify - diffpair members.
<i>g_returnDiffPairList</i>	Controls return.

Value Returned

Returns depend on value of *g_returnDiffPairList* as shown:

g_returnDiffPairList	Value Returned	Description
nil	<i>x_cnt</i>	Number of diffpairs created.
t	(<i>x_cnt</i> , <i>lo_diffpair</i>)	List of diffpairs created

Examples

Example nets

Two nets called NET1+ and NET1- are passed to this function.

Example 1

```
axlDiffPairAuto("DP_ " "+" "-")
```

Shows diffpair creation and name generation. Results in one diffpair called DP_NET1 with members NET1+ and NET1-.

Example 2

```
axlDiffPairAuto(" " "+" "-")
```

Gives the same result as the previous example, but names the diffpair NET1.

axlDiffPairDBID

```
axlDiffPairDBID(  
    t_name  
)  
⇒ o_dbid/nil
```

Description

Returns the *dbid* of the named diffpair (*t_name*) if it exists in the database.

Arguments

t_name Diffpair name.

Value Returned

o_dbid *dbid* of diffpair if it exists.

nil Diffpair does not exist.

axlMatchGroupAdd

```
axlMatchGroupAdd(  
    o_mgdbid/t_mgName  
    o_dbid/lo_dbid  
) ==> t/nil
```


Description

Adds members to a matched group. Eligible members are:

- nets (if a net is part of an xnet the xnet is added to the group)
- xnets
- pinpairs

See discussion in [axlDBMatchGroupCreate](#).

Command fails in product tiers that do not support electrical constraints or the symbol editor.



Tip

Using dbids is faster than using names.

Arguments

o_mgdbid dbid of a match group.

t_mgName Name of a match group.

o_dbid Legal database dbid to add to match group.

lo_dbid List of legal database dbids to add to match group.

Value Returned

t Added elements.

nil Failed one or more element additions.

See Also

[axlMatchGroupCreate](#)

Example

Add two nets to match group created in axlMatchGroupCreate:

```
mg = car(axlSelectByName ("MATCH_GROUP" "MG1"))
nets = axlSelectByName ("NET" ' ("B1_OUT" "B2_OUT"))
axlMatchGroupAdd (mg nets)
```

axIMatchGroupCreate

```
axIMatchGroupCreate(  
    t_name  
) ==> o_mgdbid
```

Description

Creates a new match group. If a match group already exists with the same name, `nil` is returned. Match groups need to be populated, or they are deleted when saving. Use the [axIMatchGroupAdd](#) command to populate the match groups.

Note: The `axIMatchGroupCreate` command fails in product tiers that do not support electrical constraints or the symbol editor.

If the match group was partially or completely created from an ECset, you can delete it, but it reappears when ECset flattening is required due to modifications in the design. SKILL functions do not indicate ECset-derived match groups.

You can access list of match groups in database by:

```
axIDBGetDesign() ->matchgroup
```

RELATIVE_PROPAGATION_DELAY

The `RELATIVE_PROPAGATION_DELAY` property can be added to match groups, xnets, and pinpairs. If you add it to the match group then any match group member that does not have that property inherits it from the match group.

Match groups contain the following elements: xnets, nets, and pinpairs. If a net is part of an xnet, the xnet is added to the match group.

Xnets and pinpairs can belong to multiple match groups, so an RPD property exists on the `dbid` for nets, xnets and pinpairs. This property is a list of lists where each sub-list contains a match group `dbid` and the `RELATIVE_PROPAGATION_DELAY` value:

```
rpd = ( (o_mgDbid t_rpdValue) ....)
```

Thus if a pinpair belongs to 2 match groups, you see two lists that are the inherited. A pinpair in a single match group has a single list of list. For example, a pinpair in MG3 with global scope and an override of delta/tolerance of 10ns:5% reports:

```
rpd = ((dbid:61315360 "MG3:G:::10 ns:5 %"))
```

The same pinpair without an override will report default match group value as

```
rpd = ((dbid:61315360 "MG3:G:AD:AR:0 ns:5 %"))
```

In both the examples, the dbid references the match group id (MG3).

The RELATIVE_PROPAGATION_DELAY syntax is discussed in the Allegro Property Reference Manual. In general the syntax is:

<Match group name>:<scope>:<pinpair>:<value>

You can add and delete properties to a match group or pinpair dbid using axlMatchGroupProp. When creating the property value, you must include the match group name but not an explicit pinpair. For example, the following adds an RPD property to a match group named MG2:

```
axlMatchGroupProp. (mg ' ("RELATIVE_PROPAGATION_DELAY" "MG2:G:::0 ns:5 %") )
```

Additional restrictions for this property are:

- Pinpairs should leave the pinpair section empty (" :: ").

Example: "MG2:G:::0 ns:5 %"

- Match groups should not reference an explicit pinpair but, if not empty, should use a pinpair type (for example, "AD:AR","D:R" etc.)

For nets and xnets, if you access the RELATIVE_PROPAGATION_DELAY property, you may see the flattened version. This implies that if nets and xnets are part of multiple Match Groups, they all appear concatenated in the RELATIVE_PROPAGATION_DELAY property.

Any pinpairs that are part of the net appear as part of the property at the net or xnet level. This is present to support legacy applications like netlisters. The RPD property that is dbids for pinpairs, net and xnets breaks this concatenation. Using axlDBAddProp and axlDBDeleteProp commands to modify the property may effect all match groups and pinpairs. It is recommended that axlMatchGroupProp is used for modification of the RELATIVE_PROPAGATION_DELAY property for all objects.

Arguments

t_name Name of match group (changed to upper case).

Value Returned

nil Error or match group with same name already exists.

o_mgdbid: dbid of match group.

See Also

[axlPinPairSeek](#) , [axlPinsOfNet](#) , [axlMatchGroupCreate](#), [axlMatchGroupDelete](#),
[axlMatchGroupAdd](#), [axlMatchGroupRemove](#), [axlMatchGroupProp](#)

Example

Create a match group called MG1 :

```
mg = axlMatchGroupCreate("mg1")
```

axlMatchGroupDelete

```
axlMatchGroupDelete(  
    o_mgdbid/t_mgName  
) -> t/nil
```

Description

This deletes a match group. The command fails in product tiers that do not support electrical constraints or the symbol editor.



Using dbids is faster than using names.

Arguments

o_mgdbid dbid of a match group.

t_mgName Name of a match group.

Value Returned

t Match group deleted.

nil Failed.

See Also

[axlMatchGroupCreate](#)

Examples

Delete match group created in axlMatchGroupCreate:

```
mg = car(axlSelectByName ("MATCH_GROUP" "MG1"))  
axlMatchGroupDelete(mg)
```

or

```
axlMatchGroupDelete("MG1")
```

axlMatchGroupProp

```
axlMatchGroupProp (
    o_mgdbid/t_mgName
    o_dbid
    t_value/nil
) ==> t/nil
```

Description

Adds or removes the RELATIVE_PROPAGATION_DELAY property from a member of a match group. Property must be a legal RPD syntax that includes the RPD name.

The command fails in product tiers that do not support electrical constraints or the symbol editor.

See discussion in `axlDBMatchGroupCreate`.



Using dbids is faster than using names.

Arguments

<code>o_mgdbid</code>	dbid of a match group
<code>t_mgName</code>	Name of a match group
<code>o_dbid</code>	Legal database dbid to of a member of the match group
<code>t_value</code>	RELATIVE_PROPAGATION_DELAY value in legal syntax. If value is nil; removes the property.

Value Returned

<code>t</code>	Added elements.
<code>nil</code>	Failed one or more element additions.

See Also

[axlMatchGroupCreate](#)

Examples

Add two nets to match group created in `axlMatchGroupCreate`:

```
mg = car(axlSelectByName ("MATCH_GROUP" "MG1"))
nets = axlSelectByName ("NET" ' ("B1_OUT" "B2_OUT"))
n1 = car(nets)
n2 = cadr(nets)
axlMatchGroupAdd(mg nets)
```

Add properties:

```
axlMatchGroupProp(mg n1 "MG1:G:::100 ns:5 %")
axlMatchGroupProp(mg n2 "MG1:G:AD:AR:0 ns:5 %")
```

Remove property from n2:

```
axlMatchGroupProp(mg n2 nil)
```


axlMatchGroupRemove

```
axlMatchGroupRemove (
    o_mgdbid/t_mgName
    o_dbid/lo_dbid
) ==> t/nil
```

Description

Removes elements from an existing match group. Elements must be members (attribute groupMembers) of the match group.

The command fails in product tiers that do not support electrical constraints or the symbol editor.



Tip
Using dbids is faster than using names.

Arguments

<i>o_mgdbid</i>	dbid of a match group.
<i>t_mgName</i>	Name of a match group.
<i>o_dbid</i>	Legal database dbid to remove from match group.
<i>lo_dbid</i>	List of legal database dbids to remove from match group.

Value Returned

<i>t</i>	Removed elements.
<i>nil</i>	Failed one or more element removals.

See Also

[axlMatchGroupCreate](#)

Example

To match group in example axlMatchGroupAdd remove one of the nets:

```
axlMatchGroupRemove (mg  car (nets))
```

axlNetSched

axlNetSched()

==> *t*

Description

This is the main routine that the command processor calls for the `net schedule` command.

Arguments

None

Value Returned

t

axlPinPair

Add

```
axlPinPair(  
    o_pin1/t_pin1  
    o_pin2/t_pin2  
) ==> o_pinpair
```

Delete

```
axlPinPair(  
    o_pinpair/lo_pinpair  
) ==> t/nil
```

Description

This creates or deletes a pinpair. A pinpair consists of two un-ordered pins or ratTs on the same net. For example, pinpair u1.2:r1.2 is the same pinpair as r1.2:u1.2. If the pinpair already exists then the existing pinpair is returned. The command fails in product tiers that do not support electrical constraints or the symbol editor.

Note: You cannot create a pinpair if both pins (or ratT) do not belong to the same xnet.


If the pinpair was created in an ECset, the ECsetDerived attribute will be t and cannot delete it. You must modify the pinpair in the associated ECset.

At database save, a pinpair must be part of a match group or have a legal electrical constraint property assigned to it. Legal electrical properties are:

- PROPAGATION_DELAY
- MIN_FIRST_SWITCH
- MAX_FINAL_SETTLE
- IMPEDANCE_RULE
- TIMING_DELAY_OVERRIDE
- RELATIVE_SKEW

RELATIVE_PROPAGATION_DELAY is stored on the RPD attrbiute as a list of lists.

See `axlMatchGroupCreate` for more infomation.



Tip
Using dbids is faster than using names.

Arguments

<i>o_pin1/o_pin2</i>	dbid of a pin or ratT
<i>t_pin1/t_pin2</i>	A pin name (<refdes>.<pin#>); ratT names are not supported.
<i>o_pinpair</i>	Pinpair dbid.
<i>lo_pinpair</i>	List of pinpair dbids (delete mode only).

Value Returned

Returns depending upon the mode.

nil: error

t Deletion was successful.

o_pinpair dbid of added or modified differential pair.

See Also

[axlPinPairSeek](#), [axlPinsOfNet](#), [axlMatchGroupCreate](#)

Examples

Example 1: Xnet having two nets; NET1 and NET1A. This demonstrates that pinpairs are stored on the xnet.

Create pinpair using name:

```
pp = axlPinPair("U2.13" "R1.2")
```

Create pinpair with ratT of net NET1A:

```
ratTs = axlPinsOfNet("NET1A" 'ratT)
```

Allegro SKILL Reference

Logic Access Functions

```
pp = axlPinPair("U2.13" car(ratTs))
```

Allegro SKILL Reference

Logic Access Functions

Verify pinpairs are both on NET1A:

```
n = car(axlSelectByName ("NET" "NET1A"))
n->pinpair RETURNS nil
```

Examine the xnet (NET1):

```
xn = car(axlSelectByName ("XNET" "NET1"))
xn->pinpair RETURNS (dbid:21697512 dbid:21697232)
```

Delete all pinpairs of Example 1:

```
axlPinPair(xn->pinpair)
```

axlPinPairSeek

```
axlPinPairSeek(  
    o_pin1  
    o_pin2  
) ==> o_pinpair/nil
```

Description

Given two pins or ratTs reports if they are part of a pinpair.

Arguments

<i>o_pin1/o_pin2</i>	dbid of a pin or ratT.
<i>t_pin1/t_pin2</i>	A pin name (<refdes>. <pin#>); ratT names not supported.

Value Returned

<i>o_pinpair</i>	Pinpair dbid.
<i>nil</i>	Pinpair for given pins does not exist.

See Also

[axlPinPair](#)

Example

See if a pinpair for these two pins exists:

```
pp = axlPinPair("U2.13" "R1.2")
```

axlPinsOfNet

```
axlPinsOfNet (
    o_net/t_net
    g_mode
) -> lo_pins/nil
```

Description

Returns list of pins and ratTs on a net or xnet. First argument can be either a net, xnet dbid or a net name (xnet names are not supported). Second option, *g_mode*, can be '*pin*' to return only the pins, '*ratT*' to return list of ratTs or nil to return both pins and ratTs. There is no meaning conveyed in the list of items returned.

Arguments

<i>o_net</i>	dbid of a net or xnet.
<i>t_net</i>	Name of a net (does not support xnet names).
<i>g_mode</i>	nil return both pins and ratTs of a net.
' <i>pin</i>	Return only pins.
' <i>ratT</i>	Return only the ratT's.

Value Returned

<i>lo_pins</i>	List of pins and/or ratTs on net or xnet.
nil	Nothing meeting criteria (or error, dbid not net or xnet).

Examples

All pins on GND:

```
net = car(axlSelectByName("NET" "GND"))
lpins = axlPinsOfNet(net, 'pins)
```

All pins and ratTs on first xnet in design root (could be a net):

```
xnet = car( axlDBGetDesign()->xnet )
lpins = axlPinsOfNet(xnet, nil)
```

axlRemoveNet

```
axlRemoveNet(  
    t_name/o_dbid  
    [g_ripup]  
)  
⇒ t/nil
```

Description

Removes a net. May either give a string with the net name to be renamed or *dbid* of an object on that net.



The net name may be used in properties. This function does not update these values.

Arguments

t_name Net name.

o_dbid *dbid* of a net.

g_ripup Optional argument. Ripup associated etch when a net is deleted.

Value Returned

t Net successfully removed.

nil No net is removed.

Example

```
axlRemoveNet ("GND")
```

axlRenameNet

```
axlRenameNet (
    t_old_name
    t_new_name
)
⇒ t/nil

axlRenameNet (
    o_dbid
    t_new_name
)
⇒ t/nil
```

Description

Renames a net. For the old object, may either give a string with the net name to be renamed, or *dbid* of an object on that net. Fails if the new net name already exists in the database.

```
dbid = axlSingleSelectName("NET" ' ("NET"))
```

Note: This function does not refresh any *axl dbids* to reflect the new net name.



The net name may be used in properties. This function does not update net names in property values.

Arguments

<i>t_old_name</i>	Existing net name.
<i>o_dbid</i>	<i>dbid</i> of an object on a net.
<i>t_new_name</i>	New net name (should not exist in the database.)

Value Returned

<i>t</i>	Net successfully renamed.
<i>nil</i>	Net name already exists in the database.

Example

```
axlRenameNet ("GND" "NEWGND")
```

Allegro SKILL Reference

Logic Access Functions

```
; first verify the new net name doesn't exist
axlSetFindFilter(?enabled '("noall" "nets"))
if(axlSingleSelectName("NET" '("NEWGND") ) then
    axlRenameNet(dbid "NEWGND")
```

axlRenameRefdes

```
axlRenameRefdes (
    t_old_name/o_oldCompDbid
    t_new_name/o_newCompDbid
)
⇒ t/nil
```

Description

Renames a refdes. For either argument, may use a refdes name or a component instance.

If both refdes exist, a swap is done.

Arguments

<i>t_oldName</i>	Existing refdes name.
<i>o_oldCompDbid</i>	Component <i>dbid</i> .
<i>t_newName</i>	New refdes name.
<i>o_newCompDbid</i>	Component <i>dbid</i> .

Value Returned

<i>t</i>	Refdes successfully renamed or swapped.
<i>nil</i>	No refdes renamed or swapped due to incorrect arguments.

Example 1

```
axlRenameRefdes ("U1" "X1")
```

Changes refdes by name.

Example 2

```
axlSetFindFilter (?enabled '("noall" "components") ?onButtons '(all))
axlSingleSelectName ("COMPONENT" "U1")
firstComp = car(axlGetSelSet())
axlSingleSelectName ("COMPONENT" "U2")
secondComp = car(axlGetSelSet())
axlRenameRefdes(firstComp secondComp)
```

Swaps with starting point of two component *dbids*.

axISchedule

```
axISchedule(  
    o_net/t_net  
    [g_userSchedule]  
)  
==> t_schedule/nil
```

Description

Gets net schedule. When `g_userSchedule` is `t`, this fetches the a user schedule or a partial user schedule from a net. Returns nil if the net is completely algorithm scheduled. Using `t` is recommended. When `g_userSchedule` is nil, returns the schedule of the complete net even if the net is completely algorithm scheduled.

The format of `t_schedule` is a string in the \$SCHEDULE netin (3rd party) format. See `netin` documentation for more info about the syntax.

Arguments

`o_net` *dbid of net*

`t_net` Name of net

`g_userSchedule (optional)`

If `t` returns the schdule if the net is user schedule or partial userschedule. Other nets in this netin format if nil remove

Values Returned

`t_schedule` Schedule or partial user schedule.

`nil` Failed or net is not user schedule or partial user schedule. Use `axIDebug` to obtain more data.

See Also

[axIScheduleNet](#)

Examples

Net2 has the following pins and rat-Ts:

```
P1.7 U1.4 U1.10 U2.6 T.1
```

It is partially user schedule such as P1.7, U1.4, and U1.10 should be connected to rat-T, T.1. Pin U2.6 is algorithm scheduled but the sub-schedule (partial) indicates it should connect to U1.10 (indicated by a star '*' in the schedule string).

Fetch partial schedule (note no U2.6)

```
q = axlSchedule("NET2" t)
=> "P1.7 T.1 U1.4 ; T.1 *U1.10 "
```

Same net but complete schedule

```
q = axlSchedule("NET2" t)
=> "P1.7 T.1 U1.4 ; T.1 *U1.10 U2.6 "
```

axlScheduleNet

```
axlScheduleNet(  
    o_net/t_net  
    t_schedule/nil  
)  
==> t/nil
```

Description

This applies a user schedule or a partial user schedule to a net. Format of *t_schedule* is a string in the \$SCHEDULE netin (3rd party) format.

Note: See `netin` documentation for more info about the syntax.

When *t_schedule* is *nil* it removes any user schedule or partial user schedule from the net and restores its default schedule algorithm (NET_SCHEDULE property).

Arguments

<i>o_net</i>	<i>dbid</i> of net
<i>t_net</i>	Name of net
<i>t_schedule</i>	Schedule or partial schedule using \$SCHEDULE netin format; if <i>nil</i> , remove

Value Returned

<i>t</i>	Schedule applied.
<i>nil</i>	Failed or arguments are incorrect (use <code>axlDebug</code>) for more info.

See Also

[axlSchedule](#)

axlWriteDeviceFile

```
axlWriteDeviceFile(  
    o_compDefDbid  
    [t_output_dir]  
)  
⇒ t/nil
```

Description

Given a component definition, writes out a third party device file. Writes to the directory specified, or if no directory or `nil` is given, writes to the current directory.

Name of the file is `compDef->deviceType` in lower case with a `.txt` file extension. For example, if component definition (`compDef`) device type is `CAP1`, then the device file name is `cap1.txt`.

Also creates a `devices.map` file which is empty unless the device name has characters that are not legal as a filename.

See `netin` documentation for device file syntax.

Note: Do not use this function if you use Cadence Front-End Schematic packages.



This function overwrites existing <device> and devices.map files in the directory.

Arguments

<code>o_compDefDbid</code>	Component definition of the device file to write out.
<code>t_output_dir</code>	Directory in which to write the files. If not provided, the current directory is used.

Value Returned

<code>t</code>	Device file successfully written.
<code>nil</code>	Failed to write device file due to incorrect <code>dbid</code> or directory.

Allegro SKILL Reference

Logic Access Functions

Example

```
axlWriteDeviceFile( car(axlDBGetDesign() ->components) ->compdef)
```

Writes device file of the definition for the first component instance off the design root.

axlWritePackageFile

```
axlWritePackageFile(  
    o_symDefDbid  
    [t_output_dir]  
)  
⇒ t/nil
```

Description

Given a symbol definition, writes out symbol .dra, .psm and associated padstack files. Works like `dump_libraries` on a single symbol definition.

The file name root is the symbol definition name. For example, if the symbol definition (symDef) name is CAPCK05, the output files created are named `capck05.psm` and `capck05.dra`, plus any padstacks (in lower case) that are part of the symbol.



This function overwrites existing files in the target directory.

Arguments

<code>o_symDefDbid</code>	Symbol definition to store on disk.
<code>t_output_dir</code>	Directory in which to store the files. If not provided, the current directory is used.

Value Returned

<code>t</code>	Files successfully written.
<code>nil</code>	Failed to write files due to incorrect <code>dbid</code> or directory.

Example

```
symDef = car(axlDBGetDesign()->components)->symbol->definition  
axlWritePackageFile( symDef)
```

Writes symbol files of the definition for the first component instance off the design root.

Allegro SKILL Reference
Logic Access Functions

Allegro SKILL Reference
Logic Access Functions

Building Contexts in Allegro

Introduction

A context via can be created by either of two methods – standard and autoload. Both methods substantially improve performance of Skill code loading. Even more benefits can accrue if you combine several Skill files into one context. The autoload method is a super-set of standard contexts and offers deferred context loading functionality. The autoload method is used by all Allegro provided contexts.

The standard contexts are much easier to build, are more evident to the user, and typically require more memory. The autoload contexts are much harder to build, but the system only loads the contexts upon demand. For a more complete discussion of the differences, see the section on Contexts in the *Skill Language User Guide*.

Requirements

You must have a Skill developers license and the `il_allegro` program. Currently, this license is only available on UNIX. The `il_allegro` program is part of every standard Allegro release.

Cautions

Most Skill code can be built into contexts. However, there are several potential problems that you should keep in mind when writing code. A complete discussion of these issues can be found in Chapter 10 of the *Skill Language User Guide*.

Note: Cadence recommends that you prefix your Skill functions with upper case prefixes. This minimizes the chance of naming collisions with Cadence Skill functions that use lower case prefixes.

Additionally, autoload contexts have some additional cautions. Please adhere to the following guidelines:

Autoload Context Guidelines

- Files put into an autoload context should only contain variables and procedures (functions).
- Do not load other skill files. Have `startup.il` load them.
- Do not call `axlCmdRegister`.
- Do not do anything outside of a procedure – it will not work.

Building Standard Contexts

To build a standard context

1. Create a directory that has all the Skill files to be built into the context.
2. Add the `startup.il` file (see [File B1](#) on page 1410).
3. Create a Skill function with the same name as your context that registers your commands with the Allegro shell. This step is required in `allegro_designer` if you wish to access your Skill code. Only one of these functions is permitted per context. The function name must be the same as the context name. This step is analogous to the `.ini` file in autoload contexts.

Format:

```
(defun <ContextName> ()  
  (axlCmdRegister "mycommand" '<myskillcommand> ?cmdType ....)  
  .... other axlCmdRegister ..  
)
```

Example:

```
(defun MYTEST()  
  (axlCmdRegister "mytest" 'MYTest ?cmdType "general")  
)
```

4. Run the `buildcxt <ContextName>` script (see [File S1](#) on page 1411). This produces a single file named, `<ContextName>.cxt`. For example: `buildcxt MYTEST`.

To load the context into `allegro_designer`, issue the Allegro command `loadcontext <ContextName>`. In programs where the Skill type-in mode is available, the Skill functions `loadContext <contextName.cxt>` and `callInitProc <ContextName>` perform the same function.

Example:

```
Allegro > loadcontext MYTEST
```

Skill version:

```
skill > (loadContext "MYTEST.txt")
skill > (callInitProc "MYTEST")
```

Building Autoload Contexts

To build a context by the autoload method

1. Create directory hierarchies:

```
./pvt/etc/context
./etc/context
```

2. Under ./pvt/etc/context, create a directory using your context name and populate it with your Skill files.
3. Add a `startup.il` (see [File B1](#) on page 1410) to the mix and stir well.
4. Insure that the `cxtFuncs.il` (see [File A1](#) on page 1412) is in the root directory.
5. Run the `buildautocxt` (see [File A2](#) on page 1415) UNIX command with your context name. For example: `buildautocxt <myContext>`.
6. If the context build is successful, you will have 3 files in the `./etc/context` directory with your context name (`.aux`, `.cxt`, `.toc`).
7. Add an optional fourth file with a `<myContext>.ini` that has your `axlCmdRegister`. If you do not wish to register your Skill commands as Allegro commands, you may skip this step. However, in `allegro_designer` this is the only method for accessing your Skill code.

Example:

```
(axlCmdRegister "my_command" 'MYSkillFunction ?cmdType "interactive")
```

8. Take the four context files and add them to the directory `<cds_root>/share/pcb/etc/context`.
9. Edit the `pcd` file in this directory for the product requiring the context.
Names are:

allegro.pcd	All allegro_layout (CBD) based products.
designer.pcd	allegro_designer
apd.pcd	advanced_package_designer
floorplan.pcd	allegro_si

You need to add a line at the end of the file in the following format:

<NAME><VERSION><CONTEXTS>

Note: Neither the NAME of VERSION is important. It is only used with the Skill function printBlend.

Example:

MYCONTEXT 1.0MyContext

Two environment Bourne variables help in debugging problems in this area. They are:

CDS_DEBUG_CONTEXTS	file /tmp/context.log - context stats
CDS_DEBUG_CXTINIT	file /tmp/initCxt.log - context init - also stderr init context print

Files with This Package

File B1

Helper Skill code to load all Skill files in a directory.

```
;-----
;startup.il
foreach(file rexMatchList(".*\\".il$" getDirFiles("."))
    ; don't load myself -- bad idea
    when( nequal(file, "startup.il")
        load(file)
    )
)
;-----
```

File S1

buildcxt csh script to for building standard contexts.

```
#!/bin/csh -f
# This builds a standard context see README.cxt for other set-up requirements

if ($#argv != 1) then
    echo "Usage: $0 <context name>"
    echo "Assumes that a startup.il file exists in current directory"
    echo " this file is used to specify the loading of other skill files"
    exit 1
endif
set theContext = $argv[1]

if (!(-e startup.il)) then
    echo "ERROR: Can't find standard.il file"
    exit 1
endif

il_allegro << EOF
(setSkillPath ".")
(setContext "$theContext")
(load "startup.il")
(defInitProc "$theContext" '${theContext}')
(saveContext "$theContext.cxt")
(exit)
EOF
/bin/rm -f AUTOSAVE.brd

echo ""
echo ""
echo ""
echo "Context will be found $theContext.cxt"
echo ""
exit 0
```

File A1

cxtFuncs.il Skill helper program to build autoload contexts.

```
; (
;-----
; EXPORTED FUNCTIONS:
;   buildContext : used to build a context
;   getContext    : used to load a context
;
;   Mods -- fxf 8/25/95 to support local building of contexts
;-----
;
; Constants
;   ilcDftSourceFileDir : directory name where Skill source
;                         files reside
;   ilcDftDeliveryDir   : directory name where delivered
;                         context files are saved.
;   (fxf) may be overridden before calling
;-----

unless(boundp('ilcDftSourceFileDir) ilcDftSourceFileDir = "pvt/etc/context")
unless(boundp('ilcDftDeliveryDir) ilcDftDeliveryDir = "etc/context")

(defun _parsePath (path)
(let (lpath)
  (cond (path
          lpath = parseString(path "/"))
        (while (!rindex(car(lpath) "tools")) lpath = cdr(lpath))
        buildString(lpath "/"))
        )
  (t nil)))
))

_stacktrace = 10
setSkillPath(strcat(". ~ " prependInstallPath("local")))
(cond ((getd 'dbSetPath) (dbSetPath ". ~")))

;
; loadCxt --
```

Allegro SKILL Reference

Building Contexts in Allegro

```
; Load a context and call its init function.  
;  
(defun loadCxt (cxt ctxtPath)  
  (let ((f (strcat (cdsGetInstPath ctxtPath) "/" ctxt ".cxt"))))  
    (cond  
      ((null (isFile f)) nil)  
       ((null (loadContext f))  
        (printf "load of context %s failed\n" ctxt))  
      ((null (callInitProc ctxt))  
       (printf "init proc of context %s failed\n" ctxt))  
      (t (printf "Loading context %s\n" ctxt))  
    ))  
  )  
)  
  
;  
; buildContext --  
; Build a new context, even if one exists.  
;  
  
(defun buildContext (ctxt @rest targs)  
  (let (ctxtPath srcPath fullCxtPath)  
  
    ctxtPath = ilcDftDeliveryDir  
    (setq srcPath (strcat ilcDftSourceFileDir "/" ctxt))  
  
    ;; <fxf>: doesn't allow local contexts so use above 2 lines  
    ;;(cond ((car targs) (setq ctxtPath (car targs)))  
    ;;((setq ctxtPath (_parsePath (_iliGetActualCxtPath ctxt))) t)  
    ;;(t (setq ctxtPath ilcDftDeliveryDir))  
    ;;(cond ((cadr targs) (setq srcPath (cadr targs)))  
    ;;((setq srcPath (_parsePath (_iliGetActualSrcPath ctxt))) t)  
    ;;(t (setq srcPath (strcat ilcDftSourceFileDir "/" ctxt))))  
    fullCxtPath = cdsGetInstPath(ctxtPath)  
  
    (deleteFile (strcat fullCxtPath "/" ctxt ".cxt"))  
    (deleteFile (strcat fullCxtPath "/" ctxt ".al"))  
    (deleteFile (strcat fullCxtPath "/" ctxt ".ini"))  
  
    (updateContext ctxt ctxtPath srcPath)  
    (updateAutoloads ctxt ctxtPath srcPath)
```

Allegro SKILL Reference

Building Contexts in Allegro

```
) )

;

; updateContext --
;   If there is source and it is newer than the context,
;   then build a new context. Otherwise if there is no source
;   use the existing context.
;

(defun updateContext (cxt ctxtPath srcPath)
  (cond ((isDir (cdsGetInstPath srcPath)) (makeCapContext cxt ctxtPath srcPath))
        ((loadCxt cxt ctxtPath) t)
        (t (printf "Can't find context %s\n" cxt)))
)

(defun updateAutoloads (cxt ctxtPath srcPath)
  (let ((afile (sprintf nil "%s/%s.al" (cdsGetInstPath srcPath) cxt))
        (ifile (sprintf nil "%s/%s.ini" (cdsGetInstPath srcPath) cxt)))

    (cond ((isFile ifile) (system (sprintf nil "cp %s %s" ifile (cdsGetInstPath
ctxtPath))))
          ((isFile afile) (system (sprintf nil "cp %s %s" afile (cdsGetInstPath
ctxtPath))))
          (t t)))
)

;

; getContext --
;   Load the context if it exists, otherwise build it.
;

(defun getContext (cxt &rest targs)
  (let (ctxtPath srcPath)
    (cond ((car targs) (setq ctxtPath (car targs)))
          ((setq ctxtPath (_parsePath (_iliGetActualCxtPath cxt))) t)
          (t (setq ctxtPath ilcDftDeliveryDir)))
    (cond ((cadr targs) (setq srcPath (cadr targs)))
          ((setq srcPath (_parsePath (_iliGetActualSrcPath cxt))) t)
          (t (setq srcPath (strcat ilcDftSourceFileDir "/" cxt)))))

    (cond ((loadCxt cxt ctxtPath) t)
          ((isDir cxt (cdsGetInstPath srcPath))))
```

```
(makeCapContext ctxt ctxtPath srcPath))  
(t (printf "Can't get context %s\n" ctxt)  
))  
))  
  
(sstatus trapDefs ilcDftDeliveryDir)  
(sstatus lazyComp nil)
```

File A2

buildautocxt csh script to build autoload contexts.

```
#!/bin/csh -f  
# This builds a context see README.cxt for other set-up requirements  
  
if ($#argv != 1) then  
    echo "Usage: $0 <context name>"  
    exit 1  
endif  
set theContext = $argv[1]  
  
if (!(-e pvt/etc/context/$argv[1])) then  
    echo "pvt/etc/context/$argv[1] does not exist"  
    exit 1  
endif  
  
if (!(-e etc/context)) then  
    mkdir -p etc/context  
endif  
  
il_allegro -ilLoadIL ctxtFuncs.il << EOF  
(getContext "skillCore")  
(setSkillPath ".")  
(cdsSetInstPath ".")  
buildContext "$theContext"  
exit  
EOF  
  
echo ""
```

Allegro SKILL Reference

Building Contexts in Allegro

```
echo ""
echo ""
echo "Context files will be found at etc/context/$theContext.*"
echo ""
exit 0
```